



Simple port switcher, change active device by pushing FIRE1/LMB.		
Sheet: /		
File: Amiga Mouse Switch.sch		
Title: Amiga Mouse/Joystick Switch		
Size: A4	Date:	Rev: A
KiCad E.D.A. kicad (5.1.8)–1		Id: 1/1