


The Control Room

The control room is the room from which one controls everything that happens in the Dome. The control over the dome happens via two screens, the Control Panel and the Monitor.



Control Panel



Control Panel

Through the Control Panel, doors and lights throughout the Dome are managed. It also controls audio from all microphones, from the films, and from OpenSpace. Even audio from external sources such as a presentation computer is controlled from here.

Monitor and Surf Computer

The screen is divided into two parts, each functioning as a separate screen for different computers. The one on the left is connected to the Master Computer, where films are displayed and OpenSpace is operated.

The one on the right is connected to the small computer on the table behind. This computer is used for web browsing, viewing manuals, etc. It is important NOT to surf the internet on the Master Computer for security reasons; instead, it is done on the surf computer or other devices. The surf computer has its own wired mouse and a wireless keyboard. The keyboard has a power button on the back. Remember to switch the button to 'On' when leaving the room to save the batteries. Extra batteries are available in a box on the same table."





The light in the control room

At the door to the room, there are light switches on both sides of the door. The switch at the top left (A), on the same side as the handle, controls the lamp hanging directly over the opening to the theater. This fixture can only be controlled with this switch

The switch at the top right of the door (B) controls the two large ceiling fixtures in the ceiling. These lights can also be controlled via the Control Panel/Lighting/(302 KR)

Both light switches operate as follows:

- A short press - On/Off
- When holding down the button, adjust the brightness level upward/downward



Sound


➤ Control Panel

The control screen has several different 'pages' where you can control various functions. The pages are listed to the left of the screen. The current page is indicated by a light blue box and a white arrow.

! ALWAYS ENSURE THAT 'PLANETARIUM' IS SELECTED UNDER THE HEADING 'DOME SOURCE.' 'Film' refers to a computer cluster that is not currently in use.

Control of audio levels

On the Sound (Ljud) page, you can control the audio levels of movie sound, presentation sound, and all wireless microphones separately, as well as all microphones simultaneously (known as Master volume)



Microphones

Mute buttons

"Mute buttons are used to quickly turn off the sound on the microphone you are wearing. When the button is red, the sound is muted, and when the button is blue, the sound is on. The button toggles between these modes when pressed; if it's blue, it turns red and vice versa.

Please mute microphones that are not in use via the control screen. This makes it easier for you to see which microphones are being used in case you need to quickly adjust the volume on a microphone. For example, in the image above, all wireless microphones except for headset two and three are muted. If you are wearing headset two, you know that your colleague is using headset three.

Tip! If there is no sound coming from a microphone, always check this page and see if that microphone is 'muted'.