










PIN for WS2812B LED D8
USER BUTTON pin D7
REGULAR LED pin D13



FD1 FIDUCIAL H1 HOLE_3.2mm H2 HOLE_3.2mm