

## Using X, Y and Z keys

X, Y **and** Z Keys are available in some bi-directional areas.

After removing an X, Y **or** Z key, signalled movements will occur only in the normal running direction.

There may be up to three cabinets at a location. Removing any key is sufficient to prevent bidirectional signalling.

To take a key, first ask the signaller for authority,

make sure the indicator light is on,

push the button,

turn the release handle to FREE,

turn the key and remove it from the lock.

Check the key is correct for the section and then secure the key.