



CONTROL PANEL: LEFT



PS_ON J3-4 (5V)

CONTROL PANEL: RIGHT



- Power
- Signal
- Ground
- CAN