

SPIN  
GND  
MIST  
GND  
GND  
Z-LIM  
Y-LIM  
X-LIM  
PROBE  
GND  
GND  
24V

24V-IN

USB

TF CARD

PWM-OUT  
GND  
5V-OUT  
GND  
LASER-OUT  
PWM-ADJ

X-PUL  
X-DIR  
X-ENA  
Y-PUL  
Y-DIR  
Y-ENA  
Z-PUL  
Z-DIR  
Z-ENA  
A-PUL  
A-DIR  
A-ENA  
B-PUL  
B-DIR  
B-ENA  
C-PUL  
C-DIR  
C-ENA  
24V  
COM

Driver has /+-PU-DR-MF  
Dose ENA from board go to  
the +.

