

Fuse Fire Feature

Monday, August 12, 2024 1:05 PM

REV 1 -

Will require review with dept mgrs and creation of description after initial launch.

Add Build:

- Preference: New Listing **Fuse Fire Feature** listed under Fuse Parent
- Alternate: Can be nested under Fuse Parent, but it would be nice to keep the planters and fire features as separate as possible.

Parent:

- Rectangular Fuse Fire Feature - Mirror Rectangular Fuse Planter parent input fields
- Curved Fuse - **Need to have Length, Width, and Diameter.
 - Can you add some logic, for example: if Diameter=0 use a L, W, H format for dimensions; if Diameter >0 use D, H dimensions.

Add Child:

1. Fuse Rectangular Fire Feature
 - a. Copy all Routing & BOM formulas from Fuse Planters.
 - b. Set Toe Kick Defaults to match Custom Linear.
2. Fuse Curved Fire Feature
 - a. Copy all Routing & BOM formulas from Fuse Planters.
 - b. Set Toe Kick Defaults to match Custom Cylinder.
3. ----- (divider line to separate body from options)
4. Round Firepit Pan (use existing calculator for labor and material)
5. Rectangular Firepit Pan (use modified calculator*)
6. Round Firepit Lid (use modified calculator*)
7. Rectangular Firepit Lid (use modified calculator*)

Glass surround [child] shape code not available for Fuse Fire Features (per Grif & MI)

ROUTINGS

Modified Option Logic(Options):

- Logic will be the same as [non-fuse] custom firepit options already available.
- EXCEPTION: These options may need to be split
 - Fuse split pop out window.
 - ROUTINGS:
 - Routings - CAD: 60min total (regardless of section qty)
 - Material - per normal calculations
 - NO Fuse Fit-Up time

