

How to Create CD Area (CDFS) with Xtreamer USB Flash Drive

Requirements

- Xtreamer USB Flash Drive (xUSB)
- USB Host-equipped PC running Windows (Win 2k/XP/Vista/7)
- “uDisk Tool” program
- ISO image of a supported Windows OS or bootable ISO image file

Warning!!

This instruction includes format command that will delete all data.
Don't forget to backup data on your USB Flash Drive before proceeding.

Instructions



1. Download uDisk Tool utility and save the file on the Desktop.
2. Prepare Windows OS ISO image or bootable ISO image file.
Note: The utility only supports ISO file format up to 4.7GB
3. Connect xUSB to a USB port.
4. Execute uDisk Tool utility.




5. Click CD icon once utility executes.



6. Once Partition setting appears, locate the ISO file you want to make a CD-ROM.



7. Click Burn and start creating CD-ROM area. All present data will be deleted.
It may take 1~10 minutes depending on file size, available memory and other factors.



※ If check “CDROM Only”: Only 1 CD-ROM partition is recognized.(Read only)
If not: Both CD-ROM and UDF partitions will be recognized.

8. Please check that your system recognizes both CD-ROM partition and USB drive.
9. Safely remove xUSB after the process is CD-ROM complete.