



MISSED CALL FOR ON/OFF CONTROL			MOTOR ON/OFF COMMAND SMS - MESSAGE		
S/no	Command	Action	S/no	Command	Action
1	Call cuts after Long Ring >4	Motor ON	1	#1	Motor ON
2	Call cuts after Long Ring >2	Motor OFF	2	#2	Motor OFF

Note : Send sms from your Mobile No to Gsm system sim card No
Reply SMS will be sent to stored Mobile No

To Store Only 1 Mobile No send SMS -



Commands	Example	Description	Acknowledgement
#nSTNxxxxxxxxx n=1,2,3,4,5 xxxxx - Mobile No	#1STN9999999999 #2STN9909999999 #5STN9900000000	To store 1st No To store 2nd No To store 5 th No	SMS to Stored Mobile No
SPN	#SPN	To check Stored Mobile No	SMS to stored no

Commands By SMS

SMS	EXAMPLE	DESCRIPTION
#1	#1	Pump On Thru SMS
#2	#2	Pump OFF Thru SMS
#3	#3	AUTO MODE ON
#4	#4	AUTO MODE OFF
#CLR		CLEAR STORED MOBILE NUMBER...
#7	#7	To check Status

- @ Mains power ON message will be sent to Master No
- @ Reply messages from all slave No will also sent to Master No