

VP CAMMaster Automation – Licensing & Setup Guide

1. Get Machine ID

Run get_machine_id.bat as Administrator. Copy the MachineGuid value shown and share it for license generation.

2. Generate License File

Run generate_license.bat, enter Machine ID when prompted. License file will be created automatically.

3. License File Location

C:\ProgramData\VPInformatics\CamMaster\license.key

4. Register DLL (32-bit)

Run as Administrator:

C:\Windows\Microsoft.NET\Framework\v4.0.30319\regasm.exe "CamMasterComTest.dll"
/codebase /tlb

5. Run Macro

Open CAMMaster, load macro, run. License validation happens automatically.

Common Errors

License not found: check file path.

License invalid: regenerate using correct Machine ID.

ActiveX error: ensure DLL registered with 32-bit regasm.

Notes

License is machine-locked. Do not copy to other systems.

Status

Production ready. No external dependencies.