

















90	X31	上料电机1过载
91	X32	上料1推料电机过载
92	X35	上料电机2过载
93	X36	上料2推料电机过载
94	X103 12	真空电机过载
95	M38	油泵1注油异常
96	M39	油泵2注油异常标志
97	T18	搅拌过载延时



































































































































