



JP17 choose whether A17 is managed by the console or by the dip switch
JP18 choose whether A18 is managed by the console or by the dip switch

TITLE: GX4000_Multicart

Document Number:

REV:
1

Date: not saved!

Sheet: 1/1