




Project:




Right click Build Specifications,





In the Information section, fill up the required details




In the Source Files section:




The Destinations are automatically set to:



The Source File Settings need to be changed for NCS Labview VI to RunNCS.exe:




Also, for the Dependencies:




Rest is left unchanged. Now, **do NOT** build. Click on **OK**, and this box will close.

Open RunNCS.vi from the project (selected file below, you can also see the FifthBuild under Build Specifications):



**Set the path of NCS VI to following** (This is important setting):



You're all set to run RunNCS.exe!