

For TRAINER
cable power supply


TX/6S SERIAL PORT (For SBUS TRAINER)
CONNECTION
5V GND RX

For Normal Trainer OUT
TRAINER SIGNAL (OUT)
TRAINER SIGNAL GND


To Joystick
Logitech Extreme 3D Pro ONLY




Raspberry Pi Pico



CONNECT GP2 - GND \Rightarrow HEADTRACKER CH 7-8 OUT
NOT CONNECT \Rightarrow HEADTRACKER CH 5-6 OUT



HEADTRACKER
TRAINER
GND
HEADTRACKER
TRAINER
SIGNAL



Self excited
buzzer