

CAP STANDARD 72-4
01 Dec 2021



Aircraft Information File

NATIONAL HEADQUARTERS CIVIL AIR PATROL
Maxwell Air Force Base, Alabama

This page intentionally left blank

Aircraft Information File Program

CAPR 70-1, CAP *Flight Management* requires that all CAP corporate aircraft have a standardized, complete, and up-to-date Aircraft Information File (AIF). This document establishes common standards for AIF construction, layout, and contents.

Deviations and Compliance

This standard identifies specific areas within the AIF where items can be added or omitted. No other alterations to this standard are authorized. Upon request, CAP and USAF inspectors will be provided with copies of the current AIF pages for an aircraft. Aircraft that do not have an AIF that is compliant with both CAPR 70-1 requirements, and this standard may be grounded by a competent authority.

Recommending Changes to this Standard

Recommendations for improvements to this standard and/or content are solicited from aircrew and aircraft maintenance professionals. Submit all recommendations for change via the chain of command to CAP/DO using [CAPF 1-2, Recommendation for Change of Publication](#). Please ensure that you reference this standard and the appropriate document identification information from the footer (ex: AIF-G, Aircraft Flight Time Log, Glider dated 1 Oct 18), as applicable.

AIF Construction

AIF binders will be a white $\frac{1}{2}$ " to 3" clear view binder with overlay pockets (front and back covers) and two inner pockets (inside right and left covers). AIF dividers will be numbered with 10-tab indexes ([Avery #11134](#), [Avery #11135](#) or equivalent). NOTE: The 15-tab ([Avery #11143](#)) indexes may continue to be used until replaced. Clear plastic, page-sized sheet protectors ([Avery #74203](#) or equivalent) should be used when indicated to retain document legibility. Units/Wings/Regions may elect to provide a pocket insert at the front/back of the AIF binder to hold the gas credit card, instructions, and pen/pencil. A zippered binder (Amazon ASIN B07D8RPWRG or equivalent) may also be used. After assembly is completed, the AIF front and back cover pages will be placed in document protectors at the front and rear of the binder.

AIF Content

The contents required to construct an AIF are published on [gocivilairpatrol.com](#) under [Members>Publication Library>Forms](#) and come from one of three sources as defined in CAPF 70-8 AIF Contents and CAPF 70-8G AIF-G. Printed CAP forms consist of a binder of PDF documents preceded by a Table of Contents (TOC). The TOC lists all the required and optional documents for the AIF. Within the TOC, each document name is followed by a symbol indicating the document source, († = SUPPLIED, ‡ = PUBLISHED, § = FURNISH LOCALLY, or ? = OPTIONAL). Documents annotated as SUPPLIED are included within the AIF Content file and are in a fillable format where this is appropriate. When a document is not required by a specific category of aircraft, it will be omitted from the TOC and from the AIF Content file. For example, the AIF-G Content file TOC does not show a VOR Test Record, and it is not included in the file since this document is not required for glider aircraft. The AIF Table of Contents (TOC) displays a version date for each supplied document and recent changes are highlighted.

Published Documents

Documents annotated as ‡ = PUBLISHED must be independently downloaded and printed for insertion into the AIF. Whenever a change effecting a nationally published document is announced via eServices news, the AIF must be updated with the latest version. A similar approach must be used for Region, Wing, and locally published documents.

NOTICE

Local reproduction of AIF documents is authorized.

AIF Layout

This section describes a uniform layout for all CAP AIFs. When a specified document is not required by a category of aircraft, this is noted, and the document can be omitted from the AIF. Within this standard, references to the SUPPLIED documents contained within the AIF Content file are in bold, underlined typeface (ex: Table of Contents).

Since use of the tabs is consistent across all AIF, this will result in some categories of aircraft having tabs that do not contain any documents. AIF documents must be current in comparison to the TOC version dates specified for SUPPLIED documents.

Front Cover

The Major Inspections document shall be placed in the binder's front overlay pocket and kept updated as appropriate. This form has fields that can be filled in manually or by computer, generated in the WMIRS maintenance module.

Inside Front Pocket

Two copies of the Grounded Placard are to be printed on red colored paper and placed back-to-back inside in a plastic sheet protector then placed in the inside pocket of the front cover.

Page 1

The Table of Contents (TOC) and Administrative Preflight Checklist (APC) are to be placed back-to-back in a plastic sheet protector and inserted in front of the index tabs as the first page of the binder. Each line of the TOC has a checkbox that can be used when constructing the binder. The APC has fields that can be filled in manually or by computer, allowing you to enter and store contact names & numbers prior to printing.

Tab 1 – Aircraft Flight Time Log

Multiple copies of the Aircraft Flight Time Log will be provided behind tab 1. This form has fields that can be filled in manually or by computer, allowing you to enter and save custom information for your Wing or Unit. The instruction page for the Aircraft Flight Time Log should be placed inside in a plastic sheet protector, behind the AFT Log sheets.

Tab 2 – Equipment, Inspection and Documentation

The Equipment / Inspection / Document Requirements is to be placed in a plastic sheet protector behind tab 2.

Tab 3 – VOR and Fire Extinguisher

In airplane AIFs, multiple copies of the VOR Test Record shall be place in a plastic sheet protector behind tab 3. This form has fields that can be filled in manually or by computer, allowing you to enter and save custom information for your Wing or Unit. Multiple copies of the Fire Extinguisher Inspection document will be placed back-to-back in the same sleeve. This document will face forward in balloon AIFs. Neither of these documents are required in glider AIFs.

Tab 4 – Aircraft-specific Equipment Instructions

Aircraft-specific equipment instructions shall be provided behind tab 4. This should include information specific to the actual equipment installed in the aircraft, but not included in the POH or other supplementary manuals already carried in the cockpit.

Tab 5 – Weight & Balance ForeFlight Statement

The Weight & Balance ForeFlight Statement Page shall be provided behind tab 5 in a plastic sheet protector. The current CAP Aircraft Weight & Balance is now found in the POH and in the ForeFlight Application.

Tab 6 – Pre-flight Risk Assessment Worksheet (RAW)

Multiple copies of CAPF 70-1, Preflight Risk Assessment Worksheet or 70-1G, Preflight Risk Assessment Worksheet – Glider (as applicable) are to be placed in a plastic sheet protector behind tab 6. Optionally, the instructions for completing the RAW can be extracted from the appropriate CAPS 73-series document and placed in a plastic sheet protector behind the blank RAW forms.

Tab 7 – Unit / Wing / Region Specific Items

- Radio Channels**

Information specific to local channelization of the aircraft's radio(s) should be provided behind tab 7 in plastic sheet protectors. The information should be marked *For Official Use Only*.

- Local Maintenance Authorization Procedures**

Unit/Wing/Region Maintenance Procedures shall be placed behind tab 7.

- Local Guidance**

Unit/Wing/Region guidance concerning flight and mission operations shall be placed behind tab 7. Procedures specific to a local airfield or operating area (e.g., practice areas, noise abatement/sensitive areas, etc.) shall be placed behind tab 7 in plastic sheet protectors.

Inside Back Pocket

Multiple copies of the current version of CAPF 70-9, Release (Non-CAP Members) shall be carried in the inside back pocket.

Back Cover

The **Loose / Removable Equipment List** document shall be placed in the binder's back overlay pocket and kept updated as appropriate. The PIC is responsible for all equipment listed as being with or installed in the aircraft.

Aircraft Cockpit

The latest version of the approved CAP Standardized Aircraft Checklists (NP and EP) shall be made available in the aircraft cockpit. These checklists are available in CAP's Operational Resource Management System (ORMS) in eServices for download and printing. The checklists shall be protected by sleeves or lamination to ensure durability and legibility.

The general layout of the AIF is illustrated using images of sample content on the following pages:

Front Cover and Inside Front Pocket



CIVIL AIR PATROL AIRCRAFT INFORMATION FILE					
N	CAP -	TYPE	HP		
FULL FUEL USEFUL LOAD	LBS	OIL		<input type="checkbox"/> Exxon Elite 20W50 <input type="checkbox"/> Mineral Oil / Other <input type="checkbox"/> Phillips X/C 20W-50 <input type="checkbox"/> Aeroshell	
TIRE PRESSURES: NOSE PSI MAINS PSI					
— MAJOR INSPECTIONS DUE —					
REQUIRED INSPECTIONS	DATE WHEN DONE	HOURS WHEN DONE	NEXT DUE HOURS	NEXT DUE DATE	
MID-CYCLE OIL CHANGE					
ANNUAL INSPECTION					
100 HR AIR WORTHINESS INSPI					
ENGINE OVERHAUL					
PROPELLER OVERHAUL					
PROP GOVERNOR OVERHAUL					
PITOT / STATIC / TRANSPONDER					
ELT BATTERY					
CARBON MONOXIDE DETECTOR					
CORROSION CONTROL					
AIRCRAFT REGISTRATION					
NOTE: Annual inspections due at the end of the 12M calendar month. Pilot / Inspectors inspection reports are to be submitted to CAPR 70-1.					
SERVICING & CHANGES are to be made in the manufacturer's recommended sequence and manner. Any deviation must be approved by the aircraft owner. It is the responsibility of the pilot to make sure that all required maintenance has been performed. If a major inspection is required, it must be done before the next annual inspection.					
Maintenance manual P-1, H-1, H-2, H-3, H-4, H-5, H-6, H-7, H-8, H-9, H-10, H-11, H-12, H-13, H-14, H-15, H-16, H-17, H-18, H-19, H-20, H-21, H-22, H-23, H-24, H-25, H-26, H-27, H-28, H-29, H-30, H-31, H-32, H-33, H-34, H-35, H-36, H-37, H-38, H-39, H-40, H-41, H-42, H-43, H-44, H-45, H-46, H-47, H-48, H-49, H-50, H-51, H-52, H-53, H-54, H-55, H-56, H-57, H-58, H-59, H-60, H-61, H-62, H-63, H-64, H-65, H-66, H-67, H-68, H-69, H-70, H-71, H-72, H-73, H-74, H-75, H-76, H-77, H-78, H-79, H-80, H-81, H-82, H-83, H-84, H-85, H-86, H-87, H-88, H-89, H-90, H-91, H-92, H-93, H-94, H-95, H-96, H-97, H-98, H-99, H-100, H-101, H-102, H-103, H-104, H-105, H-106, H-107, H-108, H-109, H-110, H-111, H-112, H-113, H-114, H-115, H-116, H-117, H-118, H-119, H-120, H-121, H-122, H-123, H-124, H-125, H-126, H-127, H-128, H-129, H-130, H-131, H-132, H-133, H-134, H-135, H-136, H-137, H-138, H-139, H-140, H-141, H-142, H-143, H-144, H-145, H-146, H-147, H-148, H-149, H-150, H-151, H-152, H-153, H-154, H-155, H-156, H-157, H-158, H-159, H-160, H-161, H-162, H-163, H-164, H-165, H-166, H-167, H-168, H-169, H-170, H-171, H-172, H-173, H-174, H-175, H-176, H-177, H-178, H-179, H-180, H-181, H-182, H-183, H-184, H-185, H-186, H-187, H-188, H-189, H-190, H-191, H-192, H-193, H-194, H-195, H-196, H-197, H-198, H-199, H-200, H-201, H-202, H-203, H-204, H-205, H-206, H-207, H-208, H-209, H-210, H-211, H-212, H-213, H-214, H-215, H-216, H-217, H-218, H-219, H-220, H-221, H-222, H-223, H-224, H-225, H-226, H-227, H-228, H-229, H-230, H-231, H-232, H-233, H-234, H-235, H-236, H-237, H-238, H-239, H-240, H-241, H-242, H-243, H-244, H-245, H-246, H-247, H-248, H-249, H-250, H-251, H-252, H-253, H-254, H-255, H-256, H-257, H-258, H-259, H-260, H-261, H-262, H-263, H-264, H-265, H-266, H-267, H-268, H-269, H-270, H-271, H-272, H-273, H-274, H-275, H-276, H-277, H-278, H-279, H-280, H-281, H-282, H-283, H-284, H-285, H-286, H-287, H-288, H-289, H-290, H-291, H-292, H-293, H-294, H-295, H-296, H-297, H-298, H-299, H-300, H-301, H-302, H-303, H-304, H-305, H-306, H-307, H-308, H-309, H-310, H-311, H-312, H-313, H-314, H-315, H-316, H-317, H-318, H-319, H-320, H-321, H-322, H-323, H-324, H-325, H-326, H-327, H-328, H-329, H-330, H-331, H-332, H-333, H-334, H-335, H-336, H-337, H-338, H-339, H-340, H-341, H-342, H-343, H-344, H-345, H-346, H-347, H-348, H-349, H-350, H-351, H-352, H-353, H-354, H-355, H-356, H-357, H-358, H-359, H-360, H-361, H-362, H-363, H-364, H-365, H-366, H-367, H-368, H-369, H-370, H-371, H-372, H-373, H-374, H-375, H-376, H-377, H-378, H-379, H-380, H-381, H-382, H-383, H-384, H-385, H-386, H-387, H-388, H-389, H-390, H-391, H-392, H-393, H-394, H-395, H-396, H-397, H-398, H-399, H-400, H-401, H-402, H-403, H-404, H-405, H-406, H-407, H-408, H-409, H-410, H-411, H-412, H-413, H-414, H-415, H-416, H-417, H-418, H-419, H-420, H-421, H-422, H-423, H-424, H-425, H-426, H-427, H-428, H-429, H-430, H-431, H-432, H-433, H-434, H-435, H-436, H-437, H-438, H-439, H-440, H-441, H-442, H-443, H-444, H-445, H-446, H-447, H-448, H-449, H-450, H-451, H-452, H-453, H-454, H-455, H-456, H-457, H-458, H-459, H-460, H-461, H-462, H-463, H-464, H-465, H-466, H-467, H-468, H-469, H-470, H-471, H-472, H-473, H-474, H-475, H-476, H-477, H-478, H-479, H-480, H-481, H-482, H-483, H-484, H-485, H-486, H-487, H-488, H-489, H-490, H-491, H-492, H-493, H-494, H-495, H-496, H-497, H-498, H-499, H-500, H-501, H-502, H-503, H-504, H-505, H-506, H-507, H-508, H-509, H-510, H-511, H-512, H-513, H-514, H-515, H-516, H-517, H-518, H-519, H-520, H-521, H-522, H-523, H-524, H-525, H-526, H-527, H-528, H-529, H-530, H-531, H-532, H-533, H-534, H-535, H-536, H-537, H-538, H-539, H-540, H-541, H-542, H-543, H-544, H-545, H-546, H-547, H-548, H-549, H-550, H-551, H-552, H-553, H-554, H-555, H-556, H-557, H-558, H-559, H-550, H-551, H-552, H-553, H-554, H-555, H-556, H-557, H-558, H-559, H-560, H-561, H-562, H-563, H-564, H-565, H-566, H-567, H-568, H-569, H-560, H-561, H-562, H-563, H-564, H-565, H-566, H-567, H-568, H-569, H-570, H-571, H-572, H-573, H-574, H-575, H-576, H-577, H-578, H-579, H-570, H-571, H-572, H-573, H-574, H-575, H-576, H-577, H-578, H-579, H-580, H-581, H-582, H-583, H-584, H-585, H-586, H-587, H-588, H-589, H-580, H-581, H-582, H-583, H-584, H-585, H-586, H-587, H-588, H-589, H-590, H-591, H-592, H-593, H-594, H-595, H-596, H-597, H-598, H-599, H-590, H-591, H-592, H-593, H-594, H-595, H-596, H-597, H-598, H-599, H-600, H-601, H-602, H-603, H-604, H-605, H-606, H-607, H-608, H-609, H-600, H-601, H-602, H-603, H-604, H-605, H-606, H-607, H-608, H-609, H-610, H-611, H-612, H-613, H-614, H-615, H-616, H-617, H-618, H-619, H-610, H-611, H-612, H-613, H-614, H-615, H-616, H-617, H-618, H-619, H-620, H-621, H-622, H-623, H-624, H-625, H-626, H-627, H-628, H-629, H-620, H-621, H-622, H-623, H-624, H-625, H-626, H-627, H-628, H-629, H-630, H-631, H-632, H-633, H-634, H-635, H-636, H-637, H-638, H-639, H-630, H-631, H-632, H-633, H-634, H-635, H-636, H-637, H-638, H-639, H-640, H-641, H-642, H-643, H-644, H-645, H-646, H-647, H-648, H-649, H-640, H-641, H-642, H-643, H-644, H-645, H-646, H-647, H-648, H-649, H-650, H-651, H-652, H-653, H-654, H-655, H-656, H-657, H-658, H-659, H-650, H-651, H-652, H-653, H-654, H-655, H-656, H-657, H-658, H-659, H-660, H-661, H-662, H-663, H-664, H-665, H-666, H-667, H-668, H-669, H-660, H-661, H-662, H-663, H-664, H-665, H-666, H-667, H-668, H-669, H-670, H-671, H-672, H-673, H-674, H-675, H-676, H-677, H-678, H-679, H-670, H-671, H-672, H-673, H-674, H-675, H-676, H-677, H-678, H-679, H-680, H-681, H-682, H-683, H-684, H-685, H-686, H-687, H-688, H-689, H-680, H-681, H-682, H-683, H-684, H-685, H-686, H-687, H-688, H-689, H-690, H-691, H-692, H-693, H-694, H-695, H-696, H-697, H-698, H-699, H-690, H-691, H-692, H-693, H-694, H-695, H-696, H-697, H-698, H-699, H-700, H-701, H-702, H-703, H-704, H-705, H-706, H-707, H-708, H-709, H-700, H-701, H-702, H-703, H-704, H-705, H-706, H-707, H-708, H-709, H-710, H-711, H-712, H-713, H-714, H-715, H-716, H-717, H-718, H-719, H-710, H-711, H-712, H-713, H-714, H-715, H-716, H-717, H-718, H-719, H-720, H-721, H-722, H-723, H-724, H-725, H-726, H-727, H-728, H-729, H-720, H-721, H-722, H-723, H-724, H-725, H-726, H-727, H-728, H-729, H-730, H-731, H-732, H-733, H-734, H-735, H-736, H-737, H-738, H-739, H-730, H-731, H-732, H-733, H-734, H-735, H-736, H-737, H-738, H-739, H-740, H-741, H-742, H-743, H-744, H-745, H-746, H-747, H-748, H-749, H-740, H-741, H-742, H-743, H-744, H-745, H-746, H-747, H-748, H-749, H-750, H-751, H-752, H-753, H-754, H-755, H-756, H-757, H-758, H-759, H-750, H-751, H-752, H-753, H-754, H-755, H-756, H-757, H-758, H-759, H-760, H-761, H-762, H-763, H-764, H-765, H-766, H-767, H-768, H-769, H-760, H-761, H-762, H-763, H-764, H-765, H-766, H-767, H-768, H-769, H-770, H-771, H-772, H-773, H-774, H-775, H-776, H-777, H-778, H-779, H-770, H-771, H-772, H-773, H-774, H-775, H-776, H-777, H-778, H-779, H-780, H-781, H-782, H-783, H-784, H-785, H-786, H-787, H-788, H-789, H-780, H-781, H-782, H-783, H-784, H-785, H-786, H-787, H-788, H-789, H-790, H-791, H-792, H-793, H-794, H-795, H-796, H-797, H-798, H-799, H-790, H-791, H-792, H-793, H-794, H-795, H-796, H-797, H-798, H-799, H-800, H-801, H-802, H-803, H-804, H-805, H-806, H-807, H-808, H-809, H-800, H-801, H-802, H-803, H-804, H-805, H-806, H-807, H-808, H-809, H-810, H-811, H-812, H-813, H-814, H-815, H-816, H-817, H-818, H-819, H-810, H-811, H-812, H-813, H-814, H-815, H-816, H-817, H-818, H-819, H-820, H-821, H-822, H-823, H-824, H-825, H-826, H-827, H-828, H-829, H-820, H-821, H-822, H-823, H-824, H-825, H-826, H-827, H-828, H-829, H-830, H-831, H-832, H-833, H-834, H-835, H-836, H-837, H-838, H-839, H-830, H-831, H-832, H-833, H-834, H-835, H-836, H-837, H-838, H-839, H-840, H-841, H-842, H-843, H-844, H-845, H-846, H-847, H-848, H-849, H-840, H-841, H-842, H-843, H-844, H-845, H-846, H-847, H-848, H-849, H-850, H-851, H-852, H-853, H-854, H-855, H-856, H-857, H-858, H-859, H-850, H-851, H-852, H-853, H-854, H-855, H-856, H-857, H-858, H-859, H-860, H-861, H-862, H-863, H-864, H-865, H-866, H-867, H-868, H-869, H-860, H-861, H-862, H-863, H-864, H-865, H-866, H-867, H-868, H-869, H-870, H-871, H-872, H-873, H-874, H-875, H-876, H-877, H-878, H-879, H-870, H-871, H-872, H-873, H-874, H-875, H-876, H-877, H-878, H-879, H-880, H-881, H-882, H-883, H-884, H-885, H-886, H-887, H-888, H-889, H-880, H-881, H-882, H-883, H-884, H-885, H-886, H-887, H-888, H-889, H-890, H-891, H-892, H-893, H-894, H-895, H-896, H-897, H-898, H-899, H-890, H-891, H-892, H-893, H-894, H-895, H-896, H-897, H-898, H-899, H-900, H-901, H-902, H-903, H-904, H-905, H-906, H-907, H-908, H-909, H-900, H-901, H-902, H-903, H-904, H-905, H-906, H-907, H-908, H-909, H-910, H-911, H-912, H-913, H-914, H-915, H-916, H-917, H-918, H-919, H-910, H-911, H-912, H-913, H-914, H-915, H-916, H-917, H-918, H-919, H-920, H-921, H-922, H-923, H-924, H-925, H-926, H-927, H-928, H-929, H-920, H-921, H-922, H-923, H-924, H-925, H-926, H-927, H-928, H-929, H-930, H-931, H-932, H-933, H-934, H-935, H-936, H-937, H-938, H-939, H-930, H-931, H-932, H-933, H-934, H-935, H-936, H-937, H-938, H-939, H-940, H-941, H-942, H-943, H-944, H-945, H-946, H-947, H-948, H-949, H-940, H-941, H-942, H-943, H-944, H-945, H-946, H-947, H-948, H-949, H-950, H-951, H-952, H-953, H-954, H-955, H-956, H-957, H-958, H-959, H-950, H-951, H-952, H-953, H-954, H-955, H-956, H-957, H-958, H-959, H-960, H-961, H-962, H-963, H-964, H-965, H-966, H-967, H-968, H-969, H-960, H-961, H-962, H-963, H-964, H-965, H-966, H-967, H-968, H-969, H-970, H-971, H-972, H-973, H-974, H-975, H-976, H-977, H-978, H-979, H-970, H-971, H-972, H-973, H-974, H-975, H-976, H-977, H-978, H-979, H-980, H-981, H-982, H-983, H-984, H-985, H-986, H-987, H-988, H-989, H-980, H-981, H-982, H-983, H-984, H-985, H-986, H-987, H-988, H-989, H-990, H-991, H-992, H-993, H-994, H-995, H-996, H-997, H-998, H-999, H-990, H-991, H-992, H-993, H-994, H-995, H-996, H-997, H-998, H-999, H-1000, H-1001, H-1002, H-1003, H-1004, H-1005, H-1006, H-1007, H-1008, H-1009, H-1000, H-1001, H-1002, H-1003, H-1004, H-1005, H-1006, H-1007, H-1008, H-1009, H-1010, H-1011, H-1012, H-1013, H-1014, H-1015, H-1016, H-1017, H-1018, H-1019, H-1010, H-1011, H-1012, H-1013, H-1014, H-1015, H-1016, H-1017, H-1018, H-1019, H-1020, H-1021, H-1022, H-1023, H-1024, H-1025, H-1026, H-1027, H-1028, H-1029, H-1020, H-1021, H-1022, H-1023, H-1024, H-1025, H-1026, H-1027, H-1028, H-1029, H-1030, H-1031, H-1032, H-1033, H-1034, H-1035, H-1036, H-1037, H-1038, H-1039, H-1030, H-1031, H-1032, H-1033, H-1034, H-1035, H-1036, H-1037, H-1038, H-1039, H-1040, H-1041, H-1042, H-1043, H-1044, H-1045, H-1046, H-1047, H-1048, H-1049, H-1040, H-1041, H-1042, H-1043, H-1044, H-1045, H-1046, H-1047, H-1048, H-1049, H-1050, H-1051, H-1052, H-1053, H-1054, H-1055, H-1056, H-1057, H-1058, H-1059, H-1050, H-1051, H-1052, H-1053, H-1054, H-1055, H-1056, H-1057, H-1058, H-1059, H-1060, H-1061, H-1062, H-1063, H-1064, H-1065, H-1066, H-1067, H-1068, H-1069, H-1060, H-1061, H-1062, H-1063, H-1064, H-1065, H-1066, H-1067, H-1068, H-1069, H-1070, H-1071, H-1072, H-1073, H-1074, H-1075, H-1076, H-1077, H-1078, H-1079, H-1070, H-1071, H-1072, H-1073, H-1074, H-1075, H-1076, H-1077, H-1078, H-1079, H-1080, H-1081, H-1082, H-1083, H-1084, H-1085, H-1086, H-1087, H-1088, H-1089, H-1080, H-1081, H-1082, H-1083, H-1084, H-1085, H-1086, H-1087, H-1088, H-1089, H-1090, H-1091, H-1092, H-1093, H-1094, H-1095, H-1096, H-1097, H-1098, H-1099, H-1090, H-1091, H-1092, H-1093, H-1094, H-1095, H-1096, H-1097, H-1098, H-1099, H-1100, H-1101, H-1102, H-1103, H-1104, H-1105, H-1106, H-1107, H-1108, H-1109, H-1100, H-1101, H-1102, H-1103, H-1104, H-1105, H-1106, H-1107, H-1108, H-1109, H-1110, H-1111, H-1112, H-1113, H-1114, H-1115, H-1116, H-1117, H-1118, H-1119, H-1110, H-1111, H-1112, H-1113, H-1114, H-1115, H-1116, H-1117, H-1118, H-1119, H-1120, H-1121, H-1122, H-1123, H-1124, H-1125, H-1126, H-1127, H-1128, H-1129, H-1120, H-1121, H-1122, H-1123, H-1124, H-1125, H-1126, H-1127, H-1128, H-1129, H-1130, H-1131, H-1132, H-1133, H-1134, H-1135, H-1136, H-1137, H-1138, H-1139, H-1130, H-1131, H-1132, H-1133, H-1134, H-1135, H-1136,					

Tab 2 – Equipment, Inspection and Documentation Requirements

EQUIPMENT / INSPECTION / DOCUMENT REQUIREMENTS

Tab 3 – VOR and Fire Extinguisher

Tab 4 – Aircraft-specific Equipment Instructions



Tab 5 – Weight & Balance ForeFlight Statement

CAP W&B

ForeFlight

INFORMATION

Tab 6 – Preflight Risk Assessment Worksheet (RAW)

Tab 7 – Unit / Wing / Region Specific Items (Examples)

Inside Back Pocket

RELEASE		
Mission Number	Mission Symbol	Serial Number
PART I RELEASE * (For Non CAP Member)		
KNOW ALL MEN BY THESE PRESENTS: WHEREBY I, [REDACTED] am about to take a flight or flights in certain Civil Air Patrol United States Instrumentality aircraft or aircraft in which I am flying as a passenger, and wherein, I am doing so at my own initiative, risk, and responsibility; therefore, in consideration of the permission extended by the Civil Air Patrol United States of America through its officers, agents, and employees, I do hereby release and forgive the Civil Air Patrol, Inc., United States of America, and its officers, agents, and employees, as well as all crews, stations, officers, or causes of action, as well as all persons, entities, and organizations involved in the operation of the aircraft, from any and all claims, demands, suits, or causes of action, or causes of death or personal injury to myself or my children, which may occur as a result of my taking flight or flights in the aircraft mentioned above, or in which I am flying as a passenger, or in which I am flying as a passenger, and wherein, I am doing so at my own initiative, risk, and responsibility; I also release and forgive the Civil Air Patrol United States of America through its officers and agents to take said flight or flights. I do hereby for myself, heirs, executors, and administrators release and forgive the Civil Air Patrol, Inc., United States of America, and its officers, agents, and employees, as well as all persons, entities, and organizations involved in the operation of the aircraft mentioned above, or in which I am flying as a passenger, and wherein, I am doing so at my own initiative, risk, and responsibility, from any and all claims, demands, suits, or causes of action, or causes of death or personal injury to myself or my children, which may occur as a result of my taking flight or flights in the aircraft mentioned above, or in which I am flying as a passenger, and wherein, I am doing so at my own initiative, risk, and responsibility; I acknowledge that the passenger may be safer transported in an unpressurized aircraft, sealed cockpit, and ordinary aircraft methods.		
DATE	(SIGNATURE OF RELEASEE)	
(SIGNATURE OF WITNESS)	(NAME OF PERSON TO BE NOTIFIED IN EMERGENCY)	
SIGNATURE OF WITNESS	(ADDRESS OF PERSON TO BE NOTIFIED IN EMERGENCY)	
PART II RELEASE **(For Parent of Minor)		
KNOW ALL MEN BY THESE PRESENTS: WHEREBY I, [REDACTED], [REDACTED] in [REDACTED] about to take a flight or flights in certain Civil Air Patrol United States of America instrumentality aircraft or aircraft in which I am flying as a passenger, and wherein, I am doing so at my own initiative, risk, and responsibility; therefore, in consideration of the permission extended by the Civil Air Patrol United States of America through its officers, agents, and employees, I do hereby release and forgive the Civil Air Patrol, Inc., United States of America, and its officers, agents, and employees, as well as all persons, entities, and organizations involved in the operation of the aircraft mentioned above, or in which I am flying as a passenger, and wherein, I am doing so at my own initiative, risk, and responsibility; I also release and forgive the Civil Air Patrol United States of America through its officers and agents to take said flight or flights. I do hereby for myself, heirs, executors, and administrators release and forgive the Civil Air Patrol, Inc., United States of America, and its officers, agents, and employees, as well as all persons, entities, and organizations involved in the operation of the aircraft mentioned above, or in which I am flying as a passenger, and wherein, I am doing so at my own initiative, risk, and responsibility, from any and all claims, demands, suits, or causes of action, or causes of death or personal injury to myself or my children, which may occur as a result of my taking flight or flights in the aircraft mentioned above, or in which I am flying as a passenger, and wherein, I am doing so at my own initiative, risk, and responsibility; I acknowledge that the passenger may be safer transported in an unpressurized aircraft, sealed cockpit, and ordinary aircraft methods.		
DATE	(SIGNATURE OF PARENT GUARDIAN)**	
(SIGNATURE OF WITNESS)	(SIGNATURE OF PARENT GUARDIAN)**	
SIGNATURE OF WITNESS		
* Complete appropriate part(s) of this form. ** All parent signatures must sign.		
CAFF TO-B DRAFT	PREVIOUS EDITIONS WILL NOT BE USED	
OFFICER/ROUTING: DO		

Back Cover

CIVIL AIR PATROL
AIRCRAFT INFORMATION FILE

Aircraft Cockpit

Civil Air Patrol	Preflight Emergency
Cessna C999 (NAVII)	1) Baggage 2) Under Cowl Lock 3) Tail Tie-Down 4) Tail Streamer 5) Landing Surfaces 6) Trim Tabs 7) Antennae
CVB (T6/T6C & G7C/T70)	Check Status Remove Disconnect Remove Check for security Check
A) Brake & Inspect for Airtightness	
2) Pitot Tube, Comp., Remove & Check/Clean	
3) Fuel System (Airtight in airplane) 4) R/H & Cabin Pressurization	
Ref. GuideAccessories to plane	
5) Parking BrakeSet	
6) Command ThrottleRelease	
WARNING	
When the master switch is on, using an external power source, or manually operating the propeller, the propeller is free to turn if the magneto switch is off. This could cause serious injury to anyone who comes in contact with the arc of the propeller since a loose or broken wire can cause the switch to open. This could cause the engine to start.	
7) MAGNETOS SwitchOff	
8) AVIONICS Switch (BUS 1&2)Off	
9) AVIONICS Master ALT & STBYOff	
10) VHF/FM Direct SelectionOff	
11) FUEL CYL (L&R)Check	
12) LOW FUEL AnnunciationsCheck	
13) TURBOCHARGERSVerify	
14) LOW VAC AnnunciatorCheck	
15) AVIONICS Switch (BUS 1)On	
16) AVIONICS Switch (BUS 2)On	
17) AVIONICS Switch (BUS 3)Off	
18) AVIONICS Switch (BUS 4)Off	
19) AVIONICS SWITCH (BUS 2)On	
20) RTOT/HEAT SwitchOn	
21) RTOT/HEAT SwitchCleaning	
22) RTOT/HEAT SwitchOff	
23) STALL Warning SystemCheck	
24) STALL Warning SystemCheck	
25) flap motorCheck at 10°/20°	
26) exterior lightsCheck then off	
27) interior lightsCheck	
28) Flap/Rudder Trim(Right/Left)	
29) Flap/Rudder Trim(Left/Right)	
30) FUEL SELECTOR ValveBoth	
31) AT/STATIC VARICAP (off plane)Check	
32) Flap/ElevatorCheck (off plane)	
33) Fuel QuantityCheck	See Fuel Contamination Warning in the PDR.
34) Fuel Filter Cap, Squeeze and VentClear	
Note:	
1. Static Source (Opening Port).....Check	
2. Fuel Quantity.....Check	
3. Fuel Filter Cap, Squeeze and Vent.....Clear	
See Fuel Contamination Warning in the PDR.	
1. This State Quick Change (3s).....Dish	
2. Engine Cooling Air Intake.....Check	
3. All Filter.....Check	
4. All Filter.....Check	
5. Nosewheel Strut/Tire (PSPI).....Check	
6. Tow Bar Wheel Strut/Tire (PSPI).....Check	
7. Engine Cooling Oil Filter.....Check	
8. Engine Oil Dipstick.....Check	
9. Engine Oil Dipstick.....Check	
10. Static Source (Left).....Check	
Preflight Left Wing Leading Edge	
1) Static Source (Left).....Check	
2) Stall Warning VaneCheck	
3) Land Tax (light)sCheck condition	
4) Landing GearCheck	
5) Flap/ElevatorCheck (off plane)	

Preflight Left Wing

- 1. Wing Tie Rods - Disconnect.
- 2. Fuel Quantity - Verify Check
- 3. Fuel Filler Cap - Secure
- 4. Fuel Tank Sump/QuicksDrains (5) - Drain

See Fuel Contamination Warning in the POH.

- 5. Main Brake - Check
- 6. Brake Pedal - Visual
- 7. Checks - Remind & Show

Preflight Left Wing Trailing Edge

- 1. Left Flap - Check Position
- 2. Left Rudder - Check Position
- 3. Baggage Door - Re-check (Secure)

Before Starting Engine

- 1. Preflight inspection - Complete
- 2. **PASSENGERS BIBES**

 - 3. Set belts - Verify
 - 4. Personal Electronic Devices off - Verify
 - 5. If ejection Passenger Location - Operation

- 6. Mission Brief
- 7. Destination - Flyout, RTA, ETE
- 8. NOTAMS
- 9. Navigation & CRM
- 10. sterile Cockpit Procedure
- 11. Intercom & Radio Usage
- 12. Emergency Equipment
- 13. Emergency Action & Equipment

Passenger Brief - Complete

- 1. Seats - Adjust
- 4. Seats / Belts / Shoulder Harnesses - Adjust and lock, check belt feels
- 5. Headrest - Adjust
- 6. Window shades - Check it
- 7. Electrical Equipment - Off

Using Control Column - Complete

The avionics switch (bus 2) must be off during engine start to prevent damage to the avionics system.

- 1. Bus 1 Avionics - Off
- 2. Avionics Switch (Bus 1B2) - Off
- 3. Cowl Flaps - Open
- 4. Fuel Selector Valve - Both

Starting Engine (using Battery)

- 1. Propeller Control - High RPM
- 2. Throttle - Cut Off
- 3. Static Battery Switch - Turn On
- 4. Hold for 10 seconds, verify that green test light does not go on, and verify that PFD comes on

Engines Starting System - Check

- 1. Bus 1 Volt - Verify
- 2. M/Bus Vols - Verify 15VDC (rest)
- 3. Batt Aamps - Discharge (neg)
- 4. Master Power - On
- 5. Hold Power Area - Green
- 6. Master Switch (Alt and Batt) - On
- 7. Beacon Light Switch - On

If engine is warm, omit priming procedure of

- 8. Fuel Pump Switch - Off
- 9. Mixture Control - Advance to 15 below
- 10. Fuel Pump Switch - On
- 11. Fuel Pump Switch - Off
- 12. Mixture Control - Advance to 15 rich when engine starts
- 13. Oil Pressure - Check
- 14. Altitude (Alt & Batt S) - Check change (positive)
- 20. Low Voltage Protection - Verify Off
- 21. Nav Light Switch - Verify Off
- 22. Avionics Switch (Bus1B2) - On
- 23. Mission Master Switch - On
- 24. Hold Power Area - Green
- 25. Check MFD for correct A/T type and Navigation database expiration date
- 26. Hold Power Area - Present
- 27. Fuel Totalizer - Reset
- 28. ATIS / AWOS - Copy
- 29. ATIS / Ground Weather - Enter as stated
- 30. All altimeters - PFD and Standby

1. Brakes - Check

2. Turn - Deflect - As Required

3. Attitude Indicator - Verify Proper Ops.

4. Turn Coordinator - Verify Proper Ops.

5. HSI &Compass - Verify Proper Ops.

EMERGENCY PROCEDURES	
Cessna C99 (NAVI)	EMERGENCY PROCEDURES
CEB: TWD (G1000 & GFC700)	EMERGENCY PROCEDURES
ENGINE FAILURES	
ENGINE FAILURE DURING TAKEOFF/ROLL	
1. Throttle Control	IDELE
2. Brake Pedal	APPLY
3. Flaps	UP
4. mixture Control	IDL CUT OFF
5. MAGNETOS Switch	OFF
6. Sby Batt Switch	OFF
7. Masking Switch (Alt & Batt) - OFF	
ENGINE FAILURE IMMEDIATELY AFTER TAKEOFF	
1. Airspeed... 75 KIAS (Flaps Up)	
2. Maximum Control IDLE CUT OFF	
3. Fuel Selector Valve... OFF	
4. Fuel Pump Switch... ON	
5. Wing Flaps... AS REQUIRED	
6. Sby Batt Switch... OFF	
7. Cabin Pressure... UNLATCH	
8. Land... Straight ahead	
ENGINE FAILURE DURING FLIGHT (Restart Procedures)	
1. Airspeed... 76 KIAS	(best glide speed)
2. Fuel Selector Valve... OTH	
3. Fuel Pump Switch... ON	
4. mixture Control	RICH
5. MAGNETOS Switch	BOTH
(or START if propeller is stopped)	
NOTE	
If propeller is unwilling, engine will restart after a few seconds. If propeller is still not spinning after a few seconds, turn off the propeller has stopped spinning (at low speeds). If MAGNETOS switch is set to START , attempt to start the engine again. If the mixture from tank 1 is rich, as required to idle, turn off the mixture from tank 1.	
Use a Push/Pull Switch... OFF	
FORCED LANDINGS	
EMERGENCY LANDINGS WITH ENGINE POWER	
1. Push/Pull Switch... ON	MOST UPRIGHT POSITION
2. Seats and Seat Belts	SECURE
3. Masking Switch (KAS) (Flaps Up)	OFF
4. mixture Control IDLE CUT OFF	
5. FUEL SELECTOR Valve... OFF	
6. MAGNETOS Switch... OFF	
7. Wing Flaps... AS REQUIRED	
8. Sby Batt Switch... OFF	
9. Master System Cut Off... OFF	(when landing to be assured)
10. Doors... UNLATCHED	
11. Turnoff... OFF	
12. Takeoff... Slightly tail low	
13. Brakes... APPLY HEAVILY	
PRECAUTIONARY LANDINGS WITH ENGINE POWER	
1. Pilot + Passenger Seats	
2. MOST UPRIGHT POSITION	
3. Seats and Seat Belts	SECURE
4. Airspeed	75 KIAS
5. Wing Flaps	OFF
6. Fuel Selector Valve	FLY ON APPROXIMATELY
7. Flying terrain and obstructions	
8. Wing Flaps/ULL (on final approach)	
9. Airspeed	70 KIAS

8. Sby Batt SwitchOFF	NOTE: If necessary, open window and flood cabin to equalize pressure so doors can be opened
9. Master Switch (Alt & Batt)OFF (when landing assured)	
10. Down HatchOPEN	
11. TouchdownTOUCHDOWN	
11. Touchdown	Slightly TALL LOW	
12. Mixture ControlIDLE CUTOFF	
13. MAGNETOS SwitchOFF	
14. BrakesAPPLY HEAVILY	
DITCHING		
1. RadioOFF	1. DAY/NIGHT
2. RadioOFF	2. DAY/NIGHT
3. GPSOFF	3. DAY/NIGHT
4. GPSOFF	4. SHUTDOWN
5. Heavy Objects (in baggage area)		Inspect for damage.
6. SECURE or JETTISON (if possible)		
7. Pilot & Passenger Seat Belts	SECURE	1. ENGINE FAILS TO START
8. Cabin DoorsCLOSED	2. Throttle Control, FULL OPEN
9. Seats and Seat Belts	SECURE	2. Mixture Control, FULL OPEN
10. Wing Flaps20° to Full	3. Magnetic Switch, START (crank handle)
11. Power ESTABLISH 300 FT/TIMING		4. Fuel Selector Valve, OFF
12. DESCENT TO 50 KIAS		5. Fuel Selector Valve, ON
Note		
no power is available, approach at 70 KIAS with flaps UP or 65 KIAS with flaps DOWN		
1. Approach		6. MAGNETOS Switch, OFF
2. Approach		7. Sby Batt Switch,OFF
3. High winds, Heavy Seas	INTO THE WIND	8. MASTER Switch (Alt & Batt)OFF
4. Light weight, Heavy Swells	SWIMMING POOL	9. Engine,SECURE
5. PARALLEL to SWELLS		10. Parking Brake,RELEASE
6. Touchdown	LEVEL Altitude At Established Rate Of Descent	11. Fire Extinguisher,OBTAIN
7. Touchdown	TO GROUND	12. Airplane,EVACUATE
8. Cabin Doors	UNLATCH	13. Fire,EXTINGUISH using fire extinguisher, wooden or dirt
9. Touchdown	at touchdown with folded coat	14. Fire Damage,INSPECT
10. ELTACTIVATE	
11. AirplaneEVACUATE	

Change Record

Issue Date	Change Summary
8 Jun 20	Corrected link to AIF Content files. Added option for zippered binder. Removed Archer from Tab 13.
25 Aug 20	Revised references to AIF Content files, which are now published as CAP forms. Revised AIF Cover image and corrected Change Record
01 Dec 21	Updated entire document to accommodate the AIF redesign