实验 06_ACC 的使用

【实验目的】:

- 1、掌握 MMA7455L 的基本原理
- 2、学会 MMA7455L 的使用方法。

【实验环境】:

- 1、FS_11C14 开发板
- 2 FS_Colink V2.0
- 3. RealView MDK (Keil uVision4)


【实验步骤】:

- 1、在 ACC 文件夹下找到并打开 project. uvproj 文件;
- 2、编译此工程;
- 3、通过 FS_Colink 下载编译好的工程到 FS_11C14 开发板;
- 4、按 Reset 键复位开发板,观察 OLED 显示;
- 5、转动开发板,观察 OLED 显示
- 6、查看 MMA7455L 芯片手册, 学习其原理及使用方法;
- 7、对照原理图分析实验代码

【实验现象】



OLED 上显示转换后 ACC 三轴坐标值,转动实验板相应的坐标值会发生改变。由于该传感器比较灵敏,所以即使实验板静止,相应的坐标值也会发生微小的变化,如图:







【实验分析】

硬件分析:

由原理图可知 MMA7455L 通过 I2C 总线与LPC11C14 进行通信,其中 PIO0_4 作为 MMA7455L 的 SDA, PIO0_5 作为 MMA7455L 的 SCL, PIO0_7 作为 MMA7455L 的 Axis3 INT。





```
软件分析:
        测试程序:
void Axis3_Test(void)
            buf[24];
  char
  int32 t
          xoff = 0;
  int32_t
            yoff = 0;
  int32 t
            zoff = 0;
  int8_t x = 0;
  int8_t y = 0;
  int8_t z = 0;
  OLED_ClearScreen();
  OLED_DisStrLine(0, 0, "Axis-3");
  I2CInit(I2CMASTER, 0);
                              //初始化
  acc_init();
  /* Assume base board in zero-g position when reading first value. */
  acc_read(&x, &y, &z);
                                  //读数据
  xoff = 0-x;
  yoff = 0-y;
  zoff = 0-z;
  while(1)
    /* Accelerometer */
```

```
acc_read(&x, &y, &z);
    x = x + x off:
    y = y + y off;
    z = z + z \circ ff;
    snprintf(buf, 20, "Acc x: %d ", x);
                                               //将 X 轴数据按格式存入 buf
    OLED_DisStrLine(2, 0, (uint8_t *)buf);
                                               //OLED 显示
    printf("\r\nAcc x: %d, ", x);
    snprintf(buf, 20, "Acc y: %d ", y);
                                               //将Y轴数据按格式存入 buf
    OLED_DisStrLine(3, 0, (uint8_t *)buf);
    printf("Acc y: %d, ", y);
    snprintf(buf, 20, "Acc z: %d ", z);
                                               //将 Z 轴数据按格式存入 buf
    OLED_DisStrLine(4, 0, (uint8_t *)buf);
    printf("Acc z: %d. ", z);
    delay_ms(250);
  }
}
    读取 ACC 值
void acc_read (int8_t *x, int8_t *y, int8_t *z)
{
    uint8_t buf[1];
    /* wait for ready flag */
    while ((getStatus() & ACC_STATUS_DRDY) == 0);
     * Have experienced problems reading all registers
     * at once. Change to reading them one-by-one.
     */
    buf[0] = ACC_ADDR_XOUT8;
    I2CWrite(ACC I2C ADDR, buf, 1);
    I2CRead(ACC_I2C_ADDR, buf, 1);
    x = (int8_t)buf[0];
    buf[0] = ACC ADDR YOUT8;
    I2CWrite(ACC_I2C_ADDR, buf, 1);
    I2CRead(ACC_I2C_ADDR, buf, 1);
    y = (int8 t)buf[0];
```

```
buf[0] = ACC_ADDR_ZOUT8;
I2CWrite(ACC_I2C_ADDR, buf, 1);
I2CRead(ACC_I2C_ADDR, buf, 1);
*z = (int8_t)buf[0];
}
```