

RTS Monitor Removal and Installation Guide

version 1.0 | 07/27/2009



Power off the RTS Kiosk and unplug prior to maintenance.





Tools Needed:

Magnetic Phillips head screw driver

Timeframe:

Approximatley 35 minutes for removal/installation process.

STEPS FOR REMOVAL



Unpackage replacement monitor and remove 4 VESA mount screws from back.



Remove 4 screws from back cover.



Remove back cover from kiosk and set to one side.



Remove 2 screws from rear monitor panel and set panel to one side.



Remove the 4 VESA mount screws.

STEPS FOR INSTALLATION



Gently unplug cables from the back of the monitor and set monitor to one side.



Reconnect the 3 cables that to the replacement monitor.



Make sure the USB cable is pulled snug behind the monitor panel. (see grahpic)



Align the monitor with the mounting bracket and screws.



Replace 4 screws securing the monitor to kiosk.

STEPS FOR INSTALLATION



Replace 2 screws to secure rear monitor panel.



Gently replace back cover onto kiosk and secure with 4 screws that were removed in step 2.

FINAL STEP



Use return shipping label included inside the replacement box and drop off package to UPS Center for return shipping no later than the following day.

Please do not remove, damage, or marker over the Serial Label on the box. This information is used to catalog completion of replacement install and return.