Telnet into a Cisco Router


Saturday, August 27, 2022 11:17 AM

The prerequisite to setting up Telnet on a Router is that you have IP address Router and the PC you are connecting from.

Having a remote access to a router is always helpful to create and modify corouter. All of the configurations below are done in the global config mode up telnet connection, you will be able to connect to the router and perform accessing the PC remotely.

- 1) The first step in setting up remote access is to create virtual terminals of done by the following command. The following command creates 3 virtual can configure a maximum of 100 virtual terminals.
 - a. line vty 0 2
- 2) We now configure a password for the default mode with the following
 - a. password "whatever the password is"

 The third step is to enable login which you can do by the following con
- 3) The third step is to enable login which you can do by the following co
 a. Login
 4) For Global Config mode, you can also get a "Enable Description" which
- 4) For Global Config mode, you can also set a "Enable Password" which following command
 - a. enable password "whatever the password is"
- 5) While all of this is setup, the passwords are stored in plain text format, passwords to be hashed and stored, it can be done using a single comm
 - a. service password-encryption



ses configured on both the

onfigurations on the of the router. After setting configurations by

on the router which can be rtual terminals - 0,1,2.

command

nmand

can be set by the

if you want the and which is as follows



