build a demodulator using an ideal sampler Biven a modulated signal m(t) cos (antet)

For received signal m(t) eos (artfct) +n(t) for n(t) wss with mean zero and Sn(t)= 3mm/Hz, find the SNR at your demodulator output.