MFJ-1258 CAPACITANCE METER

and SOFTWARE

Thank you for purchasing the MFJ-1258 Capacitance Meter for the Commodore VIC-20 $^{\rm tm}$.

DIRECTIONS

- Make sure that the VIC is turned off. (Never plug or unplug the board into the back of the computer without it being turned off first.)
- 2. Insert the Capacitance Meter Board into the USERS PORT of the VIC.
- 3. Turn on the computer, Load and Run the 1258 Software.
- 4. The screen will display;

INSERT CAPACITOR AND HIT THE f1 KEY

MFJ CAPACITOR METER COPYRIGHT APRIL 1984 MFJ ENTERPRISES, INC.

- Place the capacitor leads between the positive and negative lugs and hit f1.
- 6. The capacitance will be displayed at the top of the screen.

TO CALIBRATE If calibration becomes necessary, use the 470uf capacitor supplied to set the microfarad range. The 470uf capacitor is marked with the actual value, so please check this value before calibrating. The microfarad range trimpot is next to the negative lug on the left side of the board. The $2.2nf(\pm 5\%)$ capacitor is used to set the nanofarad range. The nanofarad trimpot is next to the positive lug on the right side of the board. It is not necessary to adjust the picofarad range.

VIC-20 is a trademark of Commodore Business Machines, Inc.

FULL 12 MONTHS WARRANTY ., Inc. warrants to the original owner of this product, if manufactured by ses, Inc. and purchased from an authorized dealer or directly from MFJ, inc. to be free of defects in material and workmarship for a period of 1 s, Inc. to be free of defects in material and workmarship for a period of 1 road test of purchase provided the following terms of this warranty are satisfied to warranty claim and must submit the more of the warranty of warranty claim and must submit the fine of the state of warranty of warranty claim and must submit the fine of the testable of warranty of warranty claim and must submit the fine of the testable of warranty medical purchase. Any evidence of alterating, or forgery of y shall be cause to void any and all warranty terms immediately. 2. MFJ Enterprises, inc. agrees to repair or replace at MFJ's por' the original owner any defective product provided the prodigned over any defective product provided the prodigned over any or defective product provided the prodigned over any open request. A dated proof-of-check, cashler's check or money order must it handling. 4. This warranty is NOT void for owners who call consultation is available by calling (60°). 5. This warranty does not apply to kits so'. 6. Wired and tested PC board is re the owner's cabinet or connecter prises, inc. will be returned at the owner's cabinet or connecter prises, inc. will be returned at the owner's cabinet or connecter prises, inc. will be returned at the owner's cabinet or connecter prises, inc. will be returned at the owner's cabinet or connecter prises, inc. will be returned at the product provided the un' owner. 9. This warranty is 10. MFJ Enterprise or manufacthe product warranty is 10. MFJ Enterprise or manufacthe product warranty is 10. MFJ Enterprise or manufacthe product warranty is 10. MFJ Enterprise or manufacthe products warranty is 10. MFJ Enterprise or manufacthe product warranty is 10. MFJ Enterprise or manufacthe products warranty is 10. MFJ Enterprise or manufacthe pr