Keyboard Interface
Power is provided from Display Board via Power jumper

+5V
GND
J3
Power
C1
10nF
C2
1µF
CLR
R5
680Ω
D6
R1
22KΩ
R2
22KΩ
R3
22KΩ
R4
22KΩ
COL1
COL2
COL3
COL4
U1
74LS42
A0
A1
A2
A3
KEYSTB
ROW1
ROW2
ROW3
ROW4
ROW5
ROW6
ROW7
ROW8
U2
74LS42
DWSTB
WR4
WR3
WR2
WR1
U3
CD4503BE
VDD
VSS
D1
D2
D3
D4
D5
D6
DIS_A
DIS_B
Q1
Q2
Q3
Q4
Q5
Q6
R6
22KΩ
J5
Keyboard
J2
Keyboard–Display
VBATT+
VIN
Not Used
Not Used

KEYSTB = keyboard strobe
DWSTB = display strobe

Display Board
Power jumper supplies power to the Keyboard Interface board
DISP1 is the leftmost display module
DISP4 is the rightmost display module
Cartridge connector is "Teledyne Kinetics S 426U016"

J4
Cartridge
VOUT
J6
Power
DISP1
DISP2
DISP3
DISP4
DL1414_Alphanumeric_Display
VDD
WR
A0
A1
D0
D1
D2
D3
D4
D5
D6
GND

Power Input (on Display Board)
VOUT and +5V must be bridged in the cartridge to enable the LK–3000 to power on.
Battery is four AA NiCd cells connected in series.
VIN is the input power from the PSU.
VOUT is the regulated +5V used by the system.
VBATT is the battery power source (charging/discharging).

J1
Power In
SW33
Power
R7
56Ω ½W
U4
7805
VO
VI
GND
C3
22µF 10V
C5
10pF
C4
2.2µF 35V

Keyboard Matrix

SW1 A
SW2 B
SW3 C
SW4 D
SW5 J
SW6 K
SW7 L
SW8 M
SW9 S
SW10 T
SW11 U
SW12 V
SW13 E
SW14 F
SW15 G
SW16 H
SW17 N
SW18 O
SW19 P
SW20 Q
SW21 W
SW22 X
SW23 Y
SW24 Z
SW25 [?]
SW26 [bs]
SW27 R
SW28 I
SW29 [def]
SW30 [stp]
SW31 [sp]
SW32 [f]

www.youtube.com/@Brffff
Brett Hallen

Sheet: /
File: LK3000_Schematics.kicad_sch

Title: Nixdorf LK–3000 Personal Computer

Size: A3	Date: 23/SEP/2025	**Rev: A**
KiCad E.D.A. 9.0.4		Id: 1/1