## Lista componentes

Reference	Value	Qt	y	DNP	#	
C1	100pF		1		1	
C2	100uF		1		2	•
D1	1n5365A		1		3	ò
Driver1	BD135		1		4	-
Input1	J3		1		5	,
Measurer1	J1		1	-	6	į
Output1	J2		1	-	7	,
Q2	TIP41		1	-	8	,
R1	3.75K		1	-	9	)
R2		80	1	-	10	)
R3	1K		1	-	11	
R4	15K		1	-	12	
R5	2K		1	-	13	,
R6	2.3K		1	-	14	٠
RV1	10K		1	-	15	,
Shunt?		0.33	1	-	16	į
U1	LM723 DIP14		1	_	17	,