## 12.General Diagnostic Table

## A: INSPECTION

Symptoms		Main probable cause	Other probable cause
Poor brake per- formance	Long braking/ stopping dis- tance	<ul> <li>Brake pad</li> <li>Aeration to brake line</li> <li>Tire specifications, tire wear and air pressures</li> <li>Incorrect wiring or piping connections</li> </ul>	<ul> <li>Master cylinder</li> <li>Brake caliper</li> <li>Disc rotor</li> <li>Brake pipe</li> <li>Brake booster</li> </ul>
	Long brake pedal stroke	Aeration to brake line     Brake pedal play	<ul> <li>Master cylinder</li> <li>Brake caliper</li> <li>Brake pad</li> <li>Brake pipe</li> <li>Brake booster</li> </ul>
	Short brake pedal stroke	Brake vacuum pump     Brake vacuum sensor     Brake vacuum hose	<ul> <li>Master cylinder</li> <li>Brake caliper</li> <li>Brake pad</li> <li>Brake pipe</li> <li>Brake booster</li> </ul>

## **PARKING BRAKE**



		Page
1.	General Description	2
2.	Parking Brake Lever	4
	Parking Brake Cable	
	Parking Brake Assembly (Rear Disc Brake)	
	General Diagnostic Table	18