
4. Electrical Component Location

A: LOCATION



- (1) Brake vacuum pump
- (2) Brake booster pressure sensor
- (3) Brake vacuum pump relay
- (4) Engine control module (ECM)
- (5) Brake vacuum pump warning light

Electrical Component Location

BRAKE VACUUM CONTROL (BVC) (DIAGNOSTICS)

