

12. Clearance Light and Illumination Light System


A: WIRING DIAGRAM

1. ENGINE TYPE FA



AL: WITH AUTO LIGHT






OP: WITHOUT PUSH BUTTON START


WP: WITH PUSH BUTTON START


*1 : WITHOUT PUSH BUTTON START : B/W WITH PUSH BUTTON START : Y/R




ON: WITHOUT NAVIGATION

WN: WITH NAVIGATION






2. ENGINE TYPE EJ




AL: WITH AUTO LIGHT

OP: WITHOUT PUSH BUTTON START

WP : WITH PUSH BUTTON START






SH : WITH SEAT HEATER

OP: WITHOUT PUSH BUTTON START


WP : WITH PUSH BUTTON START

*1 : WITHOUT PUSH BUTTON START : B/W WITH PUSH BUTTON START : Y/R



ON: WITHOUT NAVIGATION

WN: WITH NAVIGATION



2f

LIST OF CONNECTORS

