
## 3. Electrical Component Location

## A: LOCATION



- (1) Inhibitor switch (CVT model)
- (2) Engine control module (ECM) (engine type FA)
- (3) Neutral position switch (MT model)
- (4) Cruise indicator light and cruise set indicator light
- (5) Cruise control command switch
- (6) Clutch switch (MT model)
- (7) Transmission control module (TCM) (CVT model)
- (8) Stop light and brake switch
- Engine control module (ECM) (engine type EJ)