
# **49.Security System**


## **A: WIRING DIAGRAM**


#### 1. WITHOUT PUSH BUTTON START




- \*1 : WITHOUT TPMS : R80
- : WITHOUT TPMS : KEYLESS ENTRY CM WITH TPMS : TPMS & KEYLESS ENTRY CM
- :WITHOUT TPMS : 4 WITH TPMS : 6

- \*4 :WITHOUT TPMS :7
  - WITH TPMS : 5
- \*5 : WITHOUT TPMS : 3 WITH TPMS : 11






\*1 : ENGINE TYPE FA : B/R ENGINE TYPE EJ : B/W




1e


### LIST OF CONNECTORS


1e




## 2. WITH PUSH BUTTON START







\*1 : ENGINE TYPE FA : B/R ENGINE TYPE EJ : B/W



2e



## LIST OF CONNECTORS

