

38. Push Button Start System

A: WIRING DIAGRAM


1. ENGINE TYPE FA







ND: WITHOUT ID CODE BOX


ID : WITH ID CODE BOX









*1 :TERMINAL No. OPTIONAL ARRANGEMENT




2. ENGINE TYPE EJ






ND: WITHOUT ID CODE BOX

ID: WITH ID CODE BOX





*1 :TERMINAL No. OPTIONAL ARRANGEMENT

2e

2e

LIST OF CONNECTORS

