## 72.Door Cord RH

## A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
AB63	2	*	C-2	R124	Rear wiring harness RH
AB64	2	Υ	C-3		Front door impact sensor RH
D1	8	*	C-1	B30	Bulkhead wiring harness
D12	2	*	C-2		Front door speaker RH (standard model)
	2	*	C-2		Front door speaker RH (premium model)
D13	6	GR	C-2		Front power window motor RH
D15	10	*	C-2		Outer mirror assembly RH
D17	8	*	C-2		Front power window sub-switch
D18	10	*	B-3		Front door lock actuator RH
D28	8	*	B-3	R13	Rear wiring harness RH
D29	2	*	C-3		Rear door speaker RH (standard model)
	2	*	C-3		Rear door speaker RH (premium model)
D30	6	GR	B-4		Rear power window motor RH
D31	8	*	B-4		Rear power window switch RH
D32	10	*	A-4		Rear door lock actuator RH
D56	6	*	B-3		Outer handle RH
D83	28	*	C-2	i76	Instrument panel wiring harness
D125	5	*	C-2		Passenger's seat door lock switch
★: White or natural color					

