
## 32. Navigation System


## **A: WIRING DIAGRAM**

## 1. ENGINE TYPE FA



\*1 :TERMINAL No. OPTIONAL ARRANGEMENT






1c


MB-3
M/B FUSE NO. 5
(B)


≥



1d

1d







OR: WITHOUT SUNROOF

WR : WITH SUNROOF

\*1 : SHIELD CONNECTOR




## 2. ENGINE TYPE EJ




\*1 :TERMINAL No. OPTIONAL ARRANGEMENT






2c






2d

**2d** 





OR: WITHOUT SUNROOF

WR : WITH SUNROOF

\*1 : SHIELD CONNECTOR

