11.Registration Body Integrated Unit

A: OPERATION

1. CONFIRM CURRENT SETTING

- 1) On «Main Menu» display, select {Others}.
- 2) On «Others» display, select {Customized Setting}.
- 3) Save the setting.

Required items for new registration. (Except for system not equipped)

Item	Item to confirm			Note		
number of regist.	1	2	3	4	Number of registered ID	
Off delay time	OFF	10 Sec	20 Sec	30s	Setting for lighting off time	
Auto Light Sensitivity Adjustment	Dull	Normal (Standard)	Sensitive	Very sen- sitive	1st (slow) — 4th (fairly quick)	
Rear wiper auto setting	ON		OFF			
TPMS Setting	TPMS		No TPMS			
Driver's Door Unlock Setting	ALL		Select			
Rear Gate Unlock Setting	ALL		Select			
Rear defogger operation mode	Normal		Continuous			
Security Alarm Setup	ON		OFF			
Impact Sensor Setup	ON		OFF		Option setting	
Alarm delay setup		ON OFF				
Lockout prevention	ON		OFF			
Impact sensor	ON		OFF		Option setting	
Buzzer sounding setting	ON		OFF			
Abnormal warning lamp flashing setting	ON		OFF			
Passive Alarm	ON		OFF			
Door open warning	ON		OFF			
Dome Light Alarm Setting	ON		Ol	FF		
Auto A/C ECU Setting		ON OFF		FF		
Wiper Deicer setting	ON		OFF		Option setting	
Illumination Control On/Off	ON C		Ol	FF		
Sedan/Wagon Setting	Wagon Sedan					
MT/AT Setting	MT AT					
Seat Memory Setting	ON		OFF		N/A	
Illumination Sensor Setting		ON OFF		Option setting		
Factory initial setting	Fa	actory	Market		Do not change to factory mode.	
Welcome Light Off Delay Time(Exiting)	OFF/30s/60 s/90 s		Option setting			
Welcome Light Off Delay Time(Approaching)	OFF/30s/60 s/90 s			Option setting		
Key less buzzer volume	1234567					
					· · · · · · · · · · · · · · · · · · ·	

2. REGISTRATION BODY INTEGRATED UNIT (FUNCTION SETTING)

CAUTION

For the body integrated unit, function selection is available to control the entire vehicle systems. It is possible to control the original functions of vehicle when registrations of body integrated unit and function setting are corresponded to vehicle equipment.

If registrations and function setting are different from vehicle equipment, vehicle system does not operate normally and diagnosis cannot be performed correctly. Pay attention to following item.

- Be sure to correspond registrations, or User Customizing settings to vehicle equipment.
- Do not change the settings of vehicle improperly.
- Make sure that the key illumination does not blink with ignition switch ON, or that the body integrated unit registration item "Factory initial setting" is set to "Market". If "Factory initial setting" is set to "Factory", key illumination blinks when the ignition switch is turned ON, to notify that the settings are not confirmed. (If the vehicle is a model with keyless access, check by the current data display function of Subaru Select Monitor because no key illumination is available.)
- Key illumination does not blink with ignition switch turned to ON and go off with door closed. (Except for model with keyless access)
- Be sure to register immobilizer if body integrated unit is replaced with a new part. (Except for model with keyless access)
- Make a registration of immobilizer when the parts related to immobilizer have been replaced. Refer to the "REGISTRATION MANUAL FOR IMMOBILIZER".
- 1) On «Main Menu» display, select {Each System Check}.
- 2) On «System Selection Menu» display, select {Integ. unit mode}.
- 3) Click the [OK] button after the control module name (integrated unit) is displayed.
- 4) On «Integ. unit mode failure diag.» display, select {Work Support}.
- 5) On «Work Support» display, select {Unit customizing}.

NOTE:

For the vehicle requiring the destination setting, if the destination setting is not finished, display can not be shifted into customizing screen. <Ref. to BC(diag)-24, DESTINATION SETTING, OPERATION, Registration Body Integrated Unit.>

6) Change the setting to the contents saved at confirmation of current setting.

CAUTION:

- To perform normal operation of vehicle and diagnosis, the above settings must match the actual vehicle equipment.
- When the body integrated unit is new or in Factory mode, the key illumination blinks, and user customizing is incomplete. Check the user customizing settings. (For models with keyless access, the room light illuminates.)
- Be sure not to change Factory initial setting except when installing a new body integrated unit.

NOTE:

"Factory" mode:

- Body integrated unit has not been set yet. It can be recognized by key illumination blinking with ignition switch turned to ON. (Except for model with keyless access)
- All replacement body integrated units are set to "Factory" mode. When replacing a body integrated unit, be sure to perform the registration operation.

"Market" mode:

- Each settings have been set. It can be recognized by key ring illumination coming on in concocting with room light and going off with ignition switch turned to ON. (Except for model with keyless access)
- 7) Perform the Factory initial setting. On the «Unit customizing» display screen of Subaru Select Monitor, select the {Factory initial setting}.
- 8) Change the mode from Factory to Market.
- 9) Turn the ignition switch to OFF to settle the setting.
- 10) Change the system selection to «Immobilizer» on Subaru Select Monitor, and perform registration of immobilizer. (Except for model with keyless access)
- 11) Perform the registration according to the procedures of the "REGISTRATION MANUAL FOR IMMOBILIZER". (Except for model with keyless access)

Registration Body Integrated Unit

BODY CONTROL SYSTEM (DIAGNOSTICS)

- 12) For vehicles with remote engine starter, refer to "REGISTRATION MANUAL FOR IMMOBILIZER" and perform registration of the remote engine starter. (Except for model with keyless access)
- 13) Perform the User Customizing. <Ref. to BC(diag)-20, OPERATION, User Customizing.>

NOTF:

For detailed operation procedures, refer to "PC application help for Subaru Select Monitor".

3. DESTINATION SETTING

NOTE:

For the vehicle requiring the destination setting, if the destination setting is not finished, display can not be shifted into customizing screen.

	Step	Check	Yes	No
1	CONFIRM CURRENT SETTING. Always perform confirmation of current setting before replacing the module. Record the contents of the "Destination Setting". NOTE: Refer to the "Read Current Data" and "CONFIRMATION OF CURRENT SETTING" to confirm the current setting. <ref. bc(diag)-22,="" body="" confirm="" current="" integrated="" operation,="" registration="" setting,="" to="" unit.=""> <ref. bc(diag)-15,="" current="" data.="" operation,="" read="" to=""></ref.></ref.>	Is the current setting recorded?	Go to step 2.	Confirm the current setting. Go to step 1.
2	CONFIRM DESTINATION SETTING. 1) Connect the Subaru Select Monitor, and run the application. 2) On «Main Menu» display, select {Each System Check}. 3) On the «System Selection Menu» display, select {Integ. unit mode}. 4) On «Integ. unit mode» display, select {Work Support}. 5) On «Work Support» display, select {Unit customizing}. 6) The vehicle destination screen is displayed.	Is the vehicle destination set- ting screen displayed?	Go to step 3.	Go to step 4.
3	CONFIRM DESTINATION SETTING. Confirm the screen displayed on Subaru Select Monitor and the actual vehicle destination.	Is it necessary to change the destination setting?	Select [Yes]. Go to step 4.	Select [No]. Go to step 5 .
4	ENTER DESTINATION CODE. Enter the appropriate code in the screen. JPN: JP00 KA, KC: KA00 KS: KS00 U4, U5, U6, C6 and C0, C5 (with keyless access): U400 C0, C5 (without keyless access): C000 EK, ER: EK00 Other than above: EC00	Is the appropriate code entered?	Select [Yes]. Go to step 5 .	Enter the destination code. Go to step 5 .
5	REGISTER VEHICLE EQUIPMENTS. Customizing screen is displayed. NOTE: Match the each item setting of body integrated unit registration item list with the vehicle equipments.	Do all setting contents match with the vehicle equipment specification?	Go to step 6.	Change the items until each content setting match with the vehicle equipments specification. Go to step 6.

Registration Body Integrated Unit

BODY CONTROL SYSTEM (DIAGNOSTICS)

	Step	Check	Yes	No
6	CONFIRM MARKET MODE. 1) Customizing screen, select the {Factory initial setting} to change the setting from "Factory" mode to "Market" mode. 2) Turn the ignition switch to OFF. NOTE: When the setting is changed from "Factory" mode to "Market" mode, turning the ignition switch from ON → OFF confirms the setting. 3) Turn the ignition switch to ON, and check the contents of settings.		Go to step 7.	Perform the destination setting from the first step. Go to step 1.
7	CONFIRM MARKET MODE. Check the following. Make sure that the "Destination Setting" in the current data display is the same as the one you confirmed in step 1.	Is the display the same as indicated?	Registration of body integrated unit is finished.	It is possible that harness malfunc- tion may occur. Perform the diag- nosis.