13.List of Diagnostic Trouble Code (DTC)

A: LIST

DTC	Item	Contents of diagnosis	Remarks
C2021	Tire 1 Air Pressure Decrease	Tire pressure of tire 1 is reduced.	<ref. (dtc).="" 1="" air="" c2021="" code="" decrease,="" diagnostic="" dtc="" pressure="" procedure="" tire="" to="" tpm(diag)-23,="" trouble="" with=""></ref.>
C2022	Tire 2 Air Pressure Decrease	Tire pressure of tire 2 is reduced.	<ref. (dtc).="" 2="" air="" c2022="" code="" decrease,="" diagnostic="" dtc="" pressure="" procedure="" tire="" to="" tpm(diag)-23,="" trouble="" with=""></ref.>
C2023	Tire 3 Air Pressure Decrease	Tire pressure of tire 3 is reduced.	<ref. (dtc).="" 3="" air="" c2023="" code="" decrease,="" diagnostic="" dtc="" pressure="" procedure="" tire="" to="" tpm(diag)-23,="" trouble="" with=""></ref.>
C2024	Tire 4 Air Pressure Decrease	Tire pressure of tire 4 is reduced.	<ref. (dtc).="" 4="" air="" c2024="" code="" decrease,="" diagnostic="" dtc="" pressure="" procedure="" tire="" to="" tpm(diag)-24,="" trouble="" with=""></ref.>
C2121	Transmitter 1 No Data	Data cannot be received from transmitter 1.	<ref. (dtc).="" 1="" c2121="" code="" data,="" diagnostic="" dtc="" no="" procedure="" to="" tpm(diag)-24,="" trans-mitter="" trouble="" with=""></ref.>
C2122	Transmitter 2 No Data	Data cannot be received from transmitter 2.	<ref. (dtc).="" 2="" c2122="" code="" data,="" diagnostic="" dtc="" no="" procedure="" to="" tpm(diag)-24,="" trans-mitter="" trouble="" with=""></ref.>
C2123	Transmitter 3 No Data	Data cannot be received from transmitter 3.	<ref. (dtc).="" 3="" c2123="" code="" data,="" diagnostic="" dtc="" no="" procedure="" to="" tpm(diag)-24,="" trans-mitter="" trouble="" with=""></ref.>
C2124	Transmitter 4 No Data	Data cannot be received from transmitter 4.	<ref. (dtc).="" 4="" c2124="" code="" data,="" diagnostic="" dtc="" no="" procedure="" to="" tpm(diag)-25,="" trans-mitter="" trouble="" with=""></ref.>
C2221	Transmitter 1 Pressure Data Abnormal	Transmitter 1 data contents are abnormal.	<ref. (dtc).="" 1="" abnormal,="" c2221="" code="" data="" diagnostic="" dtc="" pressure="" procedure="" to="" tpm(diag)-26,="" trans-mitter="" trouble="" with=""></ref.>
C2222	Transmitter 2 Pressure Data Abnormal	Transmitter 2 data contents are abnormal.	<ref. (dtc).="" 2="" abnormal,="" c2222="" code="" data="" diagnostic="" dtc="" pressure="" procedure="" to="" tpm(diag)-26,="" trans-mitter="" trouble="" with=""></ref.>
C2223	Transmitter 3 Pressure Data Abnormal	Transmitter 3 data contents are abnormal.	<ref. (dtc).="" 3="" abnormal,="" c2223="" code="" data="" diagnostic="" dtc="" pressure="" procedure="" to="" tpm(diag)-26,="" trans-mitter="" trouble="" with=""></ref.>
C2224	Transmitter 4 Pressure Data Abnormal	Transmitter 4 data contents are abnormal.	<ref. (dtc).="" 4="" abnormal,="" c2224="" code="" data="" diagnostic="" dtc="" pressure="" procedure="" to="" tpm(diag)-27,="" trans-mitter="" trouble="" with=""></ref.>
C2321	Transmitter 1 Function Code Abnormal	Function code has error.	<ref. (dtc).="" 1="" abnormal,="" c2321="" code="" diagnostic="" dtc="" function="" procedure="" to="" tpm(diag)-28,="" trans-mitter="" trouble="" with=""></ref.>
C2322	Transmitter 2 Function Code Abnormal	Function code has error.	<ref. (dtc).="" 2="" abnormal,="" c2322="" code="" diagnostic="" dtc="" function="" procedure="" to="" tpm(diag)-28,="" trans-mitter="" trouble="" with=""></ref.>
C2323	Transmitter 3 Function Code Abnormal	Function code has error.	<ref. (dtc).="" 3="" abnormal,="" c2323="" code="" diagnostic="" dtc="" function="" procedure="" to="" tpm(diag)-28,="" trans-mitter="" trouble="" with=""></ref.>

List of Diagnostic Trouble Code (DTC)

TIRE PRESSURE MONITORING SYSTEM (DIAGNOSTICS)

DTC	Item	Contents of diagnosis	Remarks
C2324	Transmitter 4 Function Code Abnormal	Function code has error.	<ref. (dtc).="" 4="" abnormal,="" c2324="" code="" diagnostic="" dtc="" function="" procedure="" to="" tpm(diag)-29,="" trans-mitter="" trouble="" with=""></ref.>
C2421	Transmitter 1 Battery Voltage Decrease	Transmitter battery voltage is low.	<ref. (dtc).="" 1="" battery="" c2421="" code="" decrease,="" diagnostic="" dtc="" procedure="" to="" tpm(diag)-30,="" trans-mitter="" trouble="" voltage="" with=""></ref.>
C2422	Transmitter 2 Battery Voltage Decrease	Transmitter battery voltage is low.	<ref. (dtc).="" 2="" battery="" c2422="" code="" decrease,="" diagnostic="" dtc="" procedure="" to="" tpm(diag)-30,="" trans-mitter="" trouble="" voltage="" with=""></ref.>
C2423	Transmitter 3 Battery Voltage Decrease	Transmitter battery voltage is low.	<ref. (dtc).="" 3="" battery="" c2423="" code="" decrease,="" diagnostic="" dtc="" procedure="" to="" tpm(diag)-30,="" trans-mitter="" trouble="" voltage="" with=""></ref.>
C2424	Transmitter 4 Battery Voltage Decrease	Transmitter battery voltage is low.	<ref. (dtc).="" 4="" battery="" c2424="" code="" decrease,="" diagnostic="" dtc="" procedure="" to="" tpm(diag)-31,="" trans-mitter="" trouble="" voltage="" with=""></ref.>
C2521	Vehicle Speed Is Abnormal	Vehicle speed signal is not input to the control module when the vehicle speed is 6 km/h (3.7 MPH) or more.	<ref. c2521="" dtc="" to="" tpm(diag)-32,="" vehicle<br="">SPEED IS ABNORMAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).></ref.>