
4. Electrical Component Location

A: LOCATION



- (1) VDC CM
- (2) Electric power steering CM
- (3) ECM (engine type FA)
- (4) Keyless access CM
- (5) Auto headlight beam leveler CM
- (6) Combination meter
- (7) MFD
- (8) Body integrated unit
- (9) Data link connector
- (10) TCM

- (11) Steering angle sensor
- (12) A/C control panel
- (13) Airbag CM
- (14) Driver's control center differential (DCCD) CM
- (15) ECM (engine type EJ)