

9. Back-up Light System

A: WIRING DIAGRAM

1. ENGINE TYPE FA



WN: WITH NAVIGATION




*1 :TERMINAL No. OPTIONAL ARRANGEMENT


1c

LIST OF CONNECTORS






2. ENGINE TYPE EJ



WN : WITH NAVIGATION

2b



*1 :TERMINAL No. OPTIONAL ARRANGEMENT

2c

LIST OF CONNECTORS



| B97 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 | B128 (GR) 1 2 3 4 5 6 | 8 9 10 11 12 13 14 | 4 5 6 7 4 15 16 17 18 19 4 25 26 27 12 33 34 35 | | 4 5 6 7 8 9 10 11 12 1 24 25 26 27 28 29 30 31 32 3 | 3 14 15 16 17 18 19 20 33 34 35 36 37 38 39 40 |
|--|--|--------------------|---|----------------------------|--|---|
| i53 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 | C: 184 1 2 3 4 7 8 9 10 11 12 17 16 19 20 21 22 23 28 29 30 31 | 24 25 26 27 1 | C: \(\begin{array}{c c c c c c c c c c c c c c c c c c c | 11 12 13 14 25 26 27 28 | i229 1 2 3 4 5 6 7 8 9 10 11 12 | i232 i233 1 2 3 4 5 6 7 8 |
| | (B) 5 6 7 8 16 17 18 19 | 1 (GR) | | | | |