## **67.Instrument Panel Wiring Harness RH**

## A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
AD15	4	GR	B-2		Audio (without navigation)
					Navigation unit (with navigation)
AD16	4	GR	D-4		AUX input terminal (USB)
i7	4	GR	B-2		MFD switch
i9	2	*	C-2		Pocket light
i22	4	*	B-2		Hazard switch
i23	2	*	B-4		Glove box illumi. light
i24	2	*	C-2		Front accessory power supply socket
i29	1	*	B-2		Audio bracket ground
i50	10	*	B-2		Navigation unit
i53	24	*	C-4	R98	Rear wiring harness RH
i76	28	*	B-4	D83	Front door cord RH
i85	20	*	B-2		- Audio
i86	16	*	B-2		
i87	28	*	B-2		Navigation unit
i88	40	*	C-2		A/C control panel (auto A/C)
i89	3	*	A-3		Auto light sensor
i131	6	*	B-2		Navigation unit
i146	16	*	B-2		
i159	2	*	A-4		Side tweeter RH (without audio amplifier)
	4	*	A-4		Side tweeter RH (with audio amplifier)
i168	4	*	B-3		- J/C
i169	4	*	B-3		
i195	20	*	C-4	R382	Rear wiring harness RH
i237	12	*	B-3	B583	Bulkhead wiring harness
i238	20	*	B-3	B584	
★ White or natural color					

