
4. Electrical Component Location

A: LOCATION



- (1) DCCD control module
- (4) Mode change switch
- (6) Rear differential oil temperature warning light

- (2) DCCD relay
- (3) C.DIFF +/- switch
- (5) DCCD mode indicator
- (7) AWD light

