

Key matrix (right half, COL2ROW, 48 keys)

MCU: ATmega32U4-AU (TQFP-44), 16 MHz, 5 V

USB-C (USB 2.0 device)

Power

Split link: TRRS 3.5 mm (QMK soft serial)

OLED 0.91" 128x32 (I2C SSD1306)

Thumbwheel sensor AS5600 (I2C 0x36, magnet in the wheel)

Reset Press = DFU bootloader via HWB

Handedness: PD3 low = right

nrsk
Sheet: /
File: nrsk-right.kicad_sch
Title: nrsk split keyboard – right half
Size: A2
KiCad E.D.A. 10.0.6
Date:
Rev: 2.0
Id: 1/1

Key matrix (right half, COL2ROW, 48 keys)

MCU: ATmega32U4-AU (TQFP-44), 16 MHz, 5 V

USB-C (USB 2.0 device)

Power

Split link: TRRS 3.5 mm (QMK soft serial)



OLED 0.91" 128x32 (I2C SSD1306)

Thumbwheel sensor AS5600 (I2C 0x36, magnet in the wheel)

Reset button = DFU bootloader via HWB

Handedness: PD3 low = right

nrsk
Sheet: /
File: nrsk-right.kicad_sch
Title: nrsk split keyboard – right half
Size: A2
KiCad E.D.A. 10.0.6
Date:
Rev: 2.0
Id: 1/1

[illegible]

Key matrix (right half, COL2ROW, 48 keys)

MCU: ATmega32U4-AU (TQFP-44), 16 MHz, 5 V

USB-C (USB 2.0 device)

Power

Split link: TRRS 3.5 mm (QMK soft serial)


OLED 0.91" 128x32 (I2C SSD1306)

Thumbwheel sensor AS5600 (I2C 0x36, magnet in the wheel)

Reset Press = DFU bootloader via HWB

Handedness: PD3 low = right

nrsk
Sheet: /
File: nrsk-right.kicad_sch
Title: nrsk split keyboard – right half
Size: A2
KiCad E.D.A. 10.0.6
Date:
Rev: 2.0
Id: 1/1



Key matrix (right half, COL2ROW, 48 keys)

MCU: ATmega32U4-AU (TQFP-44), 16 MHz, 5 V

USB-C (USB 2.0 device)

Power

Split link: TRRS 3.5 mm (QMK soft serial)


OLED 0.91" 128x32 (I2C SSD1306)

Thumbwheel sensor AS5600 (I2C 0x36, magnet in the wheel)

Reset Press = DFU bootloader via HWB

Handedness: PD3 low = right

nrsk
Sheet: /
File: nrsk-right.kicad_sch
Title: nrsk split keyboard – right half
Size: A2
KiCad E.D.A. 10.0.6
Date:
Rev: 2.0
Id: 1/1

[illegible]