

AVR – HW6

임베디드스쿨1기 Lv1과정 2020. 10. 23 강경수

■ TIMER/COUNTER CODE REVIEW 2020.10.08 강경수 void overflow timer init(void) OCOA, OCOB핀에 파형을 출력하지 않겠다는 설정. TCCR0A=0; //카운터 초기화 TCCR0B=0; 만약 사용 할 거면 DDR레지스터 및 COM0A1, COMA0레지스터 설정해야 함. PORTB=0x00; DDRB=0xff; PORTB PULL-UP 분주비: 1024 → 16,000,000/1024 = 15,625Hz $TCCR0B = (1 << CS02) \mid (1 << CS00);$ TCNT0 = 131;TCNT0 → 타이머 발생시마다 쌓여 나가는 값. 초기값 설정 sbi(TIMSK0,TOIE0); sbi(SREG,7); TIMER/COUNTER 인터럽트 활성화. 전역 INTERRUPT 활성화.




TCCR0A - Timer/Counter Control Register A

Bit	7	6	5	4	3	2	1	0	
0x24 (0x44)	COM0A1	COM0A0	COM0B1	COM0B0	-	-	WGM01	WGM00	TCCR0A
Read/Write	R/W	R/W	R/W	R/W	R	R	R/W	R/W	'
Initial Value	0	0	0	0	0	0	0	0	

Table 14-2. Compare Output Mode, non-PWM Mode

COM0A1	COM0A0	Description
0	0	Normal port operation, OC0A disconnected.
0	1	Toggle OC0A on compare match
1	0	Clear OC0A on compare match
1	1	Set OC0A on compare match

TCCR0B - Timer/Counter Control Register B





CS02	CS01	CS00	Description
0	0	0	No clock source (Timer/Counter stopped)
0	0	1	clk _{I/O} /(no prescaling)
0	1	0	clk _{I/O} /8 (from prescaler)
0	1	1	clk _{I/O} /64 (from prescaler)
1	0	0	clk _{I/O} /256 (from prescaler)
1	0	1	clk _{I/O} /1024 (from prescaler)
1	1	0	External clock source on T0 pin. Clock on falling edge.
1	1	1	External clock source on T0 pin. Clock on rising edge.

TIMSK0 - Timer/Counter Interrupt Mask Register

Bit	7	6	5	4	3	2	1	0	
(0x6E)		-	-	-	-	OCIE0B	OCIE0A	TOIE0	TIMSK0
Read/Write	R	R	R	R	R	R/W	R/W	R/W	•
Initial Value	0	0	0	0	0	0	0	0	



```
void EXT_falling_timer_Init(void)
      cbi(SREG,7);
     TCCR0A=0;
      TCCR0B=0;
      PORTB=0x00;
      PORTD=0x10;
      DDRB=0xff;
      DDRD=0x00;
      TCCR0B = (1<<CS02) |(1<<CS01); T0pin의 변화를 감지 할 수 있다.
    ♠sbi(SREG,7);
   CS02
             CS01
                        CS00
                                Description
                                No clock source (Timer/Counter stopped)
     0
               0
                          0
                                clk<sub>I/O</sub>/(no prescaling)
     0
               0
                          1
                                clk<sub>I/O</sub>/8 (from prescaler)
     0
               1
                          0
                                clk<sub>I/O</sub>/64 (from prescaler)
     0
                          1
                                clk<sub>I/O</sub>/256 (from prescaler)
               0
                          0
               0
                                clk<sub>I/O</sub>/1024 (from prescaler)
                          0
                                External clock source on T0 pin. Clock on falling edge.
                                External clock source on T0 pin. Clock on rising edge.
```



2. TIMER COUNTER와 PWM 관계

- TIMER/COUNTER 와 PWM의 관계
- 0. TIMER/COUNTER와 PWM은 별도로 생각하는게 좋을듯. 단지 PWM신호를 만들어내기 위하여 TIMER/COUNTER DATA Register를 활용할 뿐이다.
- 1. TIMER/COUNTER를 이용하여 PWM신호를 만들어내는 방법
- (1) ISR루틴에서 GPIO를 제어하여 만들어 내는방법

```
ISR(TIMERO_COMPA_vect) ISR루틴에서 GPIO를 제어하여 만들어 낼 수 있다.

O 이러한 방법은 CPU의 리소스를 잡아먹는다.

}
```

(2) MCU STATUS REGISTER에서 직접 설정하여 PWM신호 만들어내는 방법

Table 14-2. Compare Output Mode, non-PWM Mode

COM0A1	COM0A0	Description	
0	0	Normal port operation, OC0A disconnected.	
0	1	Toggle OC0A on compare match	
1	0	Clear OC0A on compare match	
1	1	Set OC0A on compare match	

ATmega328p 의 OCOA, OCOB 핀은 별도의 GPIO제어 없이 (PORT제어 필요 없음, DDR 입출력만 SETTING) H/W에서 알아서 COMPARE MATCH가 발생함에 따라서 PWM 신호를 출력해 준다.



3. 모드별 DUTY 및 주기 계산


■ 8Bit TIMER/COUNTER PWM DUTY

- 1. Normal Mode
- TCNTn 값이 overflow 발생시 interrupt발생. 이 Normal Mode를 이용하여
- 항상 up(증가)하는 방향으로 TCNTn 레지스터 변화
- Normal Mode에서는 PWM OCnx H/W 출력도 지원 안한다.
- 별로 쓸일 없는 TIMER/COUNTER DATA SHEET에서도 추천안함.

The output compare unit can be used to generate interrupts at some given time. Using the output compare to generate waveforms in normal mode is not recommended, since this will occupy too much of the CPU time.

2. CTC모드






주기: (1/CLK)XOCRnX2

DUTY: 항상50%



3. 모드별 DUTY 및 주기 계산


3. FAST PWM MODE



주기 : (1/CLK) * 256 (변경불가)

DUTY: OCRn / TCNTn * 100(%)

4. Phase Correct PWM MODE



주기 및 DUTY 계산하는법 모르겠음..



4. Context Switching in AVR

■ AVR CORE에서 Context Switching

- Scheduling 개념이 포함되지 않기때문에 엄밀한 의미에서 Context Switching은 일어나지 않는다. Iss파일(assmbly) 을 까보게 되면

```
SIGNAL(TIMERØ OVF vect)
                                 r1,r0와 같은 레지스터를 push하는것위 확인
                                 가능하다. 즉 연산과 관련된 레지스터를
                     push
 98:
       1f 92
                            r1
                                 저장하는 것을 확인 할 수 있다.
                            re
       0f 92
                     push
 92:
 94:
       0f b6
                     in r0, 0x3f
                                   ; 63
     0f 92
 96:
                     push
                            r0
                                 제어 레지스터를 push하는게 아니라 연산과
 98:
     11 24
                     eor r1, r1
                                 관련된것만 한다. (여태가지 PORTB가 인터럽트
 9a:
       8f 93
                            r24
                     push
                                 수행 이후 원래 상태로 돌아오지 않아 헛갈렸음)
   if(counter==125)
       80 91 00 01
                   lds r24, 0x0100 ; 0x800100 <_edata>
 9c:
                   cpi r24, 0x7D ; 125
 a0:
     8d 37
 a2:
       29 f4
                     brne
                             .+10
                                       ; 0xae < vector 16+0x1e>
       PORTB= 0xff;
       8f ef
                     ldi r24, 0xFF ; 255
 a4:
 a6:
       85 b9
                     out 0x05, r24 ; 5
       counter = 0;
       10 92 00 01
                     sts 0x0100, r1 ; 0x800100 <_edata>
  a8:
                            .+12 ; 0xba <__vector_16+0x2a>
 ac:
       06 c0
                     rjmp
   else{
```

4. Context Switching in AVR

```
PORTB = 0 \times 00;
      15 b8
                     out 0x05, r1 ; 5
ae:
      counter++;
b0:
      80 91 00 01
                   lds r24, 0x0100 ; 0x800100 <_edata>
                      subi r24, 0xFF ; 255
b4:
      8f 5f
b6:
      80 93 00 01
                      sts 0x0100, r24; 0x800100 <_edata>
      8f 91
ba:
                      pop r24
      0f 90
                      pop r0
bc:
                      out 0x3f, r0
      Of be
                                      ; 63
be:
c0:
     0f 90
                      pop r0
                      pop r1
c2:
     1f 90
c4:
      18 95
                      reti
```



5. Task in AVR

```
typedef enum status{t_ready, t_busy, t_wait, t_quit} status;
typedef struct TaskControlBlock
                                     //tefines and controls a task for this s
    uint8_t task_id;
                                          AVR CORE로 구현한 스케쥴링 비스무리한 예시..
    enum status state;
    uint8 t priority;
                                          task control block 구조체를 만들고
    unsigned int stack pointer begin;
    unsigned int stack_pointer_end;
                                          함수포인터로 각각 실행할 함수를 할당하여
    void (*fnctpt)(void); .
} tcb;
                                          timer interrupt ISR 수행할때마다
tcb task[maxTask];
                                          각각의 함수(Task)를 조금씩 실행한다.
ISR(TIMER0_COMPA_vect)
    uint8_t q=0;
    cli();
    //getting the termination pointer of individual stacks
    task[currentTaskId].stack_pointer_end=StackPointer;
    for(q=0; q<maxTask; q++)</pre>
        if(task[q].state==t_ready)
           //setting up task parameters
           task[q].state=t_busy;
            currentTaskId=task[q].task_id;
                                             //sets task_id for saving co
           StackPointer=task[q].stack_pointer_begin;
            sei();
           task[q].fnctpt();
                                   //execute task if not priorly executed
        R=q;
```

