



Date Prepared: July 2024

EQUUS SOPREMA COLPHENE BSW

Below-ground single layer waterproofing

Specification No: 4131EB

Project & Address:	Fisher & Paykel —Home & Shed Buildings			
	830 Great South Road, Penrose, Auckland			
Certified Applicator:	Alliance Waterproofing			
Building Contractor:	Naylor Love			
Building Owner/Property M	anager:			
1. Statement of Intent				
step record of comp requirements of the Ma (b) A copy of this checklist Warranty will not be iss	completed by both the Equus Applicator and the Building Contractor, as a step by liance with both the Equus Specification provided for the contract, and the anufacturer for Warranty. It must be forwarded to the nearest Regional Office of Equus Industries Ltd. A sued by Equus Industries Ltd. without a copy of this Checklist being filed. It should form part of the Contract Documentation filed with the Property Manager			
2. Areas Treated				
The areas to which Membran	e is applied are detailed below, with reference to plans (where appropriate).			
Areas of below ground	tanking—detail reference 4131EB 4.2 / 4.3 / 4.4 and Aquafin 2-KM			
3. Sign Off We confirm that all applicable each stage has been made by	e processes listed in Section 4 have been correctly completed and that sign-off on y a person with the authority to do so.			
For:	(Signature)			
(Building Contractor) Date: / /	(Name)			
For:(Equus Applicator)	(Signature)			
Date: / /	(Name)			



4131EB 4.4—COLPHENE 3000 - Checklist And Method Statement

* Denotes those processes which must be signed off by the Building Contractor as well.

Concrete and other surfaces satisfactory for installation of COLPHENE 3000 by Equus Certified Applicator.(Note:Any sharpe corner please shamper edge). All vertical areas such as foundation walls shall be primed with Equus Peel and Stick Primer at a rate of 6 to 8 m2/L and allowed to dry for minimum 1 hour. Apply COLPHENE 3000 reinforcement strip to in all internal and external corners and connections between floor and wall areas. Apply COLPHENE 3000 self-adhesive membrane to walls by removing the siliconized film and pressing against the primed surface.				
shall be primed with Equus Peel and Stick Primer at a rate of 6 to 8 m2/L and allowed to dry for minimum 1 hour. Apply COLPHENE 3000 reinforcement strip to in all internal and external corners and connections between floor and wall areas. Apply COLPHENE 3000 self-adhesive membrane to walls by removing the siliconized film				
to in all internal and external corners and connections between floor and wall areas. Apply COLPHENE 3000 self-adhesive membrane to walls by removing the siliconized film				
brane to walls by removing the siliconized film				
and pressing against the primed surface.				
Heat weld all sheet joints by hot air welder if required and ensure all are well sealed. Including end joints. Ensure a minimum of 75mm overlap at all connections.				
(where required) Install vertical Equus Thermal Insulation against COLPHENE 3000 membrane, held in place by dots of DOUBLE-STICK tape.				
(where requierd) Aslan Flashing with reinforcement fleece a minimum 150mm all direction				
Inspection of all areas before Equus drainage layer installation.				
Areas that have been perforated or damaged to be repaired by self-adhering a piece of COLPHENE 3000 including a minimum 150mm overlap.				
Waterstops placed where required. Cold joins and stitch joins.				
Install Equus drainage layer against COL- PHENE 3000, and secure with Equus Termi- nation Bar and nominated sealant or Aq- uafin 2KM. (For Aquafin application refer to "Aquafin 2-K/M Checklist and Method State- ment")				
Final Inspection required prior to back filling.				
	brane to walls by removing the siliconized film and pressing against the primed surface. Heat weld all sheet joints by hot air welder if required and ensure all are well sealed. Including end joints. Ensure a minimum of 75mm overlap at all connections. (where required) Install vertical Equus Thermal Insulation against COLPHENE 3000 membrane, held in place by dots of DOUBLE-STICK tape. (where requierd) Aslan Flashing with reinforcement fleece a minimum 150mm all direction Inspection of all areas before Equus drainage layer installation. Areas that have been perforated or damaged to be repaired by self-adhering a piece of COLPHENE 3000 including a minimum 150mm overlap. Waterstops placed where required. Cold joins and stitch joins. Install Equus drainage layer against COL-PHENE 3000, and secure with Equus Termination Bar and nominated sealant or Aquafin 2KM. (For Aquafin application refer to "Aquafin 2-K/M Checklist and Method Statement")	brane to walls by removing the siliconized film and pressing against the primed surface. Heat weld all sheet joints by hot air welder if required and ensure all are well sealed. Including end joints. Ensure a minimum of 75mm overlap at all connections. (where required) Install vertical Equus Thermal Insulation against COLPHENE 3000 membrane, held in place by dots of DOUBLE-STICK tape. (where requierd) Aslan Flashing with reinforcement fleece a minimum 150mm all direction Inspection of all areas before Equus drainage layer installation. Areas that have been perforated or damaged to be repaired by self-adhering a piece of COLPHENE 3000 including a minimum 150mm overlap. Waterstops placed where required. Cold joins and stitch joins. Install Equus drainage layer against COL-PHENE 3000, and secure with Equus Termination Bar and nominated sealant or Aquafin 2KM. (For Aquafin application refer to "Aquafin 2-K/M Checklist and Method Statement")	brane to walls by removing the siliconized film and pressing against the primed surface. Heat weld all sheet joints by hot air welder if required and ensure all are well sealed. Including end joints. Ensure a minimum of 75mm overlap at all connections. (where required) Install vertical Equus Thermal Insulation against COLPHENE 3000 membrane, held in place by dots of DOUBLE-STICK tape. (where requierd) Aslan Flashing with reinforcement fleece a minimum 150mm all direction Inspection of all areas before Equus drainage layer installation. Areas that have been perforated or damaged to be repaired by self-adhering a piece of COLPHENE 3000 including a minimum 150mm overlap. Waterstops placed where required. Cold joins and stitch joins. Install Equus drainage layer against COL-PHENE 3000, and secure with Equus Termination Bar and nominated sealant or Aquafin 2-K/M Checklist and Method Statement ")	brane to walls by removing the siliconized film and pressing against the primed surface. Heat weld all sheet joints by hot air welder if required and ensure all are well sealed. Including end joints. Ensure a minimum of 75mm overlap at all connections. (where required) Install vertical Equus Thermal Insulation against COLPHENE 3000 membrane, held in place by dots of DOUBLE-STICK tape. (where requierd) Aslan Flashing with reinforcement fleece a minimum 150mm all direction Inspection of all areas before Equus drainage layer installation. Areas that have been perforated or damaged to be repaired by self-adhering a piece of COLPHENE 3000 including a minimum 150mm overlap. Waterstops placed where required. Cold joins and stitch joins. Install Equus drainage layer against COL-PHENE 3000, and secure with Equus Termination Bar and nominated sealant or Aquafin 2KM. (For Aquafin application refer to "Aquafin 2-K/M Checklist and Method Statement")