Conga Matrix - Onslow College

Project QA

SP3a Block H/M Link Foyer

Roof

Remove ACM and Demo

Assess Framing

New furrings @ 900cs

New roof 2 degrees

New Purlins @ 1200cs

HOLDPOINT Engineers sign off

Tray dec Installed

Vapour Barrier

80mm PIR installed

60-80mm Taped PIR

Drip edge flashing

Fibretite Membrane installed

Pressure Bar to drip edge

Fascia installed

Gutter and downpipes installed

Windows

AJ014

Remove windows

Re Frame Windows to new openings size

Chamfered sill

Window flashing tape

Fibretite continued into window opening

WANZ - Aliminmium Angle installed

Sill flashing

Windows installed

Head Flashing installed

Air seal

Reveals Installed

Archtraves installed

Painting completed

AJ015

Remove windows

Re Frame Windows to new openings size

Chamfered sill

Window flashing tape

Fibretite continued into window opening

WANZ - Aliminmium Angle installed

Sill flashing

Windows installed

Head Flashing installed

Air seal

Reveals Installed

Archtraves installed

Painting completed

AJ016

Remove windows

Re Frame Windows to new openings size

Chamfered sill

Window flashing tape

Fibretite continued into window opening

WANZ - Aliminmium Angle installed

Sill flashing

Windows installed

Head Flashing installed

Air seal

Reveals Installed

Archtraves installed

Painting completed

West wall

Install New 290x90 Beam

Reframe wall

Install Structural fixings

HOLDPOINT Engineers Sign off

Install RAB Board

Install Intello Wrap

0.9 BMT Aluminium Flashing

Cavity closer installed

Cavity Battens - 400cs

9mm Fibre Cement cladding

Fascias with air vent.

Painting cladding and fascias

SP3b Block I

Stage 1 Roof

Upper

Remove ACM

Clean Roof

Screw Exisiting roofing iron

Lay PIR Infills

Install vapour barrier

Install 80mm PIR

60-80mm Taped PIR installed

Drip edge flashing

Fibretite membrane installed

Fascias installed

Pressure bar to drip edge

Gutter and downpipes installed

Lower

Remove ACM

Clean Roof

Screw Exisiting roofing iron

Lay PIR Infills

Install vapour barrier

Install 80mm PIR

60-80mm Taped PIR installed
Drip edge flashing
Fibretite membrane installed
Fascias installed
Pressure bar to drip edge
Gutter and downpipes installed

Stage 2 Roof

Upper

Remove ACM Clean Roof Screw Exisiting roofing iron Install parapet framing Install plywood to parapet Lay PIR Infills Install vapour barrier Install 80mm PIR 60-80mm Taped PIR installed Drip edge flashing Fibretite membrane installed Install Membrane over parapet Parapet flashing installed Fascias installed Pressure bar to drip edge Gutter and downpipes installed

Lower

Remove ACM Clean Roof Screw Exisiting roofing iron Install parapet framing Install plywood to parapet Lay PIR Infills Install vapour barrier Install 80mm PIR 60-80mm Taped PIR installed Drip edge flashing Fibretite membrane installed Install Membrane over parapet Lay new Torch on up parapet Parapet flashing installed Fascias installed Pressure bar to drip edge Gutter and downpipes installed