Xilinx Standalone Library Documentation

XiIFFS Library v4.2

UG1032 (2019.2) October 30, 2019





Table of Contents

Chapter 1: Overview	
Library Files	3
Selecting a File System with an SD Interface	1
Selecting a RAM based file system	1
Chapter 2: Library Parameters in MSS File	
Appendix A: Additional Resources and Legal Notices	



Chapter 1

Overview

The Xilinx fat file system (FFS) library consists of a file system and a glue layer.

This FAT file system can be used with an interface supported in the glue layer.

The file system code is open source and is used as it is. Currently, the Glue layer implementation supports the SD/eMMC interface and a RAM based file system.

Application should make use of APIs provided in ff.h. These file system APIs access the driver functions through the glue layer.

The file system supports FAT16, FAT32, and exFAT (optional). The APIs are standard file system APIs. For more information, see the http://elm-chan.org/fsw/ff/00index_e.html.

Note

The XiIFFS library uses Revision R0.13b of the generic FAT filesystem module.

Library Files

The table below lists the file system files.

File	Description
ff.c	Implements all the file system APIs
ff.h	File system header
ffconf.h	File system configuration header – File system configurations such as READ_ONLY, MINIMAL, can be set here. This library uses FF_FS_MINIMIZE and FF_FS_TINY and Read/Write (NOT read only)



The table below lists the glue layer files.

File	Description
Glue layer – implements the function used system to call the driver APIs	
ff.h	File system header
diskio.h	Glue layer header

Selecting a File System with an SD Interface

To select a file system with an SD interface:

- 1. Launch Xilinx SDK. Xilinx SDK prompts you to create a workspace.
- 2. Select File > New > Xilinx Board Support Package. The New Board Support Package wizard appears.
- 3. Specify a project name.
- 4. Select **Standalone** from the **Board Support Package OS** drop-down list. The **Board Support Package Settings** wizard appears.
- 5. Select the **xilffs** library from the list of **Supported Libraries**.
- 6. Expand the **Overview** tree and select **xilffs**. The configuration options for xilffs are listed.
- 7. Configure the xilffs by setting the fs_interface = 1 to select the SD/eMMC. This is the default value. Ensure that the SD/eMMC interface is available, prior to selecting the fs_interface = 1 option.
- 8. Build the bsp and the application to use the file system with SD/eMMC. SD or eMMC will be recognized by the low level driver.

Selecting a RAM based file system

To select a RAM based file system:

- 1. Launch Xilinx SDK. Xilinx SDK prompts you to create a workspace.
- 2. Select File > New > Xilinx Board Support Package. The b>New Board Support Package appears.
- 3. Specify a project name.
- 4. Standalone from the Board Support Package OS drop-down list. The Board Support Package Settings wizard appears.
- 5. Select the **xilffs** library from the list of **Supported Libraries**.
- 6. Expand the **Overview** tree and select xilffs. The configuration options for xilffs are listed.
- 7. Configure the xilffs by setting the fs_interface = 2 to select RAM.



- 8. As this project is used by LWIP based application, select lwip library and configure according to your requirements. For more information, see the LwIP Library documentation.
- 9. Use any lwip application that requires a RAM based file system TCP/UDP performance test apps or tftp or webserver examples.
- 10. Build the bsp and the application to use the RAM based file system.



Chapter 2

Library Parameters in MSS File

XiIFFS Library can be integrated with a system using the following code snippet in the Microprocessor Software Specification (MSS) file:

```
BEGIN LIBRARY

PARAMETER LIBRARY_NAME = xilffs

PARAMETER LIBRARY_VER = 4.2

PARAMETER fs_interface = 1

PARAMETER read_only = false

PARAMETER use_lfn = 0

PARAMETER enable_multi_partition = false

PARAMETER num_logical_vol = 2

PARAMETER use_mkfs = true

PARAMETER use_strfunc = 0

PARAMETER set_fs_rpath = 0

PARAMETER enable_exfat = false

PARAMETER word_access = true

PARAMETER use_chmod = false

END
```

The table below describes the libgen customization parameters.

Parameter	Default Value	Description
LIBRARY_NAME	xilffs	Specifies the library name.
LIBRARY_VER	4.2	Specifies the library version.
fs_interface	1 for SD/eMMC 2 for RAM	File system interface. SD/eMMC and RAM based file system are supported.
read_only	False	Enables the file system in Read Only mode, if true. Default is false. For Zynq® UltraScale+™ MPSoC devices, sets this option as true.



Parameter	Default Value	Description
use_lfn	0	Enables the Long File Name(LFN) support if non-zero. 0: Disabled (Default) 1: LFN with static working buffer 2 (on stack) or 3 (on heap): Dynamic working buffer
enable_multi_partitio	False	Enables the multi partition support, if true.
num_logical_vol	2	Number of volumes (logical drives, from 1 to 10) to be used.
use_mkfs	True	Enables the mkfs support, if true. For Zynq UltraScale+ MPSoC devices, set this option as false.
use_strfunc	0	Enables the string functions (valid values 0 to 2). Default is 0.
set_fs_rpath	0	Configures relative path feature (valid values 0 to 2). Default is 0.
ramfs_size	3145728	Ram FS size is applicable only when RAM based file system is selected.
ramfs_start_addr	0x10000000	RAM FS start address is applicable only when RAM based file system is selected.
enable_exfat	false	Enables support for exFAT file system. 0: Disable exFAT 1: Enable exFAT(Also Enables LFN)
word_access	True	Enables word access for misaligned memory access platform.
use_chmod	false	Enables use of CHMOD functionality for changing attributes (valid only with read_only set to false).



Appendix A

Additional Resources and Legal Notices

Xilinx Resources

For support resources such as Answers, Documentation, Downloads, and Forums, see Xilinx Support.

Solution Centers

See the Xilinx Solution Centers for support on devices, software tools, and intellectual property at all stages of the design cycle. Topics include design assistance, advisories, and troubleshooting tips.

Please Read: Important Legal Notices

The information disclosed to you hereunder (the "Materials") is provided solely for the selection and use of Xilinx products. To the maximum extent permitted by applicable law: (1) Materials are made available "AS IS" and with all faults, Xilinx hereby DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE; and (2) Xilinx shall not be liable (whether in contract or tort, including negligence, or under any other theory of liability) for any loss or damage of any kind or nature related to, arising under, or in connection with, the Materials (including your use of the Materials), including for any direct, indirect, special, incidental, or consequential loss or damage (including loss of data, profits, goodwill, or any type of loss or damage suffered as a result of any action brought by a third party) even if such damage or loss was reasonably foreseeable or Xilinx had been advised of the possibility of the same. Xilinx assumes no obligation to correct any errors contained in the Materials or to notify you of updates to the Materials or to product specifications. You may not reproduce, modify, distribute, or publicly display the Materials without prior written consent. Certain products are subject to the terms and conditions of Xilinx's limited warranty, please refer to Xilinx's Terms of Sale which can be viewed at http://www.xilinx.com/legal.htm#tos; IP cores may be subject to warranty and support terms contained in a license issued to you by Xilinx. Xilinx products are not designed or intended to be fail-safe or for use in any application requiring fail-safe performance; you assume sole risk and liability for use of Xilinx products in such critical applications, please refer to Xilinx's Terms of Sale which can be viewed at http://www.xilinx.com/legal.htm#tos.



Automotive Applications Disclaimer

AUTOMOTIVE PRODUCTS (IDENTIFIED AS "XA" IN THE PART NUMBER) ARE NOT WARRANTED FOR USE IN THE DEPLOYMENT OF AIRBAGS OR FOR USE IN APPLICATIONS THAT AFFECT CONTROL OF A VEHICLE ("SAFETY APPLICATION") UNLESS THERE IS A SAFETY CONCEPT OR REDUNDANCY FEATURE CONSISTENT WITH THE ISO 26262 AUTOMOTIVE SAFETY STANDARD ("SAFETY DESIGN"). CUSTOMER SHALL, PRIOR TO USING OR DISTRIBUTING ANY SYSTEMS THAT INCORPORATE PRODUCTS, THOROUGHLY TEST SUCH SYSTEMS FOR SAFETY PURPOSES. USE OF PRODUCTS IN A SAFETY APPLICATION WITHOUT A SAFETY DESIGN IS FULLY AT THE RISK OF CUSTOMER, SUBJECT ONLY TO APPLICABLE LAWS AND REGULATIONS GOVERNING LIMITATIONS ON PRODUCT LIABILITY.

© Copyright 2019 Xilinx, Inc. Xilinx, Inc. Xilinx, the Xilinx logo, Alveo, Artix, ISE, Kintex, Spartan, Versal, Virtex, Vivado, Zynq, and other designated brands included herein are trademarks of Xilinx in the United States and other countries. OpenCL and the OpenCL logo are trademarks of Apple Inc. used by permission by Khronos. HDMI, HDMI logo, and High-Definition Multimedia Interface are trademarks of HDMI Licensing LLC. AMBA, AMBA Designer, Arm, ARM1176JZ-S, CoreSight, Cortex, PrimeCell, Mali, and MPCore are trademarks of Arm Limited in the EU and other countries. All other trademarks are the property of their respective owners.