

BONZTEL Z990 Pro WiFi - User Manual

Installation, UEFI setup, storage, memory, networking, and troubleshooting.

1. Platform overview

The Z990 Pro WiFi is a BZ-LGA1851 enthusiast motherboard for Core Ultra Bonzi, BONZERON, and BONZIUM processors. Disconnect AC power before installing or removing components.

Item	Specification
Socket	BZ-LGA1851
Chipset	BONZTEL Z990
Memory	4 DDR5 DIMM slots; up to 192 GB consumer memory
Expansion	PCIe 5.0 x16 primary slot; additional PCIe slots
Storage	M.2 NVMe Gen4/Gen5 and SATA
Networking	10GbE + Wi-Fi 7
Power	24-pin ATX + dual CPU EPS

2. Recommended installation order

Install the CPU, memory, M.2 storage, cooler, and motherboard before the graphics card. Verify ATX standoffs before mounting.

Step	Action
1	Align and install the BZ-LGA1851 processor.
2	Install DDR5 in A2/B2 for two-DIMM configurations.
3	Install M.2 drives and thermal covers.
4	Mount the cooler; connect CPU_FAN or AIO_PUMP.
5	Connect 24-pin and CPU EPS power.
6	Install GPU, front-panel, USB, storage, and fan headers.

3. UEFI / BonzBIOS

BonzBIOS includes memory profiles, fan curves, boot priority, PCIe options, virtualization, Resizable BAR, security, and BonzFlash firmware updates.

4. Troubleshooting

For no POST, verify CPU power, memory seating, diagnostic LEDs, GPU power, and BIOS version. Clear CMOS before hardware changes. High-speed DDR5 memory training can require several boot cycles.