



SGPIO-I2S Audio Demo: Interconnections and jumper settings for Hitex Rev A4



SGPIO-I2S Audio Demo: Interconnections and boot mode settings for Hitex Rev A4







SGPIO-I2S Audio Demo: Interconnections and jumper settings for Hitex Rev A2

