

## PWM Driver Sample Code Reference Guide V1.00.001

Publication Release Date: Sep. 2011



The information in this document is subject to change without notice.

The Nuvoton Technology Corp. shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material.

This documentation may not, in whole or in part, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine readable form without prior consent, in writing, from the Nuvoton Technology Corp.

Nuvoton Technology Corp. All rights reserved



#### **Table of Contents**

1	Introduction	4
	1.1 Feature	
	Block Diagram	
	Calling Sequence	
	Code Section –Smpl_DrvPWM.c	
	Execution Environment Setup and Result	
	Revision History	



#### 1 Introduction


This sample code will demo PWM IP on ISD9160 chip.

#### 1.1 Feature


- This sample test PWM Timer and capture function.
- Case 0: PWM Timer waveform test. Waveform output to Buzzer. Case 1: PWM Capture test, use PWM Capture 0 to capture the waveform from PA.12.



#### 2 Block Diagram









#### 4 Code Section - Smpl\_DrvPWM.c

```
/* Copyright(c) 2011 Nuvoton Technology Corp. All rights reserved.
                                                  */
#include <stdio.h>
#include "Driver\DrvGPIO.h"
#include "Driver\DrvPWM.h"
#include "Driver\DrvSYS.h"
#include "Driver\DrvUART.h"
/*_____*/
/* Global variables
/*_____*/
int32_t g_bCapInt = 0;
uint8 t volatile g u8PWMCount = 1;
uint16 t g u16Frequency;
static uint32_t s_u32Pulse = 0;
/*-----*/
/* PWM Timer Callback function
/*_____*/
void DRVPWM_PwmIRQHandler()
  if (s_u32Pulse == 1 * g_u16Frequency /10)
     /*_____
     /* Stop PWM Timer 0 (Recommended procedure method 2)
     /* Set PWM Timer counter as 0, When interrupt request happen, disable PWM Time
     /*_____
     DrvPWM_SetTimerCounter(DRVPWM_TIMER0, 0);
   }
  if (s_u32Pulse == 1 * g_u16Frequency /10 + 1)
     g_u8PWMCount = 0;
  s_u32Pulse++;
```



```
/* Capture function to calculate the input waveform information
/* u32Count[4]: Keep the internal counter value when input signal rising / falling
                                                                                        */
                  happens
                                                                                        */
/*
                        C
/* time
            Α
                  В
                              D
                                                                                        */
                                                                                        */
                      /*
                                                                                       */
                                                                                        */
/* index
                 0.1 2.3
                                                                                       */
/* The capture internal counter down count from 0x10000, and reload to 0x10000 after
                                                                                        */
/* input signal falling happens (Time B/C/D)
                                                                                        */
void CalPeriodTime(uint8_t u8Capture)
    uint16_t u32Count[4];
    uint32_t u32i;
    uint16_t u16RisingTime, u16FallingTime, u16HighPeroid, u16LowPeroid, u16TotalPeroid;
    /* Clear the Capture Interrupt Flag (Time A) */
    DrvPWM_ClearCaptureIntStatus(u8Capture, DRVPWM_CAP_FALLING_FLAG);
    /* Wait for Interrupt Flag (Falling) */
    while (DrvPWM_GetCaptureIntStatus(u8Capture, DRVPWM_CAP_FALLING_FLAG) != 1);
    /* Clear the Capture Interrupt Flag (Time B)*/
    DrvPWM ClearCaptureIntStatus(u8Capture, DRVPWM CAP FALLING FLAG);
    u32i = 0;
    while (u32i < 4)
        /* Wait for Interrupt Flag (Falling) */
        while(DrvPWM_GetCaptureIntStatus(u8Capture, DRVPWM_CAP_FALLING_FLAG) != 1);
        /* Clear the Capture Interrupt Flag */
        DrvPWM_ClearCaptureIntStatus(u8Capture, DRVPWM_CAP_FALLING_FLAG);
        /* Clear the Capture Rising Interrupt Flag */
        DrvPWM ClearCaptureIntStatus(u8Capture, DRVPWM CAP RISING FLAG);
        /* Get the Falling Counter Data */
        u32Count[u32i++] = DrvPWM GetFallingCounter(u8Capture);
```



```
/* Wait for Capture Rising Interrupt Flag */
       while(DrvPWM_GetCaptureIntStatus(u8Capture, DRVPWM_CAP_RISING_FLAG) != 1);
       /* Clear the Capture Rising Interrupt Flag */
       DrvPWM_ClearCaptureIntStatus(u8Capture, DRVPWM_CAP_RISING_FLAG);
       /* Get the Rising Counter Data */
       u32Count[u32i++] = DrvPWM_GetRisingCounter(u8Capture);
    }
   u16RisingTime = u32Count[1];
   u16FallingTime = u32Count[0];
   u16HighPeroid = u32Count[1] - u32Count[2];
   u16LowPeroid = 0x10000 - u32Count[1];
   u16TotalPeroid = 0x10000 - u32Count[2];
   printf("Test Result:\nRising Time = %d, Falling Time = %d,\nHigh Period = %d, Low Period = %d,
   Total Period = %d.\n\n", u16RisingTime, u16FallingTime, u16HighPeroid, u16LowPeroid,
   u16TotalPeroid);
}
void SysTimerDelay(uint32_t us)
   SysTick->LOAD = us * 48; /* Assume the internal 48M RC used */
   SysTick->VAL = (0x00);
   SysTick->CTRL = (1 << SYSTICK_CLKSOURCE) | (1 << SYSTICK_ENABLE);
   /* Waiting for down-count to zero */
   while((SysTick->CTRL & (1 << 16)) == 0);
}
/*-----*/
/* PWM Capture Callback function
/*____*/
void DRVPWM_CapIRQHandler()
   g_bCapInt = 1;
}
```



```
/* Main Function
/*_____*/
int32_t main (void)
    S_DRVPWM_TIME_DATA_T sPt;
    STR_UART_T sParam;
    uint8_t u8Item;
    uint8_t u8Timer, u8CapTimer;
    int32_t i32Loop = 1;
   int32_t i32TestLoop = 1;
    UNLOCKREG();
    SYSCLK->PWRCON.XTL32K_EN = 1;
    SYSCLK->PWRCON.OSC49M_EN = 1;
    SYSCLK->PWRCON.OSC10K_EN = 1;
    /* Waiting for Xtal stalble */
    SysTimerDelay(5000);
   /* Set UART Pin */
    DrvGPIO_InitFunction(FUNC_UART0);
    /* UART Setting */
   sParam.u32BaudRate = 115200;
sParam.u8cDataBits = DRVUA
sParam.u8cStopBits = DRVUA
                            = DRVUART_DATABITS_8;
                            = DRVUART_STOPBITS_1;
   sParam.u8cStopBits = DRVUART_STOPBITS_:
sParam.u8cParity = DRVUART_PARITY_NONE;
    sParam.u8cRxTriggerLevel= DRVUART_FIFO_1BYTES;
   /* Set UART Configuration */
    DrvUART_Open(UART_PORT0,&sParam);
    /* Enable PWM clock */
    DrvPWM_Open();
   /* Set PWM pins */
    DrvGPIO_InitFunction(FUNC_PWM01);
    UNLOCKREG();
    DrvSYS_SetHCLKSource(0);
    LOCKREG();
```



```
printf("+-----+\n");
printf("|
                     PWM Driver Sample Code
                                                            |n";
printf("|
                                                            |n''\rangle;
printf("+------+\n");
printf(" This sample code will use PWM0 to drive Buzzer or capture the signal\n from PA.12.\n");
    while (i32Loop)
         printf("\n Please Select Test Item\n");
                   0 : PWM Timer Waveform Test\n");
        printf("
        printf("
                   1 : PWM Caputre Test\n");
        printf("
                   2 : Exit(n(n'));
        u8Item = getchar();
         switch (u8Item)
             case '0':
                 uint8_t u8ItemOK;
                 printf("\nPWM Timer Waveform Test. Waveform output(PWM0) to Buzzer\n");
                 i32TestLoop = 1;
                 printf("Select Test Item\n");
                 printf(" 1: Do (256Hz)\n");
                 printf(" 2: Re (287Hz)\n");
                 printf(" 3: Mi (322Hz)\n");
                 printf(" 4: Fa (341Hz)\n");
                 printf(" 5: Sol(383Hz) \n");
                 printf(" 6: La (430Hz)\n");
                 printf(" 7: Si (483Hz)\n");
                 printf(" 0: Exit\n");
                 while (i32TestLoop)
                      u8ItemOK = 1;
                      u8Item = getchar();
                      switch (u8Item)
                          case '1':
                              g_u16Frequency = 256;
                              break;
```



```
case '2':
         g_u16Frequency = 287;
         break;
    case '3':
         g_u16Frequency = 322;
         break;
    case '4':
         g_u16Frequency = 341;
         break;
    case '5':
         g_u16Frequency = 383;
         break;
    case '6':
         g_u16Frequency = 430;
        break;
    case '7':
         g_u16Frequency = 483;
         break;
    case '0':
        i32TestLoop = 0;
         break;
    default:
         u8ItemOK = 0;
         break;
}
if (i32TestLoop && u8ItemOK)
    s_u32Pulse = 0;
    g_u8PWMCount = 1;
    /* PWM Timer property */
    sPt.u8Mode = DRVPWM_TOGGLE_MODE;
    sPt.u32Frequency = g_u16Frequency;
    /* High Pulse peroid : Total Pulse peroid = 50 :100 */
    sPt.u8HighPulseRatio = 50;
    sPt.i32Inverter = 0;
    u8Timer = DRVPWM_TIMER0;
    /* Select PWM engine clock */
    DrvPWM_SelectClockSource(DRVPWM_HCLK);
    /* Set PWM Timer0 Configuration */
    DrvPWM_SetTimerClk(u8Timer, &sPt);
```



```
/* Enable Output for PWM Timer0 */
                   DrvPWM SetTimerIO(u8Timer, 1);
               /* Enable Interrupt Sources of PWM Timer0 and install call back function */
                   DrvPWM_EnableInt(u8Timer, 0, DRVPWM_PwmIRQHandler);
                   /* Enable the PWM Timer 0 */
                   DrvPWM_Enable(u8Timer, 1);
                   while (g_u8PWMCount);
/*_____*/
/* Stop PWM Timer0 (Recommended procedure method 2)
/* Set PWM Timer counter as 0, When interrupt request happen, disable PWM Timer
/* Set PWM Timer counter as 0 in Call back function
                                                                    */
                   /* Disable the PWM Timer 0 */
                  DrvPWM Enable(u8Timer, 0);
               }
           }
           break;
       case '1':
       {
                   printf("PWM Capture Test\n");
                   printf("Use PWM Capture 0 to capture the Waveform from PA.12 \n");
           /*_____*/
           /* Set the PWM Capture 3 for capture function
           /*_____*/
           /* PWM Timer property for Capture */
           sPt.u8Mode = DRVPWM_TOGGLE_MODE;
           /* Set the proper frequency to capture data (Less than the input data)*/
           sPt.u32Frequency = 100;
           /* High Pulse peroid : Total Pulse peroid = 50 : 100 (Set a non-zero value) */
           sPt.u8HighPulseRatio = 50;
```



```
sPt.u32Duty = 0x10000;
                                        /* Set the counter to the maximum value */
            sPt.i32Inverter = 0;
            u8CapTimer = DRVPWM CAP0;
            /* Select PWM engine clock */
            DrvPWM_SelectClockSource(DRVPWM_HCLK);
            /* Set PWM Timer 0 for Capture */
            DrvPWM_SetTimerClk(u8CapTimer, &sPt);
            /* Enable Interrupt Sources of PWM Capture0 */
            DrvPWM EnableInt(u8CapTimer, DRVPWM CAP FALLING INT,
            DRVPWM_CapIRQHandler);
            /* Enable Input function for PWM Capture0 */
            DrvPWM_SetTimerIO(u8CapTimer, 1);
            /* Enable the PWM Capture0 */
            DrvPWM_Enable(u8CapTimer, 1);
            /* Capture the Input Waveform Data */
            CalPeriodTime(u8CapTimer);
/* Stop PWM Timer 0 (Recommended procedure method 1)
/* Set PWM Timer counter as 0, When PWM internal counter reaches to 0, disable PWM Timer*/
/*______*/
            /* Set PWM Capture0 counter as 0 */
            DrvPWM SetTimerCounter(u8CapTimer, 0);
            /* Wait PWM Capture 0 Counter reach to 0 */
            while (DrvPWM_GetTimerCounter(u8CapTimer));
            /* Clear the PWM Capture0 Interrupt */
            DrvPWM_ClearInt(u8CapTimer);
            /* Disable PWM Capture0 */
            DrvPWM_Enable(u8CapTimer, 0);
            /* Disable Input function for PWM Capture0 */
            DrvPWM_SetTimerIO(u8CapTimer, 0);
            break;
```

#### nuvoTon



### 5 Execution Environment Setup and Result

- Prepare a ISD9160 board.
- Compile the sample code.
- Console window show result of PWM timer waveform and capture test.



# **6 Revision History**

Version	Date	Description
V1.00.01	Sep. 2011	Created