

BOD Driver Sample Code Reference Guide

V1.00.001

Publication Release Date: Sep. 2011

Support Chips:

ISD9160

Support Platforms:

NuvotonPlatform_Keil



The information in this document is subject to change without notice.

The Nuvoton Technology Corp. shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material.

This documentation may not, in whole or in part, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine readable form without prior consent, in writing, from the Nuvoton Technology Corp.

Nuvoton Technology Corp. All rights reserved.



Table of Contents

1.	Introduction	4
	1.1 Feature	
	Block Diagram	
	Calling Sequence	
	Code Section –Smpl_DrvBODTALARM.c	
	Execution Environment Setup and Result	
	Revision History	



1. Introduction


This sample code will demo BOD IP on ISD9160 chip.

1.1 Feature

- Configure Temperature Alarm at 105C to protect the chip from dangerously high internal temperatures, generally associated with excessive load (or short circuit) on the speaker driver.
- Configure Brown Out Detection at 4.5V.
- Wait for INT, and Debug messages will show the trigger function.




2. Block Diagram





3. Calling Sequence





4. Code Section - Smpl_DrvBODTALARM.c

```
/* Global variables
char *cBODvol={"2.12.22.42.52.72.83.04.5"};
/*_____*/
/* Define functions prototype
void SysTimerDelay(uint32_t us)
   SysTick->LOAD = us * 22; /* Assume the internal 22MHz RC used */
   SysTick->VAL = (0x00);
   SysTick->CTRL = (1 << SYSTICK_CLKSOURCE) | (1 << SYSTICK_ENABLE);
   /* Waiting for down-count to zero */
   while((SysTick->CTRL & (1 << 16)) == 0);
}
void DrvBODTALARM_BODISR(void)
   char cBuffer[3];
   uint8_t u8addr;
   u8addr = 3*(BOD->BOD_SEL.BOD_LVL);
   cBuffer[0] = *(cBODvol+u8addr);
   cBuffer[1] = *(cBODvol+u8addr+1);
   cBuffer[2] = *(cBODvol+u8addr+2);
   printf("Brown Out Detect voltage level below %s\n",cBuffer);
   if(BOD->BOD_SEL.BOD_LVL > 0)
       BOD->BOD_SEL.BOD_LVL--;
}
void DrvBODTALARM_TALARMISR(void)
   printf("Temperature Sense event occurs\n");
```



```
/* BODTALARM Test Sample
/* Test Item
                                                               */
                                                               */
/* It sends the messages to HyperTerminal.
/*______*/
int32_t main()
    STR_UART_T sParam;
    uint32_t u32config0;
    UNLOCKREG();
    SYSCLK->PWRCON.XTL32K_EN = 1;
    LOCKREG();
    /* Waiting for 12M Xtal stalble */
    SysTimerDelay(5000);
    /* Set UART Pin */
    DrvGPIO_InitFunction(FUNC_UART0);
    /* UART Setting */
   sParam.u32BaudRate = 115200;

sParam.u8cDataBits = DRVUART_DATABITS_8;

sParam.u8cStopBits = DRVUART_STOPBITS_1;

sParam.u8cParity = DRVUART_PARITY_NONE;
    sParam.u8cRxTriggerLevel= DRVUART_FIFO_1BYTES;
    DrvUART_Open(UART_PORT0,&sParam);
    printf("+------+\n");
    printf("| BOD&TALAM Sample Code
    printf("+-----+\n");
    printf("| Brown out detection from 4.5V to 2.1V |\n");
printf("| Temperature Alarm Sense Level = 105C |\n");
    printf("+-----+\n");
    printf("\n");
```



```
/* Configure Temperature Alarm */
DrvBOD_SetTALARMselect(TALARM_SEL_105C);
DrvBOD_SetTALARMIE(TALARM_EN_IEENABLE);
DrvBOD_InstallISR(DrvBODTALARM_TALARMISR,1);
DrvBOD_EnableTALARM(TALARM_EN_ENENABLE);

/* Configure BOD */
DrvBOD_SelectBODVolt(BODLVL_45V);
DrvFMC_Read(CONFIG_BASE, &u32config0);
u32config0 |= 0x00800000; //BOD enable
DrvFMC_Write(CONFIG_BASE, u32config0);
DrvBOD_InstallISR(DrvBODTALARM_BODISR,0);
printf("Set Config0[23] = 1, Please reset again....\n");
while(1);
}
```



5. Execution Environment Setup and Result

- Prepare ISD9160 EVB board.
- Compile&Download the sample code.
- Console window will show the results of BOD&TALARM.



6. Revision History

Version	Date	Description
V1.00.01	Sep. 2011	Created