Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



Not for commercial use. For residential use only.



 Furniture may scratch floors. We recommend using furniture pads to protect your floors.



Do not put hot items directly on furniture surface.



• Do not clean furniture with harsh cleansers or polish.



• Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



 Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside . For indoor use only.




 Stains may be removed with mild soap solution and damp cloth.



Children should not climb or jump on the furniture.



 Dust and pick-up spills using a clean, non-colored, lint-free cloth.



Parts List			
Label	Picture	Description	QTY
Α		Table Top	1
В		Table Top	1
С		Leg	2
D		Crossbar	1
Hardware			
Label	Picture	Description	QTY
1		5mm Allen Wrench	1
2		Bolt (M8*32mm)	21
Assembly Preparation			
Before Beginning Assembly:	A B		
	D		



Read instructions, cover to cover-



Have 2 adults on hand for assembly-



Do not assemble on flooring or carpet-



Assemble on a clean non-marring surface (packing foam)-



Save all packaging until finished-


Assembly Steps

Table Top(B) Table Top(A) Leg(C) Leg(C)

This Dining Table has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Dining Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.


FRONT FACING

Step 1




Please put the two Table Tops (A) and (B) together as shown. Place all parts on a clean, undamaged surface.

Step 2



As shown in the picture above, the bottom of the table board should be facing up. Use the Allen Wrench (1) and the Bolt (2) to fix the Leg (C). During assembly, do not fully tighten the bolts.




As shown in the picture: Please put the Crossbar (D) into the slot of the Leg (C) and align the holes.

Do not fully tighten the Bolts at this time.

Step 4 ① - C ② - C


As shown in the picture: Please use the Allen Wrench (①) and the Bolt (②) to fix the Leg (C) and the Cross Bar (D), and install the other Leg (C) on the Cross Bar (D). Bit aligned.

Note: DO NOT fully tighten the Bolts at this time.




As shown in the picture: Please use the Allen Wrench (1) and Bolts (2) to fix the Leg and Crossbar.

Step 6



As shown in the picture: After turning the Dining Table over, please use the Allen Wrench (1) and Bolt (2) to fix the legs and crossbar.

Step 6



Your Dining Table is ready for use.

This Dining Table should only be used on a flat, level surface.