

$\begin{array}{c} {\rm Bluespec^{TM}\; System Verilog} \\ {\rm Reference\; Guide} \end{array}$

Revision: 17 January 2012

Copyright © 2000 - 2012 Bluespec, Inc. All rights reserved

Trademarks and copyrights

Verilog is a trademark of IEEE (the Institute of Electrical and Electronics Engineers). The Verilog standard is copyrighted, owned and maintained by IEEE.

VHDL is a trademark of IEEE (the Institute of Electrical and Electronics Engineers). The VHDL standard is copyrighted, owned and maintained by IEEE.

System Verilog is a trademark of Accellera, Inc. The System Verilog standard is owned and maintained by Accellera.

Bluespec is a trademark of Bluespec, Inc.

AzureIP is a trademark of Bluespec, Inc.

Contents

Ta	able	of Contents	3
1	Inti	roduction	13
	1.1	Meta notation	13
2	Lex	ical elements	13
	2.1	Whitespace and comments	14
	2.2	Identifiers and keywords	14
	2.3	Integer literals	14
		2.3.1 Type conversion of integer literals	15
	2.4	Real literals	15
		2.4.1 Type conversion of real literals	16
	2.5	String literals	16
	2.6	Don't-care values	17
	2.7	Compiler directives	17
		2.7.1 File inclusion: 'include and 'line	17
		2.7.2 Macro definition and substitution: 'define and related directives	18
		2.7.3 Conditional compilation: 'ifdef and related directives	19
3	Pac	kages and the outermost structure of a BSV design	20
	3.1	Scopes, name clashes and qualified identifiers	21
	3.2	The Standard Prelude package	22
	3.3	AzureIP TM Foundation Libraries	22
4	Typ	oes established to the second of the second	22
	4.1	Polymorphism	24
	4.2	Provisos (brief intro)	24
		4.2.1 The pseudo-function value of (or value Of)	26
	4.3	A brief introduction to deriving clauses	26
5	Mo	dules and interfaces, and their instances	27
	5.1	Explicit state via module instantiation, not variables	27
	5.2	Interface declaration	28
		5.2.1 Subinterfaces	30
	5.3	Module definition	31
	5.4	Module and interface instantiation	33
		5.4.1 Short form instantiation	33

		5.4.2 Long form instantiation	4
	5.5	Interface definition (definition of methods)	5
		5.5.1 Shorthands for Action and ActionValue method definitions	7
		5.5.2 Definition of subinterfaces	7
		5.5.3 Definition of methods and subinterfaces by assignment	8
	5.6	Rules in module definitions	9
	5.7	Examples	0
	5.8	Synthesizing Modules	2
		5.8.1 Type Polymorphism	3
		5.8.2 Module Interfaces and Arguments	4
6	Stat	tic and dynamic semantics 4	4
	6.1	Static semantics	4
		6.1.1 Type checking	5
		6.1.2 Proviso checking and bit-width constraints	5
		6.1.3 Static elaboration	5
	6.2	Dynamic semantics	6
		6.2.1 Reference semantics	6
		6.2.2 Mapping into efficient parallel clocked synchronous hardware 4	6
		6.2.3 How rules are chosen to fire	8
		6.2.4 Mapping specific hardware models	9
7	Use	er-defined types (type definitions) 50	0
	7.1	Type synonyms	0
	7.2	Enumerations	1
	7.3	Structs and tagged unions	2
8	Var	iable declarations and statements 5	5
	8.1	Variable and array declaration and initialization	5
	8.2	Variable assignment	6
	8.3	Implicit declaration and initialization	7
	8.4	Register reads and writes	8
		8.4.1 Registers and square-bracket notation	9
		8.4.2 Registers and range notation	0
		8.4.3 Registers and struct member selection	0
	8.5	Begin-end statements	1
	8.6	Conditional statements	1
	8.7	Loop statements	3

		8.7.1 While loops	 	 	 		63
		8.7.2 For loops	 	 	 		63
	8.8	Function definitions	 	 	 		64
		8.8.1 Definition of functions by assignment	 	 	 	•	65
		8.8.2 Function types	 	 	 		66
9	Exp	pressions					66
	9.1	Don't-care expressions	 	 	 		66
	9.2	2 Conditional expressions	 	 	 		67
	9.3	Unary and binary operators	 	 	 		67
	9.4	<u> </u>					68
	9.5	Begin-end expressions	 	 	 		69
	9.6	Actions and action blocks	 	 	 		70
	9.7	Actionvalue blocks	 	 	 		71
	9.8	Function calls	 	 	 		73
	9.9	Method calls	 	 	 		73
	9.10	0 Static type assertions	 	 	 		74
	9.11	1 Struct and union expressions	 	 	 	•	75
		9.11.1 Struct expressions	 	 	 		75
		9.11.2 Struct member selection	 	 	 		75
		9.11.3 Tagged union expressions	 	 	 		76
		9.11.4 Tagged union member selection	 	 	 		76
	9.12	2 Interface expressions	 	 	 		77
		9.12.1 Differences between interfaces and structs	 	 	 		78
	9.13	3 Rule expressions	 	 	 		79
10	Patt	attern matching					80
	10.1	1 Case statements with pattern matching	 	 	 		82
	10.2	2 Case expressions with pattern matching	 	 	 	•	83
	10.3	3 Pattern matching in if statements and other contexts	 	 	 		84
	10.4	4 Pattern matching assignment statements	 	 	 		85
11	Fini	nite state machines					86

12 I	[mp	ortant primitives	86
1	12.1	The types bit and Bit	86
		12.1.1 Bit-width compatibility	87
1	12.2	UInt, Int, int and Integer	87
1	12.3	String	87
1	12.4	Tuples	87
1	12.5	Registers	88
1	12.6	FIFOs	89
1	12.7	FIFOFs	89
1	12.8	System tasks and functions	90
		12.8.1 Displaying information	90
		12.8.2 \$format	91
		12.8.3 File data type	92
		12.8.4 Opening and closing file operations	92
		12.8.5 Writing to a file	93
		12.8.6 Formatting output to a string	94
		12.8.7 Reading from a file	94
		12.8.8 Flushing output	95
		12.8.9 Stopping simulation	95
		12.8.10 VCD dumping	95
		12.8.11 Time functions	96
		12.8.12 Real functions	96
		12.8.13 Testing command line input	96
13 (Guid	ding the compiler with attributes	96
		Verilog module generation attributes	97
		13.1.1 synthesize	97
		13.1.2 noinline	97
1	13.2	Interface attributes	98
		13.2.1 Renaming attributes	98
		13.2.2 Port protocol attributes	99
			100
1	13.3		101
			101
			102
		13.3.3 descending_urgency	103
		13.3.4 execution order	105

	13.3.5 mutually_exclusive	106
	13.3.6 conflict_free	106
	13.3.7 preempts	107
13.4	Evaluation behavior attributes	107
	13.4.1 split and nosplit	107
13.5	Input clock and reset attributes	109
	13.5.1 Clock and reset prefix naming attributes	109
	13.5.2 Gate synthesis attributes	110
	13.5.3 Default clock and reset naming attributes	110
	13.5.4 Clock family attributes	111
13.6	Module argument and parameter attributes	112
	13.6.1 Argument-level clock and reset naming attributes	112
	13.6.2 clocked_by=	113
	13.6.3 reset_by=	113
	13.6.4 port=	114
	13.6.5 parameter=	114
13.7	Documentation attributes	114
	13.7.1 Modules	115
	13.7.2 Module instantiation	115
	13.7.3 Rules	116
14 Adv	anced topics	117
	Type classes (overloading groups) and provisos	
	14.1.1 Provisos	118
	14.1.2 Type class declarations	119
	14.1.3 Instance declarations	121
	14.1.4 The Bits type class (overloading group)	122
	14.1.5 The SizeOf pseudo-function	123
	14.1.6 Deriving Bits	123
	14.1.7 Deriving Eq	124
	14.1.8 Deriving Bounded	124
	14.1.9 Deriving type class instances for isomorphic types	125
14.2	Higher-order functions	125

15	Eml	beddin	g RTL in	ı a BSV	des	ign								127
	15.1	Param	eter				 		 		 	 	 	129
	15.2	Metho	d				 		 		 	 	 	130
	15.3	Port					 		 		 	 	 	131
	15.4	Input	clock				 		 		 	 	 	131
	15.5	Defau	t clock .				 		 		 	 	 	132
	15.6	Outpu	t clock .				 		 		 	 	 	134
	15.7	Input	reset				 		 		 	 	 	134
	15.8	Defau	t reset .				 		 		 	 	 	135
	15.9	Outpu	t reset .				 		 		 	 	 	137
	15.10	0Ances	tor, same f	amily .			 		 		 	 	 	137
	15.1	1Sched	ıle				 		 		 	 	 	138
	15.15	2Path					 		 		 	 	 	139
	15.13	3Interfa	ice				 		 		 	 	 	140
	15.1	4Inout					 		 		 	 	 	140
10			G •	DOM D										
16			g C in a											141
			nent Types											142
			types .											
			it pack/ur											144
	16.4	Other	examples			• •	 	• •	 	• •	 	 	 	144
A	Key	words												146
В	The	Stand	lard Prel	ude pac	ckage	:								150
	B.1	Type	classes				 		 		 	 	 	150
		B.1.1	Bits				 		 		 	 	 	150
		B.1.2	Eq				 		 		 	 	 	151
		B.1.3	Literal .				 		 		 	 	 	152
		B.1.4	RealLiter	al			 		 		 	 	 	152
		B.1.5	SizedLite	ral			 		 		 	 	 	153
		B.1.6	Arith .				 		 		 	 	 	153
		B.1.7	Ord				 		 		 	 	 	155
		B.1.8	Bounded				 		 		 	 	 	157
		B.1.9	Bitwise				 		 		 	 	 	157
		B.1.10	BitReduc	etion			 		 		 	 	 	159
		B.1.11	BitExten	d			 		 		 	 	 	161
		D 1 19	Saturation	og A rith										169

	B.1.13	Alias and NumAlias	163
B.2	Data T	Types	163
	B.2.1	Bit	164
	B.2.2	UInt	165
	B.2.3	Int	165
	B.2.4	Integer	165
	B.2.5	Bool	166
	B.2.6	Real	167
	B.2.7	String	168
	B.2.8	Fmt	169
	B.2.9	Void	169
	B.2.10	Maybe	170
	B.2.11	Ordering	171
	B.2.12	Tuples	171
	B.2.13	Clock	173
	B.2.14	Reset	174
	B.2.15	Inout	174
	B.2.16	Action/ActionValue	176
	B.2.17	Rules	176
B.3	Operat	cions on Numeric Types	178
	B.3.1	Size Relationship/Provisos	178
	B.3.1 B.3.2		178 179
	_	Size Relationship Type Functions	
B.4	B.3.2 B.3.3	Size Relationship Type Functions	179
B.4	B.3.2 B.3.3 Registe	Size Relationship Type Functions	179 179
B.4	B.3.2 B.3.3 Registe	Size Relationship Type Functions	179 179 180
B.4	B.3.2 B.3.3 Registe B.4.1	Size Relationship Type Functions	179 179 180 180
B.4	B.3.2 B.3.3 Registe B.4.1 B.4.2 B.4.3	Size Relationship Type Functions	179 179 180 180 182
B.4	B.3.2 B.3.3 Registe B.4.1 B.4.2 B.4.3	Size Relationship Type Functions	179 179 180 180 182 184
B.4	B.3.2 B.3.3 Registe B.4.1 B.4.2 B.4.3 B.4.4	Size Relationship Type Functions valueOf and SizeOf pseudo-functions ers and Wires Reg RWire Wire BypassWire DWire	179 179 180 180 182 184 185
B.4	B.3.2 B.3.3 Registe B.4.1 B.4.2 B.4.3 B.4.4 B.4.5	Size Relationship Type Functions valueOf and SizeOf pseudo-functions ers and Wires Reg RWire Wire BypassWire DWire PulseWire	179 179 180 180 182 184 185
B.4	B.3.2 B.3.3 Registe B.4.1 B.4.2 B.4.3 B.4.4 B.4.5 B.4.6	Size Relationship Type Functions	179 179 180 180 182 184 185 186
B.4	B.3.2 B.3.3 Registe B.4.1 B.4.2 B.4.3 B.4.4 B.4.5 B.4.6 B.4.7 B.4.8	Size Relationship Type Functions valueOf and SizeOf pseudo-functions ers and Wires Reg RWire Wire BypassWire DWire PulseWire ReadOnly WriteOnly	179 180 180 182 184 185 186 187
	B.3.2 B.3.3 Registe B.4.1 B.4.2 B.4.3 B.4.4 B.4.5 B.4.6 B.4.7 B.4.8	Size Relationship Type Functions	179 179 180 180 182 184 185 186 187 189
	B.3.2 B.3.3 Register B.4.1 B.4.2 B.4.3 B.4.4 B.4.5 B.4.6 B.4.7 B.4.8 Miscell	Size Relationship Type Functions valueOf and SizeOf pseudo-functions ers and Wires Reg RWire Wire BypassWire DWire PulseWire ReadOnly WriteOnly aneous Functions Compile-time Messages	179 179 180 180 182 184 185 186 187 190 191
	B.3.2 B.3.3 Register B.4.1 B.4.2 B.4.3 B.4.4 B.4.5 B.4.6 B.4.7 B.4.8 Miscell B.5.1	Size Relationship Type Functions valueOf and SizeOf pseudo-functions ers and Wires Reg RWire Wire BypassWire DWire PulseWire ReadOnly WriteOnly aneous Functions Compile-time Messages Arithmetic Functions	179 179 180 182 184 185 186 187 199 191
	B.3.2 B.3.3 Registe B.4.1 B.4.2 B.4.3 B.4.4 B.4.5 B.4.6 B.4.7 B.4.8 Miscell B.5.1 B.5.2	Size Relationship Type Functions valueOf and SizeOf pseudo-functions ers and Wires Reg RWire Wire BypassWire DWire PulseWire ReadOnly WriteOnly aneous Functions Compile-time Messages Arithmetic Functions Operations on Functions	179 179 180 182 184 185 186 187 190 191 191
	B.3.2 B.3.3 Register B.4.1 B.4.2 B.4.3 B.4.4 B.4.5 B.4.6 B.4.7 B.4.8 Miscell B.5.1 B.5.2 B.5.3	Size Relationship Type Functions valueOf and SizeOf pseudo-functions ers and Wires Reg RWire Wire BypassWire DWire PulseWire ReadOnly WriteOnly aneous Functions Compile-time Messages Arithmetic Functions Operations on Functions Bit Functions	179 179 180 180 182 184 185 186 187 189 191 191 191
	B.3.2 B.3.3 Register B.4.1 B.4.2 B.4.3 B.4.4 B.4.5 B.4.6 B.4.7 B.4.8 Miscell B.5.1 B.5.2 B.5.3 B.5.4	Size Relationship Type Functions valueOf and SizeOf pseudo-functions ers and Wires Reg RWire Wire BypassWire DWire PulseWire ReadOnly WriteOnly aneous Functions Compile-time Messages Arithmetic Functions Operations on Functions Bit Functions Integer Functions	179 179 180 180 182 184 185 186 187 190 191 191 191 192

\mathbf{C}	Azu	reIP F	oundation Libraries	198
	C.1	Storag	e Structures	198
		C.1.1	Register File	198
		C.1.2	ConfigReg	201
		C.1.3	DReg	202
		C.1.4	RevertingVirtualReg	203
		C.1.5	BRAM	204
		C.1.6	BRAMCore	211
	C.2	FIFOs		216
		C.2.1	FIFO Overview	216
		C.2.2	FIFO and FIFOF packages	216
		C.2.3	FIFOLevel	223
		C.2.4	BRAMFIFO	231
		C.2.5	SpecialFIFOs	232
		C.2.6	AlignedFIFOs	235
		C.2.7	Gearbox	238
	C.3	Aggreg	gation: Vectors	240
		C.3.1	Creating and Generating Vectors	241
		C.3.2	Extracting Elements and Sub-Vectors	243
		C.3.3	Vector to Vector Functions	247
		C.3.4	Tests on Vectors	249
		C.3.5	Bit-Vector Functions	252
		C.3.6	Functions on Vectors of Registers	252
		C.3.7	Combining Vectors with Zip	252
		C.3.8	Mapping Functions over Vectors	254
		C.3.9	ZipWith Functions	254
		C.3.10	Fold Functions	256
		C.3.11	Scan Functions	258
		C.3.12	Monadic Operations	260
		C.3.13	Converting to and from Vectors	264
		C.3.14	ListN	264
	C.4	Aggreg	gation: Lists	265
		C.4.1	Creating and Generating Lists	265
		C.4.2	Extracting Elements and Sub-Lists	267
		C.4.3	List to List Functions	271
		C.4.4	Tests on Lists	273
		C 4 5	Combining Lists with Zip Functions	274

	C.4.6	Mapping Functions over Lists	275
	C.4.7	ZipWith Functions	276
	C.4.8	Fold Functions	277
	C.4.9	Scan Functions	280
	C.4.10	Monadic Operations	282
C.5	Math .		283
	C.5.1	Real	283
	C.5.2	Complex	287
	C.5.3	Fixed Point 	289
	C.5.4	OInt	297
	C.5.5	NumberTypes	298
C.6	FSM .		300
	C.6.1	$StmtFSM \ \dots $	300
C.7	Connec	ctivity	310
	C.7.1	GetPut	310
	C.7.2	Connectable	315
	C.7.3	ClientServer	317
	C.7.4	CGetPut	319
	C.7.5	CommitIfc	320
C.8	Utilitie	es	325
	C.8.1	LFSR	325
	C.8.2	Randomizable	327
	C.8.3	Arbiter	329
	C.8.4	GrayCounter	330
	C.8.5	Gray	331
	C.8.6	CompletionBuffer	333
	C.8.7	UniqueWrappers	336
	C.8.8	FShow	339
	C.8.9	DefaultValue	344
	C.8.10	TieOff	346
	C.8.11	Assert	346
	C.8.12	Probe	347
	C.8.13	Reserved	348
	C.8.14	TriState	350
	C.8.15	$ZBus\dots$	351
	C.8.16	CRC	354
	C.8.17	OVLAssertions	356

C.9	Multip	le Clock Domains and Clock Generators	369
	C.9.1	Clock Generators and Clock Manipulation	371
	C.9.2	Clock Multiplexing	375
	C.9.3	Clock Division	377
	C.9.4	Bit Synchronizers	380
	C.9.5	Pulse Synchronizers	384
	C.9.6	Word Synchronizers	387
	C.9.7	FIFO Synchronizers	388
	C.9.8	Asynchronous RAMs	391
	C.9.9	Null Crossing Primitives	392
	C.9.10	Reset Synchronization and Generation	394
C.10	Specia	l Collections	399
	C.10.1	ModuleContext	399
	C.10.2	ModuleCollect	404
	C.10.3	CBus	408
	C.10.4	HList	415
	C.10.5	UnitAppendList	419
C.11	Bus Fa	abric Libraries	420
	C.11.1	TLM2	420
C.12	Premi	ım Bus Fabric Libraries	432
	C.12.1	Axi	433
	C.12.2	AHB	445
Index			454
Function	on and	Module by Package	467
Packag	ges pro	vided as BSV source code	473
Typecl	asses		474

1 Introduction

Bluespec SystemVerilog (BSV) is aimed at hardware designers who are using or expect to use Verilog [IEE01], VHDL [IEE02], or SystemVerilog [Acc04] to design ASICs or FPGAs. BSV is based on a synthesizable subset of SystemVerilog, including SystemVerilog types, modules, module instantiation, interfaces, interface instantiation, parameterization, static elaboration, and "generate" elaboration. BSV can significantly improve the hardware designer's productivity with some key innovations:

- It expresses synthesizable behavior with *Rules* instead of synchronous always blocks. Rules are powerful concepts for achieving *correct* concurrency and eliminating race conditions. Each rule can be viewed as a declarative assertion expressing a potential *atomic* state transition. Although rules are expressed in a modular fashion, a rule may span multiple modules, i.e., it can test and affect the state in multiple modules. Rules need not be disjoint, i.e., two rules can read and write common state elements. The BSV compiler produces efficient RTL code that manages all the potential interactions between rules by inserting appropriate arbitration and scheduling logic, logic that would otherwise have to be designed and coded manually. The atomicity of rules gives a scalable way to avoid unwanted concurrency (races) in large designs.
- It enables more powerful generate-like elaboration. This is made possible because in BSV, actions, rules, modules, interfaces and functions are all first-class objects. BSV also has more general type parameterization (polymorphism). These enable the designer to "compute with design fragments," i.e., to reuse designs and to glue them together in much more flexible ways. This leads to much greater succinctness and correctness.
- It provides formal semantics, enabling formal verification and formal design-by-refinement. BSV rules are based on Term Rewriting Systems, a clean formalism supported by decades of theoretical research in the computer science community [Ter03]. This, together with a judicious choice of a design subset of SystemVerilog, makes programs in BSV amenable to formal reasoning.

This manual is meant to be a stand-alone reference for BSV, i.e., it fully describes the subset of Verilog and SystemVerilog used in BSV. It is not intended to be a tutorial for the beginner. A reader with a working knowledge of Verilog 1995 or Verilog 2001 should be able to read this manual easily. Prior knowledge of SystemVerilog is not required.

1.1 Meta notation

The grammar in this document is given using an extended BNF (Backus-Naur Form). Grammar alternatives are separated by a vertical bar ("|"). Items enclosed in square brackets ("[]") are optional. Items enclosed in curly braces ("[]") can be repeated zero or more times.

Another BNF extension is parameterization. For example, a moduleStmt can be a moduleIf, and an actionStmt can be an actionIf. A moduleIf and an actionIf are almost identical; the only difference is that the former can contain (recursively) moduleStmts whereas the latter can contain actionStmts. Instead of tediously repeating the grammar for moduleIf and actionIf, we parameterize it by giving a single grammar for actionStmt, where actionStmt is either actionStmt and actionStmt or an actionStmt in the productions for actionStmt in the context in which it is used.

2 Lexical elements

BSV has the same basic lexical elements as Verilog.

2.1 Whitespace and comments

Spaces, tabs, newlines, formfeeds, and carriage returns all constitute whitespace. They may be used freely between all lexical tokens.

A comment is treated as whitespace (it can only occur between, and never within, any lexical token). A one-line comment starts with // and ends with a newline. A block comment begins with /* and ends with */ and may span any number of lines.

Comments do not nest. In a one-line comment, the character sequences //, /* and */ have no special significance. In a block comment, the character sequences // and /* have no special significance.

2.2 Identifiers and keywords

An identifier in BSV consists of any sequence of letters, digits, dollar signs \$ and underscore characters (_). Identifiers are case-sensitive: glurph, gluRph and Glurph are three distinct identifiers. The first character cannot be a digit.

BSV currently requires a certain capitalization convention for the first letter in an identifier. Identifiers used for package names, type names, enumeration labels, union members and type classes must begin with a capital letter. In the syntax, we use the non-terminal *Identifier* to refer to these. Other identifiers (including names of variables, modules, interfaces, etc.) must begin with a lowercase letter and, in the syntax, we use the non-terminal *identifier* to refer to these.

As in Verilog, identifiers whose first character is \$ are reserved for so-called *system tasks and functions* (see Section 12.8).

If the first character of an instance name is an underscore, (_), the compiler will not generate this instance in the Verilog hierarchy name. This can be useful for removing sub-modules from the hierarchical naming.

There are a number of *keywords* that are essentially reserved identifiers, i.e., they cannot be used by the programmer as identifiers. Keywords generally do not use uppercase letters (the only exception is the keyword valueOf). BSV includes all keywords in SystemVerilog. All keywords are listed in Appendix A.

The types Action and ActionValue are special, and cannot be redefined.

2.3 Integer literals

Integer literals are written with the usual Verilog and C notations:

```
intLiteral\\
                        ::= '0 | '1
                             sizedIntLiteral
                             unsizedIntLiteral
sizedIntLiteral
                            bitWidth\ baseLiteral
unsized IntLiteral\\
                             [ sign ] baseLiteral
                             [ sign ] decNum
baseLiteral
                       ::= ('d | 'D) decDigitsUnderscore
                            ('h | 'H) hexDigitsUnderscore
                            ('o | 'O) octDigitsUnderscore
                            ('b | 'B) binDigitsUnderscore
decNum
                       ::= dec Digits [ dec Digits Underscore ]
```

```
\begin{array}{lll} bitWidth & ::= & decDigits \\ sign & ::= & + & | & - \\ \\ decDigits & ::= & \{ \text{ 0...9 } \} \\ decDigitsUnderscore & ::= & \{ \text{ 0...9, } \_ \} \\ hexDigitsUnderscore & ::= & \{ \text{ 0...9, a...f, A...F, } \_ \} \\ octDigitsUnderscore & ::= & \{ \text{ 0...7, } \_ \} \\ binDigitsUnderscore & ::= & \{ \text{ 0,1, } \_ \} \\ \end{array}
```

An integer literal is a sized integer literal if a specific bitWidth is given (e.g., 8'0255). There is no leading sign (+ or -) in the syntax for sized integer literals; instead we provide unary prefix + or - operators that can be used in front of any integer expression, including literals (see Section 9). An optional sign (+ or -) is part of the syntax for unsized literals so that it is possible to construct negative constants whose negation is not in the range of the type being constructed (e.g. Int#(4) x = -8; since 8 is not a valid Int#(4), but -8 is).

Examples:

```
125

-16

'h48454a

32'h48454a

8'o255

12'b101010

32'h_FF_FF_FF_FF
```

2.3.1 Type conversion of integer literals

Integer literals can be used to specify values for various integer types and even for user-defined types. BSV uses its systematic overloading resolution mechanism to perform these type conversions. Overloading resolution is described in more detail in Section 14.1.

An integer literal is a sized literal if a specific bitWidth is given (e.g., 8'o255), in which case the literal is assumed to have type bit [w-1:0]. The compiler implicitly applies the function fromSizedInteger to the literal to convert it to the type required by the context. Thus, sized literals can be used for any type on which the overloaded function fromSizedInteger is defined, i.e., for the types Bit, UInt and Int. The function fromSizedInteger is part of the SizedLiteral typeclass, defined in Section B.1.5.

If the literal is an unsized integer literal (a specific bitWidth is not given), the literal is assumed to have type Integer. The compiler implicitly applies the overloaded function fromInteger to the literal to convert it to the type required by the context. Thus, unsized literals can be used for any type on which the overloaded function fromInteger is defined. The function fromInteger is part of the Literal typeclass, defined in Section B.1.3.

The literal '0 just stands for 0. The literal '1 stands for a value in which all bits are 1 (the width depends on the context).

2.4 Real literals

Real number literals are written with the usual Verilog notation:

```
 \begin{array}{ll} \textit{realLiteral} & ::= \textit{decNum}[\textit{ .decDigitsUnderscore }] \textit{ exp} \textit{ [ sign ] decDigitsUnderscore } \\ \textit{decNum . decDigitsUnderscore} \\ \end{array}
```

```
\begin{array}{lll} sign & ::= + \mid -\\ exp & ::= e \mid E\\ \\ decNum & ::= decDigits \left[ \ decDigitsUnderscore \ \right]\\ \\ decDigits & ::= \left\{ \ 0...9 \ \right\}\\ \\ decDigitsUnderscore & ::= \left\{ \ 0...9, \ \right. \right\} \end{array}
```

There is no leading sign (+ or -) in the syntax for real literals. Instead, we provide the unary prefix + and - operators that can be used in front of any expression, including real literals (Section 9).

If the real literal contains a decimal point, there must be digits following the decimal point. An exponent can start with either an E or an e, followed by an optional sign (+ or -), followed by digits. There cannot be an exponent or a sign without any digits. Any of the numeric components may include an underscore, but an underscore cannot be the first digit of the real literal.

Unlike integer literals, real literals are of limited precision. They are represented as IEEE floating point numbers of 64 bit length, as defined by the IEEE standard.

Examples:

```
1.2

0.6

2.4E10  // exponent can be e or E

5e-3

325.761_452_e-10  // underscores are ignored

9.2e+4
```

2.4.1 Type conversion of real literals

Real literals can be used to specify values for real types. By default, real literals are assumed to have the type Real. BSV uses its systematic overloading resolution mechanism to perform these type conversions. Overloading resolution is described in more detail in Section 14.1. There are additional functions defined for Real types, provided in the Real package (Section C.5.1).

The function fromReal (Section B.1.4) converts a value of type Real into a value of another datatype. Whenever you write a real literal in BSV (such as 3.14), there is an implied fromReal applied to it, which turns the real into the specified type. By defining an instance of RealLiteral for a datatype, you can create values of that type from real literals.

The type FixedPoint, defined in the FixedPoint package, defines a type for representing fixed point numbers. The FixedPoint type has an instance of RealLiteral defined for it and contains functions for operating on fixed-point real numbers.

2.5 String literals

String literals are written enclosed in double quotes " \cdots " and must be contained on a single source line.

```
stringLiteral ::= " · · · string characters · · · "
```

Special characters may be inserted in string literals with the following backslash escape sequences:

```
\n newline
\t tab
\\ backslash
```

```
\"
           double quote
           vertical tab
\v
           form feed
\f
           bell
\a
\000
           exactly 3 octal digits (8-bit character code)
\xHH
           exactly 2 hexadecimal digits (8-bit character code)
Example - printing characters using form feed.
     module mkPrinter (Empty);
        String display_value;
        display_value = "a\nb\nc";
                                          //prints a
                                          //
                                          //
                                                     С
                                                         repeatedly
        rule every;
            $display(display_value);
         endrule
     endmodule
```

2.6 Don't-care values

A lone question mark? is treated as a special don't-care value. For example, one may return? from an arm of a case statement that is known to be unreachable.

Example - Using? as a don't-care value

2.7 Compiler directives

The following compiler directives permit file inclusion, macro definition and substitution, and conditional compilation. They follow the specifications given in the Verilog 2001 LRM plus the extensions given in the SystemVerilog 3.1a LRM.

In general, these compiler directives can appear anywhere in the source text. In particular, they do not need to be on lines by themselves, and they need not begin in the first column. Of course, they should not be inside strings or comments, where the text remains uninterpreted.

2.7.1 File inclusion: 'include and 'line

In an 'include directive, the contents of the named file are inserted in place of this line. The included files may themselves contain compiler directives. Currently there is no difference between the "..." and <...> forms. A macroInvocation should expand to one of the other two forms. The file name may be absolute, or relative to the current directory.

```
\begin{array}{lll} compiler Directive & ::= & \text{`line line Number "filename" level} \\ line Number & ::= & dec Literal \\ level & ::= & 0 \mid 1 \mid 2 \end{array}
```

A 'line directive is terminated by a newline, i.e., it cannot have any other source text after the *level*. The compiler automatically keeps track of the source file name and line number for every line of source text (including from included source files), so that error messages can be properly correlated to the source. This directive effectively overrides the compiler's internal tracking mechanism, forcing it to regard the next line onwards as coming from the given source file and line number. It is generally not necessary to use this directive explicitly; it is mainly intended to be generated by other preprocessors that may themselves need to alter the source files before passing them through the BSV compiler; this mechanism allows proper references to the original source.

The *level* specifier is either 0, 1 or 2:

- 1 indicates that an include file has just been entered
- 2 indicates that an include file has just been exited
- 0 is used in all other cases

2.7.2 Macro definition and substitution: 'define and related directives

```
compiler Directive ::= 'define macro Name [ ( macro Formals ) ] macro Text
macro Name ::= identifier
macro Formals ::= identifier { , identifier }
```

The 'define directive is terminated by a bare newline. A backslash (\) just before a newline continues the directive into the next line. When the macro text is substituted, each such continuation backslash-newline is replaced by a newline.

The *macroName* is an identifier and may be followed by formal arguments, which are a list of comma-separated identifiers in parentheses. For both the macro name and the formals, lower and upper case are acceptable (but case is distinguished). The *macroName* cannot be any of the compiler directives (such as include, define, ...).

The scope of the formal arguments extends to the end of the macro Text.

The *macroText* represents almost arbitrary text that is to be substituted in place of invocations of this macro. The *macroText* can be empty.

One-line comments (i.e., beginning with //) may appear in the *macroText*; these are not considered part of the substitutable text and are removed during substitution. A one-line comment that is not on the last line of a 'define directive is terminated by a backslash-newline instead of a newline.

A block comment (/*...*/) is removed during substitution and replaced by a single space.

The macro Text can also contain the following special escape sequences:

- '" Indicates that a double-quote (") should be placed in the expanded text.
- '\'" Indicates that a backslash and a double-quote (\") should be placed in the expanded text.
- '' Indicates that there should be no whitespace between the preceding and following text. This allows construction of identifiers from the macro arguments.

A minimal amount of lexical analysis of macroText is done to identify comments, string literals, identifiers representing macro formals, and macro invocations. As described earlier, one-line comments are removed. The text inside string literals is not interpreted except for the usual string escape sequences described in Section 2.5.

There are two define macros in the define environment initially; 'bluespec and 'BLUESPEC.

Once defined, a macro can be invoked anywhere in the source text (including within other macro definitions) using the following syntax.

```
compiler Directive ::= macro Invocation \\ macro Invocation ::= `macro Name [ ( macro Actuals ) ] \\ macro Actuals ::= subst Text { , subst Text }
```

The macroName must refer to a macro definition available at expansion time. The macroActuals, if present, consist of substitution text substText that is arbitrary text, possibly spread over multiple lines, excluding commas. A minimal amount of parsing of this substitution text is done, so that commas that are not at the top level are not interpreted as the commas separating macroActuals. Examples of such "inner" uninterpreted commas are those within strings and within comments.

```
compiler Directive ::= `undef macroName | `resetall
```

The 'undef directive's effect is that the specified macro (with or without formal arguments) is no longer defined for the subsequent source text. Of course, it can be defined again with 'define in the subsequent text. The 'resetall directive has the effect of undefining all currently defined macros, i.e., there are no macros defined in the subsequent source text.

2.7.3 Conditional compilation: 'ifdef and related directives

These directives are used together in either an 'ifdef-endif sequence or an ifndef-endif sequence. In either case, the sequence can contain zero or more elsif directives followed by zero or one else directives. These sequences can be nested, i.e., each 'ifdef or ifndef introduces a new, nested sequence until a corresponding endif.

In an 'ifdef sequence, if the *macroName* is currently defined, the subsequent text is processed until the next corresponding elsif, else or endif. All text from that next corresponding elsif or else is ignored until the endif.

If the *macroName* is currently not defined, the subsequent text is ignored until the next corresponding 'elsif, 'else or 'endif. If the next corresponding directive is an 'elsif, it is treated just as if it were an 'ifdef at that point.

If the 'ifdef and all its corresponding 'elsifs fail (macros were not defined), and there is an 'else present, then the text between the 'else and 'endif is processed.

An 'ifndef sequence is just like an 'ifdef sequence, except that the sense of the first test is inverted, i.e., its following text is processes if the *macroName* is *not* defined, and its 'elsif and 'else arms are considered only if the macro is defined.

Example using 'ifdef to determine the size of a register:

```
'ifdef USE_16_BITS
   Reg#(Bit#(16)) a_reg <- mkReg(0);
'else
   Reg#(Bit#(8)) a_reg <- mkReg(0);
'endif</pre>
```

3 Packages and the outermost structure of a BSV design

A BSV program consists of one or more outermost constructs called packages. All BSV code is assumed to be inside a package. Further, the BSV compiler and other tools assume that there is one package per file, and they use the package name to derive the file name. For example, a package called Foo is assumed to be located in a file Foo.bsv.

A BSV package is purely a linguistic namespace-management mechanism and is particularly useful for programming in the large, so that the author of a package can choose identifiers for the package components freely without worrying about choices made by authors of other packages. Package structure is usually uncorrelated with hardware structure, which is specified by the module construct.

A package contains a collection of top-level statements that include specifications of what it imports from other packages, what it exports to other packages, and its definitions of types, interfaces, functions, variables, and modules. BSV tools ensure that when a package is compiled, all the packages that it imports have already been compiled.

```
package
                      ::= package packageIde;
                          { exportDecl }
                          \{importDecl\}
                          { packageStmt }
                          endpackage [ : packageIde ]
exportDecl
                      ::= export exportItem { , exportItem } ;
exportItem
                      ::= identifier [ (...) ]
                          Identifier [ (...) ]
                          packageIde :: *
importDecl
                          import importItem { , importItem } ;
                          packageIde :: *
importItem
packageStmt
                          moduleDef
                          interface Decl
                          typeDef
                          varDecl | varAssign
                          functionDef
                          typeclassDef
                          typeclassInstanceDef
                           externModuleImport
packageIde
                      ::= Identifier
```

The name of the package is the identifier following the package keyword. This name can optionally be repeated after the endpackage keyword (and a colon). We recommend using an uppercase first letter in package names. In fact, the package and endpackage lines are optional: if they are absent, BSV derives the assumed package name from the filename.

An export item can specify an identifier defined elsewhere within the package, making the identifier accessible outside the package. An export item can also specify an identifier from an imported package. In that case, the imported identifier is re-exported from this package, so that it is accessible by importing this package (without requiring the import of its source package). It is also possible

to re-export all of the identifiers from an imported package by using the following syntax: export packageIde::*.

If there are any export statements in a package, then only those items are exported. If there are no export statements, by default all identifiers defined in this package (and no identifiers from any imported packages) are exported.

If the exported identifier is the name of a struct (structure) or union type definition, then the members of that type will be visible only if (..) is used. By omitting the (..) suffix, only the type, but not its members, are visible outside the package. This is a way to define abstract data types, i.e., types whose internal structure is hidden. When the exported identifier is not a structure or union type definition, the (..) has no effect on the exported identifier.

Each import item specifies a package from which to import identifiers, i.e., to make them visible locally within this package. For each imported package, all identifiers exported from that package are made locally visible.

Example:

```
package Foo;
export x;
export y;
import Bar::*;
... top level definition ...
... top level definition ...
... top level definition ...
endpackage: Foo
```

Here, Foo is the name of this package. The identifiers x and y, which must be defined by the top-level definitions in this package are names exported from this package. From package Bar we import all its definitions. To export all identifiers from packages Foo and Bar, add the statement: export Foo ::*

3.1 Scopes, name clashes and qualified identifiers

BSV uses standard static scoping (also known as lexical scoping). Many constructs introduce new scopes nested inside their surrounding scopes. Identifiers can be declared inside nested scopes. Any use of an identifier refers to its declaration in the nearest textually surrounding scope. Thus, an identifier \mathbf{x} declared in a nested scope "shadows", or hides, any declaration of \mathbf{x} in surrounding scopes. We recommend, however, that the programmer avoids such shadowing, because it often makes code more difficult to read.

Packages form the the outermost scopes. Examples of nested scopes include modules, interfaces, functions, methods, rules, action and actionvalue blocks, begin-end statements and expressions, bodies of for and while loops, and seq and par blocks.

When used in any scope, an identifier must have an unambiguous meaning. If there is name clash for an identifier x because it is defined in the current package and/or it is available from one or more imported packages, then the ambiguity can be resolved by using a qualified name of the form P :: x to refer to the version of x contained in package P.

3.2 The Standard Prelude package

The Standard Prelude is a predefined package that is imported implicitly into every BSV package, i.e., it does not need an explicit import statement. It contains a number of useful predefined entities (types, values, functions, modules, etc.). The Standard Prelude package is described in more detail in appendix B. Reusing the name of Prelude entity when defining other entities, which would require the entity's name to be qualified with the package name, is strongly discouraged.

3.3 AzureIPTM Foundation Libraries

Section C describes the collection of AzureIP Foundation library packages. To use any of the constructs or components of these packages you must explicitly import the library package using an import clause. Many common constructs, such as FIFOs and Vectors are provided in the library.

4 Types

Bluespec provides a strong, static type-checking environment; every variable and every expression in BSV has a *type*. Variables must be assigned values which have compatible types. Type checking, which occurs before program elaboration or execution, ensures that object types are compatible and applied functions are valid for the context and type.

Data types in BSV are case sensitive. The first character of a type is almost always uppercase, the only exceptions being the types int and bit for compatibility with Verilog.

The syntax of types (type expressions) is given below:

```
type & ::= typePrimary \\ | typePrimary (type { , type } ) & Function type \\ typePrimary & ::= typeIde [ # (type { , type } ) ] \\ | typeNat \\ | bit [ typeNat : typeNat ] \\ typeIde & ::= Identifier \\ typeNat & ::= decDigits
```

The Prelude package defines many common datatypes (Section B.2). Other types are defined in the Foundation library packages (Section C) and users can define new types (Section 7). The following tables list some of the more commonly used types. Refer to the Prelude and Foundation library packages for additional types.

Common Bit Types Defined in Prelude(B.2)							
Bit types are synthesizable							
Type	Description	Section					
Bit#(n)	Polymorphic data type containing n bits	B.2.1					
UInt#(n)	Unsigned fixed-width representation of an integer	B.2.2					
	value of n bits						
Int#(n)	Signed fixed-width representation of an integer	B.2.3					
	value of n bit						
Bool	Type which can have two values, True or False	B.2.5					
Maybe	Used to tag values as Valid or Invalid, where	B.2.10					
	valid values contain data						
Tuples	Predefined structures which group a samll number	B.2.12					
	of values together						

Common Non-Bit Types Defined in Prelude(B.2)									
Type	Description	Section							
Integer	Non-synthesizable data type used for integer values and functions	B.2.4							
Real	Non-synthesizable data type which can represent numbers with a fractional component	B.2.6, C.5.1							
String	Data type representing string literals	B.2.7							
Fmt	Representation of arguments to the \$display family of tasks	B.2.8							

Common Interface Types Defined in Prelude and Foundation Library Packages			
Type	Description	Section	
Reg	Register interface	B.4.1	
FIFO	FIFO interfaces	C.2.2	
Clock	Abstract type with a oscillator and a gate	B.2.13, C.9	
Reset	Abstract type for a reset	B.2.14, C.9	
Inout	Type used to pass Verilog inouts through a BSV	B.2.15	
	module		

Types Used by the Compiler			
Type	Description	Section	
Action	An expression intended to act on the state of the circuit	B.2.16	
ActionValue	An expression intended to act on the state of the circuit	B.2.16	
Rules	Used to represent one or more rules as a first class type	B.2.17	

Examples of simple types:

```
Integer // Unbounded signed integers, for static elaboration only int // 32-bit signed integers
Bool String Action
```

Type expressions of the form $X\#(t_1,\dots,t_N)$ are called *parameterized* types. X is called a *type constructor* and the types t_1,\dots,t_N are the parameters of X. Examples:

```
Tuple2#(int,Bool)  // pair of items, an int and a Bool
Tuple3#(int,Bool,String)  // triple of items, an int, a Bool and a String
List#(Bool)  // list containing booleans
List#(List#(Bool))  // list containing lists of booleans
RegFile#(Integer, String)  // a register file (array) indexed by integers, containing strings
```

Type parameters can be natural numbers (also known as *numeric* types). These usually indicate some aspect of the size of the type, such as a bit-width or a table capacity. Examples:

```
Bit#(16)  // 16-bit wide bit-vector (16 is a numeric type)
bit [15:0]  // synonym for Bit#(16)

UInt#(32)  // unsigned integers, 32 bits wide
Int#(29)  // signed integers, 29 bits wide

Vector#(16,Int#(29)  // Vector of size 16 containing Int#(29)'s
```

Currently the second index n in a bit [m:n] type must be 0. The type bit [m:0] represents the type of bit vectors, with bits indexed from m (msb/left) down through 0 (lsb/right), for $m \ge 0$.

4.1 Polymorphism

A type can be *polymorphic*. This is indicated by using type variables as parameters. Examples:

The type variables represent unknown (but specific) types. In other words, List#(a) represents the type of a list containing items all of which have some type a. It does not mean that different elements of a list can have different types.

4.2 Provisos (brief intro)

Provisos are described in detail in Section 14.1.1, and the general facility of type classes (overloading groups), of which provisos form a part, is described in Section 14.1. Here we provide a brief description, which is adequate for most uses and for continuity in a serial reading of this manual.

A proviso is a static condition attached to certain constructs, to impose certain restrictions on the types involved in the construct. The restrictions are of two kinds:

- Require instance of a type class (overloading group): this kind of proviso states that certain types must be instances of certain type classes, i.e., that certain overloaded functions are defined on this type.
- Require size relationships: this kind of proviso expresses certain constraints between the sizes of certain types.

The most common overloading provisos are:

```
Bits#(t,n)
               // Type class (overloading group) Bits
               // Meaning: overloaded operators pack/unpack are defined
                      on type t to convert to/from Bit#(n)
               //
Eq#(t)
               // Type class (overloading group) Eq
               // Meaning: overloaded operators == and != are defined on type t
Literal#(t)
               // Type class (overloading group) Literal
               // Meaning: Overloaded function fromInteger() defined on type t
                      to convert an integer literal to type t. Also overloaded
               //
               //
                      function inLiteralRange to determine if an Integer
               //
                      is in the range of the target type t.
Ord#(t)
               // Type class (overloading group) Ord
               // Meaning: Overloaded order-comparison operators <, <=,
                      > and >= are defined on type t
Bounded#(t)
               // Type class (overloading group) Bounded
               // Meaning: Overloaded identifiers minBound and maxBound
```

```
//
                       are defined for type t
                // Type class (overloading group) Bitwise
 Bitwise#(t)
                // Meaning: Overloaded operators &, |, ^, ~^, ~^, ~, << and >>
                       and overloaded function invert are defined on type t
BitReduction#(t)// Type class (overloading group) BitReduction
                // Meaning: Overloaded prefix operators &, |, ^,
                       ^{\sim}&, ^{\sim}I, ^{\sim}, and ^{\sim} are defined on type t
BitExtend#(t) // Type class (overloading group) BitExtend
                // Meaning: Overloaded functions extend, zeroExtend, signExtend
                       and truncate are defined on type t
 Arith#(t)
                // Type class (overloading group) Arith
                // Meaning: Overloaded operators +, -, and *, and overloaded
                       prefix operator - (same as function negate), and
                //
                //
                       overloaded function negate are defined on type t
The size relationship provisos are:
                   // Meaning: assert n1 + n2 = n3
 Add#(n1,n2,n3)
Mul#(n1,n2,n3)
                   // Meaning: assert n1 * n2 = n3
                   // Meaning: assert ceiling n1 / n2 = n3
Div#(n1,n2,n3)
Max#(n1,n2,n3)
                   // Meaning: assert max(n1,n2) = n3
Log#(n1,n2)
                   // Meaning: assert ceiling(log(n1)) = n2
                   // The logarithm is base 2
Example:
module mkExample (ProvideCurrent#(a))
  provisos(Bits#(a, sa), Arith#(a));
  Reg#(a) value_reg <- mkReg(?); // requires that type "a" be in the Bits typeclass.</pre>
   rule every;
      value_reg <= value_reg + 1; // requires that type "a" be in the Arith typeclass.</pre>
   endrule
Example:
 function Bit#(m) pad0101 (Bit#(n) x)
    provisos (Add\#(n,4,m)); // m is 4 bits longer than n
    pad0101 = { x, 0b0101 };
 endfunction: pad0101
```

This defines a function pad0101 that takes a bit vector \mathbf{x} and pads it to the right with the four bits "0101" using the standard bit-concatenation notation. The types and proviso express the idea that the function takes a bit vector of length n and returns a bit vector of length m, where n+4=m. These provisos permit the BSV compiler to statically verify that entities (values, variables, registers, memories, FIFOs, and so on) have the correct bit-width.

4.2.1 The pseudo-function value of (or value Of)

To get the value that corresponds to a size type, there is a special pseudo-function, valueof, that takes a size type and gives the corresponding Integer value. The pseudo-function is also sometimes written as valueOf; both are considered correct.

```
exprPrimary ::= valueof ( type ) | valueOf ( type )
```

In other words, it converts from a numeric type expression into an ordinary value. These mechanisms can be used to do arithmetic to derive dependent sizes. Example:

```
function ... foo (Vector#(n,int) xs) provisos (Log#(n,k));
   Integer maxindex = valueof(n) - 1;
   Int#(k) index;
   index = fromInteger(maxindex);
   ...
endfunction
```

This function takes a vector of length n as an argument. The proviso fixes k to be the (ceiling of the) logarithm of n. The variable index has bit-width k, which will be adequate to hold an index into the list. The variable is initialized to the maximum index.

Note that the function foo may be invoked in multiple contexts, each with a different vector length. The compiler will statically verify that each use is correct (e.g., the index has the correct width).

The pseudo-function valueof, which converts a numeric type to a value, should not be confused with the pseudo-function SizeOf, described in Section 14.1.5, which converts a type to a numeric type.

4.3 A brief introduction to deriving clauses

The deriving clause is a part of the general facility of type classes (overloading groups), which is described in detail in Section 14.1. Here we provide a brief description, which is adequate for most uses and for continuity in a serial reading of this manual.

It is possible to attach a deriving clause to a type definition (Section 7), thereby directing the compiler to define automatically certain overloaded functions for that type. The most common forms of these clauses are:

```
method Action process(Severity value);
    // value is a variable of type Severity
    if (value == URGENT) $display("WARNING: Urgent severity encountered.");
    // Since value is of the type Severity, == is defined
    endmethod
endmodule
```

5 Modules and interfaces, and their instances

Modules and interfaces form the heart of BSV. Modules and interfaces turn into actual hardware. An interface for a module m mediates between m and other, external modules that use the facilities of m. We often refer to these other modules as *clients* of m.

In SystemVerilog and BSV we separate the declaration of an interface from module definitions. There was no such separation in Verilog 1995 and Verilog 2001, where a module's interface was represented by its port list, which was part of the module definition itself. By separating the interface declaration, we can express the idea of a common interface that may be offered by several modules, without having to repeat that declaration in each of the implementation modules.

As in Verilog and SystemVerilog, it is important to distinguish between a module *definition* and a module *instantiation*. A module definition can be regarded as specifying a scheme that can be instantiated multiple times. For example, we may have a single module definition for a FIFO, and a particular design may instantiate it multiple times for all the FIFOs it contains.

Similarly, we also distinguish interface declarations and instances, i.e., a design will contain interface declarations, and each of these may have multiple instances. For example an interface declaration I may have one instance i_1 for communication between module instances a_1 and b_1 , and another instance i_2 for communication between module instances a_2 and b_2 .

Module instances form a pure hierarchy. Inside a module definition mkM, one can specify instantiations of other modules. When mkM is used to instantiate a module m, it creates the specified inner module instances. Thus, every module instance other than the top of the hierarchy unambiguously has a single parent module instance. We refer to the top of the hierarchy as the root module. Every module instance has a unique set, possibly empty, of child module instances. If there are no children, we refer to it as a leaf module.

A module consists of three things: state, rules that operate on that state, and the module's interface to the outside world (surrounding hierarchy). The state conceptually consists of all state in the sub-hierarchy headed by this module; ultimately, it consists of all the lower leaf module instances (see next section on state and module instantiation). Rules are the fundamental means to express behavior in BSV (instead of the always blocks used in traditional Verilog). In BSV, an interface consists of methods that encapsulate the possible transactions that clients can perform, i.e., the micro-protocols with which clients interact with the module. When compiled into RTL, an interface becomes a collection of wires.

5.1 Explicit state via module instantiation, not variables

In Verilog and SystemVerilog RTL, one simply declares variables, and a synthesis tool "infers" how these variables actually map into state elements in hardware using, for example, their lifetimes relative to events. A variable may map into a bus, a latch, a flip-flop, or even nothing at all. This ambiguity is acknowledged in the Verilog 2001 and SystemVerilog LRMs.¹

¹In the Verilog 2001 LRM, Section 3.2.2, Variable declarations, says: "A *variable* is an abstraction of a data storage element. · · · NOTE In previous versions of the Verilog standard, the term *register* was used to encompass both the **reg**, **integer**, **time**, **real** and **realtime** types; but that term is no longer used as a Verilog data type."

In the SystemVerilog LRM, Section 5.1 says: "Since the keyword reg no longer describes the user's intent in many cases, · · · Verilog-2001 has already deprecated the use of the term register in favor of variable."

BSV removes this ambiguity and places control over state instantiation explicitly in the hands of the designer. From the smallest state elements (such as registers) to the largest (such as memories), all state instances are specified explicitly using module instantiation.

Conversely, an ordinary declared variable in BSV never implies state, i.e., it never holds a value over time. Ordinary declared variables are always just convenient names for intermediate values in a computation. Ordinary declared variables include variables declared in blocks, formal parameters, pattern variables, loop iterators, and so on. Another way to think about this is that ordinary variables play a role only in static elaboration, not in the dynamic semantics. This is one of the aspects of BSV style that may initially appear unusual to the Verilog or SystemVerilog programmer.

Example:

5.2 Interface declaration

In BSV an interface contains members that are called *methods* (an interface may also contain subinterfaces, which are described in Section 5.2.1). To first order, a method can be regarded exactly like a function, i.e., it is a procedure that takes zero or more arguments and returns a result. Thus, method declarations inside interface declarations look just like function prototypes, the only difference being the use of the keyword method instead of the keyword function. Each method represents one kind of transaction between a module and its clients. When translated into RTL, each method becomes a bundle of wires.

The fundamental difference between a method and a function is that a method also carries with it a so-called implicit condition. These will be described later along with method definitions and rules.

An interface declaration also looks similar to a struct declaration. One can think of an interface declaration as declaring a new type similar to a struct type (Section 7), where the members all happen to be method prototypes. A method prototype is essentially the header of a method definition (Section 5.5).

```
interfaceDecl & ::= [ \ attributeInstances \ ] \\ interface \ typeDefType ; \\ \{ \ interfaceMemberDecl \ \} \\ endinterface [ : typeIde \ ] \\ typeDefType & ::= typeIde [ \ typeFormals \ ] \\ typeFormals & ::= \# ( \ typeFormal \ \{ \ , \ typeFormal \ \} ) \\ typeFormal & ::= [ \ numeric \ ] \ typeIde \\ interfaceMemberDecl & ::= methodProto \ | \ subinterfaceDecl \ \}
```

```
::= [attributeInstances]
  methodProto
                           method type identifier ( [ methodProtoFormals ] );
                           methodProtoFormal { , methodProtoFormal }
  methodProtoFormals
                      ::=
  methodProtoFormal
                      ::=
                           [ attributeInstances ] type identifier
Example: a stack of integers:
interface IntStack;
     method Action push
                             (int x);
     method
             Action
                      pop;
     method int
                      top;
endinterface: IntStack
```

This describes an interface to a circuit that implements a stack (LIFO) of integers. The push method takes an int argument, the item to be pushed onto the stack. Its output type is Action, namely it returns an *enable* wire which, when asserted, will carry out the pushing action.² The pop method takes no arguments, and simply returns an enable wire which, when asserted, will discard the element from the top of the stack. The top method takes no arguments, and returns a value of type int, i.e., the element at the top of the stack.

What if the stack is empty? In that state, it should be illegal to use the pop and top methods. This is exactly where the difference between methods and functions arises. Each method has an implicit ready wire, which governs when it is legal to use it, and these wires for the pop and top methods will presumably be de-asserted if the stack is empty. Exactly how this is accomplished is an internal detail of the module, and is therefore not visible as part of the interface declaration. (We can similarly discuss the case where the stack has a fixed, finite depth; in this situation, it should be illegal to use the push method when the stack is full.)

One of the major advantages of BSV is that the compiler automatically generates all the control circuitry needed to ensure that a method (transaction) is only used when it is legal to use it.

Interface types can be polymorphic, i.e., parameterized by other types. For example, the following declaration describes an interface for a stack containing an arbitrary but fixed type:

```
interface Stack#(type a);
  method Action push (a x);
  method Action pop;
  method a top;
endinterface: Stack
```

We have replaced the previous specific type int with a type variable a. By "arbitrary but fixed" we mean that a particular stack will specify a particular type for a, and all items in that stack will have that type. It does not mean that a particular stack can contain items of different types.

For example, using this more general definition, we can also define the IntStack type as follows:

```
typedef Stack#(int) IntStack;
```

i.e., we simply specialize the more general type with the particular type int. All items in a stack of this type will have the int type.

Usually there is information within the interface declaration which indicates whether a polymorphic interface type is numeric or nonnumeric. The optional numeric is required before the type when the interface type is polymorphic and must be numeric but there is no information in the interface declaration which would indicate that the type is numeric.

For example, in the following polymorphic interface, count_size must be numeric because it is defined as a parameter to Bit#().

² The type Action is discussed in more detail in Section 9.6.

```
interface Counter#(type count_size);
  method Action increment();
  method Bit#(count_size) read();
endinterface
```

From this use, it can be deduced that Counter's parameter count_size must be numeric. However, sometimes you might want to encode a size in an interface type which isn't visible in the methods, but is used by the module implementing the interface. For instance:

```
interface SizedBuffer#(numeric type buffer_size, type element_type);
  method Action enq(element_type e);
  method ActionValue#(element_type) deq();
endinterface
```

In this interface, the depth of the buffer is encoded in the type. For instance, SizedBuffer#(8, Bool) would be a buffer of depth 8 with elements of type Bool. The depth is not visible in the interface, but is used by the module to know how much storage to instantiate.

Because the parameter is not mentioned anywhere else in the interface, there is no information to determine whether the parameter is a numeric type or a non-numeric type. In this situation, the default is to assume that the parameter is non-numeric. The user can override this default by specifying numeric in the interface declaration.

The Standard Prelude defines a standard interface called Empty which contains no methods, i.e., its definition is:

```
interface Empty;
endinterface
```

This is often used for top-level modules that integrate a testbench and a design-under-test, and for modules like mkConnection(C.7.2) that just take interface arguments and do not themselves offer any interesting interface.

5.2.1 Subinterfaces

Note: this is an advanced topic that may be skipped on first reading.

Interfaces can also be declared hierarchically, using subinterfaces.

where typeDefType is another interface type available in the current scope. Example:

```
interface ILookup;
  interface Server#(RequestType, ResponseType) mif;
  interface RAMclient#(AddrType, DataType) ram;
  method Bool initialized;
endinterface: ILookup
```

This declares an interface ILookup module that consists of three members: a Server subinterface called mif, a RAMClient subinterface called ram, and a boolean method called initialized (the Server and RAMClient interface types are defined in the libraries, see Appendix C). Methods of subinterfaces are accessed using dot notation to select the desired component, e.g.,

```
ilookup.mif.request.put(...);
```

Since Clock and Reset are both interface types, they can be used in interface declarations. Example:

```
interface ClockTickIfc ;
  method Action tick() ;
  interface Clock new_clk ;
endinterface
```

5.3 Module definition

A module definition begins with a module header containing the module keyword, the module name, parameters, arguments, interface type and provisos. The header is followed by zero or more module statements. Finally we have the closing endmodule keyword, optionally labelled again with the module name.

```
moduleDef \qquad ::= [ \ attributeInstances \ ] \\ moduleProto \\ \qquad \qquad \qquad \{ \ moduleStmt \ \} \\ endmodule [ \ : \ identifier \ ] \\ moduleProto \qquad ::= \ module [ \ [ \ type \ ] \ ] \ identifier \\ \qquad \qquad [ \ moduleFormalParams \ ] \ ( \ [ \ moduleFormalArgs \ ] \ ) \ [ \ provisos \ ]; \\ moduleFormalParam \qquad ::= \ \# \ (moduleFormalParam \ \{ \ , \ moduleFormalParam \ \}) \\ moduleFormalParam \qquad ::= \ [ \ attributeInstances \ ] \ [ \ parameter \ ] \ type \ identifier \\ moduleFormalArgs \qquad ::= \ [ \ attributeInstances \ ] \ type \ identifier \\ \qquad \qquad \{ \ , \ [ \ attributeInstances \ ] \ type \ identifier \ \}
```

As a stylistic convention, many BSV examples use module names like mkFoo, i.e., beginning with the letters mk, suggesting the word make. This serves as a reminder that a module definition is not a module instance. When the module is instantiated, one invokes mkFoo to actually create a module instance.

The optional moduleFormalParams are exactly as in Verilog and SystemVerilog, i.e., they represent module parameters that must be supplied at each instantiation of this module, and are resolved at elaboration time. The optional keyword parameter specifies a Verilog parameter is to be generated; without the keyword a Verilog port is generated. A Verilog parameter requires that the value is a constant at elaboration. When the module is instantiated, the actual expression provided for the parameter must be something that can be computed using normal Verilog elaboration rules. The bluespec compiler will check for this. The parameter keyword is only relevant when the module is marked with the synthesize attribute.

Inside the module, the parameter keyword can be used for a parameter n that is used, for example, for constants in expressions, register initialization values, and so on. However, n cannot be used for structural variations in the module, such as declaring an array of n registers. Such structural decisions (*generate* decisions) are taken by the Bluespec compiler, and cannot currently be postponed into the Verilog.

The optional moduleFormalArgs represent the interfaces used by the module, such as clocks or wires. The final argument is a single interface provided by the module instead of Verilog's port list. The interpretation is that this module will define and offer an interface of that type to its clients. If the only argument is the interface, only the interface type is required. If there are other arguments, both a type and an identifier must be specified for consistency, but the final interface name will not be used in the body. Omitting the interface type completely is equivalent to using the pre-defined Empty interface type, which is a trivial interface containing no methods.

The arguments and parameters may be enclosed in a single set of parentheses, in which case the # would be omitted.

Provisos, which are optional, come next. These are part of an advanced feature called type classes (overloading groups), and are discussed in more detail in Section 14.1.

Examples

A module with parameters and an interface.

The above module definition may also be written with the arguments and parameters combined in a single set of parentheses.

The body of the module consists of a sequence of moduleStmts:

Most of these are discussed elsewhere since they can also occur in other contexts (e.g., in packages, function bodies, and method bodies). Below, we focus solely on those statements that are found only in module bodies or are treated specially in module bodies.

5.4 Module and interface instantiation

Module instances form a hierarchy. A module definition can contain specifications for instantiating other modules, and in the process, instantiating their interfaces. A single module definition may be instantiated multiple times within a module.

5.4.1 Short form instantiation

There is a one-line shorthand for instantiating a module and its interfaces.

The statement first declares an identifier with an interface type. After the <- symbol, we have a module application, consisting of a module *identifier* optionally followed by a list of parameters and arguments, if the module is defined to have parameters and arguments. Note that the parameters and the arguments are within a single set of parentheses, the parameters listed first, and there is no # before the list.

Each module has an implicit clock and reset. These defaults can be changed by explicitly specifying a clocked_by or reset_by argument in the module instantiation.

An optional documentation attribute (Section 13.7) placed before the module instantiation will place a comment in the generated Verilog file.

The following skeleton illustrates the structure and relationships between interface and module definition and instantiation.

```
ArithIO#(bit [31:0]) gcdIfc <- mkGCD (5, clocked_by dClkIn);
...
endmodule: mkTest</pre>
```

The following example shows an module instantiation using a clocked_by statement.

```
interface Design_IFC;
   method Action start(Bit#(3) in_data1, Bit#(3) in_data2, Bool select);
   interface Clock clk_out;
   method Bit#(4) out_data();
endinterface : Design_IFC

module mkDesign(Clock prim_clk, Clock sec_clk, Design_IFC ifc);
   ...
   RWire#(Bool) select <- mkRWire (select, clocked_by sec_clk);
   ...
endmodule:mkDesign</pre>
```

5.4.2 Long form instantiation

A module instantiation can also be written in its full form on two consecutive lines, as typical in SystemVerilog. The full form specifies names for both the interface instance and the module instance. In the shorthand described above, there is no name provided for the module instance and the compiler infers one based on the interface name. This is often acceptable because module instance names are only used occasionally in debugging and in hierarchical names.

An optional documentation attribute (Section 13.7) placed before the module instantiation will place a comment in the generated Verilog file.

The first line of the long form instantiation declares an identifier with an interface type. The second line actually instantiates the module and defines the interface. The moduleApp2 is the module (definition) identifier, and it must be applied to actual parameters (in #(...)) if it had been defined to have parameters. After the moduleApp, the first identifier names the new module instance. This may be followed by one or more moduleActualArg which define the arguments being used by the module. The last identifier (in parentheses) of the moduleActualArg must be the same as the interface identifier declared immediately above. It may be followed by a $clocked_by$ or $reset_by$ statement.

The following examples show the complete form of the module instantiations of the examples shown above.

```
//declares a module mkTest
module mkTest ();
                                        //
   ArithIO#(bit [31:0]) gcdIfc();
                                        //declares the interface instance
  mkGCD#(5) a_GCD (gcdIfc);
                                        //instantiates module mkGCD
                                        //sets N=5, names module instance a_GCD
endmodule: mkTest
                                        //and interface instance gcdIfc
module mkDesign(Clock prim_clk, Clock sec_clk, Design_IFC ifc);
   RWire#(Bool)
                    select();
  mkRWire
                    t_select(select, clocked_by sec_clk);
endmodule:mkDesign
```

5.5 Interface definition (definition of methods)

A module definition contains a definition of its interface. Typically this takes the form of a collection of definitions, one for each method in its interface. Each method definition begins with the keyword method, followed optionally by the return-type of the method, then the method name, its formal parameters, and an optional implicit condition. After this comes the method body which is exactly like a function body. It ends with the keyword endmethod, optionally labelled again with the method name.

```
moduleStmt
                      methodDef
methodDef
                      method [ type ] identifier ( methodFormals ) [ implicitCond ];
                          functionBody
                       endmethod [ : identifier ]
                      methodFormal { , methodFormal }
methodFormals
                      [ type ] identifier
methodFormal
implicitCond
                   ::= if ( condPredicate )
cond Predicate \\
                       exprOrCondPattern
                       expression
                  ::=
                       expression matches pattern
```

The method name must be one of the methods in the interface whose type is specified in the module header. Each of the module's interface methods must be defined exactly once in the module body.

The compiler will issue a warning if a method is not defined within the body of the module.

The return type of the method and the types of its formal arguments are optional, and are present for readability and documentation purposes only. The compiler knows these types from the method prototypes in the interface declaration. If specified here, they must exactly match the corresponding types in the method prototype.

The implicit condition, if present, may be a boolean expression, or it may be a pattern-match (pattern matching is described in Section 10). Expressions in the implicit condition can use any of the variables in scope surrounding the method definition, i.e., visible in the module body, but they cannot use the formal parameters of the method itself. If the implicit condition is a pattern-match, any variables bound in the pattern are available in the method body. Omitting the implicit condition is equivalent to saying if (True). The semantics of implicit conditions are discussed in Section 9.13, on rules.

Every method is ultimately invoked from a rule (a method m_1 may be invoked from another method m_2 which, in turn, may be invoked from another method m_3 , and so on, but if you follow the chain, it will end in a method invocation inside a rule). A method's implicit condition controls whether the invoking rule is enabled. Using implicit conditions, it is possible to write client code that is not cluttered with conditionals that test whether the method is applicable. For example, a client of a FIFO module can just call the enqueue or the dequeue method without having explicitly to test whether the FIFO is full or empty, respectively; those predicates are usually specified as implicit conditions attached to the FIFO methods.

Please note carefully that the implicit condition precedes the semicolon that terminates the method definition header. There is a very big semantic difference between the following:

The only syntactic difference is the position of the semicolon. In the first case, if (expr) is an implicit condition on the method. In the second case the method has no implicit condition, and if (expr) starts a conditional statement inside the method. In the first case, if the expression is false, any rule that invokes this method cannot fire, i.e., no action in the rule or the rest of this method is performed. In the second case, the method does not prevent an invoking rule from firing, and if the rule does fire, the conditional statement is not executed but other actions in the rule and the method may be performed.

The method body is exactly like a function body, which is discussed in Section 8.8 on function definitions.

See also Section 9.12 for the more general concepts of interface expressions and expressions as first-class objects.

Example:

```
// interface is declared
interface GrabAndGive;
    method Action grab(Bit#(8) value); // method grab is declared
    method Bit#(8) give();
                                         // method give is declared
 endinterface
module mkExample (GrabAndGive);
    Reg#(Bit#(8)) value_reg <- mkReg(?);</pre>
    Reg#(Bool) not_yet <- mkReg(True);</pre>
    // method grab is defined
    method Action grab(Bit#(8) value) if (not_yet);
       value_reg <= value;</pre>
       not_yet <= False;</pre>
    endmethod
    //method give is defined
    method Bit#(8) give() if (!not_yet);
       return value_reg;
    endmethod
 endmodule
```

5.5.1 Shorthands for Action and ActionValue method definitions

If a method has type Action, then the following shorthand syntax may be used. Section 9.6 describes action blocks in more detail.

```
methodDef ::= method Action identifier ( methodFormals ) [ implicitCond ]; { actionStmt } endmethod [ : identifier ]
```

i.e., if the type Action is used after the method keyword, then the method body can directly contain a sequence of *actionStmts* without the enclosing action and endaction keywords.

Similarly, if a method has type ActionValue(t) (Section 9.7), the following shorthand syntax may be used:

```
methodDef ::= method ActionValue #( type ) identifier ( methodFormals ) [ implicitCond ; ] { actionValueStmt } endmethod [ : identifier ]
```

i.e., if the type ActionValue(t) is used after the method keyword, then the method body can directly contain a sequence of actionStmts without the enclosing actionvalue and endactionvalue keywords.

Example: The long form definition of an Action method:

```
method grab(Bit#(8) value);
   action
       last_value <= value;
   endaction
endmethod</pre>
```

can be replaced by the following shorthand definition:

```
method Action grab(Bit#(8) value);
   last_value <= value;
endmethod</pre>
```

5.5.2 Definition of subinterfaces

Declaration of subinterfaces (hierarchical interfaces) was described in Section 5.2.1. A subinterface member of an interface can be defined using the following syntax.

```
moduleStmt
                      ::= subinterfaceDef
                      ::= interface Identifier\ identifier;
subinterfaceDef
                              { interfaceStmt }
                           endinterface [ : identifier ]
interfaceStmt
                      ::= methodDef
                           subinterface Def
                           expressionStmt
expressionStmt
                      ::= varDecl \mid varAssign
                           functionDef
                           moduleDef
                           <\!expression\!>\!BeginEndStmt
                           < expression > If \mid < expression > Case
                           < expression> For | < expression> While
```

The subinterface member is defined within interface-endinterface brackets. The first *Identifier* must be the name of the subinterface member's type (an interface type), without any parameters. The second *identifier* (and the optional *identifier* following the endinterface must be the subinterface member name. The *interfaceStmts* then define the methods or further nested subinterfaces of this member. Example (please refer to the ILookup interface defined in Section 5.2.1):

```
module ...
...
...
interface Server mif;

interface Put request;
    method put(...);
    ...
    endmethod: put
    endinterface: request

interface Get response;
    method get();
    ...
    endmethod: get
    endinterface: response

endinterface: mif
...
endmodule
```

5.5.3 Definition of methods and subinterfaces by assignment

Note: this is an advanced topic and can be skipped on first reading.

A method can also be defined using the following syntax.

The part up to and including the *implicitCond* is the same as the standard syntax shown in Section 5.5. Then, instead of a semicolon, we have an assignment to an expression that represents the method body. The expression can of course use the method's formal arguments, and it must have the same type as the return type of the method. See Sections 9.6 and 9.7 for how to construct expressions of Action type and ActionValue type, respectively.

A subinterface member can also be defined using the following syntax.

```
subinterfaceDef ::= interface [ type ] identifier = expression ;
```

The *identifier* is just the subinterface member name. The *expression* is an interface expression (described in Section 9.12) of the appropriate interface type.

For example, in the following module the subinterface Put is defined by assignment.

```
//in this module, there is an instanciated FIFO, and the Put interface
//of the "mkSameInterface" module is the same interface as the fifo's:
interface IFC1;
  interface Put#(int) in0;
endinterface
```

```
(*synthesize*)
module mkSameInterface (IFC1);
  FIFO#(int) myFifo <- mkFIFO;
  interface Put inO = fifoToPut(myFifo);
endmodule</pre>
```

5.6 Rules in module definitions

The internal behavior of a module is described using zero or more rules.

```
moduleStmt
                  ::= rule
                  ::= [ attributeInstances ]
rule
                      rule identifier [ ruleCond ];
                          ruleBody
                      endrule [ : identifier ]
ruleCond
                      ( condPredicate )
condPredicate
                      ::=
exprOrCondPattern
                      expression
                  ::=
                      expression matches pattern
ruleBody
                     \{actionStmt\}
```

A rule is optionally preceded by an *attributeInstances*; these are described in Section 13.3. Every rule must have a name (the *identifier*). If the closing **endrule** is labelled with an identifier, it must be the same name. Rule names must be unique within a module.

The *ruleCond*, if present, may be a boolean expression, or it may be a pattern-match (pattern matching is described in Section 10). It can use any identifiers from the scope surrounding the rule, i.e., visible in the module body. If it is a pattern-match, any variables bound in the pattern are available in the rule body.

The *ruleBody* must be of type Action, using a sequence of zero or more *actionStmts*. We discuss *actionStmts* in Section 9.6, but here we make a key observation. Actions include updates to state elements (including register writes). There are *no restrictions* on different rules updating the same state elements. The BSV compiler will generate all the control logic necessary for such shared update, including multiplexing, arbitration, and resource control. The generated control logic will ensure rule atomicity, discussed briefly in the next paragraphs.

A more detailed discussion of rule semantics is given in Section 6.2, Dynamic Semantics, but we outline the key point briefly here. The rule Cond is called the explicit condition of the rule. Within the rule Cond and rule Body, there may be calls to various methods of various interfaces. Each such method call has an associated implicit condition. The rule is enabled when its explicit condition and all its implicit conditions are true. A rule can fire, i.e., execute the actions in its rule Body, when the rule is enabled and when the actions cannot "interfere" with the actions in the bodies of other rules. Non-interference is described more precisely in Section 6.2 but, roughly speaking, it means that the rule execution can be viewed as an atomic state transition, i.e., there cannot be any race conditions between this rule and other rules.

This atomicity and the automatic generation of control logic to guarantee atomicity is a key benefit of BSV. Note that because of method calls in the rule and, transitively, method calls in those methods, a rule can touch (read/write) state that is distributed in several modules. Thus, a rule can express a major state change in the design. The fact that it has atomic semantics guarantees the absence of a whole class of race conditions that might otherwise bedevil the designer. Further, changes in the design, whether in this module or in other modules, cannot introduce races, because the compiler will verify atomicity.

See also Section 9.13 for a discussion of the more general concepts of rule expressions and rules as first-class objects.

5.7 Examples

A register is primitive module with the following predefined interface:

```
interface Reg#(type a);
  method Action _write (a x1);
  method a _read ();
endinterface: Reg
```

It is polymorphic, i.e., it can contain values of any type a. It has two methods. The _write() method takes an argument x1 of type a and returns an Action, i.e., an enable-wire that, when asserted, will deposit the value into the register. The _read() method takes no arguments and returns the value that is in the register.

The principal predefined module definition for a register has the following header:

```
// takes an initial value for the register
module mkReg#(a v) (Reg#(a)) provisos (Bits#(a, sa));
```

The module parameter v of type a is specified when instantiating the module (creating the register), and represents the initial value of the register. The module defines an interface of type Reg #(a). The proviso specifies that the type a must be convertible into an sa-bit value. Provisos are discussed in more detail in Sections 4.2 and 14.1.

Here is a module to compute the GCD (greatest common divisor) of two numbers using Euclid's algorithm.

```
interface ArithIO#(type a);
    method Action start (a x, a y);
    method a
                    result;
endinterface: ArithIO
module mkGCD(ArithIO#(Bit#(size_t)));
    Reg#(Bit#(size_t)) x(); // x is the interface to the register
                            // reg_1 is the register instance
    Reg #(Bit#(size_t)) y(); // y is the interface to the register
    mkRegU reg_2(y);
                             // reg_2 is the register instance
    rule flip (x > y && y != 0);
        x \le y;
        y \le x;
    endrule
    rule sub (x \le y \&\& y != 0);
        y \le y - x;
    endrule
    method Action start(Bit#(size_t) num1, Bit#(size_t) num2) if (y == 0);
        action
```

```
x <= num1;
y <= num2;
endaction
endmethod: start

method Bit#(size_t) result() if (y == 0);
    result = x;
endmethod: result

endmodule: mkGCD</pre>
```

The interface type is called ArithIO because it expresses the interactions of modules that do any kind of two-input, one-output arithmetic. Computing the GCD is just one example of such arithmetic. We could define other modules with the same interface that do other kinds of arithmetic.

The module contains two rules, flip and sub, which implement Euclid's algorithm. In other words, assuming the registers x and y have been initialized with the input values, the rules repeatedly update the registers with transformed values, terminating when the register y contains zero. At that point, the rules stop firing, and the GCD result is in register x. Rule flip uses standard Verilog non-blocking assignments to express an exchange of values between the two registers. As in Verilog, the symbol <= is used both for non-blocking assignment as well as for the less-than-or-equal operator (e.g., in rule sub's explicit condition), and as usual these are disambiguated by context.

The start method takes two arguments num1 and num2 representing the numbers whose GCD is sought, and loads them into the registers x and y, respectively. The result method returns the result value from the x register. Both methods have an implicit condition (y == 0) that prevents them from being used while the module is busy computing a GCD result.

A test bench for this module might look like this:

The first two lines instantiate a GCD module. The getInputs rule gets the next two inputs from a file, and then initiates the GCD computation by calling the start method. The putOutput rule prints the result. Note that because of the semantics of implicit conditions and enabling of rules, the getInputs rule will not fire until the GCD module is ready to accept input. Similarly, the putOutput rule will not fire until the output method is ready to deliver a result.³

The mkGCD module is trivial in that the rule conditions ((x > y) and (x <= y)) are mutually exclusive, so they can never fire together. Nevertheless, since they both write to register y, the compiler will insert the appropriate multiplexers and multiplexer control logic.

³The astute reader will recognize that in this small example, since the **result** method is initially ready, the test bench will first output a result of 0 before initiating the first computation. Let us overlook this by imagining that Euclid is clearing his throat before launching into his discourse.

Similarly, the rule getInputs, which calls the start method, can never fire together with the mkGCD rules because the implicit condition of getInputs, i.e., (y == 0) is mutually exclusive with the explicit condition (y != 0) in flip and sub. Nevertheless, since getInputs writes into the_gcd's registers via the start method, the compiler will insert the appropriate multiplexers and multiplexer control logic.

In general, many rules may be enabled simultaneously, and subsets of rules that are simultaneously enabled may both read and write common state. The BSV compiler will insert appropriate scheduling, datapath multiplexing, and control to ensure that when rules fire in parallel, the net state change is consistent with the atomic semantics of rules.

5.8 Synthesizing Modules

In order to generate code for a BSV design (for either Verilog or Bluesim), it is necessary to indicate to the complier which module(s) are to be synthesized. A BSV module that is marked for code generation is said to be a *synthesized* module.

In order to be synthesizable, a module must meet the following characteristics:

- The module must be of type Module and not of any other module type that can be defined with ModuleCollect;
- Its interface must be fully specified; there can be no polymorphic types in the interface;
- Its interface is a type whose methods and subinterfaces are all convertible to wires (see Section 5.8.2).
- All other inputs to the module must be convertible to Bits (see Section 5.8.2).

A module can be marked for synthesis in one of two ways.

1. A module can be annotated with the synthesize attribute (see section 13.1.1). The appropriate syntax is shown below.

```
(* synthesize *)
module mkFoo (FooIfc);
...
endmodule
```

2. Alternatively, the -g compiler flag can be used on the bsc command line to indicate which module is to be synthesized. In order to have the same effect as the attribute syntax shown above, the flag would be used with the format -g mkFoo (the appropriate module name follows the -g flag).

Note that multiple modules may be selected for code generation (by using multiple synthesize attributes, multiple -g compiler flags, or a combination of the two).

Separate synthesis of a module can affect scheduling. This is because input wires to the module, such as method arguments, now become a fixed resource that must be shared, whereas without separate synthesis, module inlining allows them to be bypassed (effectively replicated). Consider a module representing a register file containing 32 registers, with a method read(j) that reads the value of the j'th register. Inside the module, this just indexes an array of registers. When separately synthesized, the argument j becomes a 5-bit wide input port, which can only be driven with one value in any given clock. Thus, two rules that invoke read(3) and read(11), for example, will conflict and then they cannot fire in the same clock. If, however, the module is not separately synthesized, the module and the read() method are inlined, and then each rule can directly read its target register, so the rules can fire together in the same clock. Thus, in general, the addition of a synthesis boundary can restrict behaviors.

5.8.1 Type Polymorphism

As discussed in section 4.1, BSV supports polymorphic types, including interfaces (which are themselves types). Thus, a single BSV module definition, which provides a polymorphic interface, in effect defines a family of different modules with different characteristics based on the specific parameter(s) of the polymorphic interface. Consider the module definition presented in section 5.7.

```
module mkGCD (ArithIO#(Bit#(size_t)));
...
endmodule
```

Based on the specific type parameter given to the ArithIO interface, the code required to implement mkGCD will differ. Since the Bluespec compiler does not create "parameterized" Verilog, in order for a module to be synthesizable, the associated interface must be fully specified (i.e not polymorphic). If the mkGCD module is annotated for code generation as is

```
(* synthesize *)
module mkGCD (ArithIO#(Bit#(size_t)));
...
endmodule
```

and we then run the compiler, we get the following error message.

```
Error: "GCD.bsv", line 7, column 8: (T0043)
    "Cannot synthesize 'mkGCD': Its interface is polymorphic"
```

If however we instead re-write the definition of mkGCD such that all the references to the type parameter size_t are replaced by a specific value, in other words if we write something like,

```
(* synthesize *)
module mkGCD32 (ArithIO#(Bit#(32)));

Reg#(Bit#(32)) x(); // x is the interface to the register
mkRegU reg_1(x); // reg_1 is the register instance
...
endmodule
```

then the compiler will complete successfully and provide code for a 32-bit version of the module (called mkGCD32). Equivalently, we can leave the code for mkGCD unchanged and instantiate it inside another synthesized module which fully specifies the provided interface.

```
(* synthesize *)
module mkGCD32(ArithIO#(Bit#(32)));
  let ifc();
  mkGCD _temp(ifc);
  return (ifc);
endmodule
```

5.8.2 Module Interfaces and Arguments

As mentioned above, a module is synthesizable if its interface is convertible to wires.

- An interface is convertible to wires if all methods and subinterfaces are convertible to wires.
- A method is convertible to wires if
 - all arguments are convertible to bits;
 - it is an Action method or it is an ActionValue or value method where the return value is convertible to bits.
- Clock, Reset, and Inout subinterfaces are convertible to wires.
- A Vector interface can be synthesized as long as the type inside the Vector is of type Clock, Reset, Inout or a type which is convertible to bits.

To be convertible to bits, a type must be in the Bits typeclass.

For a module to be synthesizable its arguments must be of type Clock, Reset, Inout, or a type convertible to bits. Vectors of the preceding types are also synthesizable. If a module has one or more arguments which are not one of the above types, the module is not synthesizable. For example, if an argument is a datatype, such as Integer, which is not in the Bits typeclass, then the module cannot be separately synthesized.

6 Static and dynamic semantics

What is a legal BSV source text, and what are its legal behaviors? These questions are addressed by the static and dynamic semantics of BSV. The BSV compiler checks that the design is legal according to the static semantics, and produces RTL hardware that exhibits legal behaviors according to the dynamic semantics.

Conceptually, there are three phases in processing a BSV design, just like in Verilog and SystemVerilog:

- Static checking: this includes syntactic correctness, type checking and proviso checking.
- Static elaboration: actual instantiation of the design and propagation of parameters, producing the module instance hierarchy.
- Execution: execution of the design, either in a simulator or as real hardware.

We refer to the first two as the static phase (i.e., pre-execution), and to the third as the dynamic phase. Dynamic semantics are about the temporal behavior of the statically elaborated design, that is, they describe the dynamic execution of rules and methods and their mapping into clocked synchronous hardware.

A BSV program can also contain assertions; assertion checking can occur in all three phases, depending on the kind of assertion.

6.1 Static semantics

The static semantics of BSV are about syntactic correctness, type checking, proviso checking, static elaboration and static assertion checking. Syntactic correctness of a BSV design is checked by the parser in the BSV compiler, according to the grammar described throughout this document.

6.1.1 Type checking

BSV is statically typed, just like Verilog, SystemVerilog, C, C++, and Java. This means the usual things: every variable and every expression has a type; variables must be assigned values that have compatible types; actual and formal parameters/arguments must have compatible types, etc. All this checking is done on the original source code, before any elaboration or execution.

BSV uses SystemVerilog's new tagged union mechanism instead of the older ordinary unions, thereby closing off a certain kind of type loophole. BSV also allows more type parameterization (polymorphism), without compromising full static type checking.

6.1.2 Proviso checking and bit-width constraints

In BSV, overloading constraints and bit-width constraints are expressed using provisos (Sections 4.2 and 14.1.1). Overloading constraints provide an extensible mechanism for overloading.

BSV is stricter about bit-width constraints than Verilog and SystemVerilog in that it avoids implicit zero-extension, sign-extension and truncation of bit-vectors. These operations must be performed consciously by the designer, using library functions, thereby avoiding another source of potential errors.

6.1.3 Static elaboration

As in Verilog and SystemVerilog, static elaboration is the phase in which the design is instantiated, starting with a top-level module instance, instantiating its immediate children, instantiating their children, and so on to produce the complete instance hierarchy.

BSV has powerful generate-like facilities for succinctly expressing regular structures in designs. For example, the structure of a linear pipeline may be expressed using a loop, and the structure of a tree-structured reduction circuit may be expressed using a recursive function. All these are also unfolded and instantiated during static elaboration. In fact, the BSV compiler unfolds all structural loops and functions during static elaboration.

A fully elaborated BSV design consists of no more than the following components:

- A module instance hierarchy. There is a single top-level module instance, and each module instance contains zero or more module instances as children.
- An interface instance. Each module instance presents an interface to its clients, and may itself be a client of zero or more interfaces of other module instances.
- Method definitions. Each interface instance consists of zero or more method definitions.
 - A method's body may contain zero or more invocations of methods in other interfaces.
 - Every method has an implicit condition, which can be regarded as a single output wire that is asserted only when the method is ready to be invoked. The implicit condition may directly test state internal to its module, and may indirectly test state of other modules by invoking their interface methods.
- Rules. Each module instance contains zero or more rules, each of which contains a condition
 and an action. The condition is a boolean expression. Both the condition and the action may
 contain invocations of interface methods of other modules. Since those interface methods can
 themselves contain invocations of other interface methods, the conditions and actions of a rule
 may span many modules.

6.2 Dynamic semantics

The dynamic semantics of BSV specify the temporal behavior of rules and methods and their mapping into clocked synchronous hardware.

Every rule has a syntactically explicit condition and action. Both of these may contain invocations of interface methods, each of which has an implicit condition. A rule's *composite condition* consists of its syntactically explicit condition ANDed with the implicit conditions of all the methods invoked in the rule. A rule is said to be *enabled* if its composite condition is true.

6.2.1 Reference semantics

The simplest way to understand the dynamic semantics is through a reference semantics, which is completely sequential. However, please do not equate this with slow execution; the execution steps described below are not the same as clocks; we will see in the next section that many steps can be mapped into each clock. The execution of any BSV program can be understood using the following very simple procedure:

Repeat forever:

Step: Pick any one enabled rule, and perform its action. (We say that the rule is fired or executed.)

Note that after each step, a different set of rules may be enabled, since the current rule's action will typically update some state elements in the system which, in turn, may change the value of rule conditions and implicit conditions.

Also note that this sequential, reference semantics does not specify how to choose which rule to execute at each step. Thus, it specifies a *set* of legal behaviors, not just a single unique behavior. The principles that determine which rules in a BSV program will be chosen to fire (and, hence, more precisely constrain its behavior) are described in section 6.2.3.

Nevertheless, this simple reference semantics makes it very easy for the designer to reason about invariants (correctness conditions). Since only one rule is executed in each step, we only have to look at the actions of each rule in isolation to check how it maintains or transforms invariants. In particular, we do not have to consider interactions with other rules executing simultaneously.

Another way of saying this is: each rule execution can be viewed as an *atomic state transition*.⁴ Race conditions, the bane of the hardware designer, can generally be explained as an atomicity violation; BSV's rules are a powerful way to avoid most races.

The reference semantics is based on Term Rewriting Systems (TRSs), a formalism supported by decades of research in the computer science community [Ter03]. For this reason, we also refer to the reference semantics as "the TRS semantics of BSV."

6.2.2 Mapping into efficient parallel clocked synchronous hardware

A BSV design is mapped by the BSV compiler into efficient parallel clocked synchronous hardware. In particular, the mapping permits multiple rules to be executed in each clock cycle. This is done in a manner that is consistent with the reference TRS semantics, so that any correctness properties ascertained using the TRS semantics continue to hold in the hardware.

Standard clocked synchronous hardware imposes the following restrictions:

 $^{^4}$ We use the term atomic as it is used in concurrency theory (and in operating systems and databases), i.e., to mean indivisible.

- Persistent state is updated only once per clock cycle, at a clock edge. During a clock cycle, values read from persistent state elements are the ones that were registered in the last cycle.
- Clock-speed requirements place a limit on the amount of combinational computation that can be performed between state elements, because of propagation delay.

The composite condition of each rule is mapped into a combinational circuit whose inputs, possibly many, sense the current state and whose 1-bit output specifies whether this rule is enabled or not.

The action of each rule is mapped into a combinational circuit that represents the state transition function of the action. It can have multiple inputs and multiple outputs, the latter being the computed next-state values.




Figure 1: A general scheme for mapping an N-rule system into clocked synchronous hardware.

Figure 1 illustrates a general scheme to compose rule components when mapping the design to clocked synchronous hardware. The State box lumps together all the state elements in the BSV design (as described earlier, state elements are explicitly specified in BSV). The BSV compiler produces a rule-control circuit which conceptually takes all the enable (cond) signals and all the data (action) outputs and controls which of the data outputs are actually captured at the next clock in the state elements. The enable signals feed a *scheduler* circuit that decides which of the rules will actually fire. The scheduler, in turn, controls data multiplexers that select which data outputs reach the data inputs of state elements, and controls which state elements are enabled to capture the new data values. Firing a rule simply means that the scheduler selects its data output and clocks it into the next state.

At each clock, the scheduler selects a subset of rules to fire. Not all subsets are legal. A subset is legal if and only if the rules in the subset can be ordered with the following properties:

- A hypothetical sequential execution of the ordered subset of rules is legal at this point, according to the TRS semantics. In particular, the first rule in the ordered subset is currently enabled, and each subsequent rule would indeed be enabled when execution reaches it in the hypothetical sequence.
 - A special case is where all rules in the subset are already currently enabled, and no rule would be disabled by execution of prior rules in the order.
- The hardware execution produces the same net effect on the state as the hypothetical sequential execution, even though the hardware execution performs reads and writes in a different order from the hypothetical sequential execution.

The BSV compiler performs a very sophisticated analysis of the rules in a design and synthesizes an efficient hardware scheduler that controls execution in this manner.

Note that the scheme in Figure 1 is for illustrative purposes only. First, it lumps together all the state, shows a single rule-control box, etc., whereas in the real hardware generated by the BSV compiler these are distributed, localized and modular. Second, it is not the only way to map the design into clocked synchronous hardware. For example, any two enabled rules can also be executed in a single clock by feeding the action outputs of the first rule into the action inputs of the second rule, or by synthesizing hardware for a composite circuit that computes the same function as the composition of the two actions, and so on. In general, these alternative schemes may be more complex to analyze, or may increase total propagation delay, but the compiler may use them in special circumstances.

In summary, the BSV compiler performs a detailed and sophisticated analysis of rules and their interactions, and maps the design into very efficient, highly parallel, clocked synchronous hardware including a dynamic scheduler that allows many rules to fire in parallel in each clock, but always in a manner that is consistent with the reference TRS semantics. The designer can use the simple reference semantics to reason about correctness properties and be confident that the synthesized parallel hardware will preserve those properties. (See Section 13.3 for the "scheduling attributes" mechanism using which the designer can guide the compiler in implementing the mapping.)

When coding in other HDLs, the designer must maintain atomicity manually. He must recognize potential race conditions, and design the appropriate data paths, control and synchronization to avoid them. Reasoning about race conditions can cross module boundaries, and can be introduced late in the design cycle as the problem specification evolves. The BSV compiler automates all of this and, further, is capable of producing RTL that is competitive with hand-coded RTL.

6.2.3 How rules are chosen to fire

The previous section described how an efficient circuit can be built whose behavior will be consistent with sequential TRS semantics of BSV. However, as noted previously, the sequential reference semantics can be consistent with a range of different behaviors. There are two rule scheduling principles that guide the BSV compiler in choosing which rules to schedule in a clock cycle (and help a designer build circuits with predictable behavior). Except when overridden by an explicit user command or annotation, the BSV compiler schedules rules according to the following two principles:

- 1. Every rule enabled during a clock cycle will either be fired as part of that clock cycle or a warning will be issued during compilation.
- 2. A rule will fire at most one time during a particular clock cycle.

The first principle comes into play when two (or more) rules conflict - either because they are competing for a limited resource or because the result of their simultaneous execution is not consistent with any sequential rule execution. In the absence of a user annotation, the compiler will arbitrarily choose ⁵ which rule to prioritize, but *must* also issue a warning. This guarantees the designer is aware of the ambiguity in the design and can correct it. It might be corrected by changing the rules themselves (rearranging their predicates so they are never simultaneously applicable, for example) or by adding an urgency annotation which tells the compiler which rule to prefer (see section 13.3.3). When there are no scheduling warnings, it is guaranteed that the compiler is making no arbitrary choices about which rules to execute.

⁵The compiler's choice, while arbitrary, is deterministic. Given the same source and compiler version, the same schedule (and, hence, the same hardware) will be produced. However, because it is an arbitrary choice, it can be sensitive to otherwise irrelevant details of the program and is not guaranteed to remain the same if the source or compiler version changes.

The second principle ensures that continuously enabled rules (like a counter increment rule) will not be executed an unpredictable number of times during a clock cycle. According to the first rule scheduling principle, a rule that is always enabled will be executed at least once during a clock cycle. However, since the rule remains enabled it theoretically could execute multiple times in a clock cycle (since that behavior would be consistent with a sequential semantics). Since rules (even simple things like a counter increment) consume limited resources (like register write ports) it is pragmatically useful to restrict them to executing only once in a cycle (in the absence of specific user instructions to the contrary). Executing a continuously enabled rule only once in a cycle is also the more straightforward and intuitive behavior.

Together, these two principles allow a designer to completely determine the rules that will be chosen to fire by the schedule (and, hence, the behavior of the resulting circuit).

6.2.4 Mapping specific hardware models

Annotations on the methods of a module are used by the BSV compiler to model the hardware behavior into TRS semantics. For example, all reads from a register must be scheduled before any writes to the same register. That is to say, any rule which reads from a register must be scheduled *earlier* than any other rule which writes to it. More generally, there exist scheduling constraints for specific hardware modules which describe how methods interact within the schedule. The scheduling annotations describe the constraints enforced by the BSV compiler.

The meanings of the scheduling annotations are:

C	conflicts
CF	conflict-free
SB	sequence before
SBR	sequence before restricted (cannot be in the same rule)
SA	sequence after
SAR	sequence after restricted (cannot be in the same rule)

The annotations SA and SAR are provided for documentation purposes only; they are not supported in the BSV language.

Below is an example of the scheduling annotations for a register:

Scheduling Annotations			
Register			
	read	write	
read	CF	SB	
write	SA	SBR	

The table describes the following scheduling constraints:

- Two read methods would be conflict-free (CF), that is, you could have multiple methods that read from the same register in the same rule, sequenced in any order.
- A write is sequenced after (SA) a read.
- A read is sequenced before (SB) a write.
- And finally, if you have two write methods, one must be sequenced before the other, and they cannot be in the same rule, as indicated by the annotation SBR.

The scheduling annotations are specific to the TRS model desired and a single hardware component can have multiple TRS models. For example, a register may be implemented using a mkReg module or a mkConfigReg module, which are identical except for their scheduling annotations.

7 User-defined types (type definitions)

User-defined types must be defined at the top level of a package.

```
\begin{array}{cccc} typeDef & ::= & typedefSynonym \\ & | & typedefEnum \\ & | & typedefStruct \\ & | & typedefTaggedUnion \end{array}
```

As a matter of style, BSV requires that all enumerations, structs and unions be declared only via typedef, i.e., it is not possible directly to declare a variable, formal parameter or formal argument as an enum, struct or union without first giving that type a name using a typedef.

Each typedef of an enum, struct or union introduces a new type that is different from all other types. For example, even if two typedefs give names to struct types with exactly the same corresponding member names and types, they define two distinct types.

Other typedefs, i.e., not involving an enum, struct or union, merely introduce type synonyms for existing types.

7.1 Type synonyms

Type synonyms are just for convenience and readability, allowing one to define shorter or more meaningful names for existing types. The new type and the original type can be used interchangeably anywhere.

Examples. Defining names for bit vectors of certain lengths:

```
typedef bit [7:0] Byte;
typedef bit [31:0] Word;
typedef bit [63:0] LongWord;
```

Examples. Defining names for polymorphic data types.

```
typedef Tuple#3(a, a, a) Triple#(type a);
typdef Int#(n) MyInt#(type n);
```

The above example could also be written as:

```
typedef Int#(n) MyInt#(numeric type n);
```

The numeric is not required because the parameter to Int will always be numeric. numeric is only required when the compiler can't determine whether the parameter is a numeric or non-numeric type. It will then default to assuming it is non-numeric. The user can override this default by specifying numeric in the typedef statement.

A typedef statement can be used to define a synonym for an already defined synonym. Example:

```
typedef Triple#(Longword) TLW;
```

Since an Interface is a type, we can have nested types:

```
typedef Reg#(Vector#(8, UInt#(8))) ListReg;
typedef List#(List#(Bit#(4))) ArrayOf4Bits;
```

The typedef statement must always be at the top level of a package, not within a module. To introduce a local name within a module, use Alias or NumAlias (B.1.13). Since these introduce new names which are type variables as opposed to types, the new names must begin with lower case letters. NumAlias is used to give new names to numeric types, while Alias is used for types which can be the types of variables. Example:

```
module mkMod(Ifc)
  provisos (Alias#(Bit#(crc_size), crc));

module mkRAM(RAMIfc)
  provisos (NumAlias#(addr_size, TLog#(buff_size)));
```

7.2 Enumerations

```
 \begin{array}{llll} typedefEnum & ::= & typedefEnumElements \  \  \, Identifier \  \, [ & derives \  \, ] \  \, ; \\ typedefEnumElements & ::= & typedefEnumElement \  \, \{ \  \, , typedefEnumElement \  \, \} \\ typedefEnumElement & ::= & Identifier \  \, [ = intLiteral \  \, ] \\ & | & Identifier \  \, [intLiteral \  \, ] \  \, [ = intLiteral \  \, ] \\ & | & Identifier \  \, [intLiteral \  \, ] \  \, [ = intLiteral \  \, ] \\ \hline \end{aligned}
```

Enumerations (enums) provide a way to define a set of unique symbolic constants, also called *labels* or *member names*. Each enum definition creates a new type different from all other types. Enum labels may be repeated in different enum definitions. Enumeration labels must begin with an uppercase letter.

The optional derives clause is discussed in more detail in Sections 4.3 and 14.1. One common form is deriving (Bits), which tells the compiler to generate a bit-representation for this enum. Another common form of the clause is deriving (Eq), which tells the compiler to pick a default equality operation for these labels, so they can also be tested for equality and inequality. A third common form is deriving (Bounded), which tells the compiler to define constants minBound and maxBound for this type, equal in value to the first and last labels in the enumeration. These specifications can be combined, e.g., deriving (Bits, Eq, Bounded). All these default choices for representation, equality and bounds can be overridden (see Section 14.1). The form deriving (Ord) is not currently supported for enums.

The declaration may specify the encoding used by deriving(Bits) by assigning numbers to tags. When an assignment is omitted, the tag receives an encoding of the previous tag incremented by one; when the encoding for the initial tag is omitted, it defaults to zero. Specifying the same encoding for more than one tag results in an error.

Multiple tags may be declared by using the index (Tag[ntags]) or range (Tag[start:end]) notation. In the former case, ntags tags will be generated, from Tag0 to Tagn-1; in the latter case, |end-start|+1 tags, from Tagstart to Tagend.

Example. The boolean type can be defined in the language itself:

```
typedef enum { False, True } Bool deriving (Bits, Eq);
```

The compiler will pick a one-bit representation, with 1'b0 and 1'b1 as the representations for False and True, respectively. It will define the == and != operators to also work on Bool values.

Example. Excerpts from the specification of a processor:

```
typedef enum { R0, R1, ..., R31 } RegName deriving (Bits);
typedef RegName Rdest;
typedef RegName Rsrc;
```

The first line defines an enum type with 32 register names. The second and third lines define type synonyms for RegName that may be more informative in certain contexts ("destination" and "source" registers). Because of the deriving clause, the compiler will pick a five-bit representation, with values 5'h00 through 5'h1F for R0 through R31.

Example. Tag encoding when deriving (Bits) can be specified manually:

```
typedef enum {
  Add = 5,
  Sub = 0,
  Not,
  Xor = 3,
  ...
} OpCode deriving (Bits);
```

The Add tag will be encoded to five, Sub to zero, Not to one, and Xor to three.

Example. A range of tags may be declared in a single clause:

```
typedef enum {
  Foo[2],
  Bar[5:7],
  Quux[3:2]
} Glurph;
```

This is equivalent to the declaration

```
typedef enum {
  Foo0,
  Foo1,
  Bar5,
  Bar6,
  Bar7,
  Quux3,
  Quux2
} Glurph;
```

7.3 Structs and tagged unions

A struct definition introduces a new record type.

SystemVerilog has ordinary unions as well as tagged unions, but in BSV we only use tagged unions, for several reasons. The principal benefit is safety (verification). Ordinary unions open a serious type-checking loophole, whereas tagged unions are completely type-safe. Other reasons are that, in conjunction with pattern matching (Section 10), tagged unions yield much more succinct and readable code, which also improves correctness. In the text below, we may simply say "union" for brevity, but it always means "tagged union."

```
typedefStruct ::= typedef struct \{ \\ \{ structMember \} \\ \} typeDefType [ derives ];
```

```
::= typedef union tagged {
typedefTaggedUnion
                              \{unionMember\}
                          } typeDefType [ derives ];
structMember
                         type identifier;
                          subUnion identifier;
unionMember
                         type Identifier;
                          subStruct Identifier;
                          subUnion Identifier;
                          void Identifier ;
subStruct
                         struct {
                              \{ structMember \}
subUnion
                     ::= union tagged {
                              \{ unionMember \}
typeDefType
                     ::= typeIde [ typeFormals ]
                     ::= # ( typeFormal { , typeFormal })
typeFormals
                     ::= [numeric] type typeIde
typeFormal
```

All types can of course be mutually nested if mediated by typedefs, but unions can also be mutually nested directly, as described in the syntax above. Structs and unions contain *members*. A union member (but not a struct member) can have the special void type (see the types MaybeInt and Maybe in the examples below for uses of void). All the member names in a particular struct or union must be unique, but the same names can be used in other structs and members; the compiler will try to disambiguate based on type.

A struct value contains the first member and the second member and the third member, and so on. A union value contains just the first member or just the second member or just the third member, and so on. Struct member names must begin with a lowercase letter, whereas union member names must begin with an uppercase letter.

In a tagged union, the member names are also called *tags*. Tags play a very important safety role. Suppose we had the following:

```
typedef union tagged { int Tagi; OneHot Tagoh; } U deriving (Bits); U \mathbf{x}:
```

The variable x not only contains the bits corresponding to one of its member types int or OneHot, but also some extra bits (in this case just one bit) that remember the tag, 0 for Tagi and 1 for Tagoh. When the tag is Tagi, it is impossible to read it as a OneHot member, and when the tag is Tagoh it is impossible to read it as an int member, i.e., the syntax and type checking ensure this. Thus, it is impossible accidentally to misread what is in a union value.

The optional derives clause is discussed in more detail in Section 14.1. One common form is deriving (Bits), which tells the compiler to pick a default bit-representation for the struct or union. For structs it is simply a concatenation of the representations of the members. For unions, the representation consists of t+m bits, where t is the minimum number of bits to code for the tags in this union and m is the number of bits for the largest member. Every union value has a code in the t-bit field that identifies the tag, concatenated with the bits of the corresponding member, right-justified in the m-bit field. If the member needs fewer than m bits, the remaining bits (between the tag and the member bits) are undefined.

Struct and union typedefs can define new, polymorphic types, signalled by the presence of type parameters in #(...). Polymorphic types are discussed in section 4.1.

Section 9.11 on struct and union expressions describes how to construct struct and union values and to access and update members. Section 10 on pattern-matching describes a more high-level way to access members from structs and unions and to test union tags.

Example. Ordinary, traditional record structures:

```
typedef struct { int x; int y; } Coord;
typedef struct { Addr pc; RegFile rf; Memory mem; } Proc;

Example. Encoding instruction operands in a processor:

typedef union tagged {
   bit [4:0] Register;
   bit [21:0] Literal;
   struct {
      bit [4:0] regAddr;
      bit [4:0] regIndex;
   } Indexed;
} InstrOperand;
```

An instruction operand is either a 5-bit register specifier, a 22-bit literal value, or an indexed memory specifier, consisting of two 5-bit register specifiers.

Example. Encoding instructions in a processor:

```
typedef union tagged {
    struct {
        Op op; Reg rs; CPUReg rt; UInt16 imm;
    } Immediate;

    struct {
        Op op; UInt26 target;
    } Jump;
} Instruction
    deriving (Bits);
```

An Instruction is either an Immediate or a Jump. In the former case, it contains a field, op, containing a value of type Op; a field, rs, containing a value of type Reg; a field, rt, containing a value of type CPUReg; and a field, imm, containing a value of type UInt16. In the latter case, it contains a field, op, containing a value of type Op, and a field, target, containing a value of type UInt26.

Example. Optional integers (an integer together with a valid bit):

```
typedef union tagged {
    void Invalid;
    int Valid;
} MaybeInt
    deriving (Bits);
```

A MaybeInt is either invalid, or it contains an integer (Valid tag). The representation of this type will be 33 bits—one bit to represent Invalid or Valid tag, plus 32 bits for an int. When it carries an invalid value, the remaining 32 bits are undefined. It will be impossible to read/interpret those 32 bits when the tag bit says it is Invalid.

This MaybeInt type is very useful, and not just for integers. We generalize it to a polymorphic type:

```
typedef union tagged {
    void Invalid;
    a Valid;
} Maybe#(type a)
deriving (Bits);
```

This Maybe type can be used with any type a. Consider a function that, given a key, looks up a table and returns some value associated with that key. Such a function can return either an invalid result (Invalid), if the table does not contain an entry for the given key, or a valid result Valid v if v is associated with the key in the table. The type is polymorphic (type parameter a) because it may be used with lookup functions for integer tables, string tables, IP address tables, etc. In other words, we do not over-specify the type of the value v at which it may be used.

See Section 12.4 for an important, predefined set of struct types called *Tuples* for adhoc structs of between two and eight members.

8 Variable declarations and statements

Statements can occur in various contexts: in packages, modules, function bodies, rule bodies, action blocks and actionvalue blocks. Some kinds of statements have been described earlier because they were specific to certain contexts: module definitions (moduleDef) and instantiation (moduleInst), interface declarations (interfaceDecl), type definitions (typeDef), method definitions (methodDef) inside modules, rules (rule) inside modules, and action blocks (actionBlock) inside modules.

Here we describe variable declarations, register assignments, variable assignments, loops, and function definitions. These can be used in all statement contexts.

8.1 Variable and array declaration and initialization

Variables in BSV are used to name intermediate values. Unlike Verilog and SystemVerilog, variables never represent state, i.e., they do not hold values over time. Every variable's type must be declared, after which it can be bound to a value one or more times.

One or more variables can be declared by giving the type followed by a comma-separated list of identifiers with optional initializations:

```
varDecl ::= type varInit { , varInit } ; 

varInit ::= identifier [ arrayDims ] [ = expression ] 

arrayDims ::= [ expression ] { [ expression ] }
```

The declared identifier can be an array (when arrayDims is present). The expressions in arrayDims represent the array dimensions, and must be constant expressions (i.e., computable during static elaboration). The array can be multidimensional.

Note that array variables are distinct from the RegFile (section C.1.1) and Vector (section C.3) data types. Array variables are just a structuring mechanism for values, whereas the RegFile type represents a particular hardware module, like a register file, with a limited number of read and write ports. In many programs, array variables are used purely for static elaboration, e.g., an array of registers is just a convenient way to refer to a collection of registers with a numeric index.

Each declared variable can optionally have an initialization.

Example. Declare two integer variables and initialize them:

```
Integer x = 16, y = 32;
```

Example. Declare two array identifiers a and b containing int values at each index:

```
int a[20], b[40];
```

Example. Declare an array of 3 Int#(5) values and initialize them:

```
Int#(5) xs[3] = {14, 12, 9};
```

Example. Declare an array of 3 arrays of 4 Int#(5) values and initialize them:

```
Int#(5) xs[3][4] = {{1,2,3,4},
{5,6,7,8},
{9,10,11,12}};
```

Example. The array values can be polymorphic, but they must defined during elaboration:

```
Get \#(a) gs[3] = {g0,g2, g2};
```

8.2 Variable assignment

A variable can be bound to a value using assignment:

```
varAssign ::= lValue = expression;
lValue ::= identifier
| lValue : identifier
| lValue [ expression ]
| lValue [ expression : expression ]
```

The left-hand side (*lValue*) in its simplest form is a simple variable (*identifier*).

Example. Declare a variable wordSize to have type Integer and assign it the value 16:

```
Integer wordSize;
wordSize = 16;
```

Multiple assignments to the same variable are just a shorthand for a cascaded computation. Example:

```
int x;  x = 23; \\ // \text{ Here, x represents the value 23} \\ x = \text{ifc.meth (34);} \\ // \text{ Here, x represents the value returned by the method call } \\ x = x + 1; \\ // \text{ Here, x represents the value returned by the method call, plus 1}
```

Note that these assignments are ordinary, zero-time assignments, i.e., they never represent a dynamic assignment of a value to a register. These assignments only represent the convenient naming of an intermediate value in some zero-time computation. Dynamic assignments are always written using the non-blocking assignment operator <=, and are described in Section 8.4.

In general, the left-hand side (lValue) in an assignment statement can be a series of index- and field-selections from an identifier representing a nesting of arrays, structs and unions. The array-indexing expressions must be computable during static elaboration.

For bit vectors, the left-hand side (IValue) may also be a range between two indices. The indices must be computable during static elaboration, and, if the indices are not literal constants, the right-hand side of the assignment should have a defined bit width. The size of the updated range (determined by the two literal indices or by the size of the right-hand side) must be less than or equal to the size of the target bit vector.

Example. Update an array variable b:

```
b[15] = foo.bar(x);
Example. Update bits 15 to 8 (inclusive) of a bit vector b:
b[15:8] = foo.bar(x);
Example. Update a struct variable (using the processor example from Section 7.3):
cpu.pc = cpu.pc + 4;
Semantically, this can be seen as an abbreviation for:
cpu = Proc { pc: cpu.pc + 4, rf: cpu.rf, mem: cpu.mem };
```

i.e., it reassigns the struct variable to contain a new struct value in which all members other than the updated member have their old values. The right-hand side is a struct expression; these are described in Section 9.11.

Update of tagged union variables is done using normal assignment notation, i.e., one replaces the current value in a tagged union variable by an entirely new tagged union value. In a struct it makes sense to update a single member and leave the others unchanged, but in a union, one member replaces another. Example (extending the previous processor example):

```
typedef union tagged {
    bit [4:0] Register;
    bit [21:0] Literal;
    struct {
        bit [4:0] regAddr;
        bit [4:0] regIndex;
    } Indexed;
} InstrOperand;
...
InstrOperand orand;
...
orand = tagged Indexed { regAddr:3, regIndex:4 };
...
orand = tagged Register 23;
```

The right-hand sides of the assignments are tagged union expressions; these are described in Section 9.11.

8.3 Implicit declaration and initialization

The let statement is a shorthand way to declare and initialize a variable in a single statement. A variable which has not been declared can be assigned an initial value and the compiler will infer the type of the variable from the expression on the right hand side of the statement:

```
varDecl ::= let identifier = expression;
Example:
```

```
let n = valueof(BuffSize);
```

The pseudo-function value of returns an Integer value, which will be assigned to n at compile time. Thus the variable n is assumed to have the type of Integer.

If the expression is the value returned by an action alue method, the notation will be:

```
varAssign ::= let identifier <- expression ;</pre>
```

Note the difference between this statement:

```
let m1 = m1displayfifo.first;
```

and this statement:

```
let z1 <- rndm.get;</pre>
```

In the first example, mldisplayfifo.first is a value method; m1 is assigned the value and type returned by the value method. In the latter, rndm.get is an actionvalue method; z1 is assigned the value and type returned by the actionvalue method.

8.4 Register reads and writes

Register writes occur primarily inside rules and methods.

```
regWrite ::= lValue <= expression \\ ( expression ) <= expression
```

The left-hand side must contain a writeable interface type, such as Reg#(t) (for some type t that has a representation in bits). It is either an lValue or a parenthesized expression (e.g., the register interface could be selected from an array of register interfaces or returned from a function). The right-hand side must have the same type as the left-hand side would have if it were typechecked as an expression (including read desugaring, as described below). BSV allows only the so-called non-blocking assignments of Verilog, i.e., the statement specifies that the register gets the new value at the end of the current cycle, and is only available in the next cycle.

Following BSV's principle that all state elements (including registers) are module instances, and all interaction with a module happens through its interface, a simple register assignment $r \le e$ is just a convenient alternative notation for a method call:

```
r_write (e)
```

Similarly, if r is an expression of type Reg#(t), then mentioning r in an expression is just a convenient alternative notation for different method call:

```
r_read ()
```

The implicit addition of the $_read$ method call to variables of type Reg#(t) is the simplest example of read designing.

Example. Instantiating a register interface and a register, and using it:

8.4.1 Registers and square-bracket notation

Register writes can be combined with the square-bracket notation.

```
regWrite ::= lValue \ arrayIndexes <= expression arrayIndexes ::= [expression] \{ [expression] \}
```

There are two different ways to interpret this combination. First, it can mean to select a register out of a collection of registers and write it.

Example. Updating a register in an array of registers:

```
List#(Reg#(int)) regs;
...
regs[3] <= regs[3] + 1;  // increment the register at position 3</pre>
```

Note that when the square-bracket notation is used on the right-hand side, read desugaring is also applied⁶. This allows the expression regs[3] to be interpreted as a register read without unnecessary clutter.

The indexed register assignment notation can also be used for partial register updates, when the register contains an array of elements of some type t (in a particular case, this could be an array of bits). This interpretation is just a shorthand for a whole register update where only the selected element is updated. In other words,

```
x[j] \ll v;
```

can be a shorthand for:

```
x \le replace(x, j, v);
```

where replace is a pure function that takes the whole value from register x and produces a whole new value with the j'th element replaced by v. The statement then assigns this new value to the register x.

It is important to understand the tool infers the appropriate meaning for an indexed register write based on the types available and the context:

```
Reg#(Bit#(32)) x;
x[3] <= e;
List#(Reg#(a)) x;
y[3] <= e;</pre>
```

In the former case, x is a register containing an array of items (in this example a bit vector), so the statement updates the third item in this array (a single bit) and stores the updated bit vector in the register. In the latter case, y is an array of registers, so register at position 3 in the array is updated. In the former case, multiple writes to different indices in a single rule with non-exclusive conditions are forbidden (because they would be multiple conflicting writes to the same register)⁷, writing the final result back to the register. In the latter case, multiple writes to different indices will be allowed, because they are writes to different registers (though multiple writes to the same index, under non-exclusive conditions would not be allowed, of course).

It also is possible to mix these notations, i.e., writing a single statement to perform a partial update of a register in an array of registers.

Example: Mixing types of square-bracket notation in a register write

 $^{^6\}mathrm{To}$ suppress read desugaring use asReg or asIfc

⁷If multiple partial register writes are desired the best thing to do is to assign the register's value to a variable and then do cascaded variable assignments (as described in section 8.2)

```
List#(Reg#(bit[3:0])) ys;
...
y[4][3] <= e;  // Update bit 3 of the register at position 4</pre>
```

8.4.2 Registers and range notation

Just as there is a range notation for bit extraction and variable assignments, there is also a range notation for register writes.

```
regWrite ::= lValue [expression : expression] <= expression
```

The index expressions in the range notation follow the same rules as the corresponding expressions in variable assignment range updates (they must be static expressions and if they are not literal constants the right-hand side should have a defined bit width). Just as the indexed, partial register writes described in the previous subsection, multiple range-notation register writes cannot be mixed in the same rule⁸.

Example: A range-notation register write

```
Reg#(Bit#(32)) r;  r[23:12] <= e; // Update a 12-bit range in the middle of r
```

8.4.3 Registers and struct member selection

```
regWrite ::= lValue . identifier <= expression
```

As with the square-bracket notation, a register update involving a field selection can mean one of two things. First, for a register containing a structure, it means update the particular field of the register value and write the result back to the register.

Example: Updating a register containing a structure

```
typedef struct { Bit#(32) a; Bit#(16) b; } Foo deriving(Bits);
...
Reg#(Foo) r;
...
r.a <= 17;</pre>
```

Second, it can mean to select the named field out of a compile-time structure that *contains* a register and write that register.

Example: Writing a register contained in a structure

```
typedef struct { Reg#(Bit#(32)) c; Reg#(Bit#(16)) d; } Baz;
...
Baz b;
...
b.a <= 23;</pre>
```

In both cases, the same notation is used and the compiler infers which interpretation is appropriate. As with square-bracket selection, struct member selection implies read desugaring, unless inhibited by asReg or asIfc.

⁸As described in the preceding footnote, using variable assignment is the best way to achive this effect, if desired.

8.5 Begin-end statements

A begin-end statement is a block that allows one to collect multiple statements into a single statement, which can then be used in any context where a statement is required.

```
<\!ctxt\!>\!BeginEndStmt ::= begin[: identifier]  { <\!ctxt\!>\!Stmt } end[: identifier]
```

The optional identifier labels are currently used for documentation purposes only; in the future they may be used for hierarchical references. The statements contained in the block can contain local variable declarations and all the other kinds of statements. Example:

```
module mkBeginEnd#(Bit#(2) sel) ();
   Reg#(Bit#(4)) a
                        <- mkReg(0);
  Reg#(Bool)
                 done <- mkReg(False);</pre>
  rule decode (!done);
     case (sel)
        2'b00: a <= 0;
        2'b01: a <= 1;
        2'b10: a <= 2;
        2'b11: begin
                              //in the 2'b11 case we don't want more than
                 <= 3:
           done <= True;</pre>
                              //one action done, therefore we add begin/end
        end
     endcase
   endrule
endmodule
```

8.6 Conditional statements

Conditional statements include if statements and case statements. An if statement contains a predicate, a statement representing the true arm and, optionally, the keyword else followed by a statement representing the false arm.

If-statements have the usual semantics—the predicate is evaluated, and if true, the true arm is executed, otherwise the false arm (if present) is executed. The predicate can be any boolean expression. More generally, the predicate can include pattern matching, and this is described in Section 10, on pattern matching.

There are two kinds of case statements: ordinary case statements and pattern-matching case statements. Ordinary case statements have the following grammar:

```
< ctxt > Case ::= case ( expression ) { < ctxt > CaseItem } [ < ctxt > DefaultItem ] endcase
```

```
< ctxt > CaseItem ::= expression \{ , expression \} : < ctxt > Stmt < < ctxt > DefaultItem ::= default[ : ] < ctxt > Stmt
```

Each case item contains a left-hand side and a right-hand side, separated by a colon. The left-hand side contains a series of expressions, separated by commas. The case items may optionally be followed, finally, by a default item (the colon after the default keyword is optional).

Case statements are equivalent to an expansion into a series of nested if-then-else statements. For example:

```
case (e1)
   e2, e3
              : s2;
   e4
              : s4;
   e5, e6, e7: s5;
   default
              : s6;
 endcase
is equivalent to:
x1 = e1;
              // where x1 is a new variable:
            (x1 == e2)
 if
                         s2;
 else if
            (x1 == e3)
                         s2;
 else if
            (x1 == e4)
                         s4;
else if
            (x1 == e5)
                         s5;
 else if
            (x1 == e6)
                         s5;
            (x1 == e7)
 else if
                         s5:
 else
                         s6;
```

The case expression (e1) is evaluated once, and tested for equality in sequence against the value of each of the left-hand side expressions. If any test succeeds, then the corresponding right-hand side statement is executed. If no test succeeds, and there is a default item, then the default item's right-hand side is executed. If no test succeeds, and there is no default item, then no right-hand side is executed.

Example:

```
module mkConditional#(Bit#(2) sel) ();
   Reg#(Bit#(4)) a
                          \leftarrow mkReg(0);
   Reg#(Bool)
                   done <- mkReg(False);</pre>
   rule decode ;
     case (sel)
        2'b00: a <= 0;
        2'b01: a <= 1;
         2'b10: a <= 2;
        2'b11: a <= 3;
     endcase
   endrule
   rule finish;
     if (a == 3)
         done <= True;</pre>
     else
         done <= False;</pre>
   endrule
endmodule
```

Pattern-matching case statements are described in Section 10.

8.7 Loop statements

BSV has for loops and while loops.

It is important to note that this use of loops does not express time-based behavior. Instead, they are used purely as a means to express zero-time iterative computations, i.e., they are statically unrolled and express the concatenation of multiple instances of the loop body statements. In particular, the loop condition must be evaluable during static elaboration. For example, the loop condition can never depend on a value in a register, or a value returned in a method call, which are only known during execution and not during static elaboration.

See Section 11 on FSMs for an alternative use of loops to express time-based (temporal) behavior.

8.7.1 While loops

```
<\!ctxt\!>\!While ::= while ( expression ) <\!ctxt\!>\!Stmt
```

While loops have the usual semantics. The predicate *expression* is evaluated and, if true, the loop body statement is executed, and then the while loop is repeated. Note that if the predicate initially evaluates false, the loop body is not executed at all.

Example. Sum the values in an array:

```
int a[32];
int x = 0;
int j = 0;
...
while (j < 32)
    x = x + a[j];</pre>
```

8.7.2 For loops

```
< ctxt > For
                       ::= for ( forInit ; forTest ; forIncr )
                                 < ctxt > Stmt
for Init
                       ::= forOldInit \mid forNewInit
for Old Init
                       ::= simple Var Assign \{ , simple Var Assign \}
simple Var Assign
                       ::= identifier = expression
for New Init
                            type identifier = expression { , simple VarDeclAssign }
                            [ type ] identifier = expression
simple Var Decl Assign
                      ::=
for Test
                            expression
for Incr
                       ::= varIncr \{ , varIncr \}
varIncr
                       ::= identifier = expression
```

The forInit phrase can either initialize previously declared variables (forOldInit), or it can declare and initialize new variables whose scope is just this loop (forNewInit). They differ in whether or not the first thing after the open parenthesis is a type.

In forOldInit, the initializer is just a comma-separated list of variable assignments.

In forNewInit, the initializer is a comma-separated list of variable declarations and initializations. After the first one, not every initializer in the list needs a type; if missing, the type is the nearest type earlier in the list. The scope of each variable declared extends to subsequent initializers, the rest of the for-loop header, and the loop body statement.

Example. Copy values from one array to another:

```
int a[32], b[32];
...
for (int i = 0, j = i+offset; i < 32-offset; i = i+1, j = j+1)
    a[i] = b[j];</pre>
```

8.8 Function definitions

A function definition is introduced by the function keyword. This is followed by the type of the function return-value, the name of the function being defined, the formal arguments, and optional provisos (provisos are discussed in more detail in Section 14.1). After this is the function body and, finally, the endfunction keyword that is optionally labelled again with the function name. Each formal argument declares an identifier and its type.

```
functionDef
                        ::= [attributeInstances]
                             functionProto
                                 functionBody
                             endfunction [ : identifier ]
  function Proto
                             function type identifier ( [ functionFormals ] ) [ provisos ];
  functionFormals
                             functionFormal { , functionFormal }
  functionFormal
                             type identifier
The function body can contain the usual repertoire of statements:
                             actionBlock
  functionBody
                             action Value Block
                             { functionBodyStmt }
  functionBodyStmt
                        ::= returnStmt
                             varDecl \mid varAssign
                             functionDef
                             moduleDef
                             < functionBody > BeginEndStmt
                             < functionBody > If \mid < functionBody > Case
                             < functionBody > For \mid < functionBody > While
  returnStmt
                        ::= return expression ;
```

A value can be returned from a function in two ways, as in SystemVerilog. The first method is to assign a value to the function name used as an ordinary variable. This "variable" can be assigned multiple times in the function body, including in different arms of conditionals, in loop bodies, and so on. The function body is viewed as a traditional sequential program, and value in the special variable at the end of the body is the value returned. However, the "variable" cannot be used in an expression (e.g., on the right-hand side of an assignment) because of ambiguity with recursive function calls.

Alternatively, one can use a **return** statement anywhere in the function body to return a value immediately without any further computation. If the value is not explicitly returned nor bound, the returned value is undefined.

Example. The boolean negation function:

```
function Bool notFn (Bool x);
   if (x) notFn = False;
   else   notFn = True;
endfunction: notFn
```

Example. The boolean negation function, but using return instead:

```
function Bool notFn (Bool x);
     if (x) return False;
     else
           return True;
 endfunction: notFn
Example. The factorial function, using a loop:
function int factorial (int n);
    int f = 1, j = 0;
    while (j < n)
      begin
        f = f * j;
        j = j + 1;
      end
    factorial = f;
 endfunction: factorial
Example. The factorial function, using recursion:
```

```
function int factorial (int n);
   if (n <= 1) return (1);
   else return (n * factorial (n - 1));
endfunction: factorial
```

8.8.1 Definition of functions by assignment

A function can also be defined using the following syntax.

```
functionProto
                    ::= function type identifier ( [ functionFormals ] ) [ provisos
                        = expression;
```

The part up to and including the *provisos* is the same as the standard syntax shown in Section 8.8. Then, instead of a semicolon, we have an assignment to an expression that represents the function body. The expression can of course use the function's formal arguments, and it must have the same type as the return type of the function.

Example 1. The factorial function, using recursion (from above:)

```
function int factorial (int n) = (n<=1 ? 1 : n * factorial(n-1));</pre>
```

Example 2. Turning a method into a function. The following function definition:

```
function int f1 (FIFO#(int) i);
      return i.first();
   endfunction
could be rewritten as:
```

```
function int f2(FIFO#(int) i) = i.first();
```

8.8.2 Function types

The function type is required for functions defined at the top level of a package and for recursive functions (such as the factorial examples above). You may choose to leave out the types within a function definition at lower levels for non-recursive functions,

If not at the top level of a package, Example 2 from the previous section could be rewritten as:

```
function f1(i);
  return i.first();
endfunction
```

or, if defining the function by assignment:

```
function f1 (i) = i.first();
```

Note that currently incomplete type information will be ignored. If, in the above example, partial type information were provided, it would be the same as no type information being provided. This may cause a type-checking error to be reported by the compiler.

9 Expressions

Expressions occur on the right-hand sides of variable assignments, on the left-hand and right-hand side of register assignments, as actual parameters and arguments in module instantiation, function calls, method calls, array indexing, and so on.

There are many kinds of primary expressions. Complex expressions are built using the conditional expressions and unary and binary operators.

9.1 Don't-care expressions

When the value of an expression does not matter, a *don't-care* expression can be used. It is written with just a question mark and can be used at any type. The compiler will pick a suitable value.

```
exprPrimary ::= ?
```

A don't-care expression is similar, but not identical to, the x value in Verilog, which represents an unknown value. A don't-care expression is unknown to the programmer, but represents a particular fixed value chosen statically by the compiler.

The programmer is encouraged to use don't-care values where possible, both because it is useful documentation and because the compiler can often choose values that lead to better circuits.

Example:

9.2 Conditional expressions

Conditional expressions include the conditional operator and case expressions. The conditional operator has the usual syntax:

```
\begin{array}{lll} condExpr & ::= & condPredicate \ ? \ expression \ := & exprOrCondPattern \ \} \\ exprOrCondPattern & ::= & expression \\ & & expression \ \\
```

Conditional expressions have the usual semantics. In an expression e_1 ? e_2 : e_3 , e_1 can be a boolean expression. If it evaluates to True, then the value of e_2 is returned; otherwise the value of e_3 is returned. More generally, e_1 can include pattern matching, and this is described in Section 10, on pattern matching

Example.

```
module mkCondExp ();

// instantiating registers
  Reg#(Bit#(4)) a <- mkReg(0);
  Reg#(Bit#(4)) b <- mkReg(0);

rule dostuff;
  a <= (b>4) ? 2 : 10;
  endrule
endmodule
```

Case expressions are described in Section 10, on pattern matching.

9.3 Unary and binary operators

```
operatorExpr ::= unop\ expression | expression\ binop\ expression
```

Binary operator expressions are built using the *unop* and *binop* operators listed in the following table, which are a subset of the operators in SystemVerilog. The operators are listed here in order of decreasing precedence.

Unary and Binary Operators in order of Precedence				
Operator	Associativity	Comments		
+ - ! ~	n/a	Unary: plus, minus, logical not, bitwise invert		
&	n/a	Unary: and bit reduction		
~&	n/a	Unary: nand bit reduction		
1	n/a	Unary: or bit reduction		
~	n/a	Unary: nor bit reduction		
^	n/a	Unary: xor bit reduction		
~~ ~~	n/a	Unary: xnor bit reduction		
* / %	Left	multiplication, division, modulus		
+ -	Left	addition, subtraction		
<< >>	Left	left and right shift		
<= >= < >	Left	comparison ops		
== !=	Left	equality, inequality		
&	Left	bitwise and		
^	Left	bitwise xor		
~~ ~~	Left	bitwise equivalence (xnor)		
I	Left	bitwise or		
&&	Left	logical and		
11	Left	logical or		

Constructs that do not have any closing token, such as conditional statements and expressions, have lowest precedence so that, for example,

```
e1 ? e2 : e3 + e4
```

is parsed as follows:

```
e1 ? e2 : (e3 + e4)
```

and not as follows:

(e1 ? e2 : e3) + e4

9.4 Bit concatenation and selection

Bit concatenation and selection are expressed in the usual Verilog notation:

```
exprPrimary ::= bitConcat \mid bitSelect

bitConcat ::= { expression \  \} }

bitSelect ::= exprPrimary \  [ expression \  ] ]
```

In a bit concatenation, each component must have the type $\mathtt{bit}[m:0]$ $(m\geq 0, \text{ width } m+1)$. The result has type $\mathtt{bit}[n:0]$ where n+1 is the sum of the individual bit-widths $(n\geq 0)$.

In a bit or part selection, the exprPrimary must have type bit [m:0] ($m\ge 0$), and the index expressions must have an acceptable index type (e.g. Integer, Bit#(n), Int#(n), or UInt#(n)). With a single index ([e]), a single bit is selected, and the output is of type bit [1:0]. With two indexes ($[e_1:e_2]$), e_1 must be $\ge e_2$, and the indexes are inclusive, i.e., the bits selected go from the low index to the high index, inclusively. The selection has type bit [k:0] where k+1 is the width of the selection and bit [0] is the least significant bit. Since the index expressions can in general be dynamic values (e.g., read out of a register), the type-checker may not be able to figure out this

type, in which case it may be necessary to use a type assertion to tell the compiler the desired result type (see Section 9.10). The type specified by the type assertion need not agree with width specified by the indexes— the system will truncate from the left (most-significant bits) or pad with zeros to the left as necessary.

Example:

In BSV programs one will sometimes encounter the Bit#(0) type. One common idiomatic example is the type Maybe#(Bit#(0)) (see the Maybe#() type in Section 7.3). Here, the type Bit#(0) is just used as a place holder, when all the information is being carried by the Maybe structure.

9.5 Begin-end expressions

A begin-end expression is like an "inline" function, i.e., it allows one to express a computation using local variables and multiple variable assignments and then finally to return a value. A begin-end expression is analogous to a "let block" commonly found in functional programming languages. It can be used in any context where an expression is required.

```
\begin{array}{lll} exprPrimary & ::= & beginEndExpr \\ & beginEndExpr & ::= & begin [ : identifier ] \\ & & \{ expressionStmt \} \\ & & expression \\ & & end [ : identifier ] \end{array}
```

Optional identifier labels are currently used for documentation purposes only. The statements contained in the block can contain local variable declarations and all the other kinds of statements.

```
expressionStmt \qquad ::= \quad varDecl \mid varAssign \\ \mid \quad functionDef \\ \mid \quad moduleDef \\ \mid \quad <expression>BeginEndStmt \\ \mid \quad <expression>If \mid <expression>Case \\ \mid \quad <expression>For \mid \quad <expression>While \\ \\ \text{Example:} \qquad \\
```

9.6 Actions and action blocks

Any expression that is intended to act on the state of the circuit (at circuit execution time) is called an *action* and has type Action. The type Action is special, and cannot be redefined.

Primitive actions are provided as methods in interfaces to predefined objects (such as registers or arrays). For example, the predefined interface for registers includes a ._write() method of type Action:

```
interface Reg#(type a);
  method Action _write (a x);
  method a _read ();
endinterface: Reg
```

Section 8.4 describes special syntax for register reads and writes using non-blocking assignment so that most of the time one never needs to mention these methods explicitly.

The programmer can create new actions only by building on these primitives, or by using Verilog modules. Actions are combined by using action blocks:

```
exprPrimary
                       ::= actionBlock
                       ::= action [ : identifier ]
actionBlock
                                 \{ actionStmt \}
                            endaction [ : identifier ]
actionStmt
                           regWrite
                       ::=
                            varDo \mid varDeclDo
                            function Call
                            system TaskStmt
                            ( expression )
                            actionBlock
                            varDecl \mid varAssign
                            functionDef
                            moduleDef
                            < action > BeginEndStmt
                            < action > If \mid < action > Case
                            < action > For \mid < action > While
```

The action block can be labelled with an identifier, and the endaction keyword can optionally be labelled again with this identifier. Currently this is just for documentation purposes.

Example:

The Standard Prelude package defines the trivial action that does nothing:

```
Action noAction;
```

which is equivalent to the expression:

```
action endaction
```

The Action type is actually a special case of the more general type ActionValue, described in the next section:

```
typedef ActionValue#(void) Action;
```

9.7 Actionvalue blocks

Note: this is an advanced topic and can be skipped on first reading.

Actionvalue blocks express the concept of performing an action and simultaneously returning a value. For example, the pop() method of a stack interface may both pop a value from a stack (the action) and return what was at the top of the stack (the value). ActionValue is a predefined abstract type:

```
ActionValue#(a)
```

The type parameter a represents the type of the returned value. The type ActionValue is special, and cannot be redefined.

Actionvalues are created using actionvalue blocks. The statements in the block contain the actions to be performed, and a return statement specifies the value to be returned.

```
exprPrimary
                       ::= actionValueBlock
action Value Block
                       ::= actionvalue [ : identifier ]
                                 { action ValueStmt }
                            endactionvalue [ : identifier ]
action Value Stmt \\
                       ::= regWrite
                            varDo \mid varDeclDo
                            function Call
                            system TaskStmt
                             ( expression )
                            returnStmt
                            varDecl \mid varAssign
                            functionDef
                            moduleDef
                            <\!actionValue\!\!>\!BeginEndStmt
                             < action Value > If \mid < action Value > Case
                             < action Value > For \mid < action Value > While
```

Given an action and yield the value:

```
varDeclDo ::= type identifier <- expression;

varDo ::= identifier <- expression;
```

The first rule above declares the identifier, performs the actionvalue represented by the expression, and assigns the returned value to the identifier. The second rule is similar and just assumes the identifier has previously been declared.

Example. A stack:

. . .

```
IntStack s1;
...
   IntStack s2;
...
   action
      int x <- s1.pop; -- A
      s2.push (x+1); -- B
   endaction</pre>
```

In line A, we perform a pop action on stack s1, and the returned value is bound to x. If we wanted to discard the returned value, we could have omitted the "x <-" part. In line B, we perform a push action on s2.

Note the difference between this statement:

```
x \leftarrow s1.pop;
```

and this statement:

```
z = s1.pop;
```

In the former, x must be of type int; the statement performs the pop action and x is bound to the returned value. In the latter, z must be a method of type (ActionValue#(int)) and z is simply bound to the method s1.pop. Later, we could say:

```
x <- z;
```

endfunction

to perform the action and assign the returned value to x. Thus, the = notation simply assigns the left-hand side to the right-hand side. The <- notation, which is only used with action value right-hand sides, performs the action and assigns the returned value to the left-hand side.

Example: Using an actionvalue block to define a pop in a FIFO.

```
import FIFO :: *;
// Interface FifoWithPop combines first with deq
interface FifoWithPop#(type t);
  method Action eng(t data);
  method Action clear;
  method ActionValue#(t) pop;
endinterface
// Data is an alias of Bit#(8)
typedef Bit#(8) Data;
// The next function makes a deq and first from a fifo and returns an actionvalue block
function ActionValue#(t) fifoPop(FIFO#(t) f) provisos(Bits#(t, st));
  return(
     actionvalue
        f.deq;
        return f.first;
      endactionvalue
  );
```

```
// Module mkFifoWithPop
(* synthesize, always_ready = "clear" *)
module mkFifoWithPop(FifoWithPop#(Data));

// A fifo of depth 2
FIFO#(Data) fifo <- mkFIFO;

// methods
method enq = fifo.enq;
method clear = fifo.clear;
method pop = fifoPop(fifo);
endmodule</pre>
```

9.8 Function calls

Function calls are expressed in the usual notation, i.e., a function applied to its arguments, listed in parentheses. If a function does not have any arguments, the parentheses are optional.

```
exprPrimary ::= functionCall 
 functionCall ::= exprPrimary [ ( [ expression { , expression } ] ) ]
```

A function which has a result type of Action can be used as a statement when in the appropriate context.

Note that the function position is specified as *exprPrimary*, of which *identifier* is just one special case. This is because in BSV functions are first-class objects, and so the function position can be an expression that evaluates to a function value. Function values and higher-order functions are described in Section 14.2.

Example:

```
module mkFunctionCalls ();
  function Bit#(4) everyOtherBit(Bit#(8) a);
      let result = {a[7], a[5], a[3], a[1]};
      return result;
   endfunction
  function Bool isEven(Bit#(8) b);
      return (b[0] == 0);
   endfunction
  Reg#(Bit#(8)) a
                       <- mkReg(0);
  Reg#(Bit#(4)) b
                       <- mkReg(0);
  rule doSomething (isEven(a)); // calling "isEven" in predicate: fire if a is an even number
      b <= everyOtherBit(a);</pre>
                              // calling a function in the rule body
   endrule
endmodule
```

9.9 Method calls

Method calls are expressed by selecting a method from an interface using dot notation, and then applying it to arguments, if any, listed in parentheses. If the method does not have any arguments the parentheses are optional.

```
exprPrimary ::= methodCall 
 methodCall ::= exprPrimary . identifier [ ( [ expression { , expression } ] ) ]
```

The *exprPrimary* is any expression that represents an interface, of which *identifier* is just one special case. This is because in BSV interfaces are first-class objects. The *identifier* must be a method in the supplied interface. Example:

```
// consider the following stack interface
interface StackIFC #(type data_t);
   method Action push(data_t data);
                                       // an Action method with an argument
   method ActionValue#(data_t) pop(); // an actionvalue method
                                       // a value method
   method data_t first;
endinterface
// when instantiated in a top module
module mkTop ();
  StackIFC#(int) stack
                          <- mkStack; // instantiating a stack module
                 counter <- mkReg(0);// a counter register</pre>
 Reg#(int)
                 result <- mkReg(0);// a result register
  rule pushdata;
     stack.push(counter); // calling an Action method
  endrule
 rule popdata;
     let x <- stack.pop; // calling an ActionValue method</pre>
     result <= x;
  endrule
  rule readValue;
     let temp_val = stack.first; // calling a value method
  endrule
 rule inc_counter;
     counter <= counter +1;</pre>
  endrule
endmodule
```

9.10 Static type assertions

We can assert that an expression must have a given type by using Verilog's "type cast" notation:

```
\begin{array}{lll} exprPrimary & ::= & typeAssertion \\ typeAssertion & ::= & type ', bitConcat \\ | & type ', (expression ) \\ bitConcat & ::= & \{expression \ \{\ , expression \ \}\ \} \end{array}
```

In most cases type assertions are used optionally just for documentation purposes. Type assertions are necessary in a few places where the compiler cannot work out the type of the expression (an example is a bit-selection with run-time indexes).

In BSV although type assertions use Verilog's type cast notation, they are never used to change an expression's type. They are used either to supply a type that the compiler is unable to determine by itself, or for documentation (to make the type of an expression apparent to the reader of the source code).

9.11 Struct and union expressions

Section 7.3 describes how to define struct and union types. Section 8.1 describes how to declare variables of such types. Section 8.2 describes how to update variables of such types.

9.11.1 Struct expressions

To create a struct value, e.g., to assign it to a struct variable or to pass it an actual argument for a struct formal argument, we use the following notation:

```
exprPrimary ::= structExpr

structExpr ::= Identifier \{ memberBind \{ , memberBind \} \}

memberBind ::= identifier : expression
```

The leading *Identifier* is the type name to which the struct type was typedefed. Each *memberBind* specifies a member name (*identifier*) and the value (*expression*) it should be bound to. The members need not be listed in the same order as in the original typedef. If any member name is missing, that member's value is undefined.

Semantically, a *structExpr* creates a struct value, which can then be bound to a variable, passed as an argument, stored in a register, etc.

Example (using the processor example from Section 7.3):

```
typedef struct { Addr pc; RegFile rf; Memory mem; } Proc;
...
Proc cpu;
cpu = Proc { pc : 0, rf : ... };
```

In this example, the mem field is undefined since it is omitted from the struct expression.

9.11.2 Struct member selection

A member of a struct value can be selected with dot notation.

```
exprPrimary ::= exprPrimary . identifier
Example (using the processor example from Section 7.3):
```

```
cpu.pc
```

Since the same member name can occur in multiple types, the compiler uses type information to resolve which member name you mean when you do a member selection. Occasionally, you may need to add a type assertion to help the compiler resolve this.

Update of struct variables is described in Section 8.2.

9.11.3 Tagged union expressions

To create a tagged union value, e.g., to assign it to a tagged union variable or to pass it an actual argument for a tagged union formal argument, we use the following notation:

```
\begin{array}{lll} exprPrimary & ::= & taggedUnionExpr \\ taggedUnionExpr & ::= & taggedIdentifier \{ memberBind \{ \ , memberBind \} \} \\ & | & taggedIdentifier exprPrimary \\ \\ memberBind & ::= & identifier : expression \\ \end{array}
```

The leading *Identifier* is a member name of a union type, i.e., it specifies which variant of the union is being constructed.

The first form of taggedUnionExpr can be used when the corresponding member type is a struct. In this case, one directly lists the struct member bindings, enclosed in braces. Each memberBind specifies a member name (identifier) and the value (expression) it should be bound to. The members do not need to be listed in the same order as in the original struct definition. If any member name is missing, that member's value is undefined.

Otherwise, one can use the second form of taggedUnionExpr, which is the more general notation, where exprPrimary is directly an expression of the required member type.

Semantically, a *taggedUnionExpr* creates a tagged union value, which can then be bound to a variable, passed as an argument, stored in a register, etc.

Example (extending the previous one-hot example):

```
typedef union tagged { int Tagi; OneHot Tagoh; } U deriving (Bits);
  U x; // these lines are (e.g.) in a module body.
  x = tagged Tagi 23;
  x = tagged Tagoh (encodeOneHot (23));
Example (extending the previous processor example):
 typedef union tagged {
     bit [4:0] Register;
     bit [21:0] Literal;
     struct {
         bit
              [4:0] regAddr;
              [4:0] regIndex;
     } Indexed;
} InstrOperand;
 InstrOperand orand;
 orand = tagged Indexed { regAddr:3, regIndex:4 };
```

9.11.4 Tagged union member selection

A tagged union member can be selected with the usual dot notation. If the tagged union value does not have the tag corresponding to the member selection, the value is undefined. Example:

```
InstrOperand orand;
...
... orand.Indexed.regAddr ...
```

In this expression, if orand does not have the Indexed tag, the value is undefined. Otherwise, the regAddr field of the contained struct is returned.

Selection of tagged union members is more often done with pattern matching, which is discussed in Section 10.

Update of tagged union variables is described in Section 8.2.

9.12 Interface expressions

Note: this is an advanced topic that may be skipped on first reading.

Section 5.2 described top-level interface declarations. Section 5.5 described definition of the interface offered by a module, by defining each of the methods in the interface, using *methodDefs*. That is the most common way of defining interfaces, but it is actually just a convenient alternative notation for the more general mechanism described in this section. In particular, method definitions in a module are a convenient alternative notation for a **return** statement that returns an interface value specified by an interface expression.

```
moduleStmt
                      ::= returnStmt
returnStmt
                      ::= return expression ;
expression
                          \cdots see other productions \cdots
                      ::=
                           exprPrimary
                          interface Expr
exprPrimary
interface Expr
                           interface Identifier ;
                      ::=
                               { interfaceStmt }
                           endinterface [ : Identifier ]
interfaceStmt
                      ::= methodDef
                           subinterfaceDef
                           expressionStmt
                          varDecl | varAssign
expressionStmt
                           functionDef
                           moduleDef
                           < expression > BeginEndStmt
                           < expression > If \mid < expression > Case
                           <expression>For | <expression> While
```

An interface expression defines a value of an interface type. The *Identifier* must be an interface type in an existing interface type definition.

Example. Defining the interface for a stack of depth one (using a register for storage):

The Maybe type is described in Section 7.3. Note that an interface expression looks similar to an interface declaration (Section 5.2) except that it does not list type parameters and it contains method definitions instead of method prototypes.

Interface values are first-class objects. For example, this makes it possible to write interface *trans-formers* that convert one form of interface into another. Example:

```
interface FIFO#(type a);
                                   // define interface type FIFO
   method Action enq (a x);
   method Action deg;
   method a
                  first;
endinterface: FIFO
interface Get#(type a);
                                   // define interface type Get
   method ActionValue#(a) get;
endinterface: Get
// Function to transform a FIFO interface into a Get interface
function Get#(a) fifoToGet (FIFO#(a) f);
   return (interface Get
              method get();
                  actionvalue
                      f.deq();
                      return f.first();
                  endactionvalue
              endmethod: get
           endinterface);
endfunction: fifoToGet
```

9.12.1 Differences between interfaces and structs

Interfaces are similar to structs in the sense that both contain a set of named items—members in structs, methods in interfaces. Both are first-class values—structs are created with struct expressions, and interfaces are created with interface expressions. A named item is selected from both using the same notation—struct.member or interface.method.

However, they are different in the following ways:

- Structs cannot contain methods; interfaces can contain nothing but methods (and subinterfaces).
- Struct members can be updated; interface methods cannot.
- Struct members can be selected; interface methods cannot be selected, they can only be invoked (inside rules or other interface methods).
- Structs can be used in pattern matching; interfaces cannot.

9.13 Rule expressions

Note: This is an advanced topic that may be skipped on first reading.

Section 5.6 described definition of rules in a module. That is the most common way to define rules, but it is actually just a convenient alternative notation for the more general mechanism described in this section. In particular, rule definitions in a module are a convenient alternative notation for a call to the built-in addRules() function passing it an argument value of type Rules. Such a value is in general created using a rule expression. A rule expression has type Rules and consists of a collection of individual rule constructs.

```
exprPrimary
                      ::= rulesExpr
                      ::= [attributeInstances]
rulesExpr
                            rules [ : identifier ]
                                rulesStmt
                            endrules [ : identifier ]
rulesStmt
                          rule \mid expressionStmt
expressionStmt
                          varDecl \mid varAssign
                            functionDef
                            moduleDef
                            <expression>BeginEndStmt
                            < expression > If \mid < expression > Case
                            < expression > For \mid < expression > While
```

A rule expression is optionally preceded by an *attributeInstances*; these are described in Section 13.3. A rule expression is a block, bracketed by rules and endrules keywords, and optionally labelled with an identifier. Currently the identifier is used only for documentation. The individual rule construct is described in Section 5.6.

Example. Executing a processor instruction:

```
rules
   Word instr = mem[pc];
   rule instrExec;
       case (instr) matches
          tagged Add { .r1, .r2, .r3 }: begin
                                              pc <= pc+1;
                                              rf[r1] <= rf[r2] + rf[r3];
                                            end;
                                       : if (r1 == 0)
          tagged Jz {.r1, .r2}
                                              begin
                                                pc <= r2;
                                              end;
       endcase
   endrule
 endrules
Example. Defining a counter:
// IfcCounter with read method
interface IfcCounter#(type t);
 method t
                readCounter;
endinterface
```

```
// Definition of CounterType
typedef Bit#(16) CounterType;
// The next function returns the rule addOne
function Rules incReg(Reg#(CounterType) a);
 return( rules
    rule addOne;
       a \le a + 1;
    endrule
  endrules);
endfunction
// Module counter using IfcCounter interface
(* synthesize,
  reset_prefix = "reset_b",
   clock_prefix = "counter_clk",
   always_ready, always_enabled *)
module counter (IfcCounter#(CounterType));
   // Reg counter gets reset to 1 asynchronously with the RST signal
  Reg#(CounterType) counter <- mkRegA(1);</pre>
   // Add incReg rule to increment the counter
  addRules(incReg(asReg(counter)));
   // Next rule resets the counter to 1 when it reaches its limit
  rule resetCounter (counter == '1);
   action
     counter <= 0;</pre>
   endaction
   endrule
  // Output the counters value
  method CounterType readCounter;
     return counter;
   endmethod
endmodule
```

10 Pattern matching

Pattern matching provides a visual and succinct notation to compare a value against structs, tagged unions and constants, and to access members of structs and tagged unions. Pattern matching can be used in case statements, case expressions, if statements, conditional expressions, rule conditions, and method conditions.

A pattern is a nesting of tagged union and struct patterns with the leaves consisting of pattern variables, constant expressions, and the wildcard pattern .*.

In a pattern x, the variable x is declared at that point as a pattern variable, and is bound to the corresponding component of the value being matched.

A constant pattern is an integer literal, or an enumeration label (such as True or False). Integer literals can include the wildcard character? (example: 4'b00??).

A tagged union pattern consists of the tagged keyword followed by an identifier which is a union member name. If that union member is not a void member, it must be followed by a pattern for that member.

In a struct pattern, the *Identifier* following the tagged keyword is the type name of the struct as given in its typedef declaration. Within the braces are listed, recursively, the member name and a pattern for each member of the struct. The members can be listed in any order, and members can be omitted.

A tuple pattern is enclosed in braces and lists, recursively, a pattern for each member of the tuple (tuples are described in Section 12.4).

A pattern always occurs in a context of known type because it is matched against an expression of known type. Recursively, its nested patterns also have known type. Thus a pattern can always be statically type-checked.

Each pattern introduces a new scope; the extent of this scope is described separately for each of the contexts in which pattern matching may be used. Each pattern variable is implicitly declared as a new variable within the pattern's scope. Its type is uniquely determined by its position in the pattern. Pattern variables must be unique in the pattern, i.e., the same pattern variable cannot be used in more than one position in a single pattern.

In pattern matching, the value V of an expression is matched against a pattern. Note that static type checking ensures that V and the pattern have the same type. The result of a pattern match is:

- A boolean value, True, if the pattern match succeeds, or False, if the pattern match fails.
- ullet If the match succeeds, the pattern variables are bound to the corresponding members from V, using ordinary assignment.

Each pattern is matched using the following simple recursive rule:

- A pattern variable always succeeds (matches any value), and the variable is bound to that value (using ordinary procedural assignment).
- The wildcard pattern .* always succeeds.
- A constant pattern succeeds if V is equal to the value of the constant. Integer literals can include the wildcard character?. An integer literal containing a wildcard will match any constant obtained by replacing each wildcard character by a valid digit. For example, 'h12?4 will match any constant between 'h1204 and 'h12f4 inclusive.

- A tagged union pattern succeeds if the value has the same tag and, recursively, if the nested pattern matches the member value of the tagged union.
- A struct or tuple pattern succeeds if, recursively, each of the nested member patterns matches the corresponding member values in V. In struct patterns with named members, the textual order of members does not matter, and members may be omitted. Omitted members are ignored.

Conceptually, if the value V is seen as a flattened vector of bits, the pattern specifies the following: which bits to match, what values they should be matched with and, if the match is successful, which bits to extract and bind to the pattern identifiers.

10.1 Case statements with pattern matching

Case statements can occur in various contexts, such as in modules, function bodies, action and actionValue blocks, and so on. Ordinary case statements are described in Section 8.6. Here we describe pattern-matching case statements.

```
< ctxt> Case & ::= case (expression) matches \\ & \{ < ctxt> CasePatItem \} \\ & [ < ctxt> DefaultItem ] \\ & endcase \\ < ctxt> CasePatItem & ::= pattern \{ &&& expression \} : < ctxt> Stmt \\ < ctxt> DefaultItem & ::= default [::] < ctxt> Stmt \\ \end{aligned}
```

The keyword matches after the main *expression* (following the case keyword) signals that this is a pattern-matching case statement instead of an ordinary case statement.

Each case item contains a left-hand side and a right-hand side, separated by a colon. The left-hand side contains a pattern and an optional filter (&&& followed by a boolean expression). The right-hand side is a statement. The pattern variables in a pattern may be used in the corresponding filter and right-hand side. The case items may optionally be followed, finally, by a default item (the colon after the default keyword is optional).

The value of the main *expression* (following the case keyword) is matched against each case item, in the order given, until an item is selected. A case item is selected if and only if the value matches the pattern and the filter (if present) evaluates to True. Note that there is a left-to-right sequentiality in each item— the filter is evaluated only if the pattern match succeeds. This is because the filter expression may use pattern variables that are meaningful only if the pattern match succeeds. If none of the case items matches, and a default item is present, then the default item is selected.

If a case item (or the default item) is selected, the right-hand side statement is executed. Note that the right-hand side statement may use pattern variables bound on the left hand side. If none of the case items succeed, and there is no default item, no statement is executed.

Example (uses the Maybe type definition of Section 7.3):

```
case (f(a)) matches
   tagged Valid .x : return x;
   tagged Invalid : return 0;
endcase
```

First, the expression f(a) is evaluated. In the first arm, the value is checked to see if it has the form tagged Valid .x, in which case the pattern variable x is assigned the component value. If so, then the case arm succeeds and we execute return x. Otherwise, we fall through to the second case arm, which must match since it is the only other possibility, and we return 0.

Example:

```
typedef union tagged {
    bit [4:0] Register;
    bit [21:0] Literal;
     struct {
         bit [4:0] regAddr;
         bit [4:0] regIndex;
     } Indexed:
} InstrOperand;
InstrOperand orand;
     case (orand) matches
        tagged Register .r
                                                      : x = rf [r];
        tagged Literal .n
                                                      : x = n;
        tagged Indexed {regAddr: .ra, regIndex: .ri} : x = mem[ra+ri];
     endcase
Example:
Reg#(Bit#(16)) rg <- mkRegU;</pre>
 rule r;
    case (rg) matches
      'b_0000_000?_0000_0000: $display("1");
      'o_0?_00: $display("2");
      'h_?_0: $display("3");
     default: $display("D");
    endcase
 endrule
```

10.2 Case expressions with pattern matching

Case expressions with pattern matching are similar to case statements with pattern matching. In fact, the process of selecting a case item is identical, i.e., the main expression is evaluated and matched against each case item in sequence until one is selected. Case expressions can occur in any expression context, and the right-hand side of each case item is an expression. The whole case expression returns a value, which is the value of the right-hand side expression of the selected item. It is an error if no case item is selected and there is no default item.

In contrast, case statements can only occur in statement contexts, and the right-hand side of each case arm is a statement that is executed for side effect. The difference between case statements and case expressions is analogous to the difference between if statements and conditional expressions.

Example. Rules and rule composition for Pipeline FIFO using case statements with pattern matching.

```
package PipelineFIFO;
import FIFO::*;
```

```
module mkPipelineFIFO (FIFO#(a))
  provisos (Bits#(a, sa));
   // STATE -----
  Reg#(Maybe#(a))
                    taggedReg <- mkReg (tagged Invalid); // the FIFO</pre>
  RWire#(a)
                                                         // enq method signal
                    rw_enq
                              <- mkRWire;
                              <- mkRWire;
  RWire#(Bit#(0))
                    rw_deq
                                                         // deq method signal
  // RULES and RULE COMPOSITION -----
  Maybe#(a) taggedReg_post_deq = case (rw_deq.wget) matches
                                    tagged Invalid : return taggedReg;
                                    tagged Valid .x : return tagged Invalid;
                                  endcase;
  Maybe#(a) taggedReg_post_enq = case (rw_enq.wget) matches
                                   tagged Invalid : return taggedReg_post_deq;
                                    tagged Valid .v : return tagged Valid v;
                                  endcase;
  rule update_final (isValid(rw_enq.wget) || isValid(rw_deq.wget));
       taggedReg <= taggedReg_post_enq;</pre>
   endrule
```

10.3 Pattern matching in if statements and other contexts

If statements are described in Section 8.6. As the grammar shows, the predicate (condPredicate) can be a series of pattern matches and expressions, separated by &&&. Example:

```
if ( e_1 matches p_1 %%% e_2 %%% e_3 matches p_3 ) stmt1 else stmt2
```

Here, the value of e_1 is matched against the pattern p_1 ; if it succeeds, the expression e_2 is evaluated; if it is true, the value of e_3 is matched against the pattern p_3 ; if it succeeds, stmt1 is executed, otherwise stmt2 is executed. The sequential order is important, because e_2 and e_3 may use pattern variables bound in p_1 , and stmt1 may use pattern variables bound in p_1 and p_3 , and pattern variables are only meaningful if the pattern matches. Of course, stmt2 cannot use any of the pattern variables, because none of them may be meaningful when it is executed.

In general the condPredicate can be a series of terms, where each term is either a pattern match or a filter expression (they do not have to alternate). These are executed sequentially from left to right, and the condPredicate succeeds only if all of them do. In each pattern match e matches p, the value of the expression e is matched against the pattern p and, if successful, the pattern variables are bound appropriately and are available for the remaining terms. Filter expressions must be boolean expressions, and succeed if they evaluate to True. If the whole condPredicate succeeds, the bound pattern variables are available in the corresponding "consequent" arm of the construct.

The following contexts also permit a $condPredicate\ cp$ with pattern matching:

• Conditional expressions (Section 9.2):

```
cp ? e_2 : e_3
```

The pattern variables from cp are available in e_2 but not in e_3 .

• Conditions of rules (Sections 5.6 and 9.13):

```
rule r (cp);
... rule body ...
endrule
```

The pattern variables from cp are available in the rule body.

• Conditions of methods (Sections 5.5 and 9.12):

```
method t \ f \ (\dots) if (cp); ... method \ body \ \dots endmethod
```

The pattern variables from cp are available in the method body.

Example. Continuing the Pipeline FIFO example from the previous section (10.2).

```
// INTERFACE -----
method Action enq(v) if (taggedReg_post_deq matches tagged Invalid);
    rw_enq.wset(v);
endmethod

method Action deq() if (taggedReg matches tagged Valid .v);
    rw_deq.wset(?);
endmethod

method first() if (taggedReg matches tagged Valid .v);
    return v;
endmethod

method Action clear();
    taggedReg <= tagged Invalid;
endmethod

endmodule: mkPipelineFIFO

endpackage: PipelineFIFO</pre>
```

10.4 Pattern matching assignment statements

Pattern matching can be used in variable assignments for convenient access to the components of a tuple or struct value.

```
varAssign ::= match pattern = expression;
```

The pattern variables in the left-hand side pattern are declared at this point and their scope extends to subsequent statements in the same statement sequence. The types of the pattern variables are determined by their position in the pattern.

The left-hand side pattern is matched against the value of the right-hand side expression. On a successful match, the pattern variables are assigned the corresponding components in the value.

Example:

```
Reg#(Bit#(32)) a <- mkReg(0);
Tuple2#(Bit#(32), Bool) data;

rule r1;
  match {.in, .start} = data;
  //using "in" as a local variable
  a <= in;
endrule</pre>
```

11 Finite state machines

BSV contains a powerful and convenient notation for expressing finite state machines (FSMs). FSMs are essentially well-structured processes involving sequencing, parallelism, conditions and loops, with a precise compositional model of time. In principle, FSMs can be coded with rules, which are strictly more powerful, but the FSM sublanguage herein provides a succinct notation for FSM structures and automates all the generation and management of the actual FSM state. In fact, the BSV compiler translates all the constructs described here internally into rules. In particular, the primitive statements in these FSMs are standard actions (Section 9.6), obeying all the scheduling semantics of actions (Section 6.2).

First, one uses the Stmt sublanguage, described in Section C.6.1 to compose the actions of an FSM using sequential, parallel, conditional and looping structures. This sublanguage is within the *expression* syntactic category, i.e., a term in the sublanguage is an expression whose value is of type Stmt. This value can be bound to identifiers, passed as arguments and results of functions, held in static data structures, etc., like any other value. Finally, the FSM can be instantiated into hardware, multiple times if desired, by passing the Stmt value to the module constructor mkFSM. The resulting module interface has type FSM, which has methods to start the FSM and to wait until it completes.

In order to use this sublanguage, it is necessary to import the StmtFSM package, which is described in more detail in Section C.6.1.

12 Important primitives

These primitives are available via the Standard Prelude package and other standard libraries. See also Appendix $\mathbb C$ more useful libraries.

12.1 The types bit and Bit

The type bit[m:0] and its synonym Bit#(Mplus1) represents bit-vectors of width m+1, provided the type Mplus1 has been suitably defined. The lower (lsb) index must be zero. Example:

```
bit [15:0] zero;
zero = 0

typedef bit [50:0] BurroughsWord;
```

Syntax for bit concatenation and selection is described in Section 9.4.

There is also a useful function, split, to split a bit-vector into two sub-vectors:

```
function Tuple2#(Bit#(m), Bit#(n)) split (Bit#(mn) xy)
provisos (Add#(m,n,mn));
```

It takes a bit-vector of size mn and returns a 2-tuple (a pair, see Section 12.4) of bit-vectors of size m and n, respectively. The proviso expresses the size constraints using the built-in Add type class.

The function split is polymorphic, i.e, m and n may be different in different applications of the function, but each use is fully type-checked statically, i.e., the compiler verifies the proviso, performing any calculations necessary to do so.

12.1.1 Bit-width compatibility

BSV is currently very strict about bit-width compatibility compared to Verilog and SystemVerilog, in order to reduce the possibility of unintentional errors. In BSV, the types bit [m:0] and bit [n:0] are compatible only if m=n. For example, an attempt to assign from one type to the other, when $m\neq n$, will be reported by the compiler as a type-checking error—there is no automatic padding or truncation. The Standard Prelude package (see Section B) contains functions such as extend() and truncate(), which may be used explicitly to extend or truncate to a required bit-width. These functions, being overloaded over all bit widths, are convenient to use, i.e., you do not have to constantly calculate the amount by which to extend or truncate; the type checker will do it for you.

12.2 UInt, Int, int and Integer

The types $\mathtt{UInt#}(n)$ and $\mathtt{Int#}(n)$, respectively, represent unsigned and signed integer data types of width n bits. These types have all the operations from the type classes (overloading groups) \mathtt{Bits} , $\mathtt{Literal}$, \mathtt{Eq} , \mathtt{Arith} , \mathtt{Ord} , $\mathtt{Bounded}$, $\mathtt{Bitwise}$, $\mathtt{BitReduction}$, and $\mathtt{BitExtend}$. (See Appendix B for the specifications of these type classes and their associated operations.)

Note that the types UInt and Int are not really primitive; they are defined completely in BSV.

The type int is just a synonym for Int#(32).

The type Integer represents unbounded integers. Because they are unbounded, they are only used to represent static values used during static elaboration. The overloaded function fromInteger allows conversion from an Integer to various other types.

12.3 String

The type String is defined in the Standard Prelude package (B.2.7). Strings are mostly used in system tasks (such as \$display). Strings can be concatenated using the + infix operator or, equivalently, the strConcat function. Strings can be tested for equality and inequality using the == and != operators. String literals, written in double-quotes, are described in Section 2.5.

12.4 Tuples

It is frequently necessary to group a small number of values together, e.g., when returning multiple results from a function. Of course, one could define a special struct type for this purpose, but BSV predefines a number of structs called *tuples* that are convenient:

```
typedef struct {a _1; b _2;} Tuple2#(type a, type b) deriving (Bits,Eq,Bounded);
typedef ... Tuple3#(type a, type b, type c) ...;
typedef ... ...;
typedef ... Tuple8#(type a, ..., type h) ...;
```

Values of these types can be created by applying a predefined family of constructor functions:

```
tuple2 (e1, e2)
tuple3 (e1, e2, e3)
...
tuple8 (e1, e2, e3, ..., e8)
```

where the expressions eJ evaluate to the component values of the tuples. The tuple types are defined in the Standard Prelude package (B.2.12).

Components of tuples can be extracted using a predefined family of selector functions:

```
tpl_1 (e)
tpl_2 (e)
...
tpl_8 (e)
```

where the expression **e** evaluates to tuple value. Of course, only the first two are applicable to Tuple2 types, only the first three are applicable to Tuple3 types, and so on.

In using a tuple component selector, it is sometimes necessary to use a static type assertion to help the compiler work out the type of the result. Example:

```
UInt#(6)'(tpl_2 (e))
```

Tuple components are more conveniently selected using pattern matching. Example:

```
Tuple2#(int, Bool) xy;
...
  case (xy) matches
    { .x, .y } : ... use x and y ...
  endcase
```

12.5 Registers

The most elementary module available in BSV is the register (B.4), which has a Reg interface. Registers are instantiated using the mkReg module, whose single parameter is the initial value of the register. Registers can also be instantiated using the mkRegU module, which takes no parameters (don't-care initial value). The Reg interface type and the module types are shown below.

```
interface Reg#(type a);
   method Action _write (a x);
   method a _read;
endinterface: Reg

module mkReg#(a initVal) (Reg#(a))
   provisos (Bits#(a, sa));

module mkRegU (Reg#(a))
   provisos (Bits#(a, sa));
```

Registers are polymorphic, i.e., in principle they can hold a value of any type but, of course, ultimately registers store bits. Thus, the provisos on the modules indicate that the type must be in the Bits type class (overloading group), i.e., the operations pack() and unpack() must be defined on this type to convert into to bits and back.

Section 8.4 describes special notation whereby one rarely uses the _write() and _read methods explicitly. Instead, one more commonly uses the traditional non-blocking assignment notation for writes and, for reads, one just mentions the register interface in an expression.

Since mentioning the register interface in an expression is shorthand for applying the _read method, BSV also provides a notation for overriding this implicit read, producing an expression representing the register interface itself:

```
asReg (r)
```

Since it is also occasionally desired to have automatically read interfaces that are not registers, BSV also provides a notation for more general suppression of read desugaring, producing an expression that always represents an interface itself:

```
asIfc(ifc)
```

12.6 FIFOs

Package FIFO (C.2.2) defines several useful interfaces and modules for FIFOs:

```
interface FIFO#(type a);
  method Action enq (a x);
  method Action deq;
  method a first;
  method Action clear;
endinterface: FIFO

module mkFIFO (FIFO#(a))
  provisos (Bits#(a, as));

module mkSizedFIFO#(Integer depth) (FIFO#(a))
  provisos (Bits#(a, as));
```

The FIFO interface type is polymorphic, i.e., the FIFO contents can be of any type a. However, since FIFOs ultimately store bits, the content type a must be in the Bits type class (overloading group); this is specified in the provisos for the modules.

The module mkFIFO leaves the capacity of the FIFO unspecified (the number of entries in the FIFO before it becomes full).

The module mkSizedFIFO takes the desired capacity of the FIFO explicitly as a parameter.

Of course, when compiled, mkFIFO will pick a particular capacity, but for formal verification purposes it is useful to leave this undetermined. It is often useful to be able to prove the correctness of a design without relying on the capacity of the FIFO. Then the choice of FIFO depth can only affect circuit performance (speed, area) and cannot affect functional correctness, so it enables one to separate the questions of correctness and "performance tuning." Thus, it is good design practice initially to use mkFIFO and address all functional correctness questions. Then, if performance tuning is necessary, it can be replaced with mkSizedFIFO.

12.7 FIFOFs

Package FIF0F (C.2.2) defines several useful interfaces and modules for FIFOs. The FIF0F interface is like FIF0, but it also has methods to test whether the FIFO is full or empty:

```
interface FIFOF#(type a);
  method Action enq (a x);
  method Action deq;
  method a first;
  method Action clear;
  method Bool notFull;
  method Bool notEmpty;
endinterface: FIFOF

module mkFIFOF (FIFOF#(a))
  provisos (Bits#(a, as));

module mkSizedFIFOF#(Integer depth) (FIFOF#(a))
  provisos (Bits#(a, as));
```

The module mkFIFOF leaves the capacity of the FIFO unspecified (the number of entries in the FIFO before it becomes full). The module mkSizedFIFOF takes the desired capacity of the FIFO as an argument.

12.8 System tasks and functions

BSV supports a number of Verilog's system tasks and functions. There are two types of system tasks; statements which are conceptually equivalent to Action functions, and calls which are conceptually equivalent to ActionValue and Value functions. Calls can be used within statements.

```
system TaskStmt ::= system TaskCall;
```

12.8.1 Displaying information

These system task statements are conceptually function calls of type Action, and can be used in any context where an action is expected.

The only difference between the \$display family and the \$write family is that members of the former always output a newline after displaying the arguments, whereas members of the latter do not.

The only difference between the ordinary, b, o and h variants of each family is the format in which numeric expressions are displayed if there is no explicit format specifier. The ordinary \$display and \$write will output, by default, in decimal format, whereas the b, o and h variants will output in binary, octal and hexadecimal formats, respectively.

There can be any number of argument expressions between the parentheses. The arguments are displayed in the order given. If there are no arguments, \$display just outputs a newline, whereas \$write outputs nothing.

The argument expressions can be of type String, Bit#(n) (i.e., of type bit[n-1:0]), Integer, or any type that is a member of the overloading group Bits. Members of Bits will display their packed representation. The output will be interpreted as a signed number for the types Integer and Int#(n). Arguments can also be literals. Integers and literals are limited to 32 bits.

Arguments of type String are interpreted as they are displayed. The characters in the string are output literally, except for certain special character sequences beginning with a % character, which

are interpreted as format-specifiers for subsequent arguments. The following format specifiers are supported⁹:

%d	Output a number in decimal format
%b	Output a number in binary format
% o	Output a number in octal format
%h	Output a number in hexadecimal format
%с	Output a character with given ASCII code
%s	Output a string (argument must be a string)
%t	Output a number in time format
%m	Output hierarchical name

The values output are sized automatically to the largest possible value, with leading zeros, or in the case of decimal values, leading spaces. The automatic sizing of displayed data can be overridden by inserting a value $\bf n$ indicating the size of the displayed data. If $\bf n=0$ the output will be sized to minimum needed to display the data without leading zeros or spaces.

ActionValues (see Section 9.7) whose returned type is displayable can also be directly displayed. This is done by performing the associated action (as part of the action invoking \$display) and displaying the returned value.

Example:

```
$display ("%t", $time);
```

For display statements in different rules, the outputs will appear in the usual logical scheduling order of the rules. For multiple display statements within a single rule, technically there is no defined ordering in which the outputs should appear, since all the display statements are Actions within the rule and technically all Actions happen simultaneously in the atomic transaction. However, as a convenience to the programmer, the compiler will arrange for the display outputs to appear in the normal textual order of the source text, taking into account the usual flow around if-then-elses, statically elaborated loops, and so on. However, for a rule that comprises separately compiled parts (for example, a rule that invokes a method in a separately compiled module), the system cannot guarantee the ordering of display statements across compilation boundaries. Within each separately compiled part, the display outputs will appear in source text order, but these groups may appear in any order. In particular, verification engineers should be careful about these benign (semantically equivalent) reorderings when checking the outputs for correctness.

12.8.2 \$format

```
systemTaskCall ::= format([expression[, expression]])
```

Bluespec also supports \$format, a display related system task that does not exist in Verilog. \$format takes the same arguments as the \$display family of system tasks. However, unlike \$display (which is a function call of type Action), \$format is a value function which returns an object of type Fmt (section B.2.8). Fmt representations of data objects can thus be written hierarchically and applied to polymorphic types. The FShow package, described in Section C.8.8, defines a typeclass based on this capability.

Example:

⁹Displayed strings are passed through the compiler unchanged, so other format specifiers may be supported by your Verilog simulator. Only the format specifiers above are supported by Bluespec's C-based simulator.

```
typedef struct {OpCommand command;
        Bit#(8)
                  addr;
        Bit#(8)
                  data;
        Bit#(8)
                  length;
        Bool
                  lock;
        } Header deriving (Eq, Bits, Bounded);
function Fmt fshow (Header value);
    return ($format("<HEAD ")
        fshow(value.command)
        $format(" (%0d)", value.length)
        $format(" A:%h", value.addr)
        $format(" D:%h>", value.data));
endfunction
```

12.8.3 File data type

File is a defined type in BSV which is defined as:

```
typedef union tagged {
    void InvalidFile;
    Bit#(31) MCD;
    Bit#(31) FD;
} File;
```

	Type Classes for File								
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit
								Reduction	Extend
File									

Note: Bitwise operations are valid only for sub-type MCD.

12.8.4 Opening and closing file operations

```
systemTaskCall ::= $fopen ( fileName [ , fileType ] ) systemTaskStmt ::= $fclose ( fileIdentifier );
```

The \$fopen system call is of type ActionValue and can be used anywhere an ActionValue is expected. The argument fileName is of type String. \$fopen returns a fileIdentifier of type File. If there is a fileType argument, the fileIdentifier returned is a file descriptor of type FD. If there is not a fileType argument, the fileIdentifier returned is a multi channel descriptor of type MCD.

One file of type MCD is pre-opened for append, stdout_mcd (value 1).

Three files of type FD are pre-opened; they are stdin (value 0), stdout (value 1), and stderr (value 2). stdin is pre-opened for reading and stdout and stderr are pre-opened for append.

The fileType determines, according to the following table, how other files of type FD are opened:

File Types for File Descriptors				
Argument	Description			
"r" or "rb"	open for reading			
"w" or "wb"	truncate to zero length or create for writing			
"a" or "ab"	append; open for writing at end of file, or create for writing			
"r+", or "r+b", or "rb+"	open for update (reading and writing)			
"w+", or "w+b", or "wb+"	truncate or create for update			
"a+", or "a+b", or "ab+"	append; open or create for update at end of file			

The **\$fclose** system call is of type **Action** and can be used in any context where an action is expected.

12.8.5 Writing to a file

These system task calls are conceptually function calls of type Action, and can be used in any context where an action is expected. They correspond to the display tasks (\$display, \$write) but they write to specific files instead of to the standard output. They accept the same arguments (Section 12.8.1) as the tasks they are based on, with the addition of a first parameter fileIdentifier which indicates where to direct the file output.

Example:

```
Reg#(int) cnt <- mkReg(0);</pre>
let fh <- mkReg(InvalidFile) ;</pre>
let fmcd <- mkReg(InvalidFile) ;</pre>
rule open (cnt == 0 );
   // Open the file and check for proper opening
   String dumpFile = "dump_file1.dat";
   File lfh <- $fopen( dumpFile, "w" ) ;</pre>
   if ( lfh == InvalidFile )
         $display("cannot open %s", dumpFile);
         $finish(0);
      end
   cnt <= 1 ;
   fh <= 1fh ;
                             // Save the file in a Register
endrule
rule open2 (cnt == 1 ) ;
   // Open the file and check for proper opening
   // Using a multi-channel descriptor.
   String dumpFile = "dump_file2.dat";
   File lmcd <- $fopen( dumpFile ) ;</pre>
   if ( lmcd == InvalidFile )
         $display("cannot open %s", dumpFile );
         $finish(0);
```

12.8.6 Formatting output to a string

```
systemTaskStmt ::= stringTaskName ( ifcIdentifier , [ expression [ , expression ] ] ); stringTaskName ::= swrite | s
```

These system task calls are analogous to the **\$fwrite** family of system tasks. They are conceptually function calls of type **Action**, and accept the same type of arguments as the corresponding **\$fwrite** tasks, except that the first parameter must now be an interface with an _write method that takes an argument of type Bit#(n).

The task \$sformat is similar to \$swrite, except that the second argument, and only the second argument, is interpreted as a format string. This format argument can be a static string, or it can be a dynamic value whose content is interpreted as the format string. No other arguments in \$sformat are interpreted as format strings. \$sformat supports all the format specifies supported by \$display, as documented in 12.8.1.

The Bluespec compiler de-sugars each of these task calls into a call of an ActionValue version of the same task. For example:

```
$swrite(foo, "The value is %d", count);
de-sugars to
    let x <- $swriteAV("The value is %d", count);
    foo <= x;</pre>
```

An ActionValue value version is available for each of these tasks. The associated syntax is given below.

```
systemTaskCall ::= stringAVTaskName ([ expression [ , expression ] ]) stringAVTaskName ::= swriteAV | swrite
```

The ActionValue versions of these tasks can also be called directly by the user.

Use of the system tasks described in this section allows a designer to populate state elements with dynamically generated debugging strings. These values can then be viewed using other display tasks (using the **%s** format specifier) or output to a VCD file for examination in a waveform viewer.

12.8.7 Reading from a file

```
systemTaskCall ::= $fgetc ( fileIdentifier )
systemTaskStmt ::= $ungetc ( expression, fileIdentifier );
```

The **\$fgetc** system call is a function of type **ActionValue#(int)** which returns an **int** from the file specified by *fileIdentifier*.

The **\$ungetc** system statement is a function of type **Action** which inserts the character specified by *expression* into the buffer specified by *fileIdentifier*.

Example:

```
rule open ( True ) ;
   String readFile = "gettests.dat";
   File lfh <- $fopen(readFile, "r" );</pre>
   int i <- $fgetc( lfh );</pre>
   if (i != -1)
      begin
         Bit#(8) c = truncate( pack(i) );
      end
   else // an error occurred.
      begin
         $display( "Could not get byte from %s",
            readFile ) ;
      end
   $fclose ( lfh ) ;
   $finish(0);
endrule
```

12.8.8 Flushing output

```
systemTaskStmt ::= fflush ([fileIdentifier]);
```

The system call \$fflush is a function of type Action and can be used in any context where an action is expected. The \$fflush function writes any buffered output to the file(s) specified by the fileIdentifier. If no argument is provided, \$fflush writes any buffered output to all open files.

12.8.9 Stopping simulation

```
systemTaskStmt ::= finish[(expression)]; | stop[(expression))];
```

These system task calls are conceptually function calls of type Action, and can be used in any context where an action is expected.

The \$finish task causes simulation to stop immediately and exit back to the operating system. The \$stop task causes simulation to suspend immediately and enter an interactive mode. The optional argument expressions can be 0, 1 or 2, and control the verbosity of the diagnostic messages printed by the simulator. the default (if there is no argument expression) is 1.

12.8.10 VCD dumping

```
system TaskStmt ::= \$dumpvars \mid \$dumpon \mid \$dumpoff;
```

These system task calls are conceptually function calls of type Action, and can be used in any context where an action is expected.

A call to \$dumpvars starts dumping the changes of all the state elements in the design to the VCD file. BSV's \$dumpvars does not currently support arguments that control the specific module instances or levels of hierarchy that are dumped.

Subsequently, a call to \$dumpoff stops dumping, and a call to \$dumpon resumes dumping.

12.8.11 Time functions

```
systemFunctionCall ::= time \mid stime
```

These system function calls are conceptually of ActionValue type (see Section 9.7), and can be used anywhere an ActionValue is expected. The time returned is the time when the associated action was performed.

The \$time function returns a 64-bit integer (specifically, of type Bit#(64)) representing time, scaled to the timescale unit of the module that invoked it.

The \$stime function returns a 32-bit integer (specifically, of type Bit#(32)) representing time, scaled to the timescale unit of the module that invoked it. If the actual simulation time does not fit in 32 bits, the lower-order 32 bits are returned.

12.8.12 Real functions

There are two system tasks defined for the Real data type (section B.2.6), used to convert between Real and IEEE standard 64-bit vector representation, \$realtobits and \$bitstoreal. They are identical to the Verilog functions.

```
systemTaskCall ::= $realtobits ( expression ) systemTaskCall ::= $bitstoreal ( expression )
```

12.8.13 Testing command line input

Information for use in simulation can be provided on the command line. This information is specified via optional arguments in the command used to invoke the simulator. These arguments are distinguished from other simulator arguments by starting with a plus (+) character and are therefore known as *plusargs*. Following the plus is a string which can be examined during simulation via system functions.

```
systemTaskCall ::= test\plusargs (expression)
```

The \$test\$plusargs system function call is conceptually of ActionValue type (see Section 9.7), and can be used anywhere an ActionValue is expected. An argument of type String is expected and a boolean value is returned indicating whether the provided string matches the beginning of any plusarg from the command line.

13 Guiding the compiler with attributes

This section describes how to guide the compiler in some of its decisions using BSV's attribute syntax.

```
attributeInstances ::= attributeInstance { attributeInstance } attributeInstance } *:= (* attrSpec { , attrSpec } *)
```

Attributes can be associated with a number of different language constructs such as module, interface, and function definitions. A given attribute declaration is applied to the first attribute construct that follows the declaration.

13.1 Verilog module generation attributes

In addition to compiler flags on the command line, it is possible to guide the compiler with attributes that are included in the BSV source code.

The attributes synthesize and noinline control code generation for top-level modules and functions, respectively.

Attribute name	Section	Top-level module definitions	Top-level function definitions
synthesize	13.1.1		
noinline	13.1.2		$\sqrt{}$

13.1.1 synthesize

When the compiler is directed to generate Verilog or Bluesim code for a BSV module, by default it tries to integrate all definitions into one big module. The synthesize attribute marks a module for code generation and ensures that, when generated, instantiations of the module are not flattened but instead remain as references to a separate module definition. Modules that are annotated with the synthesize attribute are said to be synthesized modules. The BSV hierarchy boundaries associated with synthesized modules are maintained during code generation. Not all BSV modules can be synthesized modules (i.e.,can maintain a module boundary during code generation). Section 5.8 describes in more detail which modules are synthesizable.

13.1.2 noinline

The noinline attribute is applied to functions, instructing the compiler to generate a separate module for the function. This module is instantiated as many times as required by its callers. When used in complicated calling situations, the use of the noinline attribute can simplify and speed up compilation. The noinline attribute can only be applied to functions that are defined at the top level and the inputs and outputs of the function must be in the typeclass Bits.

Example:

```
(* noinline *)
function Bit#(LogK) popCK(Bit#(K) x);
  return (popCountTable(x));
endfunction: popCK
```

13.2 Interface attributes

Interface attributes express protocol and naming requirements for generated Verilog interfaces. They are considered during generation of the Verilog module which uses the interface. These attributes can be applied to synthesized modules, methods, interfaces, and subinterfaces at the top level only. If the module is not synthesized, the attribute is ignored. The following table shows which attributes can be applied to which elements. These attributes cannot be applied to Clock, Reset, or Inout subinterface declarations.

Attribute name	Section	Synthesized module definitions	Interface type declarations	Methods of interface type declarations	Subinterfaces of interface type declarations
ready=	13.2.1				
enable=	13.2.1				
result=	13.2.1			√	
prefix=	13.2.1				
port=	13.2.1				
always_ready	13.2.2				
always_enabled	13.2.2				

There is a direct correlation between interfaces in Bluespec and ports in the generated Verilog. These attributes can be applied to interfaces to control the naming and the protocols of the generated Verilog ports.

Bluespec uses a simple Ready-Enable micro-protocol for each method within the module's interface. Each method contains both a output Ready (RDY) signal and an input Enable (EN) signal in addition to any needed directional data lines. When a method can be safely called it asserts its RDY signal. When an external caller sees the RDY signal it may then call (in the same cycle) the method by asserting the method's EN signal and providing any required data.

Generated Verilog ports names are based the method name and argument names, with some standard prefixes. In the ActionValue method method shown below

```
method ActionValue#( type_out ) method1 ( type_in data_in ) ;
```

the following ports are generated:

RDY_method1 Output ready signal of the protocol

EN_method1 Input signal for Action and Action Value methods method1 Output signal of ActionValue and Value methods

method1_data_in Input signal for method arguments

Interface attributes allow control over the naming and protocols of individual methods or entire interfaces.

13.2.1 Renaming attributes

ready= and enable= Ready and enable ports use RDY_ and EN_ as the default prefix to the method names. The attributes ready= "string" and enable= "string" replace the prefix annotation and method name with the specified string as the name instead. These attributes may be associated with method declarations (methodProto) only (Section 5.2).

In the above example, the following attribute would replace the RDY_method1 with avMethodIsReady and EN_method1 with GO.

```
(* ready = "avMethodIsReady", enable = "GO" *)
```

Note that the ready= attribute is ignored if the method or module is annotated as always_ready or always_enabled, while the enable= attribute is ignored for value methods as those are annotated as always_enabled.

result= By default the output port for value methods and ActionValue methods use the method name. The attribute result = "string" causes the output to be renamed to the specified string. This is useful when the desired port names must begin with an upper case letter, which is not valid for a method name. These attributes may be associated with method declarations (methodProto) only (Section 5.2).

In the above example, the following attribute would replace the method1 port with OUT.

```
(* result = "OUT" *)
```

Note that the result= attribute is ignored if the method is an Action method which does not return a result.

prefix= and port= By default, the input ports for methods are named by using the name of the method as the prefix and the name of the method argument as the suffix, into method_argument. The prefix and/or suffix name can be replaced by the attributes prefix="string" and port="string". By combining these attributes any desired string can be generated. The prefix= attribute replaces the method name and the port= attribute replaces the argument name in the generated Verilog port name. The prefix string may be empty, in which case the joining underscore is not added.

The prefix= attribute may be associated with method declarations (*methodProto*) or sub-interface declarations (*subinterfaceDecl*). The port= attribute may be associated with each method prototype argument in the interface declaration (*methodProtoFormal*) (Section 5.2).

In the above example, the following attribute would replace the method1_data_in port with IN_DATA.

Note that the prefix= attribute is ignored if the method does not have any arguments.

The prefix= attribute may also be used on sub-interface declarations to aid the renaming of interface hierarchies. By default, interface hierarchies are named by prefixing the sub-interface name to names of the methods within that interface (Section 5.2.1.) Using the prefix attribute on the subinterface is a way of replacing the sub-interface name. This is demonstrated in the example in Section 13.2.3.

13.2.2 Port protocol attributes

The port protocol attributes always_enabled and always_ready remove unnecessary ports. These attributes are applied to synthesized modules, methods, interfaces, and subinterfaces at the top level only. If the module is not synthesized, the attribute is ignored. The compiler verifies that the attributes are correctly applied.

The attribute always_enabled specifies that no enable signal will be generated for the associated interface methods. The methods will be executed on every clock cycle and the compiler verifies that the caller does this.

The attribute always_ready specifies that no ready signals will be generated. The compiler verifies that the associated interface methods are permanently ready. always_enabled implies always_ready.

The always_ready and always_enabled attributes can be associated with the method declarations (methodProto), the sub-interface declarations (subinterfaceDecl), or the interface declaration (interfaceDecl) itself. In these cases, the attribute does not take any arguments. Example:

```
interface Test;
   (* always_enabled *)
   method ActionValue#(Bool) check;
endinterface: Test
```

The attributes can also be associated with a module, in which case the attribute can have as an argument the list of methods to which the attribute is applied. When associated with a module, the attributes are applied when the interface is implemented by a module, not at the declaration of the interface. Example:

In this example, note that only the enq method of the subifc interface is always_ready. Other methods of the interface, such as deq, are not always_ready.

If every method of the interface is always_ready or always_enabled, individual methods don't have to be specified when applying the attribute to a module. Example:

```
(* synthesize *)
(* always_enabled *)
module mkServer (ILookup);
```

13.2.3 Interface attributes example

```
(* always_ready *)
                                     // all methods in this and all sub-interface
                                     // have this property
                                     // always_enabled is also allowed here
interface ILookup;
    (* prefix = "" *)
                                     // subifc_ will not be used in naming
                                     // always_enabled and always_ready are allowed.
   interface Fifo#(int) subifc;
    (* enable = "GOread" *)
                                     // EN_read becomes GOread
   method Action read ();
    (* always_enabled *)
                                     // always_enabled and always_ready
                                     // are allowed on any individual method
    (* result = "CHECKOK" *)
                                     // output checkData becomes CHECKOK
    (* prefix = "" *)
                                     // checkData_datain1 becomes DIN1
```

13.3 Scheduling attributes

Attribute name	Section	Module definitions	rule definitions	rules expressions
fire_when_enabled	13.3.1			
no_implicit_conditions	13.3.2			
descending_urgency	13.3.3			
execution_order	13.3.4			
mutually_exclusive	13.3.5			
conflict_free	13.3.6			
preempts	13.3.7			

Scheduling attributes are used to express certain performance requirements. When the compiler maps rules into clocks, as described in Section 6.2.2, scheduling attributes guide or constrain its choices, in order to produce a schedule that will meet performance goals.

Scheduling attributes are most often attached to rules or to rule expressions, but some can also be added to module definitions.

The scheduling attributes are are only applied when the module is synthesized.

13.3.1 fire_when_enabled

The fire_when_enabled scheduling attribute immediately precedes a rule (just before the rule keyword) and governs the rule.

It asserts that this rule must fire whenever its predicate and its implicit conditions are true, *i.e.*, when the rule conditions are true, the attribute checks that there are no scheduling conflicts with other rules that will prevent it from firing. This is statically verified by the compiler. If the rule won't fire, the compiler will report an error.

Example. Using fire_when_enabled to ensure the counter is reset:

```
// IfcCounter with read method
interface IfcCounter#(type t);
  method t         readCounter;
endinterface

// Definition of CounterType
typedef Bit#(16) CounterType;

// Module counter using IfcCounter interface. It never contains 0.

(* synthesize,
    reset_prefix = "reset_b",
    clock_prefix = "counter_clk",
    always_ready = "readCounter",
```

```
always_enabled= "readCounter" *)
module counter (IfcCounter#(CounterType));
   // Reg counter gets reset to 1 asynchronously with the RST signal
  Reg#(CounterType)
                       counter
                                 <- mkRegA(1);
  //
         Next rule resets the counter to 1 when it reaches its limit.
  //
         The attribute fire_when_enabled will check that this rule will fire
   //
         if counter == '1
   (* fire_when_enabled *)
  rule resetCounter (counter == '1);
     counter <= 1;</pre>
   endrule
  // Next rule updates the counter.
  rule updateCounter;
     counter <= counter + 1;</pre>
   endrule
   // Method to output the counter's value
  method CounterType readCounter;
    return counter;
   endmethod
endmodule
```

Rule resetCounter conflicts with rule updateCounter because both try to modify the counter register when it contains all its bits set to one. If the rule updateCounter is more urgent, only the rule updateCounter will fire. In this case, the assertion fire_when_enabled will be violated and the compiler will produce an error message. Note that without the assertion fire_when_enabled the compilation process will be correct.

13.3.2 no_implicit_conditions

The no_implicit_conditions scheduling attribute immediately precedes a rule (just before the rule keyword) and governs the rule.

It asserts that the implicit conditions of all interface methods called within the rule must always be true; only the explicit rule predicate controls whether the rule can fire or not. This is statically verified by the compiler, and it will report an error if necessary.

Example:

```
// Import the FIFO package
import FIFO :: *;

// IfcCounter with read method
interface IfcCounter#(type t);
  method t     readCounter;
  method Action setReset(t a);
endinterface

// Definition of CounterType
typedef Bit#(16) CounterType;
```

```
// Module counter using IfcCounter interface
(* synthesize,
  reset_prefix = "reset_b",
   clock_prefix = "counter_clk",
   always_ready = "readCounter",
   always_enabled = "readCounter" *)
module counter (IfcCounter#(CounterType));
   // Reg counter gets reset to 1 asynchronously with the RST signal
   Reg#(CounterType)
                       counter
                                 <- mkRegA(1);
   // The 4 depth valueFifo contains a list of reset values
   FIFO#(CounterType) valueFifo <- mkSizedFIFO(4);</pre>
        Next rule increases the counter with each counter_clk rising edge
        if the maximum has not been reached
   (* no_implicit_conditions *)
   rule updateCounter;
     if (counter != '1)
       counter <= counter + 1;</pre>
   endrule
  // Next rule resets the counter to a value stored in the valueFifo
   (* no_implicit_conditions *)
  rule resetCounter (counter == '1);
     counter <= valueFifo.first();</pre>
     valueFifo.deq();
   endrule
  // Output the counters value
  method CounterType readCounter;
     return counter;
   endmethod
   // Update the valueFifo
  method Action setReset(CounterType a);
     valueFifo.enq(a);
   endmethod
endmodule
```

The assertion no_implicit_conditions is incorrect for the rule resetCounter, resulting in a compilation error. This rule has the implicit condition in the FIFO module due to the fact that the deq method cannot be invoked if the fifo valueFifo is empty. Note that without the assertion no error will be produced and that the condition if (counter != '1) is not considered an implicit one.

13.3.3 descending_urgency

The compiler maps rules into clocks, as described in Section 6.2.2. In each clock, amongst all the rules that can fire in that clock, the system picks a subset of rules that do not conflict with each other, so that their parallel execution is consistent with the reference TRS semantics. The order in which rules are considered for selection can affect the subset chosen. For example, suppose rules r1 and r2 conflict, and both their conditions are true so both can execute. If r1 is considered first and selected, it may disqualify r2 from consideration, and vice versa. Note that the urgency ordering is

independent of the TRS ordering of the rules, i.e., the TRS ordering may be r1 before r2, but either one could be considered first by the compiler.

The designer can specify that one rule is more *urgent* than another, so that it is always considered for scheduling before the other. The relationship is transitive, i.e., if rule r1 is more urgent than rule r2, and rule r2 is more urgent than rule r3, then r1 is considered more urgent than r3.

Urgency is specified with the descending_urgency attribute. Its argument is a string containing a comma-separated list of rule names (see Section 5.6 for rule syntax, including rule names). Example:

```
(* descending_urgency = "r1, r2, r3" *)
```

This example specifies that r1 is more urgent than r2 which, in turn, is more urgent than r3.

If urgency attributes are contradictory, i.e., they specify both that one rule is more urgent than another and its converse, the compiler will report an error. Note that such a contradiction may be a consequence of a collection of urgency attributes, because of transitivity. One attribute may specify r1 more urgent than r2, another attribute may specify r2 more urgent than r3, and another attribute may specify r3 more urgent than r1, leading to a cycle, which is a contradiction.

The descending_urgency attribute can be placed in one of three syntactic positions:

- It can be placed just before the module keyword in a module definitions (Section 5.3), in which case it can refer directly to any of the rules inside the module.
- It can be placed just before the rule keyword in a rule definition, (Section 5.6) in which case it can refer directly to the rule or any other rules at the same level.
- It can be placed just before the rules keyword in a rules expression (Section 9.13), in which case it can refer directly to any of the rules in the expression.

In addition, an urgency attribute can refer to any rule in the module hierarchy at or below the current module, using a hierarchical name. For example, suppose we have:

```
module mkFoo ...;

mkBar the_bar (barInterface);

(* descending_urgency = "r1, the_bar.r2" *)
rule r1 ...
...
endrule
endmodule: mkFoo
```

The hierarchical name the_bar.r2 refers to a rule named r2 inside the module instance the_bar. This can be several levels deep, i.e., the scheduling attribute can refer to a rule deep in the module hierarchy, not just the sub-module immediately below. In general a hierarchical rule name is a sequence of module instance names and finally a rule name, separated by periods.

A reference to a rule in a sub-module cannot cross synthesis boundaries. This is because synthesis boundaries are also scheduler boundaries. Each separately synthesized part of the module hierarchy contains its own scheduler, and cannot directly affect other schedulers. Urgency can only apply to rules considered within the same scheduler.

If rule urgency is not specified, and it impacts the choice of schedule, the compiler will print a warning to this effect during compilation.

Example. Using descending_urgency to control the scheduling of conflicting rules:

```
// IfcCounter with read method
interface IfcCounter#(type t);
                readCounter;
 method t
endinterface
// Definition of CounterType
typedef Bit#(16) CounterType;
// Module counter using IfcCounter interface. It never contains 0.
(* synthesize,
  reset_prefix = "reset_b",
   clock_prefix = "counter_clk",
   always_ready = "readCounter",
   always_enabled= "readCounter" *)
module counter (IfcCounter#(CounterType));
   // Reg counter gets reset to 1 asynchronously with the RST signal
   Reg#(CounterType)
                       counter
                                <- mkRegA(1);
         The descending_urgency attribute will indicate the scheduling
         order for the indicated rules.
   (* descending_urgency = "resetCounter, updateCounter" *)
   // Next rule resets the counter to 1 when it reaches its limit.
  rule resetCounter (counter == '1);
   action
     counter <= 1;</pre>
   endaction
   endrule
   // Next rule updates the counter.
  rule updateCounter;
   action
     counter <= counter + 1;</pre>
   endaction
   endrule
  // Method to output the counter's value
  method CounterType readCounter;
     return counter;
   endmethod
```

endmodule

Rule resetCounter conflicts with rule updateCounter because both try to modify the counter register when it contains all its bits set to one. Without any descending_urgency attribute, the updateCounter rule may obtain more urgency, meaning that if the predicate of resetCounter is met, only the rule updateCounter will fire. By setting the descending_urgency attribute the designer can control the scheduling in the case of conflicting rules.

13.3.4 execution_order

With the execution_order attribute, the designer can specify that, when two rules fire in the same cycle, one rule should sequence before the other. This attribute is similar to the descending_urgency

attribute (section 13.3.3) except that it specifies the execution order instead of the urgency order. The execution_order attribute may occur in the same syntactic positions as the descending_urgency attribute (Section 13.3.3) and takes a similar argument, a string containing a comma-separated list of rule names. Example:

```
(* execution_order = "r1, r2, r3" *)
```

This example specifies that r1 should execute before r2 which, in turn, should execute before r3.

If two rules cannot execute in the order specified, because of method calls which must sequence in the opposite order, for example, then the two rules are forced to conflict.

13.3.5 mutually_exclusive

The scheduler always attempts to deduce when two rules are mutually exclusive (based on their predicates). However, this deduction can fail even when two rules are actually exclusive, either because the scheduler effort limit is exceeded or because the mutual exclusion depends on a higher-level invariant that the scheduler does not know about. The mutually_exclusive attribute allows the designer to overrule the scheduler's deduction and forces the generated schedule to treat the annotated rules as exclusive. The mutually_exclusive attribute may occur in the same syntactic positions as the descending_urgency attribute (Section 13.3.3) and takes a similar argument, a string containing a comma-separated list of rule names. Example:

```
(* mutually_exclusive = "r1, r2, r3" *)
```

This example specifies that every pair of rules that are in the annotation (i.e (r1, r2), (r1, r3), and (r2, r3)) is a mutually-exclusive rule pair.

Since an asserted mutual exclusion does not come with a proof of this exclusion, the compiler will insert code that will check and generate a runtime error if two rules ever execute during the same clock cycle during simulation. This allows a designer to find out when their use of the mutually_exclusive attribute is incorrect.

13.3.6 conflict_free

Like the mutually_exclusive rule attribute (section 13.3.5), the conflict_free rule attribute is a way to overrule the scheduler's deduction about the relationship between two rules. However, unlike rules that are annotated mutually_exclusive, rules that are conflict_free may fire in the same clock cycle. Instead, the conflict_free attribute asserts that the annotated rules will not make method calls that are inconsistent with the generated schedule when they execute.

The conflict_free attribute may occur in the same syntactic positions as the descending_urgency attribute (Section 13.3.3) and takes a similar argument, a string containing a comma-separated list of rule names. Example:

```
(* conflict_free = "r1, r2, r3" *)
```

This example specifies that every pair of rules that are in the annotation (i.e (r1, r2), (r1, r3), and (r2, r3)) is a conflict-free rule pair.

For example, two rules may both conditionally enqueue data into a FIFO with a single enqueue port. Ordinarily, the scheduler would conclude that the two rules conflict since they are competing for a single method. However, if they are annotated as conflict_free the designer is asserting that when one rule is enqueuing into the FIFO, the other will not be, so the conflict is apparent, not real.

With the annotation, the schedule will be generated as if any conflicts do not exist and code will be inserted into the resulting model to check if conflicting methods are actually called by the conflict free rules during simulation.

It is important to know the conflict_free attribute's capabilities and limitations. The attribute works with more than method calls that totally conflict (like the single enqueue port). During simulation, it will check and report any method calls amongst conflict_free rules that are inconsistent with the generated schedule (including registers being read after they have been written and wires being written after they are read). On the other hand, the conflict_free attribute does not overrule the scheduler's deductions with respect to resource usage (like uses of a multi-ported register file).

13.3.7 preempts

The designer can also prevent a rule from firing whenever another rule (or set of rules) fires. The preempts attribute accepts two elements as arguments. Each element may be either a rule name or a list of rule names. A list of rule names must be separated by commas and enclosed in parentheses. In each cycle, if any of the rule names specified in the first list can be executed and are scheduled to fire, then none of the rules specified in the second list will be allowed to fire.

The preempts attribute is similar to the descending_urgency attribute (section 13.3.3), and may occur in the same syntactic positions. The preempts attribute is equivalent to forcing a conflict and adding descending_urgency. With descending_urgency, if two rules do not conflict, then both would be allowed to fire even if an urgency order had been specified; with preempts, if one rule preempts the other, they can never fire together. If r1 preempts r2, then the compiler forces a conflict and gives r1 priority. If r1 is able to fire, but is not scheduled to, then r2 can still fire.

Examples:

```
(* preempts = "r1, r2" *)
If r1 will fire, r2 will not.
    (* preempts = "(r1, r2), r3" *)
If either r1 or r2 (or both) will fire, r3 will not.
    (* preempts = "(the_bar.r1, (r2, r3)" *)
```

If the rule r1 in the sub-module the_bar will fire, then neither r2 nor r3 will fire.

13.4 Evaluation behavior attributes

13.4.1 split and nosplit

Attribute name	Section	Action statements	ActionValue statements
split/nosplit	13.4.1		

The split/nosplit attributes are applied to Action and ActionValue statements, but cannot preced certain expressions inside an action/endaction including return, variable declarations, instantiations, and function statements.

When a rule contains an if (or case) statement, the compiler has the option either of splitting the rule into two mutually exclusive rules, or leaving it as one rule for scheduling but using MUXes in the production of the action. Rule splitting can sometimes be desirable because the two split rules are scheduled independently, so non-conflicting branches of otherwise conflicting rules can be scheduled concurrently. Splitting also allows the split fragments to appear in different positions in the logical execution order, providing the effect of condition dependent scheduling.

Splitting is turned off by default for two reasons:

- When a rule contains many if statements, it can lead to an exponential explosion in the number of rules. A rule with 15 if statements might split into 2¹⁵ rules, depending on how independent the statements and their branch conditions are. An explosion in the number of rules can dramatically slow down the compiler and cause other problems for later compiler phases, particularly scheduling.
- Splitting propagates the branch condition of each if to the predicates of the split rules. Resources required to compute rule predicates are reserved on every cycle. If a branch condition requires a scarce resource, this can starve other parts of the design that want to use that resource.

The split and nosplit attributes override any compiler flags, either the default or a flag entered on the command line (-split-if).

The split attribute splits all branches in the statement immediately following the attribute statement, which must be an Action statement. A split immediately preceding a binding (e.g. let) statement is not valid. If there are nested if or case statements within the split statement, it will continue splitting recursively through the branches of the statement. The nosplit attribute can be used to disable rule splitting within nested if statements.

Example:

```
module mkConditional#(Bit#(2) sel) ();
   Reg#(Bit#(4)) a
                          <- mkReg(0);
   Reg#(Bool)
                  done <- mkReg(False);</pre>
   rule finish;
     (*split*)
     if (a == 3)
         begin
            done <= True;
         end
     else
         (*nosplit*)
         if (a == 0)
            begin
               done <= False;</pre>
                     <= 1;
            end
         else
            begin
               done <= False;</pre>
            end
   endrule
endmodule
```

To enable rule splitting for an entire design, use the compiler flag -split-if at compile time. See the user guide for more information on compiler flags. You can enable rule splitting for an entire design

with the -split-if flag and then disable the effect for specific rules, by specifying the nosplit attribute before the rules you do not want to split.

13.5 Input clock and reset attributes

The following attributes control the definition and naming of clock oscillator, clock gate, and reset ports. The attributes can only be applied to top-level module definitions.

Attribute name	Section	Top-level module
clock_prefix=	13.5.1	$\sqrt{}$
gate_prefix=	13.5.1	$\sqrt{}$
reset_prefix=	13.5.1	$\sqrt{}$
gate_input_clocks=	13.5.2	$\sqrt{}$
gate_all_clocks	13.5.2	$\sqrt{}$
default_clock_osc=	13.5.3	$\sqrt{}$
default_clock_gate=	13.5.3	$\sqrt{}$
default_gate_inhigh	13.5.3	$\sqrt{}$
default_gate_unused	13.5.3	
default_reset=	13.5.3	
clock_family=	13.5.4	
clock_ancestors=	13.5.4	

13.5.1 Clock and reset prefix naming attributes

The generated port renaming attributes clock_prefix=, gate_prefix=, and reset_prefix= rename the ports for the clock oscillators, clock gates, and resets in a module by specifying a prefix string to be added to each port name. The prefix is used *only* when a name is not provided for the port, (as described in Sections 13.5.3 and 13.6.1), requiring that the port name be created from the prefix and argument name. The attributes are associated with a module and are only applied when the module is synthesized.

Clock Prefix Naming Attributes		
Attribute	Default name	Description
clock_prefix=	CLK	Provides the prefix string to be added to port names for
		all the clock oscillators in a module.
gate_prefix=	CLK_GATE	Provides the prefix string to be added to port names for
		all the clock gates in a module.
reset_prefix=	RST_N	Provides the prefix string to be added to port names for
		all the resets in a module.

If a prefix is specified as the empty string, then no prefix will be used when creating the port names; that is the argument name alone will be used as the name.

Example:

```
(* synthesize, clock_prefix = "CK" *)
module mkMod(Clock clk2, ModIfc ifc);
```

generates the following in the Verilog:

```
module mkMod (CK, RST_N, CK_clk2, ...
```

Where CK is the default clock (using the user-supplied prefix), RST_N is the default reset (using the default prefix), and CK_clk2 is the oscillator for the input clk2 (using the user-supplied prefix).

13.5.2 Gate synthesis attributes

When a module is synthesized, one port, for the oscillator, is created for each clock input (including the default clock). The gate for the clock is defaulted to a logical 1. The attributes gate_all_clocks and gate_input_clocks= specify that a second port be generated for the gate.

The attribute gate_all_clocks will add a gate port to the default clock and to all input clocks. The attribute gate_input_clocks= is used to individually specify each input clock which should have a gate supplied by the parent module.

If an input clock is part of a vector of clocks, the gate port will be added to all clocks in the vector. Example:

```
(* gate_input_clock = "clks, c2" *)
module mkM(Vector#(2, Clock) clks, Clock c2);
```

In this example, a gate port will be added to both the clocks in the vector clks and the clock c2. A gate port cannot be added to just one of the clocks in the vector clks.

The gate_input_clocks= attribute can be used to add a gate port to the default clock. Example:

```
( * gate_input_clocks = "default_clock" * )
```

Note that by having a gate port, the compiler can no longer assume the gate is always logical 1. This can cause an error if the clock is connected to a sub-module which requires the gate to be logical 1.

The gate synthesis attributes are associated with a module and are only applied when the module is synthesized.

13.5.3 Default clock and reset naming attributes

The default clock and reset naming attributes are associated with a module and are only applied when the module is synthesized.

The attributes default_clock_osc=, default_clock_gate=, and default_reset= provide the names for the default clock oscillator, default gate, and default reset ports for a module. When a name for the default clock or reset is provided, any prefix attribute for that port is ignored.

The attributes default_gate_inhigh and default_gate_unused indicate that a gate port should not be generated for the default clock and whether the gate is always logical 1 or unused. The default is default_gate_inhigh. This is only necessary when the attribute gate_all_clocks (section 13.5.2) has been used.

The attributes no_default_clock and no_default_reset are used to remove the ports for the default clock and the default reset.

Default Clock and Reset Naming Attributes		
Attribute	Description	
default_clock_osc=	Provides the name for the default oscillator port.	
no_default_clock	Removes the port for the default clock.	
default_clock_gate=	Provides the name for the default gate port.	
default_gate_inhigh	Removes the gate ports for the module and the gate is always	
	high.	
default_gate_unused	Removes the gate ports for the module and the gate is un-	
	used.	
default_reset=	Provides the name for the default reset port.	
no_default_reset	Removes the port for the default reset.	

13.5.4 Clock family attributes

The clock_family and clock_ancestors attributes indicate to the compiler that clocks are in the same domain in situations where the compiler may not recognize the relationship. For example, when clocks split in synthesized modules and are then recombined in a subsequent module, the compiler may not recognize that they have a common ancestor. The clock_ancestors and clock_family attributes allow the designer to explicitly specify the family relationship between the clocks. These attributes are applied to modules only.

The clock_ancestors attribute specifies an ancestry relationship between clocks. A clock is a gated version of its ancestors. In other words, if clk1 is an ancestor of clk2 then clk2 is a gated version of clk1, as specified in the following statement:

```
(* clock_ancestors = "clk1 AOF clk2" *)
```

Multiple ancestors as well as multiple independent groups can be listed in a single attribute statement. For example:

```
(* clock_ancestors = "clk1 AOF clk2 AOF clk3, clk1 AOF clk4, clka AOF clkb" *)
```

The above statement specifies that clk1 is an ancestor of clk2, which is itself an ancestor of clk3; that clk1 is also an ancestor of clk4; and that clka is an ancestor of clkb. You can also repeat the attribute statement instead of including all clock ancestors in a single statement. Example:

```
(* clock_ancestors = "clk1 AOF clk2 AOF clk3" *)
(* clock_ancestors = "clk1 AOF clk4" *)
(* clock_ancestors = "clka AOF clkb" *)
```

For clocks which do not have an ancestor relationship, but do share a common ancestor, you can use the clock_family attribute. Clocks which are in the same family have the same oscillator with a different gate. To be in the same family, one does not have to be a gated version of the other, instead they may be gated versions of a common ancestor.

```
(* clock_family = "clk1, clk2, clk3" *)
```

Note that clock_ancestors implies same_family.

13.6 Module argument and parameter attributes

The attributes in this section are applied to module arguments and module parameters. The following table shows which type of module argument or parameter each attribute can be applied to. More information on module arguments and module parameters can be found in Section 5.3.

		Clock/	Reset/	Inout/	Value	
Attribute	Section	vector of clock	vector of reset	vector of inouts	argument	Parameter
osc=	13.6.1					
gate=	13.6.1					
gate_inhigh	13.6.1					
gate_unused	13.6.1					
reset=	13.6.1					
clocked_by=	13.6.2					
reset_by=	13.6.3					
port=	13.6.4					
parameter=	13.6.5					

13.6.1 Argument-level clock and reset naming attributes

The non-default clock and reset inputs to a module will have a port name created using the argument name and any associated prefix for that port type. This name can be overridden on a per-argument basis by supplying argument-level attributes that specify the names for the ports.

These attributes are applied to the clock module arguments, except for reset= which is applied to the reset module arguments.

Argument-level Clock and Reset Naming Attributes		
Attribute	Applies to	Description
osc=	Clock or vector of clocks	Provides the full name of the oscillator port.
	module arguments	
gate=	Clock or vector of clocks	Provides the full name of the gate port.
	module arguments	
gate_inhigh	Clock or vector of clocks	Indicates that the gate port should be omitted and
	module arguments	the gate is assumed to be high.
gate_unused	Clock or vector of clocks	Indicates that the gate port should be omitted and is
	module arguments	never used within the module.
reset=	Reset or vector of resets	Provides the full name of the reset port.
	module arguments	

Example:

module mkMod(CLK, RST_N, ACLK, AGATE, RESET, ...

The attributes can be applied to the base name generated for a vector of clocks, gates or resets. Example:

generates the following in the Verilog:

```
module mkMod(CLK, RST_N, ACLK_0, AGATE_0, ACLK_1, AGATE_1, ARST_0, ARST_1,...
```

13.6.2 clocked_by=

The attribute clocked_by= allows the user to assert which clock a reset, inout, or value module argument is associated with, to specify that the argument has no_clock, or to associate the argument with the default_clock. If the clocked_by= attribute is not provided, the default clock will be used for inout and value arguments; the clock associated with a reset argument is dervied from where the reset is connected.

Examples:

To specify that an argument is not associated with any clock domain, the clock no_clock is used. Example:

13.6.3 reset_by=

The attribute reset_by= allows the user to assert which reset an inout or value module argument is associated with, to specify that the argument has no_reset, or to associate the argument with the default_reset. If the reset_by= attribute is not provided, the default reset will be used.

Examples:

To specify that the port is not associated with any reset, no_reset is used. Example:

13.6.4 port=

The attribute port= allows renaming of value module arguments. These are port-like arguments that are not clocks, resets or parameters. It provides the full name of the port generated for the argument. This is the same attribute as the port= attribute in Section 13.2.1, as applied to module arguments instead of interface methods.

```
module mkMod (a_type initValue, (* port="B" *) Bool b, ModIfc ifc);
module mkMod ((* port="PBUS" *) Inout#(Bit#(32)) pbus, ModIfc ifc);
```

13.6.5 parameter=

The attribute parameter= allows renaming of parameters in the generated RTL. This is similar to the port= attribute, except that the parameter= attribute can only be used for parameters in the moduleFormalParams list. More detail on module parameters can be found in Section 5.3. The name provided in the parameter= attribute statement is the name generated for the parameter in the RTL.

Example:

13.7 Documentation attributes

A BSV design can specify comments to be included in the generated Verilog by use of the doc attribute.

Attribute name	Section	Top-level module definitions	Sub-Module instantiations	rule definitions	rules expressions
doc=	13.7				

Example:

```
(* doc = "This is a user-provided comment" *)
```

To provide a multi-line comment, either include a \n character:

```
(* doc = "This is one line\nAnd this is another" *)
```

Or provide several instances of the doc attribute:

```
(* doc = "This is one line" *)
(* doc = "And this is another" *)
```

Or:

```
(* doc = "This is one line",
  doc = "And this is another" *)
```

Multiple doc attributes will appear together in the order that they are given. doc attributes can be added to modules, module instantiations, and rules, as described in the following sections.

13.7.1 Modules

The Verilog file that is generated for a synthesized BSV module contains a header comment prior to the Verilog module definition. A designer can include additional comments between this header and the module by attaching a doc attribute to the module being synthesized. If the module is not synthesized, the doc attributes are ignored.

Example:

```
(* synthesize *)
(* doc = "This is important information about the following module" *)
module mkMod (IFC);
...
endmodule
```

13.7.2 Module instantiation

In generated Verilog, a designer might want to include a comment on sub-module instantiations, to document something about that sub-module. This can be achieved with a doc attribute on the corresponding BSV module. There are three ways to express instantiation in BSV syntax, and the doc attribute can be attached to all three.

```
(* doc = "This sub-module does something" *)
FIFO#(Bool) f();
mkFIFO the_f(f);

(* doc = "This sub-module does something else" *)
Server srv <- mkServer;

Client c;
...
(* doc = "This sub-module does a third thing" *)
c <- mkClient;</pre>
```

The syntax also works if the type of the module interface is given with let, a variable, or the current module type. Example:

```
(* doc = "This sub-module does something else" *)
let srv <- mkServer;</pre>
```

If the sub-module being instantiated is a separately synthesized module or primitive, then its corresponding Verilog instantiation will be preceded by the comments. Example:

```
// sub-module the_f
// This sub-module does something
wire the_f$CLR, the_f$DEQ, the_f$ENQ;
FIF02 #(.width(1)) the_f(...);
```

If the sub-module is not separately synthesized, then there is no place in the Verilog module to attach the comment. Instead, the comment is included in the header at the beginning of the module. For example, assume that the module the_sub was instantiated inside mkTop with a user-provided comment but was not separately synthesized. The generated Verilog would include these lines:

```
// ...
// Comments on the inlined module 'the_sub':
// This is the sub-module
//
module mkTop(...);
```

The doc attribute can be attached to sub-module instantiations inside functions and for-loops.

If several sub-modules are inlined and their comments carry to the top-module's header comment, all of their comments are printed. To save space, if the comments on several modules are the same, the comment is only displayed once. This can occur, for instance, with doc attributes on instantiations inside for-loops. For example:

```
// Comments on the inlined modules 'the_sub_1', 'the_sub_2',
// 'the_sub_3':
// ...
```

If the doc attribute is attached to a register instantiation and the register is inlined (as is the default), the Verilog comment is included with the declaration of the register signals. Example:

```
// register the_r
// This is a register
reg the_r;
wire the_r$D_IN, the_r$EN;
```

If the doc attribute is attached to an RWire instantiation, and the wire instantiation is inlined (as is the default), then the comment is carried to the top-module's header comment.

If the doc attribute is attached to a probe instantiation, the comment appears in the Verilog above the declaration of the probe signals. Since the probe signals are declared as a group, the comments are listed at the start of the group. Example:

```
// probes
//
// Comments for probe 'the_r':
// This is a probe
//
wire the_s$PROBE;
wire the_r$PROBE;
...
```

13.7.3 Rules

In generated Verilog, a designer might want to include a comment on rule scheduling signals (such as CAN_FIRE_ and WILL_FIRE_ signals), to say something about the actions that are performed when that rule is executed. This can be achieved with a doc attribute attached to a BSV rule declaration or rules expression.

The doc attribute can be attached to any rule..endrule or rules...endrules statement. Example:

```
(* doc = "This rule is important" *)
rule do_something (b);
   x <= !x;
endrule</pre>
```

If any scheduling signals for the rule are explicit in the Verilog output, their definition will be preceded by the comment. Example:

```
// rule RL_do_something
// This rule is important
assign CAN_FIRE_RL_do_something = b ;
assign WILL_FIRE_RL_do_something = CAN_FIRE_RL_do_something ;
```

If the signals have been inlined or otherwise optimized away and thus do not appear in the Verilog, then there is no place to attach the comments. In that case, the comments are carried to the top module's header. Example:

```
// ...
// Comments on the inlined rule 'RL_do_something':
// This rule is important
//
module mkTop(...);
```

The designer can ensure that the signals will exist in the Verilog by using an appropriate compiler flag, the -keep-fires flag which is documented in the Bluespec SystemVerilog User Guide.

The doc attribute can be attached to any rule..endrule expression, such as inside a function or inside a for-loop.

As with comments on sub-modules, if the comments on several rules are the same, and those comments are carried to the top-level module header, the comment is only displayed once.

```
// ...
// Comments on the inlined rules 'RL_do_something_2', 'RL_do_something_1',
// 'RL_do_something':
// This rule is important
//
module mkTop(...);
```

14 Advanced topics

This section can be skipped on first reading.

14.1 Type classes (overloading groups) and provisos

Note that for most BSV programming, one just needs to know about a few predefined type classes such as Bits and Eq, about provisos, and about the automatic mechanism for defining the overloaded functions in those type classes using a deriving clause. The brief introduction in Sections 4.2 and 4.3 should suffice.

This section is intended for the advanced programmer who may wish to define new type classes (using a typeclass declaration), or explicitly to define overloaded functions using an instance declaration.

In programming languages, the term *overloading* refers to the use of a common function name or operator symbol to represent some number (usually finite) of functions with distinct types. For example, it is common to overload the operator symbol + to represent integer addition, floating point addition, complex number addition, matrix addition, and so on.

Note that overloading is distinct from *polymorphism*, which is used to describe a single function or operator that can operate at an infinity of types. For example, in many languages, a single polymorphic function arraySize() may be used to determine the number of elements in any array, no matter what the type of the contents of the array.

A type class (or overloading group) further recognizes that overloading is often performed with related groups of function names or operators, giving the group of related functions and operators a name. For example, the type class Ord contains the overloaded operators for order-comparison: <, <=, > and >=.

If we specify the functions represented by these operator symbols for the types int, Bool, bit [m:0] and so on, we say that those types are *instances* of the Ord type class.

A proviso is a (static) condition attached to some constructs. A proviso requires that certain types involved in the construct must be instances of certain type classes. For example, a generic sort function for sorting lists of type $\mathtt{List\#}(t)$ will have a proviso (condition) that t must be an instance of the \mathtt{Ord} type class, because the generic function uses an overloaded comparison operator from that type class, such as the operator < or >.

Type classes are created explicitly using a typeclass declaration (Section 14.1.2). Further, a type class is explicitly populated with a new instance type t, using an instance declaration (Section 14.1.3), in which the programmer provides the specifications for the overloaded functions for the type t.

14.1.1 Provisos

Consider the following function prototype:

```
function List#(t) sort (List#(t) xs)
    provisos (Ord#(t));
```

This prototype expresses the idea that the sorting function takes an input list xs of items of type t (presumably unsorted), and produces an output list of type t (presumably sorted). In order to perform its function it needs to compare elements of the list against each other using an overloaded comparison operator such as <. This, in turn, requires that the overloaded operator be defined on objects of type t. This is exactly what is expressed in the proviso, i.e., that t must be an instance of the type class (overloading group) Ord, which contains the overloaded operator <.

Thus, it is permissible to apply sort to lists of Integers or lists of Bools, because those types are instances of Ord, but it is not permissible to apply sort to a list of, say, some interface type Ifc (assuming Ifc is not an instance of the Ord type class).

The syntax of provisos is the following:

```
provisos ::= provisos ( proviso { , proviso } )
proviso ::= Identifier #(type { , type } )
```

In each proviso, the *Identifier* is the name of type class (overloading group). In most provisos, the type class name T is followed by a single type t, and can be read as a simple assertion that t is an instance of T, i.e., that the overloaded functions of type class T are defined for the type t. In some provisos the type class name T may be followed by more than one type $t_1, ..., t_n$ and these express more general relationships. For example, a proviso like this:

```
provisos (Bits#(macAddress, 48))
```

can be read literally as saying that the types macAddress and 48 are in the Bits type class, or can be read more generally as saying that values of type macAddress can be converted to and from values of the type bit [47:0] using the pack and unpack overloaded functions of type class Bits.

We sometimes also refer to provisos as *contexts*, meaning that they constrain the types that may be used within the construct to which the provisos are attached.

Occasionally, if the context is too weak, the compiler may be unable to figure out how to resolve an overloading. Usually the compiler's error message will be a strong hint about what information is missing. In these situations it may be necessary for the programmer to guide the compiler by adding more type information to the program, in either or both of the following ways:

- Add a static type assertion (Section 9.10) to some expression that narrows down its type.
- Add a proviso to the surrounding construct.

14.1.2 Type class declarations

A new class is declared using the following syntax:

```
::= typeclass typeclassIde typeFormals [ provisos ]
typeclassDef
                           [ typedepends ];
                               { overloadedDef }
                           endtypeclass[: typeclassIde ]
typeclassIde
                      ::= Identifier
typeFormals
                      ::= # ( typeFormal { , typeFormal })
typeFormal
                      ::= [ numeric ] type typeIde
typedepends
                      ::= dependencies ( typedepend { , typedepend } )
typedepend
                      ::= typelist determines typelist
typelist
                      ::= typeIde
                          ( typeIde { , typeIde } )
overloadedDef
                          function Proto
                           varDecl
```

The typeclassIde is the newly declared class name. The typeFormals represent the types that will be instances of this class. These typeFormals may themselves be constrained by provisos, in which case the classes named in provisos are called the "super type classes" of this type class. Type dependencies (typedepends) are relevant only if there are two or more type parameters; the typedepends comes after the typeclass's provisos (if any) and before the semicolon. The overloadedDefs declare the overloaded variables or function names, and their types.

Example (from the Standard Prelude package):

```
typeclass Literal#(type a);
  function a  fromInteger (Integer x);
  function Bool inLiteralRange(a target, Integer i);
endtypeclass: Literal
```

This defines the type class Literal. Any type a that is an instance of Literal must have an overloaded function called fromInteger that converts an Integer value into the type a. In fact, this is the mechanism that BSV uses to interpret integer literal constants, e.g., to resolve whether a literal like 6847 is to be interpreted as a signed integer, an unsigned integer, a floating point number, a bit value of 10 bits, a bit value of 8 bits, etc. (See Section 2.3.1 for a more detailed description.).

The typeclass also provides a function inLiteralRange that takes an argument of type a and an Integer and returns a Bool. In the standard Literal typeclass this boolean indicates whether or not the supplied Integer is in the range of legal values for the type a.

Example (from a predefined type class in BSV):

```
typeclass Bounded#(type a);
    a minBound;
    a maxBound;
endtypeclass
```

This defines the type class Bounded. Any type a that is an instance of Bounded will have two values called minBound and maxBound that, respectively, represent the minimum and maximum of all values of this type.

Example (from a predefined type class in BSV):¹⁰

```
typeclass Arith #(type data_t)
provisos (Literal#(data_t));
function data_t \+ (data_t x, data_t y);
function data_t \- (data_t x, data_t y);
function data_t negate (data_t x);
function data_t \* (data_t x, data_t y);
function data_t \/ (data_t x, data_t y);
function data_t \/ (data_t x, data_t y);
endtypeclass
```

This defines the type class Arith with super type class Literal, i.e., the proviso states that in order for a type data_t to be an instance of Arith it must also be an instance of the type class Literal. Further, it has six overloaded functions with the given names and types. Said another way, a type that is an instance of the Arith type class must have a way to convert integer literals into that type, and it must have addition, subtraction, negation, multiplication, and division defined on it.

The semantics of a dependency say that once the types on the left of the determines keyword are fixed, the types on the right are uniquely determined. The types on either side of the list can be a single type or a list of types, in which case they are enclosed in parentheses.

Example of a typeclass definition specifying type dependencies:

```
typeclass Connectable #(type a, type b)
  dependencies (a determines b, b determines a);
    module mkConnection#(a x1, b x2) (Empty);
endtypeclass
```

For any type t we know that Get#(t) and Put#(t) are connectable because of the following declaration in the GetPut package:

```
instance Connectable#(Get#(element_type), Put#(element_type));
```

In the Connectable dependency above, it states that a determines b. Therefore, you know that if a is Get#(t), the *only* possibility for b is Put#(t).

Example of a typeclass definition with lists of types in the dependencies:

¹⁰ We are using Verilog's notation for *escaped identifiers* to treat operator symbols as ordinary identifiers. The notation allows an identifier to be constructed from arbitrary characters beginning with a backslash and ending with a whitespace (the backslash and whitespace are not part of the identifier.)

```
typeclass Extend #(type a, type b, type c)
    dependencies ((a,c) determines b, (b,c) determines a);
endtypeclass
```

An example of a case where the dependencies are not commutative:

```
typeclass Bits#(type a, type sa)
  dependencies (a determines sa);
    function Bit#(sa) pack(a x);
    function a unpack (Bit#(sa) x);
endtypeclass
```

In the above example, if a were UInt#(16) the dependency would require that b had to be 16; but the fact that something occupies 16 bits by no means implies that it has to be a UInt.

14.1.3 Instance declarations

A type can be declared to be an instance of a class in two ways, with a general mechanism or with a convenient shorthand. The general mechanism of instance declarations is the following:

```
typeclassInstanceDef ::= instance \ typeclassIde \ \# \ ( \ type \ \{ \ \ , \ type \ \} \ ) \ [ \ provisos \ ] \ ; \\ \{ \ \ varAssign \ ; \ | \ functionDef \ | \ moduleDef \ \} \\ endinstance \ [ \ : \ typeclassIde \ ]
```

This says that the types are an instance of type class typeclassIde with the given provisos. The varAssigns, functionDefs and moduleDefs specify the implementation of the overloaded identifiers of the type class.

Example, declaring a type as an instance of the Eq typeclass:

The shorthand mechanism is to attach a deriving clause to a typedef of an enum, struct or tagged union and let the compiler do the work. In this case the compiler chooses the "obvious" implementation of the overloaded functions (details in the following sections). The only type classes for which deriving can be used for general types are Bits, Eq and Bounded. Furthermore, deriving can be used for any class if the type is a data type that is isomorphic to a type that has an instance for the derived class.

```
derives ::= deriving ( typeclassIde { , typeclassIde } )
Example:
typedef enum { Red, Blue, Green } Color deriving (Eq);
```

14.1.4 The Bits type class (overloading group)

The type class Bits contains the types that are convertible to bit strings of a certain size. Many constructs have membership in the Bits class as a proviso, such as putting a value into a register, array, or FIFO.

Example: The Bits type class definition (which is actually predefined in BSV) looks something like this:

```
typeclass Bits#(type a, type n);
  function Bit#(n) pack (a x);
  function a unpack (Bit#(n) y);
endtypeclass
```

Here, a represents the type that can be converted to/from bits, and n is always instantiated by a size type (Section 4) representing the number of bits needed to represent it. Implementations of modules such as registers and FIFOs use these functions to convert between values of other types and the bit representations that are really stored in those elements.

Example: The most trivial instance declaration states that a bit-vector can be converted to a bit vector, by defining both the pack and unpack functions to be identity functions:

```
instance Bits#(Bit#(k), k);
     function Bit#(k) pack (Bit#(k) x);
         return x;
     endfunction: pack
     function Bit#(k) unpack (Bit#(k) x);
         return x;
     endfunction: unpack
endinstance
Example:
typedef enum { Red, Green, Blue } Color deriving (Eq);
instance Bits#(Color, 2);
     function Bit#(2) pack (Color c);
                 (c == Red)
                              return 3;
         else if (c == Green) return 2;
         else
                              return 1;
                                          // (c == Blue)
     endfunction: pack
     function Color unpack (Bit#(2) x);
                 (x == 3) return Red;
         else if (x == 2) return Green;
         else if (x == 1) return Blue;
         else ? //Illegal opcode; return unspecified value
     endfunction: unpack
endinstance
```

Note that the deriving (Eq) phrase permits us to use the equality operator == on Color types in the pack function. Red, Green and Blue are coded as 3, 2 and 1, respectively. If we had used the deriving(Bits) shorthand in the Color typedef, they would have been coded as 0, 1 and 2, respectively (Section 14.1.6).

14.1.5 The SizeOf pseudo-function

The pseudo-function SizeOf#(t) can be applied to a type t to get the numeric type representing its bit size. The type t must be in the Bits class, i.e., it must already be an instance of Bits#(t,n), either through a deriving clause or through an explicit instance declaration. The SizeOf function then returns the corresponding bit size n. Note that SizeOf returns a numeric type, not a numeric value, i.e., the output of SizeOf can be used in a type expression, and not in a value expression.

SizeOf, which converts a type to a (numeric) type, should not be confused with the pseudo-function value of, described in Section 4.2.1, which converts a numeric type to a numeric value.

Example:

```
typedef Bit#(8) MyType;
// MyType is an alias of Bit#(8)

typedef SizeOf#(MyType) NumberOfBits;
// NumberOfBits is a numeric type, its value is 8

Integer ordinaryNumber = valueOf(NumberOfBits);
// valueOf converts a numeric type into Integer
```

14.1.6 Deriving Bits

When attaching a deriving(Bits) clause to a user-defined type, the instance derived for the Bits type class can be described as follows:

- For an enum type it is simply an integer code, starting with zero for the first enum constant and incrementing by one for each subsequent enum constant. The number of bits used is the minimum number of bits needed to represent distinct codes for all the enum constants.
- For a struct type it is simply the concatenation of the bits for all the members. The first member is in the leftmost bits (most significant) and the last member is in the rightmost bits (least significant).
- For a tagged union type, all values of the type occupy the same number of bits, regardless of which member it belongs to. The bit representation consists of two parts—a tag on the left (most significant) and a member value on the right (least significant).

The tag part uses the minimum number of bits needed to code for all the member names. The first member name is given code zero, the next member name is given code one, and so on.

The size of the member value part is always the size of the largest member. The member value is stored in this field, right-justified (i.e., flush with the least-significant end). If the member value requires fewer bits than the size of the field, the intermediate bits are don't-care bits.

Example. Symbolic names for colors:

```
typedef enum { Red, Green, Blue } Color deriving (Eq, Bits);
```

This is the same type as in Section 14.1.4 except that Red, Green and Blue are now coded as 0, 1 and 2, instead of 3, 2, and 1, respectively, because the canonical choice made by the compiler is to code consecutive labels incrementing from 0.

Example. The boolean type can be defined in the language itself:

```
typedef enum { False, True} Bool deriving (Bits);
```

The type Bool is represented with one bit. False is represented by 0 and True by 1.

Example. A struct type:

```
typedef struct { Bit#(8) foo; Bit#(16) bar } Glurph deriving (Bits);
```

The type Glurph is represented in 24 bits, with foo in the upper 8 bits and bar in the lower 16 bits. Example. Another struct type:

```
typedef struct{ int x; int y } Coord deriving (Bits);
```

The type Coord is represented in 64 bits, with x in the upper 32 bits and y in the lower 32 bits.

Example. The Maybe type from Section 7.3:

```
typedef union tagged {
    void Invalid;
    a Valid;
} Maybe#(type a)
deriving (Bits);
```

is represented in 1+n bits, where n bits are needed to represent values of type a. If the leftmost bit is 0 (for Invalid) the remaining n bits are unspecified (don't-care). If the leftmost bit is 1 (for Valid) then the remaining n bits will contain a value of type a.

14.1.7 Deriving Eq

The Eq type class contains the overloaded operators == (logical equality) and != (logical inequality):

```
typeclass Eq#(type a);
  function Bool \== (a x1, a x2);
  function Bool \/= (a x1, a x2);
endtypeclass: Eq
```

When deriving(Eq) is present on a user-defined type definition t, the compiler defines these equality/inequality operators for values of type t. It is the natural recursive definition of these operators, i.e.,

- If t is an enum type, two values of type t are equal if they represent the same enum constant.
- If t is a struct type, two values of type t are equal if the corresponding members are pairwise equal.
- If t is a tagged union type, two values of type t are equal if they have the same tag (member name) and the two corresponding member values are equal.

14.1.8 Deriving Bounded

The predefined type class Bounded contains two overloaded identifiers minBound and maxBound representing the minimum and maximum values of a type a:

```
typeclass Bounded#(type a);
    a minBound;
    a maxBound;
endtypeclass
```

The clause deriving (Bounded) can be attached to any user-defined enum definition t, and the compiler will define the values minBound and maxBound for values of type t as the first and last enum constants, respectively.

The clause deriving(Bounded) can be attached to any user-defined struct definition t with the proviso that the type of each member is also an instance of Bounded. The compiler-defined minBound (or maxBound) will be the struct with each member having its respective minBound (respectively, maxBound).

14.1.9 Deriving type class instances for isomorphic types

Generally speaking, the deriving(...) clause can only be used for the predefined type classes Bits, Eq and Bounded. However there is a special case where it can be used for any type class. When a user-defined type t is isomorphic to an existing type t', then all the functions on t' automatically work on t, and so the compiler can trivially derive a function for t by just using the corresponding function for t'.

There are two situations where a newly defined type is isomorphic to an old type: a struct or tagged union with precisely one member. For example:

```
typedef struct { t' x; } t deriving (anyClass); typedef union tagged { t' X; } t deriving (anyClass);
```

One sometimes defines such a type precisely for type-safety reasons because the new type is distinct from the old type although isomorphic to it, so that it is impossible to accidentally use a t value in a t' context and vice versa. Example:

The typedef could also have been written with a singleton tagged union instead of a singleton struct:

```
typedef union tagged { UInt#(32) X; } Apples deriving (Literal, Arith);
```

14.2 Higher-order functions

In BSV it is possible to write an expression whose value is a *function value*. These function values can be passed as arguments to other functions, returned as results from functions, and even carried in data structures.

Example - the function map, as defined in the package Vector (C.3.8):

The function map is polymorphic, i.e., is defined for any size type vsize and value types a_type and b_type. It takes two arguments:

- A function func with input of type a_type and output of type b_type.
- A vector xvect of size vsize containing values of type a_type.

Its result is a new vector yvect that is also of size vsize and containing values of type b_type, such that yvect[j]=func(xvect[j]). In the last line of the example, we call map passing it the sqr function and the vector avect to produce a vector bvect that contains the squared versions of all the elements of vector avect.

Observe that in the last line, the expression sqr is a function-valued expression, representing the squaring function. It is not an invocation of the sqr function. Similarly, inside map, the identifier func is a function-valued identifier, and the expression func (xsize [j]) invokes the function.

The function map could be called with a variety of arguments:

```
// Apply the extend function to each element of avect
Vector#(13, Bit#(5)) avect;
Vector#(13, Bit#(10)) bvect;
...
bvect = map(extend, avect);

or

// test all elements of avect for even-ness
Vector#(100,Bool) bvect = map (isEven, avect);
```

In other words, map captures, in one definition, the generic idea of applying some function to all elements of a vector and returning all the results in another vector. This is a very powerful idea enabled by treating functions as first-class values. Here is another example, which may be useful in many hardware designs:

```
interface SearchableFIFO#(type element_type);
    ... usual eng() and deg() methods ...
```

The SearchableFIFO interface is like a normal FIFO interface (contains usual enq() and deq() methods), but it has an additional bit of functionality. It has a search() method to which you can pass a search key key, and it searches the FIFO using that key, returning True if the search succeeds.

Inside the mkSearchableFIFO module, the method applies some element test predicate test_func to each element of the FIFO and ORs all the results. The particular element-test function test_func to be used is passed in as a parameter to mkSearchableFIFO. In one instantiation of mkSearchableFIFO we might pass in the equality function for this parameter ("search this FIFO for this particular element"). In another instantiation of mkSearchableFIFO we might pass in the "greater-than" function ("search this FIFO for any element greater than the search key"). Thus, a single FIFO definition captures the general idea of being able to search a FIFO, and can be customized for different applications by passing in different search functions to the module constructor.

A final important point is that all this is perfectly *synthesizable* in BSV, i.e., the compiler can produce RTL hardware for such descriptions. Since polymporphic modules cannot be synthesized, for synthesis a non-polymorphic version of the module would have to be instantiated.

15 Embedding RTL in a BSV design

This section describes how to embed existing RTL modules, Verilog or VHDL, in a BSV module. The import "BVI" statement is used to utilize existing components, utilize components generated by other tools, or to define a custom set of primitives. One example is the definition of BSV primitives (registers, FIFOs, etc.), which are implemented through import of Verilog modules. The import "BVI" statement creates a Bluespec wrapper around the RTL module so that it looks like a BSV module. Instead of ports, the wrapped module has methods and interfaces.

The import "BVI" statement can be used to wrap Verilog or VHDL modules. Throughout this section Verilog will be used to refer to either Verilog or VHDL. (One limitatation for VHDL is that BSV does not support two dimensional ports.)

```
externModuleImport ::= import "BVI" [ identifier = ] moduleProto \\ { moduleStmt } \\ { importBVIStmt } \\ { endmodule [ : identifier ] } \\ The body consists of a sequence of importBVIStmts: \\ importBVIStmt ::= parameterBVIStmt \\ { methodBVIStmt } \\ { portBVIStmt } \\ { portBVIStmt } \\ }
```

inputClockBVIStmt
defaultClockBVIStmt
outputClockBVIStmt
inputResetBVIStmt
defaultResetBVIStmt
noResetBVIStmt
outputResetBVIStmt
sameFamilyBVIStmt
scheduleBVIStmt
pathBVIStmt
interfaceBVIStmt
inoutBVIStmt

The optional *identifier* immediately following the "BVI" is the name of the Verilog module to be imported. This will usually be found in a Verilog file of the same name (*identifier.v*). If this *identifier* is excluded, it is assumed that the Verilog module name is the same as the BSV name of the module.

The module Proto is the first line in the module definition as described in Section 5.3.

The BSV wrapper returns an interface. All arguments and return values must be in the Bits class or be of type Clock, Reset, Inout, or a subinterface which meets these requirements. Note that the BSV module's parameters have no inherent relationship to the Verilog module's parameters. The BSV wrapper is used to connect the Verilog ports to the BSV parameters, performing any data conversion, such as packs or unpacks, as necessary.

Example of the header of a BVI import statement:

```
import "BVI" RWire =
  module RWire (VRWire#(a))
    provisos (Bits#(a,sa));
  ...
  endmodule: vMkRWire
```

Since the Verilog module's name matches the BSV name, the header could be also written as:

```
import "BVI"
  module RWire (VRWire#(a))
    provisos (Bits#(a,sa));
  ...
  endmodule: vMkRWire
```

The module body may contain both *moduleStmts* and *importBVIStmts*. Typically when including a Verilog module, the only module statements would be a few local definitions. However, all module statements, except for method definitions, sub-interface definitions, and return statements, are valid, though most are rarely used in this instance. Only the statements specific to *importBVIStmt* bodies are described in this section.

The *importBVIStmts* must occur at the end of the body, after the *moduleStmts*. They may be written in any order.

The following is an example of embedding a Verilog SRAM model in BSV. The Verilog file is shown after the BSV wrapper.

```
import "BVI" mkVerilog_SRAM_model =
  module mkSRAM #(String filename) (SRAM_Ifc #(addr_t, data_t))
```

This is the Verilog module being wrapped in the above BVI import statement.

```
module mkVerilog_SRAM_model (clk,
                              v_in_address, v_in_data,
                              v_in_write_not_read,
                              v_in_enable,
                              v_out_data);
 parameter FILENAME
                           = "Verilog_SRAM_model.data";
 parameter ADDRESS_WIDTH = 10;
 parameter DATA_WIDTH
 parameter NWORDS
                           = (1 << ADDRESS_WIDTH);</pre>
 input
                               clk;
 input
         [ADDRESS_WIDTH-1:0]
                              v_in_address;
 input
         [DATA_WIDTH-1:0]
                               v_in_data;
                               v_in_write_not_read;
  input
  input
                               v_in_enable;
 output [DATA_WIDTH-1:0]
                               v_out_data;
endmodule
```

15.1 Parameter

The parameter statement specifies the parameter values which will be used by the Verilog module.

```
parameter BVIStmt ::= parameter identifier = expression;
```

The value of *expression* is supplied to the Verilog module as the parameter named *identifier*. The *expression* must be a compile-time constant. The valid types for parameters are String, Integer and Bit#(n). Example:

15.2 Method

The method statement is used to connect methods in a Bluespec interface to the appropriate Verilog wires. The syntax imitates a function prototype in that it doesn't define, but only declares. In the case of the method statement, instead of declaring types, it declares ports.

```
methodBVIStmt ::= method [ portId ] identifer [ ( [ portId { , portId } ] ) ] 
[ enable (portId ) ] [ ready ( portId ) ] 
[ clocked_by ( clockId ) ] [ reset_by ( resetId ) ] ;
```

The first portId is the output port for the method, and is only used when the method has a return value. The identifier is the method's name according to the BSV interface definition. The parenthesized list is the input port names corresponding to the method's arguments, if there are any. There may follow up to four optional clauses (in any order): enable (for the enable input port if the method has an Action component), ready (for the ready output port), clocked_by (to indicate the clock of the method, otherwise the default clock will be assumed) and reset_by (for the associated reset signal, otherwise the default reset will be assumed). If no ready port is given, the constant value 1 is used meaning the method is always ready. The names no_clock and no_reset can be used in clocked_by and reset_by clauses indicating that there is no associated clock and no associated reset, respectively.

If the input port list is empty and none of the optional clauses are specified, the list and its parentheses may be omitted. If any of the optional clauses are specified, the empty list () must be shown. Example:

```
method CLOCKREADY_OUT clockready() clocked_by(clk);
```

If there was no clocked_by statement, the following would be allowed:

```
method CLOCKREADY_OUT clockready;
```

The BSV types of all the method's arguments and its result (if any) must all be in the Bits typeclass.

Any of the port names may have an attribute attached to them. The allowable attributes are reg, const, unused, and inhigh. The attributes are translated into port descriptions. Not all port attributes are allowed on all ports.

For the output ports, the ready port and the method return value, the properties reg and const are allowed. The reg attribute specifies that the value is coming directly from a register with no intermediate logic. The const attribute indicates that the value is hardwired to a constant value.

For the input ports, the input arguments and the enable port, reg and unused are allowed. In this context reg specifies that the value is immediately written to a register without intermediate logic. The attribute unused indicates that the port is not used inside the module; its value is ignored.

Additionally, for the method enable, there is the inhigh property, which indicates that the method is always_enabled, as described in Section 13.2.2. Inside the module, the value of the enable is assumed to be 1 and, as a result, the port doesn't exist. The user still gives a name for the port as a placeholder. Note that only Action or ActionValue methods can have an enable signal.

The following code fragment shows an attribute on a method enable:

```
method load(flopA, flopB) enable((*inhigh*) EN);
```

The output ports may be shared across methods (and ready signals).

15.3 Port

The port statement declares an input port, which is not part of a method, along with the value to be passed to the port. While parameters must be compile-time constants, ports can be dynamic. The port statements are analogous to arguments to a BSV module, but are rarely needed, since BSV style is to interact and pass arguments through methods.

```
portBVIStmt ::= port identifier [ clocked_by ( clockId ) ] [ reset_by ( resetId ) ] = expression ;
```

The defining operator \leftarrow or = may be used.

The value of expression is supplied to the Verilog port named identifier. The type of expression must be in the Bits typeclass. The expression may be dynamic (e.g. the _read method of a register instantiated elsewhere in the module body), which differentiates it from a parameter statement. The Bluespec compiler cannot check that the import has specified the same size as declared in the Verilog module. If the width of the value is not the same as that expected by the Verilog module, Verilog will truncate or zero-extend the value to fit.

Example - Setting port widths to a specific width:

The clocked_by clause is used to specify the clock domain that the port is associated with, named by *clockId*. Any clock in the domain may be used. The values no_clock and default_clock, as described in Section 15.5, may be used. If the clause is omitted, the associated clock is the default clock.

Example - BVI import statement including port statements

```
port BUS_ID clocked_by (clk2) = busId ;
```

The reset_by clause is used to specify the reset the port is associated with, named by resetId. Any reset in the domain may be used. The values no_reset and default_reset, as described in Section 15.8 may be used. If the clause is omitted, the associated reset is the default reset.

15.4 Input clock

The input_clock statement specifies how an incoming clock to a module is connected. Typically, there are two ports, the oscillator and the gate, though the connection may use fewer ports.

```
inputClockBVIStmt ::= input_clock [ identifier ] ( [ portsDef ] ) = expression ; portsDef ::= portId [ , [ attributeInstances ] portId ] portId ::= identifier
```

The defining operator = or <- may be used.

The *identifier* is the clock name which may be used elsewhere in the import to associate the clock with resets and methods via a clocked_by clause, as described in Sections 15.7 and 15.2. The *portsDef* statement describes the ports that define the clock. The clock value which is being connected is given by *expression*.

If the *expression* is an identifier being assigned with =, and the user wishes this to be the name of the clock, then the *identifier* of the clock can be omitted and the *expression* will be assumed to be the name. The clock name can be omitted in other circumstances, but then no name is associated with the clock. An unamed clock cannot be referred to elsewhere, such as in a method or reset or other statement. Example:

```
input_clock (OSC, GATE) = clk;
```

is equivalent to:

```
input_clock clk (OSC, GATE) = clk;
```

The user may leave off the gate (one port) or the gate and the oscillator (no ports). It is the designer's responsibility to ensure that not connecting ports does not lead to incorrect behavior. For example, if the Verilog module is purely combinational, there is no requirement to connect a clock, though there may still be a need to associate its methods with a clock to ensure that they are in the correct clock domain. In this case, the *portsDef* would be omitted. Example of an input clock without any connection to the Verilog ports:

```
input_clock ddClk() = dClk;
```

If the clock port is specified and the gate port is to be unconnected, an attribute, either unused or inhigh, describing the gate port should be specified. The attribute unused indicates that the sub-module doesn't care what the unconnected gate is, while inhigh specifies the gate is assumed in the module to be logical 1. It is an error if a clock with a gate that is not logical 1 is connected to an input clock with an inhigh attribute. The default when a gate port is not specified is inhigh, though it is recommended style that the designer specify the attribute explicitly.

To add an attribute, the usual attribute syntax, (* attribute_name *) immediately preceding the object of the attribute, is used. For example, if a Verilog module has no internal transitions and responds only to method calls, it might be unnecessary to connect the gating signal, as the implicit condition mechanism will ensure that no method is invoked if its clock is off. So the second portId, for the gate port, would be marked unused.

```
input_clock ddClk (OSC, (*unused*) UNUSED) = dClk;
```

The options for specifying the clock ports in the *portsDef* clause are:

```
() // there are no Verilog ports
(OSC, GATE) // both an oscillator port and a gate port are specified
(OSC, (*unused*)GATE) // there is no gate port and it's unused
(OSC, (*inhigh*)GATE) // there is no gate port and it's required to be logical 1
(OSC) // same as (OSC, (*inhigh*) GATE)
```

In an input_clock statement, it is an error if both the port names and the input clock name are omitted, as the clock is then unusable.

15.5 Default clock

In BSV, each module has an implicit clock (the *current clock*) which is used to clock all instantiated sub-modules unless otherwise specified with a clocked_by clause. Other clocks to sub-modules must be explicitly passed as input arguments.

Every BVI import module must declare which input clock (if any) is the default clock. This default clock is the implicit clock provided by the parent module, or explicitly given via a clocked_by clause. The default clock is also the clock associated with methods and resets in the BVI import when no clocked_by clause is specified.

The simplest definition for the default clock is:

```
defaultClockBVIStmt ::= default_clock identifier ;
```

where the *identifier* specifies the name of an input clock which is designated as the default clock.

The default clock may be unused or not connected to any ports, but it must still be declared. Example:

```
default_clock no_clock;
```

This statement indicates the implicit clock from the parent module is ignored (and not connected). Consequently, the default clock for methods and resets becomes no_clock, meaning there is no associated clock.

To save typing, you can merge the default_clock and input_clock statements into a single line:

```
defaultClockBVIStmt ::= default_clock [ identifier ] [ ( portsDef ) ] [ = expression ] ;
```

The defining operator = or <- may be used.

This is precisely equivalent to defining an input clock and then declaring that clock to be the default clock. Example:

```
default_clock clk_src (OSC, GATE) = sClkIn;
```

is equivalent to:

```
input_clock clk_src (OSC, GATE) = sClkIn;
default_clock clk_src;
```

If omitted, the = expression in the default_clock statement defaults to <- exposeCurrentClock. Example:

```
default_clock xclk (OSC, GATE);
```

is equivalent to:

```
default_clock xclk (OSC, GATE) <- exposeCurrentClock;</pre>
```

If the portnames are excluded, the names default to CLK, CLK_GATE. Example:

```
default_clock xclk = clk;
```

is equivalent to:

```
default_clock xclk (CLK, CLK_GATE) = clk;
```

Alternately, if the *expression* is an identifier being assigned with =, and the user wishes this to be the name of the default clock, then he can leave off the name of the default clock and *expression* will be assumed to be the name. Example:

```
default_clock (OSC, GATE) = clk;
is equivalent to:
    default_clock clk (OSC, GATE) = clk;
```

If an expression is provided, both the ports and the name cannot be omitted.

However, omitting the entire statement is equivalent to:

```
default_clock (CLK, CLK_GATE) <- exposeCurrentClock;</pre>
```

specifying that the current clock is to be associated with all methods which do not specify otherwise.

15.6 Output clock

The output_clock statement gives the port connections for a clock provided in the module's interface.

```
outputClockBVIStmt ::= output_clock identifier ( [ portsDef ] ) ;
```

The *identifier* defines the name of the output clock, which must match a clock declared in the module's interface. Example:

It is an error for the same *identifier* to be declared by more than one output_clock statement.

15.7 Input reset

The input_reset statement defines how an incoming reset to the module is connected. Typically there is one port. BSV assumes that the reset is inverted (the reset is asserted with the value 0).

where the = may be replaced by <-.

The reset given by *expression* is to be connected to the Verilog port specified by *portId*. The *identifier* is the name of the reset and may be used elsewhere in the import to associate the reset with methods via a reset_by clause.

The clocked_by clause is used to specify the clock domain that the reset is associated with, named by *clockId*. Any clock in the domain may be used. If the clause is omitted, the associated clock is the default clock. Example:

```
input_reset rst(sRST_N) = sRstIn;
```

is equivalent to:

```
input_reset rst(sRST_N) clocked_by(clk) = sRstIn;
```

where clk is the identifier named in the default_clock statement.

If the user doesn't care which clock domain is associated with the reset, no_clock may be used. In this case the compiler will not check that the connected reset is associated with the correct domain. Example

```
input_reset rst(sRST_N) clocked_by(no_clock) = sRstIn;
```

If the *expression* is an identifier being assigned with =, and the user wishes this to be the name of the reset, then he can leave off the *identifier* of the reset and the *expression* will be assumed to be the name. The reset name can be left off in other circumstances, but then no name is associated with the reset. An unamed reset cannot be referred to elsewhere, such as in a method or other statement.

In the cases where a parent module needs to associate a reset with methods, but the reset is not used internally, the statement may contain a name, but not specify a port. In this case, there is no port expected in the Verilog module. Example:

```
input_reset rst() clocked_by (clk_src) = sRstIn ;
```

Example of a BVI import statement containing an input_reset statement:

```
import "BVI" SyncReset =
module vSyncReset#(Integer stages ) ( Reset rstIn, ResetGenIfc rstOut );
...
// we don't care what the clock is of the input reset
input_reset rst(IN_RST_N) clocked_by (no_clock) = rstIn;
...
endmodule
```

15.8 Default reset

In BSV, when you define a module, it has an implicit reset (the *current reset*) which is used to reset all instantiated sub-modules (unless otherwise specified via a reset_by clause). Other resets to submodules must be explicitly passed as input arguments.

Every BVI import module must declare which reset, if any, is the default reset. The default reset is the implicit reset provided by the parent module (or explicitly given with a reset_by). The default reset is also the reset associated with methods in the BVI import when no reset_by clause is specified.

The simplest definition for the default reset is:

```
defaultResetBVIStmt ::= default_reset identifier ;
```

where identifier specifies the name of an input reset which is designated as the default reset.

The reset may be unused or not connected to a port, but it must still be declared. Example:

```
default_reset no_reset;
```

The keyword default_reset may be omitted when declaring an unused reset. The above statement can thus be written as:

```
no_reset; // the default_reset keyword can be omitted
```

This statement declares that the implicit reset from the parent module is ignored (and not connected). In this case, the default reset for methods becomes no_reset, meaning there is no associated reset.

To save typing, you can merge the default_reset and input_reset statements into a single line:

```
defaultResetBVIStmt ::= \texttt{default\_reset} \left[ \ identifier \ \right] \left[ \ ( \ portId \ ) \ \right] \left[ \ clocked\_by \ ( \ clockId \ ) \ \right] \\ \left[ \ = \ expression \ \right] \ ;
```

The defining operator = or <- may be used.

This is precisely equivalent to defining an input reset and then declaring that reset to be the default. Example:

```
default_reset rst (RST_N) clocked_by (clk) = sRstIn;
```

is equivalent to:

```
input_reset rst (RST_N) clocked_by (clk) = sRstIn;
default_reset rst;
```

If omitted, = expression in the default_reset statement defaults to <- exposeCurrentReset. Example:

```
default_reset rst (RST_N);
```

is equivalent to

```
default_reset rst (RST_N) <- exposeCurrentReset;</pre>
```

The clocked_by clause is optional; if omitted, the reset is clocked by the default clock. Example:

```
default_reset rst (sRST_N) = sRstIn;
```

is equivalent to

```
default_reset rst (sRST_N) clocked_by(clk) = sRstIn;
```

where clk is the default_clock.

If no_clock is specified, the reset is not associated with any clock. Example:

```
input_reset rst (sRST_N) clocked_by(no_clock) = sRstIn;
```

If the *portId* is excluded, the reset port name defaults to RST_N. Example:

```
default_reset rstIn = rst;
```

is equivalent to:

```
default_reset rstIn (RST_N) = rst;
```

Alternatively, if the *expression* is an identifier being assigned with =, and the user wishes this to be the name of the default reset, then he can leave off the name of the default reset and *expression* will be assumed to be the name. Example:

```
default_reset (rstIn) = rst;
```

is equivalent to:

```
default_reset rst (rstIn) = rst;
```

Both the ports and the name cannot be omitted.

However, omitting the entire statement is equivalent to:

```
default_reset (RST_N) <- exposeCurrentReset;</pre>
```

specifying that the current reset is to be associated with all methods which do not specify otherwise.

15.9 Output reset

The output_reset statement gives the port connections for a reset provided in the module's interface.

```
outputResetBVIStmt ::= output_reset identifier [ ( portId ) ] [ clocked_by ( clockId ) ];
```

The *identifier* defines the name of the output reset, which must match a reset declared in the module's interface. Example:

```
interface ResetGenIfc;
  interface Reset gen_rst;
endinterface

import "BVI" SyncReset =
module vSyncReset#(Integer stages ) ( Reset rstIn, ResetGenIfc rstOut ) ;
    ...
    output_reset gen_rst(OUT_RST_N) clocked_by(clk) ;
endmodule
```

It is an error for the same *identifier* to be declared by more than one output_reset statement.

15.10 Ancestor, same family

There are two statements for specifying the relationship between clocks: ancestor and same_family.

```
ancestorBVIStmt ::= ancestor ( clockId , clockId );
```

This statement indicates that the second named clock is an ancestor of the first named clock. To say that clock1 is an ancestor of clock2, means that clock2 is a gated version of clock1. This is written as:

```
ancestor (clock2, clock1);
```

For clocks which do not have an ancestor relationship, but do share a common ancestor, we have:

```
sameFamilyBVIStmt ::= same_family ( clockId , clockId );
```

This statement indicates that the clocks specified by the *clockIds* are in the same family (same clock domain). When two clocks are in the same family, they have the same oscillator with a different gate. To be in the same family, one does not have to be a gated version of the other, instead they may be gated versions of a common ancestor. Note that ancestor implies same_family, which then need not be explicitly stated. For example, a module which gates an input clock:

```
input_clock clk_in(CLK_IN, CLK_GATE_IN) = clk_in;
output_clock new_clk(CLK_OUT, CLK_GATE_OUT);
ancestor(new_clk, clk_in);
```

15.11 Schedule

The schedule statement specifies the scheduling constraints between methods in an imported module. The operators relate two sets of methods; the specified relation is understood to hold for each pair of an element of the first set and an element of the second set. The order of the methods in the lists is unimportant and the parentheses may be omitted if there is only one name in the set.

The meanings of the operators are:

```
CF conflict-free
SB sequences before
SBR sequences before, with range conflict (that is, not composable in parallel)
C conflicts
```

It is an error to specify two relationships for the same pair of methods. It is an error to specify a scheduling annotation other than CF for methods clocked by unrelated clocks. For such methods, CF is the default; for methods clocked by related clocks the default is C. The compiler generates a warning if an annotation between a method pair is missing. Example:

```
import "BVI" FIF02 =
module vFIF0F2_MC
                                    ( Clock sClkIn, Reset sRstIn,
                                       Clock dClkIn, Reset dRstIn,
                                       Clock realClock, Reset realReset,
                                      FIFOF_MC#(a) ifc )
                                    provisos (Bits#(a,sa));
                    enq( D_IN ) enable(ENQ) clocked_by( clk_src ) reset_by( srst ) ;
    method
    method FULL_N
                    notFull
                                             clocked_by( clk_src ) reset_by( srst ) ;
    method
                                enable(DEQ) clocked_by( clk_dst ) reset_by( drst ) ;
                    deq()
    method D_OUT
                    first
                                             clocked_by( clk_dst ) reset_by( drst ) ;
                                             clocked_by( clk_dst ) reset_by( drst ) ;
    method EMPTY_N
                    notEmpty
```

```
schedule (enq, notFull) CF (deq, first, notEmpty) ;
   schedule (first, notEmpty) CF (first, notEmpty) ;
   // CF: conflict free - methods in the first list can be scheduled
   // in any order or any number of times, with the methods in the
   // second list - there is no conflict between the methods.
   schedule first SB deq ;
   schedule (notEmpty) SB (deq) ;
   schedule (notFull) SB (eng);
   // SB indicates the order in which the methods must be scheduled
   // the methods in the first list must occur (be scheduled) before
   // the methods in the second list
  // SB allows these methods to be called from one rule but the
   // SBR relationship does not.
   schedule (enq) C (enq);
   schedule (deq) C (deq);
   schedule (notFull) CF (notFull) ;
   // C: conflicts - methods in the first list conflict with the
   // methods in the second - they cannot be called in the same clock cycle.
  // if a method conflicts with itself, (enq,deq, and notFull), it
   // cannot be called more than once in a clock cycle
endmodule
```

15.12 Path

The path statement indicates that there is a combinational path from the first port to the second port.

```
pathBVIStmt ::= path ( portId , portId );
```

It is an error to specify a path between ports that are connected to methods clocked by unrelated clocks. This would be, by definition, an unsafe clock domain crossing. Note that the compiler assumes that there will be a path from a value or ActionValue method's input parameters to its result, so this need not be specified explicitly.

The paths defined by the path statement are used in scheduling. A path may impact rule urgency by implying an order in how the methods are scheduled. The path is also used in checking for combinational cycles in a design. The compiler will report an error if it detects a cycle in a design. In the following example, there is a path declared between WSET and WHAS, as shown in figure 2.




Figure 2: Path in the RWire0 Verilog module between WSET and WHAS ports

```
import "BVI" RWire0 =
  module vMkRWire0 (VRWire0);
    ...
  method wset() enable(WSET) ;
  method WHAS whas ;
  schedule whas CF whas ;
  schedule wset SB whas ;
```

```
path (WSET, WHAS);
endmodule: vMkRWire0
```

15.13 Interface

```
interfaceBVIStmt ::= interface typeDefType; { interfaceBVIMembDecl } endinterface [ : typeIde ] interfaceBVIMembDect:= methodBVIStmt | interfaceBVIStmt;
```

An interface statement can contain two types of statements: method statements and subinterface declarations. The interface statement in BVI import is the same as any other interface statement (Section 5.2) with one difference: the method statements within the interface are BVI method statements (methodBVIStmt 15.2).

Example:

Since a BVI wrapper module can only provide a single interface (BRAM_DUAL_PORT in this example), to provide multiple interfaces you have to create an interface hierarchy using interface statements.

The interface hierarchy provided in this example is:

```
interface BRAM_DUAL_PORT#(type addr, type data);
  interface BRAM_PORT#(addr, data) a;
  interface BRAM_PORT#(addr, data) b;
endinterface: BRAM_DUAL_PORT
```

where the subinterfaces, a and b, are defined as interface statements in the body of the import "BVI" statement.

15.14 Inout

The following statements describe how to pass an inout port from a wrapped Verilog module through a BSV module. These ports are represented in BSV by the type Inout. There are two ways that

an Inout can appear in BSV modules: as an argument to the module or as a subinterface of the interface provided by the module. There are, therefore, two ways to declare an Inout port in a BVI import: the statement inout declares an argument of the current module; and the statement ifc_inout declares a subinterface of the provided interface.

```
inoutBVIStmt ::= inout portId [ clocked_by ( clockId ) ] [ reset_by ( resetId ) ] = expression ;
```

The value of portId is the Verilog name of the inout port and expression is the name of an argument from the module.

Here, the identifier is the name of the subinterface of the provided interface and portId is, again, the Verilog name of the inout port.

The clock and reset associated with the Inout are assumed to be the default clock and default reset unless explicitly specified.

Example:

```
interface Q;
     interface Inout#(Bit#(13)) q_inout;
     interface Clock c_clock;
 endinterface
 import "BVI" Foo =
 module mkFoo#(Bool b)(Inout#(int) x, Q ifc);
     default_clock ();
    no_reset;
     inout iport = x;
     ifc_inout q_inout(qport);
     output_clock c_clock(clockport);
 endmodule
The wrapped Verilog module is:
 module Foo (iport, clockport, qport);
     input cccport;
     inout [31:0] iport;
     inout [12:0] qport;
     . . .
 endmodule
```

16 Embedding C in a BSV Design

This section describes how to declare a BSV function that is provided as a C function. This is used when there are existing C functions which the designer would like to include in a BSV module. Using the *importBDPI* syntax, the user can specify that the implementation of a BSV function is provided as a C function.

```
CFuncArgs ::= CFuncArg { , CFuncArg }
CFuncArg ::= type \ [identifier \ ]
```

This defines a function *identifier* in the BSV source code which is implemented by a C function of the same name. A different link name (C name) can be specified immediately after the "BDPI", using an optional [identifier =]. The link name is not bound by BSV case-restrictions on identifiers and may start with a capital letter.

Example of an import statement where the C name matches the BSV name:

```
// the C function and the BSV function are both named checksum
import "BDPI" function Bit#(32) checksum (Bit#(n), Bit#(32));
```

Example of an import statement where the C name does not match the BSV name:

```
// the C function name is checksum
// the BSV function name is checksum_raw
import "BDPI" checksum = function Bit#(32) checksum_raw (Bit#(n), Bit#(32));
```

The first *type* specifies the return type of the function. The optional *CFuncArgs* specify the arguments of the function, along with an optional identifier to name the arguments.

For instance, in the above checksum example, you might want to name the arguments to indicate that the first argument is the input value and the second argument is the size of the input value.

```
import "BDPI" function Bit#(32) checksum (Bit#(n) input_val, Bit#(32) input_size);
```

16.1 Argument Types

The types for the arguments and return value are BSV types. The following table shows the correlation from BSV types to C types.

BSV Type	C Type
String	char*
Bit#(0) - Bit#(8)	unsigned char
Bit#(9) - Bit#(32)	unsigned int
Bit#(33) - Bit#(64)	unsigned long long
Bit#(65) -	unsigned int*
Bit#(n)	unsigned int*

The *importBDPI* syntax provides the ability to import simple C functions that the user may already have. A C function with an argument of type char or unsigned char should be imported as a BSV function with an argument of type Bit#(8). For int or unsigned int, use Bit#(32). For long long or unsigned long long, use Bit#(64). While BSV creates unsigned values, they can be passed to a C function which will treat the value as signed. This can be reflected in BSV with Int#(8), Int#(32), Int#(64), etc.

The user may also import new C functions written to match a given BSV function type. For instance, a function on bit-vectors of size 17 (that is, Bit#(17)) would expect to pass this value as the C type unsigned int and the C function should be aware that only the first 17 bits of the value are valid data.

Wide data Bit vectors of size 65 or greater are passed by reference, as type unsigned int*. This is a pointer to an array of 32-bit words, where bit 0 of the BSV vector is bit 0 of the first word in the array, and bit 32 of the BSV vector is bit 0 of the second word, etc. Note that we only pass the pointer; no size value is passed to the C function. This is because the size is fixed and the C function could have the size hardcoded in it. If the function needs the size as an additional parameter, then either a C or BSV wrapper is needed. See the examples below.

Polymorphic data As the above table shows, bit vectors of variable size are passed by reference, as type unsigned int*. As with wide data, this is a pointer to an array of 32-bit words, where bit 0 of the BSV vector is bit 0 of the first word in the array, and bit 32 of the BSV vector is bit 0 of the second word, etc. No size value is passed to the C function, because the import takes no stance on how the size should be communicated. The user will need to handle the communication of the size, typically by adding an additional argument to the import function and using a BSV wrapper to pass the size via that argument, as follows:

```
// This function computes a checksum for any size bit-vector
// The second argument is the size of the input bit-vector
import "BDPI" checksum = function Bit#(32) checksum_raw (Bit#(n), Bit#(32));
// This wrapper handles the passing of the size
function Bit#(32) checksum (Bit#(n) vec);
  return checksum_raw(vec, fromInteger(valueOf(n)));
endfunction
```

16.2 Return types

Imported functions can be value functions, Action functions, or ActionValue functions. The acceptable return types are the same as the acceptable argument types, except that String is not permitted as a return type.

Imported functions with return values correlate to C functions with return values, except in the cases of wide and polymorphic data. In those cases, where the BSV type correlates to unsigned int*, the simulator will allocate space for the return result and pass a pointer to this memory to the C function. The C function will not be responsible for allocating memory. When the C function finishes execution, the simulator copies the result in that memory to the simulator state and frees the memory. By convention, this special argument is the first argument to the C function.

For example, the following BSV import:

```
import "BDPI" function Bit#(32) f (Bit#(8));
would connect to the following C function:
    unsigned int f (unsigned char x);
While the following BSV import with wide data:
    import "BDPI" function Bit#(128) g (Bit#(8));
would connect to the following C function:
    void g (unsigned int* resultptr, unsigned char x);
```

16.3 Implicit pack/unpack

So far we have only mentioned Bit and String types for arguments and return values. Other types are allowed as arguments and return values, as long as they can be packed into a bit-vector. These types include Int, UInt, Bool, and Maybe, all of which have an instance in the Bits class.

For example, this is a valid import:

```
import "BDPI" function Bool my_and (Bool, Bool);
```

Since a Bool packs to a Bit#(1), it would connect to a C function such as the following:

```
unsigned char
my_and (unsigned char x, unsigned char y);
```

In this next example, we have two C functions, signedGT and unsignedGT, both of which implement a greater-than function, returning a Bool indicating whether x is greater than y.

```
import "BDPI" function Bool signedGT (Int#(32) x, Int#(32) y);
import "BDPI" function Bool unsignedGT (UInt#(32) x, UInt#(32) y);
```

Because the function signedGT assumes that the MSB is a sign bit, we use the type-system to make sure that we only call that function on signed values by specifying that the function only works on Int#(32). Similarly, we can enforce that unsignedGT is only called on unsigned values, by requiring its arguments to be of type UInt#(32).

The C functions would be:

```
unsigned char signedGT (unsigned int x, unsigned int y); unsigned char unsignedGT (unsigned int x, unsigned int y);
```

In both cases, the packed value is of type Bit#(32), and so the C function is expected to take the its arguments as unsigned int. The difference is that the signedGT function will then treat the values as signed values while the unsignedGT function will treat them as unsigned values. Both functions return a Bool, which means the C return type is unsigned char.

Argument and return types to imported functions can also be structs, enums, and tagged unions. The C function will receive the data in bit form and must return values in bit form.

16.4 Other examples

Shared resources In some situations, several imported functions may share access to a resource, such as memory or the file system. If these functions wish to share file handles, pointers, or other cookies between each other, they will have to pass the data as a bit-vector, such as unsigned int/Bit#(32).

When to use Action components If an imported function has a side effect or if it matters how many times or in what order the function is called (relative to other calls), then the imported function should have an Action component in its BSV type. That is, the functions should have a return type of Action or ActionValue.

Removing indirection for polymorphism within a range A polymorphic type will always become unsigned int* in the C, even if there is a numeric proviso which restricts the size. Consider the following import:

```
import "BDPI" function Bit#(n) f(Bit#(n), Bit#(8)) provisos (Add#(n,j,32));
```

This is a polymorphic vector, so the conversion rules indicate that it should appear as unsigned int* in the C. However, the proviso indicates that the value of n can never be greater than 32. To make the import be a specific size and not a pointer, you could use a wrapper, as in the example below.

```
import "BDPI" f = function Bit#(32) f_aux(Bit#(32), Bit#(8));
function Bit#(n) f (Bit#(n) x) provisos (Add#(n,j,32));
  return f_aux(extend(x), fromInteger(valueOf(n)));
endfunction
```

References

- [Acc04] Accellera. SystemVerilog 3.1a Language Reference Manual: Accellera's Extensions to Verilog (R), 2004. See: www.accelera.org, www.systemverilog.org.
- [IEE01] IEEE. IEEE Standard Verilog (R) Hardware Description Language, March 2001. IEEE Std 1364-2001.
- [IEE02] IEEE. IEEE Standard VHDL Language Reference Manual, IEEE Std 1076-1993, 2002.
- [Ter03] Terese. Term Rewriting Systems. Cambridge University Press, 2003.

A Keywords

In general, keywords do not use uppercase letters (the only exception is the keyword valueOf). The following are the keywords in BSV (and so they cannot be used as identifiers).

```
Action
ActionValue
BVI
C
CF
Ε
SB
SBR
                                   endaction
action
actionvalue
                                   endactionvalue
ancestor
begin
bit
case
                                   endcase
clocked_by
default
default_clock
default_reset
dependencies
deriving
determines
else
enable
end
enum
export
for
function
                                   endfunction
if
ifc_inout
import
inout
input_clock
input_reset
instance
                                   endinstance
interface
                                   endinterface
let
match
matches
                                   endmethod
method
module
                                   endmodule
numeric
output_clock
output_reset
package
                                   endpackage
parameter
path
port
```

provisos reset_by return rule ${\tt endrule}$ rules endrules same_family schedule struct ${\tt tagged}$ type endtypeclass typeclass typedef union valueOf ${\tt valueof}$ void while

The following are keywords in System Verilog (which includes all the keywords in Verilog). Although most of them are not used in BSV, for compatibility reasons they are not allowed as identifiers in BSV either.

				_	
alias		expect		negedge	
always		export		new	
always_comb		extends		nmos	
always_ff		extern		nor	
always_latc	h	final		noshowcancel	led
and		first_match		not	
assert		for		notif0	
assert_stro	be	force		notif1	
assign		foreach		null	
assume		forever		or	
automatic		fork		output	
before		forkjoin		package	endpackage
begin end		function	endfunction	packed	. 0
bind		generate	endgenerate	parameter	
bins		genvar	O	pmos	
binsof		highz0		posedge	
bit		highz1		primitive	endprimitive
break		if		priority	
buf		iff		program	endprogram
bufif0		ifnone		property	endproperty
bufif1		ignore_bins		protected	onaproporty
byte		illegal_bin		pull0	
•	.case	import		pull1	
case end	case	incdir		pulldown	
casez		include		•	
cell				pullup	n a
chandle		initial		pulsestyle_o	
		inout		pulsestyle_o	nderect
class	endclass	input		pure	
clocking	endclocking	inside		rand	
cmos		instance		randc	
config	endconfig	int		randcase	
const		integer		randsequence	
constraint		interface	endinterface	rcmos	
context		intersect		real	
continue		join		realtime	
cover		join_any		ref	
covergroup	endgroup	join_none		reg	
coverpoint		large		release	
cross		liblist		repeat	
deassign		library		return	
default		local		rnmos	
${\tt defparam}$		localparam		rpmos	
design		logic		rtran	
disable		longint		rtranif0	
dist		macromodule	1	rtranif1	
do		matches		scalared	
edge		medium		sequence	endsequence
else		modport		shortint	
enum		module	endmodule	shortreal	
event		nand		showcancelle	d

signed		time	var
small		timeprecision	vectored
solve		timeunit	virtual
specify	endspecify	tran	void
specparam		tranif0	wait
static		tranif1	wait_order
string		tri	wand
strong0		tri0	weak0
strong1		tri1	weak1
struct		triand	while
super		trior	wildcard
supply0		trireg	wire
supply1		type	with
table	endtable	typedef	within
tagged		union	wor
task	endtask	unique	xnor
this		unsigned	xor
throughout		use	

B The Standard Prelude package

This section describes the type classes, data types, interfaces and functions provided by the Prelude package. The standard Prelude package is automatically included in all BSV packages. You do not need to take any special action to use any of the features defined in the Prelude package.

Section C describes BSV's large collection of AzureIP Foundation libraries. To use any of these libraries in a design you must explicitly import the library package.

B.1 Type classes

A type class groups related functions and operators and allows for instances across the various datatypes which are members of the typeclass. Hence the function names within a type class are *overloaded* across the various type class members.

A typeclass declaration creates a type class. An instance declaration defines a datatype as belonging to a type class. A datatype may belong to zero or many type classes.

The Prelude package declares the following type classes:

	Prelude Type Classes
Bits	Types that can be converted to bit vectors and back.
Eq	Types on which equality is defined.
Literal	Types which can be created from integer literals.
RealLiteral	Types which can be created from real literals.
Arith	Types on which arithmetic operations are defined.
Ord	Types on which comparison operations are defined.
Bounded	Types with a finite range.
Bitwise	Types on which bitwise operations are defined.
BitReduction	Types on which bitwise operations on a single operand to produce
	a single bit result are defined.
BitExtend	Types on which extend operations are defined.

B.1.1 Bits

Bits defines the class of types that can be converted to bit vectors and back. Membership in this class is required for a data type to be stored in a state, such as a Register or a FIFO, or to be used at a synthesized module boundary. Often instance of this class can be automatically derived using the deriving statement.

```
typeclass Bits #(type a, numeric type n)
  function Bit#(n) pack(a x);
  function a unpack(Bit#(n) x);
endtypeclass
```

Note: the numeric keyword is not required

The functions pack and unpack are provided to convert elements to Bit#() and to convert Bit#() elements to another datatype.

Bits Functions		
pack	Converts element a of datatype data_t to a element of datatype Bit#() of size_a. function Bit#(size_a) pack(data_t a);	

unpack	Converts an element a of datatype Bit#() and size_a into an element with of element type data_t.
	<pre>function data_t unpack(Bit#(size_a) a);</pre>

B.1.2 Eq

Eq defines the class of types whose values can be compared for equality. Instances of the Eq class are often automatically derived using the deriving statement.

```
typeclass Eq #(type data_t);
  function Bool \== (data_t x, data_t y);
  function Bool \/= (data_t x, data_t y);
endtypeclass
```

The equality functions == and != are Boolean functions which return a value of True if the equality condition is met. When defining an instance of an Eq typeclass, the \== and \/= notations must be used. If using or referring to the functions, the standard Verilog operators == and != may be used.

Eq Functions		
==	Returns True if x is equal to y.	
	<pre>function Bool \== (data_t x, data_t y,);</pre>	

/=	Returns True if x is not equal to y.
	<pre>function Bool \/= (data_t x, data_t y,);</pre>
	<pre>function Bool \/= (data_t x, data_t y,);</pre>

Examples

```
return (pack(i) & 3) == 0;
if (a != maxInt)
```

B.1.3 Literal

Literal defines the class of types which can be created from integer literals.

```
typeclass Literal #(type data_t);
  function data_t fromInteger(Integer x);
  function Bool inLiteralRange(data_t target, Integer x);
endtypeclass
```

The fromInteger function converts an Integer into an element of datatype data_t. Whenever you write an integer literal in BSV(such as "0" or "1"), there is an implied fromInteger applied to it, which turns the literal into the type you are using it as (such as Int, UInt, Bit, etc.). By defining an instance of Literal for your own datatypes, you can create values from literals just as for these predefined types.

The typeclass also provides a function inLiteralRange that takes an argument of the target type and an Integer and returns a Bool that indicates whether the Integer argument is in the legal range of the target type. For example, assuming x has type Bit#(4), inLiteralRange(x, 15) would return True, but inLiteralRange(x, 22) would return False.

Literal Functions		
fromInteger	Converts an element x of datatype Integer into an element of data type data_t function data_t fromInteger(Integer x);	

inLiteralRange	Tests whether an element x of datatype Integer is in the legal range of data type data_t		
	<pre>function Bool inLiteralRange(data_t target, Integer x);</pre>		

Examples

```
function foo (Vector#(n,int) xs) provisos (Log#(n,k));
    Integer maxindex = valueof(n) - 1;
    Int#(k) index;
    index = fromInteger(maxindex);
    ...
endfunction

function Bool inLiteralRange(RegAddress a, Integer i);
    return(i >= 0 && i < 83);
endfunction</pre>
```

B.1.4 RealLiteral

RealLiteral defines the class of types which can be created from real literals.

```
typeclass RealLiteral #(type data_t);
   function data_t fromReal(Real x);
endtypeclass
```

The fromReal function converts a Real into an element of datatype data_t. Whenever you write a real literal in BSV(such as "3.14"), there is an implied fromReal applied to it, which turns the real into the specified type. By defining an instance of RealLiteral for a datatype, you can create values from reals for any type.

RealLiteral Functions		
fromReal	Converts an element x of datatype Real into an element of data	
	type data_t	
	<pre>function data_t fromReal(Real x);</pre>	

Examples

```
FixedPoint#(is, fs) f = fromReal(n); //n is a Real number
```

B.1.5 SizedLiteral

SizedLiteral defines the class of types which can be created from integer literals with a specified size.

```
typeclass SizedLiteral #(type data_t, type size_t)
  dependencies (data_t determines size_t);
    function data_t fromSizedInteger(Bit#(size_t);
endtypeclass
```

The fromSizedInteger function converts a literal of type Bit#(size_t) into an element of datatype data_t. Whenever you write a sized literal like 1'b0, there is an implied fromSizedInteger which turns the literal into the type you are using it as, with the defined size. Instances are defined for the types Bit, UInt, and Int.

SizedLiteral Functions		
fromSizedInteger	Converts an element of Bit#(size_t) into an element of data	
	type data_t	
	<pre>function data_t fromSizedInteger(Bit#(size_t));</pre>	

B.1.6 Arith

Arith defines the class of types on which arithmetic operations are defined.

```
typeclass Arith #(type data_t)
provisos (Literal#(data_t));
function data_t \+ (data_t x, data_t y);
function data_t \- (data_t x, data_t y);
function data_t negate (data_t x);
function data_t \* (data_t x, data_t y);
function data_t \/ (data_t x, data_t y);
function data_t \% (data_t x, data_t y);
function data_t abs (data_t x);
function data_t signum (data_t x);
function data_t \** (data_t x, data_t y);
```

```
function data_t exp_e (data_t x);
function data_t log (data_t x);
function data_t logb (data_t b, data_t x);
function data_t log2 (data_t x);
function data_t log10 (data_t x);
endtypeclass
```

The Arith functions provide arithmetic operations. For the arithmetic symbols, when defining an instance of the Arith typeclass, the escaped operator names must be used as shown in the tables below. The negate name may be used instead of the operator for negation. If using or referring to these functions, the standard (non-escaped) Verilog operators can be used.

	Arith Functions
+	Element x is added to element y.
	<pre>function data_t \+ (data_t x, data_t y);</pre>
_	Element y is subtracted from element x.
	<pre>function data_t \- (data_t x, data_t y);</pre>
negate	Change the sign of the number. When using the function the Ver-
_	ilog negate operator, -, may be used.
	<pre>function data_t negate (data_t x);</pre>
*	Element x is multiplied by y.
	<pre>function data_t * (data_t x, data_t y);</pre>
/	Element x is divided by y. The definition depends on the type - many types truncate the remainder . Note: may not be synthesizable with downstream tools.
	<pre>function data_t \/ (data_t x, data_t y);</pre>
%	Returns the remainder of x/y . Obeys the identity $((x/y) * y) + (x\%y) = x$.
	<pre>function data_t \% (data_t x, data_t y);</pre>

Note: Division by 0 is undefined. Both x/0 and x%0 will generate errors at compile-time and run-time for most instances.

abs	Returns the absolute value of x.
	<pre>function data_t abs (data_t x);</pre>

signum	Returns a unit value with the same sign as x, such that
	abs(x)*signum(x) = 1. signum(12) returns 1 and signum(-12)
	returns -1.
	function data_t signum (data_t x);
	Tunovion dubu_0 bigham (dubu_0 k),
**	The element x is raised to the y power $(x**y = x^y)$.
	function data_t ** (data_t x, data_t y);
	Tunovion duod_o (** (duod_o x, duod_o y),
log2	Returns the base 2 logarithm of x (log $_2x$).
	<pre>function data_t log2(data_t x) ;</pre>
	:
exp_e	e is raised to the power of $x(e^x)$.
	<pre>function data_t exp_e (data_t x);</pre>
log	Returns the base e logarithm of x ($\log_e x$).
106	
	function data_t log (data_t x);
logb	Returns the base b logarithm of x ($\log_b x$).
	function data_t logb (data_t b, data_t x);
log10	Returns the base 10 logarithm of x ($\log_{10}x$).
	function data_t log10(data_t x);

```
real u = log(1);
real x = 128.0;
real y = log2(x);
real z = 100.0;
real v = log10(z);
real w = logb(3,9.0);
real a = -x;
real b = abs(x);
```

B.1.7 Ord

Ord defines the class of types for which an order is defined, allowing comparison operations. A complete definition of an instance of Ord requires defining either <= or compare.

```
typeclass Ord #(type data_t);
  function Bool \< (data_t x, data_t y);
  function Bool \<= (data_t x, data_t y);
  function Bool \> (data_t x, data_t y);
  function Bool \>= (data_t x, data_t y);
  function Ordering compare(data_t x, data_t y);
  function data_t min(data_t x, data_t y);
  function data_t max(data_t x, data_t y);
  endtypeclass
```

The functions <, <=, >, and >= are Boolean functions which return a value of True if the comparison condition is met.

Ord Functions	
<	Returns True if x is less than y.
	<pre>function Bool \< (data_t x, data_t y);</pre>
<=	Returns True if x is less than or equal to y.
	<pre>function Bool \<= (data_t x, data_t y);</pre>
>	Returns True if x is greater than y.
	<pre>function Bool \> (data_t x, data_t y);</pre>
>=	Returns True if x is greater than or equal to y.
	<pre>function Bool \>= (data_t x, data_t y);</pre>

The function compare returns a value of the Ordering (Section B.2.11) data type (LT, GT, or EQ).

compare	Returns the Ordering value describing the relationship of x to y.
	<pre>function Ordering compare (data_t x, data_t y);</pre>

The functions min and max return a value of datatype data_t which is either the minimum or maximum of the two values, depending on the function.

min	Returns the minimum of the values x and y.
	<pre>function data_t min (data_t x, data_t y);</pre>
max	Returns the maximum of the values x and y.
	function data_t max (data_t x, data_t y);

```
rule r1 (x <= y);
rule r2 (x > y);
function Ordering onKey(Record r1, Record r2);
  return compare(r1.key,r2.key);
endfunction
...
  List#(Record) sorted_rs = sortBy(onKey,rs);
  List#(List#(Record)) grouped_rs = groupBy(equiv,sorted_rs);
let read_count = min(reads_remaining, 16);
```

B.1.8 Bounded

Bounded defines the class of types with a finite range and provides functions to define the range.

```
typeclass Bounded #(type data_t);
   data_t minBound;
   data_t maxBound;
endtypeclass
```

The Bounded functions minBound and maxBound define the minimum and maximum values for the type data_t.

Bounded Functions	
minBound	The minimum value the type data_t can have.
	data_t minBound;

maxBound	The maximum value the type data_t can have.
	data_t maxBound;

Examples

```
module mkGenericRandomizer (Randomize#(a))
   provisos (Bits#(a, sa), Bounded#(a));

typedef struct {
    Bit#(2) red;
   Bit#(1) blue;
} RgbColor deriving (Eq, Bits, Bounded);
```

B.1.9 Bitwise

Bitwise defines the class of types on which bitwise operations are defined.

```
typeclass Bitwise #(type data_t);
  function data_t \& (data_t x1, data_t x2);
  function data_t \| (data_t x1, data_t x2);
  function data_t \^ (data_t x1, data_t x2);
  function data_t invert (data_t x1);
  function data_t \< (data_t x1, x2);
  function data_t \> (data_t x1, x2);
  function Bit#(1) msb (data_t x);
  function Bit#(1) lsb (data_t x);
endtypeclass
```

The Bitwise functions compare two operands bit by bit to calculate a result. That is, the bit in the first operand is compared to its equivalent bit in the second operand to calculate a single bit for the result.

	Bitwise Functions
&	Performs an and operation on each bit in x1 and x2 to calculate the result.
	function data_t \& (data_t x1, data_t x2);
1	Performs an or operation on each bit in $x1$ and $x2$ to calculate the result.
	<pre>function data_t \ (data_t x1, data_t x2);</pre>
^	Performs an <i>exclusive or</i> operation on each bit in x1 and x2 to calculate the result.
	<pre>function data_t \^ (data_t x1, data_t x2);</pre>
~~	Performs an <i>exclusive nor</i> operation on each bit in x1 and x2 to calculate the result.
	function data_t \~^ (data_t x1, data_t x2);
	<pre>function data_t \^~ (data_t x1, data_t x2);</pre>
invert	Performs a <i>unary negation</i> operation on each bit in x1. When using this function, the corresponding Verilog operator, ~, may be used.
	function data_t invert (data_t x1);

The << and >> operators perform left and right shift operations. Whether the shift is an arithmetic shift (Int) or a logical shift (Bit, UInt) is dependent on how the type is defined.

Reference Guide

<<	Performs a <i>left shift</i> operation of x1 by the number of bit positions given by x2. x2 must be of an acceptable index type (Integer, Bit#(n), Int#(n) or UInt#(n)). function data_t \<< (data_t x1, x2);
>>	Performs a $right$ shift operation of $x1$ by the number of bit positions

Performs a right shift operation of x1 by the number of bit positions given by x2. x2 must be of an acceptable index type (Integer, Bit#(n), Int#(n) or UInt#(n)).

function data_t \>> (data_t x1, x2);

The functions msb and lsb operate on a single argument.

msb	Returns the value of the most significant bit of x. Returns 0 if
	width of data_t is 0.
	<pre>function Bit#(1) msb (data_t x);</pre>

lsb	Returns the value of the least significant bit of x. Returns 0 if width of data_t is 0.
	function Bit#(1) lsb (data_t x);

Examples

```
function Value computeOp(AOp aop, Value v1, Value v2);
    case (aop) matches
        Aand : return v1 & v2;
        Anor : return invert(v1 | v2);
        Aor : return v1 | v2;
        Axor : return v1 ^ v2;
        Asll : return v1 << vToNat(v2);
        Asrl : return v1 >> vToNat(v2);
        endcase
endfunction: computeOp

Bit#(3) msb = read_counter [5:3];
Bit#(3) lsb = read_counter [2:0];
read_counter <= (msb == 3'b111) ? {msb+1,lsb+1} : {msb+1,lsb};</pre>
```

B.1.10 BitReduction

BitReduction defines the class of types on which the Verilog bit reduction operations are defined.

```
typeclass BitReduction #(type x, numeric type n)
  function x#(1) reduceAnd (x#(n) d);
  function x#(1) reduceOr (x#(n) d);
  function x#(1) reduceXor (x#(n) d);
```

```
function x#(1) reduceNand (x#(n) d);
function x#(1) reduceNor (x#(n) d);
function x#(1) reduceXnor (x#(n) d);
endtypeclass
```

Note: the numeric keyword is not required

The BitReduction functions take a sized type and reduce it to one element. The most common example is to operate on a Bit#() to produce a single bit result. The first step of the operation applies the operator between the first bit of the operand and the second bit of the operand to produce a result. The function then applies the operator between the result and the next bit of the operand, until the final bit is processed.

Typically the bit reduction operators will be accessed through their Verilog operators. When defining a new instance of the BitReduction type class the BSV names must be used. The table below lists both values. For example, the BSV bit reduction and operator is reduceAnd and the corresponding Verilog operator is &.

	BitReduction Functions
reduceAnd &	Performs an <i>and</i> bit reduction operation between the elements of d to calculate the result.
	<pre>function x#(1) reduceAnd (x#(n) d);</pre>
reduceOr	Performs an <i>or</i> bit reduction operation between the elements of d to calculate the result.
	<pre>function x#(1) reduceOr (x#(n) d);</pre>
reduceXor	Performs an <i>xor</i> bit reduction operation between the elements of d to calculate the result.
	<pre>function x#(1) reduceXor (x#(n) d);</pre>
reduceNand ^&	Performs an <i>nand</i> bit reduction operation between the elements of d to calculate the result.
	function x#(1) reduceNand (x#(n) d);
reduceNor	Performs an <i>nor</i> bit reduction operation between the elements of control to calculate the result.
•	<pre>function x#(1) reduceNor (x#(n) d);</pre>

Performs an <i>xnor</i> bit reduction operation between the elements of
d to calculate the result.
<pre>function x#(1) reduceXnor (x#(n) d);</pre>

B.1.11 BitExtend

BitExtend defines types on which bit extension operations are defined.

```
typeclass BitExtend #(numeric type m, numeric type n, type x); // n > m
  function x#(n) extend (x#(m) d);
  function x#(n) zeroExtend (x#(m) d);
  function x#(n) signExtend (x#(m) d);
  function x#(m) truncate (x#(n) d);
endtypeclass
```

The BitExtend operations take as input of one size and changes it to an input of another size, as described in the tables below. It is recommended that extend be used in place of zeroExtend or signExtend, as it will automatically perform the correct operation based on the data type of the argument.

	BitExtend Functions						
extend	Performs either a zeroExtend or a signExtend as appropriate, do pending on the data type of the argument (zeroExtend for an ur signed argument, signExtend for a signed argument). function x#(n) extend (x#(m) d) provisos (Add#(k, m, n));						
zeroExtend	Use of extend instead is recommended. Adds extra zero bits to the MSB of argument d of size m to make the datatype size n.						
	<pre>function x#(n) zeroExtend (x#(m) d) provisos (Add#(k, m, n));</pre>						
signExtend	Use of extend instead is recommended. Adds extra sign bits to the MSB of argument d of size m to make the datatype size n by replicating the sign bit.						
	<pre>function x#(n) signExtend (x#(m) d) provisos (Add#(k, m, n));</pre>						
truncate	Removes bits from the MSB of argument d of size n to make the datatype size m.						

function x#(m) truncate (x#(n) d)
 provisos (Add#(k, n, m));

```
UInt#(TAdd#(1,TLog#(n))) zz = extend(xx) + extend(yy);
Bit#(n) v1 = zeroExtend(v);
Int#(4) i_index = signExtend(i) + 4;
Bit#(32) upp = truncate(din);
r <= zeroExtend(c + truncate(r))</pre>
```

B.1.12 SaturatingArith

The SaturatingArith typeclass contains modified addition and subtraction functions which saturate to the values defined by maxBound or minBound when the operation would otherwise overflow or wrap-around.

There are 4 types of saturation modes which determine how an overflow or underflow should be handled, as defined by the SaturationMode type.

Saturation Modes				
Enum Value	Description			
Sat_Wrap	Ignore overflow and underflow, just wrap around			
Sat_Bound	On overflow or underflow result becomes maxBound or minBound			
Sat_Zero	On overflow or underflow result becomes 0			
Sat_Symmetric	On overflow or underflow result becomes maxBound or (minBound+1)			

Instances of the SaturatingArith class are defined for Int, UInt, Complex, and FixedPoint.

satPlus	Modified plus function which saturates when the operation would otherwise over-
	flow or wrap-around. The saturation value (maxBound, wrap, or 0) is determined
	by the value of mode, the SaturationMode.
	function t satPlus (SaturationMode mode, t x, t y);

satMinus	Modified minus function which saturates when the operation would otherwise
	overflow or wrap-around. The saturation value (minBound, wrap, minBound +1,
	or 0) is determined by the value of mode, the SaturationMode.
	function t satMinus (SaturationMode mode, t x, t y);

boundedPlus	Modified plus function which saturates to maxBound when the operation would
	otherwise overflow or wrap-around. The function is the same as satPlus where
	the SaturationMode is Sat_Bound.
	<pre>function t boundedPlus (t x, t y) = satPlus (Sat_Bound, x, y);</pre>

```
boundedMinus Modified minus function which saturates to minBound when the operation would otherwise overflow or wrap-around. The function is the same as satMinus where the SaturationMode is Sat_Bound.

function t boundedMinus (t x, t y) = satMinus(Sat_Bound, x, y);
```

```
Reg#(SaturationMode) smode <- mkReg(Sat_Wrap);
rule okdata (isOk);
  tstCount <= boundedPlus (tstCount, 1);
endrule</pre>
```

B.1.13 Alias and NumAlias

Alias specifies that two types can be used interchangeably, providing a way to introduce local names for types within a module. They are used in Provisos. See Section 7.1 for more information.

B.2 Data Types

Every variable and every expression in BSV has a *type*. Prelude defines the data types which are always available. An **instance** declaration defines a data type as belonging to a type class. Each data type may belong to one or more type classes; all functions, modules, and operators declared for the type class are then defined for the data type. A data type does not have to belong to any type classes.

Data type identifiers must always begin with a capital letter. There are three exceptions; bit, int, and real, which are predefined for backwards compatibility.

B.2.1 Bit

To define a value of type Bit:

Bit#(type n);

	Type Classes for Bit								
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit
								Reduction	Extend
Bit	$\sqrt{}$								

	Bit type aliases
bit	The data type bit is defined as a single bit. This is a special case of Bit.
	<pre>typedef Bit#(1) bit;</pre>

Examples

```
Bit#(32) a;  // like 'reg [31:] a'
Bit#(1) b;  // like 'reg a'
bit     c;  // same as Bit#(1) c
```

The Bit data type provides functions to concatenate and split bit-vectors.

	Bit Functions
{x,y}	Concatenate two bit vectors, x of size n and y of size m returning a bit vector of size k. The Verilog operator { } is used. function Bit#(k) bitconcat(Bit#(n) x, Bit#(m) y) provisos (Add#(n, m, k));

```
Split a bit vector into two bit vectors (higher-order bits (n), lower-order bits (m)).

function Tuple2 #(Bit#(n), Bit#(m)) split(Bit#(k) x)
provisos (Add#(n, m, k));
```

Examples

B.2.2 UInt

The UInt type is an unsigned fixed width representation of an integer value.

	Type Classes for UInt								
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit
								Reduction	Extend
UInt									

Examples

```
UInt#(8) a = 'h80;
UInt#(12) b = zeroExtend(a); // b => 'h080
UInt#(8) c = truncate(b); // c => 'h80
```

B.2.3 Int

The Int type is a signed fixed width representation of an integer value.

	Type Classes for Int								
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit
								Reduction	Extend
Int									

Examples

```
Int#(8) a = 'h80;
Int#(12) b = signExtend(a);  // b => 'hF80
Int#(8) c = truncate(d);  // c => 'h80
```

	Int type aliases
int	The data type int is defined as a 32-bit signed integer. This is a special case of Int. typedef Int#(32) int;

B.2.4 Integer

The Integer type is a data type used for integer values and functions. Because Integer is not part of the Bits typeclass, the Integer type is used for static elaboration only; all values must be resolved at compile time.

Type Classes for Integer									
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit
								Reduction	Extend
Integer									

	Integer Functions
div	Element x is divided by element y and the result is rounded toward negative infinity. Division by 0 is undefined.
	function Integer div(Integer x, Integer y);
mod	Element x is divided by element y using the div function and the remainder is returned as an Integer value. div and mod satisfy the identity $(div(x,y)*y)+mod(x,y)==x$. Division by 0 is undefined.
	<pre>function Integer mod(Integer x, Integer y);</pre>
quot	Element x is divided by element y and the result is truncated (rounded towards 0). Division by 0 is undefined.
	<pre>function Integer quot(Integer x, Integer y);</pre>
rem	Element x is divided by element y using the quot function and the remainder is returned as an Integer value. quot and rem satisfy the identity $(quot(x,y)*y) + rem(x,y) == x$. Division by 0 is undefined.
	function Integer rem(Integer x, Integer y);

The fromInteger function, defined in Section B.1.3, can be used to convert an Integer into any type in the Literal typeclass.

Examples

```
Int#(32) arr2[16];
for (Integer i=0; i<16; i=i+1)
    arr2[i] = fromInteger(i);

Integer foo = 10;
foo = foo + 1;
foo = foo * 5;
Bit#(16) var1 = fromInteger( foo );</pre>
```

B.2.5 Bool

The Bool type is defined to have two values, True and False. typedef enum {False, True} Bool;

	Type Classes for Bool								
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit
								Reduction	Extend
Bool									

The Bool functions return either a value of True or False.

	Bool Functions
not	Returns True if x is false, returns False if x is true.
!	
	function Bool not (Bool x);

&&	Returns True if x and y are true, else it returns False.
	function Bool \&& (Bool x, Bool y);

П	Returns True if x or y is true, else it returns False.
	<pre>function Bool \ (Bool x, Bool y);</pre>

```
Bool a
                    // A variable named a with a type of Bool
Reg#(Bool) done
                    // A register named done with a type of Bool
Vector#(5, Bool)
                    // A vector of 5 Boolean values
Bool a = 0;
                 // ERROR! You cannot do this
Bool a = True; // correct
if (a)
                 // correct
  . . . .
if (a == 0)
                 // ERROR!
  . . . .
Bool b1 = True;
Bool b2 = True;
Bool b3 = b1 && b2;
```

B.2.6 Real

The Real type is a data type used for real values and functions.

Real numbers are of the form:

If there is a decimal point, there must be digits following the decimal point. An exponent can start with either an E or an e, followed by an optional sign (+ or -), followed by digits. There cannot be an exponent or a sign without any digits. Any of the numeric components may include an underscore, but an underscore cannot be the first digit of the real number.

Unlike integer numbers, real numbers are of limited precision. They are represented as IEEE floating point numbers of 64 bit length, as defined by the IEEE standard.

Because the type Real is not part of the Bits typeclass, the Real type is used for static elaboration only; all values must be resolved at compile time.

There are many functions defined for Real types, provided in the Real package (Section C.5.1). To use these functions, the Real package must be imported.

	Type Classes for Real									
	Bits	Eq	Literal	Real	Arith	Ord	Bounded	Bitwise	Bit	Bit
				Literal					Reduction	Extend
Real			√							

Real type aliases					
real	The SystemVerilog name real is an alias for Real				
	typedef Real real;				

There are two system tasks defined for the Real data type, used to convert between Real and IEEE standard 64-bit vector representation (Bit#(64)).

Real system tasks					
\$realtobits	Converts from a Real to the IEEE 64-bit vector representation.				
	function Bit#(64) \$realtobits (Real x);				

\$bitstoreal	Converts from a 64-bit vector representation to a Real.
	function Real \$bitstoreal (Bit#(64) x);

Examples

```
Bit#(1) sign1 = 0;
Bit#(52) mantissa1 = 0;
Bit#(11) exp1 = 1024;
Real r1 = $bitstoreal({sign1, exp1, mantissa1}); //r1 = 2.0

Real x = pi;
let m = realToString(x)); // m = 3.141592653589793
```

B.2.7 String

Strings are mostly used in system tasks (such as \$display). The String type belongs to the Eq type class; strings can be tested for equality and inequality using the == and != operators. The String type is also part of the Arith class, but only the addition (+) operator is defined. All other Arith operators will produce an error message.

	Type Classes for String									
		Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit
									Reduction	Extend
ĺ	String			√						

The strConcat function is provided for combining String values.

	String Functions
strConcat	Concatenates two elements of type String, x and y.
+	
	<pre>function String strConcat(String x, String y);</pre>

Examples

```
String s1 = "This is a test";
$display("first string = ", s1);

// we can use + to concatenate
String s2 = s1 + " of concatenation";
$display("Second string = ", s2);
```

B.2.8 Fmt

The Fmt primitive type provides a representation of arguments to the \$display family of system tasks (Section 12.8.1) that can be manipulated in BSV code. Fmt representations of data objects can be written hierarchically and applied to polymorphic types.

Objects of type Fmt can be supplied directly as arguments to system tasks in the \$display family. An object of type Fmt is returned by the \$format (Section 12.8.2) system task.

The Fmt type is part of the Arith class, but only the addition (+) operator is defined. All other Arith operators will produce an error message.

	Type Classes for Fmt											
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit			
								Reduction	Extend			
Fmt												

Examples

```
Reg#(Bit#(8)) count <- mkReg(0);
Fmt f = $format("(%0d)", count + 1);
$display(" XYZ ", f, " ", $format("(%0d) ", count));
\\value displayed: XYZ (6) (5)</pre>
```

B.2.9 Void

The Void type is a type which has one literal? used for constructing concrete values of the type void. The Void type is part of the Bits and Literal typeclasses.

	Type Classes for Void											
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit			
								Reduction	Extend			
Void												

```
typedef union tagged {
   void Invalid;
   data_t Valid;
} Maybe #(type data_t) deriving (Eq, Bits);

typedef union tagged {
   void InvalidFile;
   Bit#(31) MCD;
   Bit#(31) FD;
} File;
```

B.2.10 Maybe

The Maybe type is used for tagging values as either *Valid* or *Invalid*. If the value is *Valid*, the value contains a datatype data_t.

```
typedef union tagged {
    void Invalid;
    data_t Valid;
} Maybe #(type data_t) deriving (Eq, Bits);
```

	Type Classes for Maybe											
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit			
								Reduction	Extend			
Maybe	Maybe $\sqrt{}$											

The Maybe data type provides functions to check if the value is Valid and to extract the valid value.

Maybe Functions									
fromMaybe	Extracts the Valid value out of a Maybe argument. If the tag is								
	Invalid the default value, defaultval, is returned.								
	<pre>function data_t fromMaybe(data_t defaultval,</pre>								

isValid	Returns a value of True if the Maybe argument is Valid.
	<pre>function Bool isValid(Maybe#(data_t) val);</pre>

Examples

```
RWire#(int) rw_incr <- mkRWire(); // increment method is being invoked
RWire#(int) rw_decr <- mkRWire(); // decrement method is being invoked
rule doit;
   Maybe#(int) mbi = rw_incr.wget();
   Maybe#(int) mbd = rw_decr.wget();
                   = fromMaybe (?, mbi);
   int
         di
                   = fromMaybe (?, mbd);
   int
   if
           ((! isValid (mbi)) && (! isValid (mbd)))
      noAction;
   else if (
               isValid (mbi) && (! isValid (mbd)))
      value2 <= value2 + di;</pre>
                                     isValid (mbd))
   else if ((! isValid (mbi)) &&
      value2 <= value2 - dd;</pre>
   else // ( isValid (mbi)
                                     isValid (mbd))
                               &&
      value2 <= value2 + di - dd;</pre>
endrule
```

B.2.11 Ordering

The Ordering type is used as the return type for the result of generic comparators, including the compare function defined in the Ord (Section B.1.7) type class. The valid values of Ordering are: LT, GT, and EQ.

```
typedef enum {
   LT,
   EQ,
   GT
} Ordering deriving (Eq, Bits, Bounded);
```

	Type Classes for Ordering											
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit			
								Reduction	Extend			
Ordering												

Examples

```
function Ordering onKey(Record r1, Record r2);
  return compare(r1.key,r2.key);
endfunction
```

B.2.12 Tuples

Tuples are predefined structures which group a small number of values together. The following pseudo code explains the structure of the tuples. You cannot define your own tuples, but must use the seven predefined tuples, Tuple2 through Tuple8. As shown, Tuple2 groups two items together, Tuple3 groups three items together, up through Tuple8 which groups eight items together.

```
typedef struct{
   a tpl_1;
   b tpl_2;
} Tuple2 #(type a, type b) deriving (Bits, Eq, Bounded);
```

```
typedef struct{
    a tpl_1;
    b tpl_2;
    c tpl_3;
 } Tuple3 #(type a, type b, type c) deriving (Bits, Eq, Bounded);
typedef struct{
    a tpl_1;
    b tpl_2;
    c tpl_3;
    d tpl_4;
 } Tuple4 #(type a, type b, type c, type d) deriving (Bits, Eq, Bounded);
typedef struct{
    a tpl_1;
    b tpl_2;
    c tpl_3;
    d tpl_4;
    e tpl_5;
 } Tuple5 #(type a, type b, type c, type d, type e)
   deriving (Bits, Eq, Bounded);
typedef struct{
    a tpl_1;
    b tpl_2;
    c tpl_3;
    d tpl_4;
    e tpl_5;
    f tpl_6;
 } Tuple6 #(type a, type b, type c, type d, type e, type f)
   deriving (Bits, Eq, Bounded);
typedef struct{
    a tpl_1;
    b tpl_2;
    c tpl_3;
    d tpl_4;
    e tpl_5;
    f tpl_6;
   g tpl_7;
 } Tuple7 #(type a, type b, type c, type d, type e, type f, type g)
   deriving (Bits, Eq, Bounded);
typedef struct{
    a tpl_1;
    b tpl_2;
    c tpl_3;
    d tpl_4;
    e tpl_5;
    f tpl_6;
    g tpl_7;
    h tpl_8;
 } Tuple8 #(type a, type b, type c, type d, type e, type f, type g, type h)
   deriving (Bits, Eq, Bounded);
```

	Type Classes for Tuples											
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit			
								Reduction	Extend			
TupleN						√						

Tuples cannot be manipulated like normal structures; you cannot create values of and select fields from tuples as you would a normal structure. Values of these types can be created only by applying a predefined family of constructor functions.

Tuple Constr	uctor Functions
tuple2 (e1, e2)	Creates a variable of type Tuple2 with com-
	ponent values e1 and e2.
tuple3 (e1, e2, e3)	Creates a variable of type Tuple3 with values
	e1, e2, and e3.
tuple4 (e1, e2, e3, e4)	Creates a variable of type Tuple4 with com-
	ponent values e1, e2, e3, and e4.
tuple5 (e1, e2, e3, e4, e5)	Creates a variable of type Tuple5 with com-
	ponent values e1, e2, e3, e4, and e5.
tuple6 (e1, e2, e3, e4, e5, e6)	Creates a variable of type Tuple6 with com-
	ponent values e1, e2, e3, e4, e5, and e6.
tuple7 (e1, e2, e3, e4, e5, e6, e7)	Creates a variable of type Tuple7 with com-
	ponent values e1, e2, e3, e4, e5, e6, and e7.
tuple8 (e1, e2, e3, e4, e5, e6, e7,	Creates a variable of type Tuple8 with com-
e8)	ponent values e1, e2, e3, e4, e5, e6, e7, and
	e8.

Fields of these types can be extracted only by applying a predefined family of selector functions.

	Tuple Extract Functions
tpl_1 (x)	Extracts the first field of x from a Tuple2 to Tuple8.
tpl_2 (x)	Extracts the second field of x from a Tuple2 to Tuple8.
tpl_3 (x)	Extracts the third field of x from a Tuple3 to Tuple8.
tpl_4 (x)	Extracts the fourth field of x from a Tuple4 to Tuple8.
tpl_5 (x)	Extracts the fifth field of x from a Tuple5 to Tuple8.
tpl_6 (x)	Extracts the sixth field of x from a Tuple6, Tuple7 or Tuple8.
tpl_7 (x)	Extracts the seventh field of x from a Tuple7 or Tuple8.
tpl_8 (x)	Extracts the seventh field of x from a Tuple8.

Examples

```
Tuple2#( Bool, int ) foo = tuple2( True, 25 );
Bool field1 = tpl_1( foo ); // this is value 1 in the list
int field2 = tpl_2( foo ); // this is value 2 in the list
foo = tuple2( !field1, field2 );
```

B.2.13 Clock

Clock is an abstract type of two components: a single Bit oscillator and a Bool gate.

```
typedef ... Clock;
```

Clock is in the Eq type class, meaning two values can be compared for equality.

	Type Classes for Clock											
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit			
								Reduction	Extend			
Clock												

```
Clock clk <- exposeCurrentClock;
module mkTopLevel( Clock readClk, Reset readRst, Top ifc );</pre>
```

B.2.14 Reset

Reset is an abstract type.

```
typedef ... Reset ;
```

Reset is in the Eq type class, meaning two fields can be compared for equality.

	Type Classes for Reset									
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit	
								Reduction	Extend	
Reset										

Examples

B.2.15 Inout

An Inout type is a first class type that is used to pass Verilog inouts through a BSV module. It takes an argument which is the type of the underlying signal:

```
Inout#(type t)
```

For example, the type of an Inout signal which communicates boolean values would be:

Inout#(Bool)

	Type Classes for Inout											
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit			
								Reduction	Extend			
Inout	Inout											

An Inout type is a valid subinterface type (like Clock and Reset). A value of an Inout type is clocked_by and reset_by a particular clock and reset.

Inouts are connectable via the Connectable typeclass. The use of mkConnection instantiates a Verilog module InoutConnect. The connected inouts must be on the same clock and the same reset. The clock and reset of the inouts may be different than the clock and reset of the parent module of the mkConnection.

```
instance Connectable#(Inout#(a, x1), Inout#(a, x2))
provisos (Bit#(a,sa));
```

A module with an Inout subinterface cannot leave that interface undefined since there is no way to create or examine inout values in BSV. For example, you cannot even write:

```
Inout#(int) i = ?; // not valid in BSV
```

The Inout type exists only so that RTL inout signals can be connected in BSV; the ultimate users of the signal will be outside the BSV code. An imported Verilog module might have an inout port that your BSV design doesn't use, but which needs to be exposed at the top level. In this case, the submodule will introduce an inout signal that the BSV cannot read or write, but merely provides in its interfaces until it is exposed at the top level. Or, a design may contain two imported Verilog modules that have inout ports that expect to be connected. You can import these two modules, declaring that they each have a port of type Inout#(t) and connect them together. The compiler will check that both ports are of the same type t and that they are in the same clock domain with the same reset. Beyond that, BSV does not concern itself with the values of the inout signals.

Examples

Instantiating a submodule with an input and exposing it at the next level:

```
interface SubIfc;
    ...
    interface Inout#(Bool) b;
endinterface

interface TopIfc;
    ...
    interface Inout#(Bool) bus;
endinterface

module mkTop (TopIfc);
    SubIfc sub <- mkSub;
    ...
    interface bus = sub.b;
endmodule</pre>
```

Connecting two submodules, using SubIfc defined above:

```
module mkTop(...);
...
SubIfc sub1 <- mkSub;
SubIfc sub2 <- mkSub;
mkConnection (sub1.b, sub2.b);
...
endmodule</pre>
```

B.2.16 Action/ActionValue

Any expression that is intended to act on the state of the circuit (at circuit execution time) is called an *action* and has type Action or ActionValue#(a). The type parameter a represents the type of the returned value.

Type Classes for Action/ActionValue									
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit
								Reduction	Extend
Action									

The types Action and ActionValue are special keywords, and therefore cannot be redefined.

typedef \cdots abstract \cdots struct ActionValue#(type a);

ActionValue type aliases				
Action	The Action type is a special case of the more general type ActionValue where nothing is returned. That is, the returns type is (void).			
	typedef ActionValue#(void) Action;			

Action Functions				
noAction	An empty Action, this is an Action that does nothing.			
	function Action noAction();			

Examples

B.2.17 Rules

A rule expression has type Rules and consists of a collection of individual rule constructs. Rules are first class objects, hence variables of type Rules may be created and manipulated. Rules values must eventually be added to a module in order to appear in synthesized hardware.

	Type Classes for Rules								
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit
								Reduction	Extend
Rules									

The Rules data type provides functions to create, manipulate, and combine values of the type Rules.

	Rules Functions				
emptyRules	An empty rules variable.				
	<pre>function Rules emptyRules();</pre>				
addRules	Takes rules r and adds them into a module. This function may only be called from within a module. The return type Empty indicates that the instantiation does not return anything.				
	<pre>module addRules#(Rules r) (Empty);</pre>				
rJoin	Symmetric union of two sets of rules. A symmetric union mean that neither set is implied to have any relation to the other: no more urgent, not execute before, etc.				
	<pre>function Rules rJoin(Rules x, Rules y);</pre>				
rJoinPreempts	Union of two sets of rules, with rules on the left getting scheduling precedence and blocking the rules on the right. That is, if a rule in set x fires, then all rules in set y are prevented from firing. This is the same as specifying descending_urgency plus a forced conflict.				
	<pre>function Rules rJoinPreempts(Rules x, Rules y);</pre>				
	.1				
	gUrgency				
rJoinDescendin					
Unio	on of two sets of rule, with rules in the left having higher urgency. That				
Unic is, if	some rules compete for resources, then scheduling will select rules in				
Unic is, if set x					
Unic is, if set x rules	some rules compete for resources, then scheduling will select rules in a set before set y. If the rules do not conflict, no conflict is added; the				

TJoinMutuallyExclusive Union of two sets of rule, with rules in the all rules in the left set annotated as mutually exclusive with all rules in the right set. No relationship between the rules in the left set or between the rules in the right set is assumed. This annotation is used in scheduling and checked during simulation. function Rules rJoinMutuallyExclusive(Rules x, Rules y);

rJoinExec	rJoinExecutionOrder			
	Union of two sets of rule, with the rules in the left set executing before the rules in the right set. No relationship between the rules in the left set or between the rules in the right set is assumed. If any pair of rules cannot execute in the specified order in the same clock cycle, that pair of rules will conflict.			
	<pre>function Rules rJoinExecutionOrder(Rules x, Rules y);</pre>			

rJoinConf	rJoinConflictFree			
	Union of two sets of rule, with the rules in the left set annotated as conflict-free with the rules in the right set. This assumption is used during scheduling and checked during simulation. No relationship between the rules in the left set or between the rules in the right set is assumed.			
	<pre>function Rules rJoinConflictFree(Rules x, Rules y);</pre>			

Examples (See Section 9.13 for complete example)

```
function Rules incReg(Reg#(CounterType) a);
  return( rules
    rule addOne;
        a <= a + 1;
    endrule
  endrules);
endfunction

// Add incReg rule to increment the counter
  addRules(incReg(asReg(counter)));</pre>
```

B.3 Operations on Numeric Types

B.3.1 Size Relationship/Provisos

These classes are used in provisos to express constraints between the sizes of types.

Class	Proviso	Description
Add	Add#(n1,n2,n3)	Assert $n1 + n2 = n3$
Mul	Mul#(n1,n2,n3)	Assert $n1 * n2 = n3$
Div	Div#(n1,n2,n3)	Assert ceiling $n1/n2 = n3$
Max	Max#(n1,n2,n3)	Assert $\max(n1, n2) = n3$
Min	Min#(n1,n2,n3)	Assert $\min(n1, n2) = n3$
Log	Log#(n1,n2)	Assert ceiling $\log_2(n1) = n2$.

Examples of Provisos using size relationships:

B.3.2 Size Relationship Type Functions

These type functions are used when "defining" size relationships between data types, where the defined value need not (or cannot) be named in a proviso. They may be used in datatype definition statements when the size of the datatype may be calculated from other parameters.

Type Function	Size Relationship	Description
TAdd	TAdd#(n1,n2)	Calculate $n1 + n2$
TSub	TSub#(n1,n2)	Calculate $n1 - n2$
TMul	TMul#(n1,n2)	Calculate $n1 * n2$
TDiv	TDiv#(n1,n2)	Calculate ceiling $n1/n2$
TLog	TLog#(n1)	Calculate ceiling $\log_2(n1)$
TExp	TExp#(n1)	Calculate 2^{n1}
TMax	TMax#(n1,n2)	Calculate $max(n1, n2)$
TMin	TMin#(n1,n2)	Calculate $min(n1, n2)$

Examples using other arithmetic functions:

B.3.3 valueOf and SizeOf pseudo-functions

Prelude provides these pseudo-functions to convert between types and numeric values. The pseudo-function valueof (or valueOf) is used to convert a numeric type into the corresponding Integer value. The pseudo-function SizeOf is used to convert a type t into the numeric type representing its bit size.

valueof valueOf	Converts a numeric type into its Integer value.
	function Integer valueOf (t);

```
module mkFoo (Foo#(n));
  UInt#(n) x;
  Integer y = valueOf(n);
endmodule
```

SizeOf	Converts a type into a numeric type representing its bit size.
	<pre>function t SizeOf#(any_type) provisos (Bits#(any_type, sa));</pre>

Examples

```
any_type x = structIn;
Bit#(SizeOf#(any_type)) = pack(structIn);
```

B.4 Registers and Wires

		Register and Wire Interfaces
Name	Section	Description
Reg	B.4.1	Register interface.
RWire	B.4.2	Similar to a register with output wrapped in a Maybe type to indi-
		cate validity.
Wire	B.4.3	Interchangeable with a Reg interface, validity of the data is implicit.
BypassWire	B.4.4	Implementation of the Wire interface where the _write method is
		always_enabled.
DWire	B.4.5	Implementation of the Wire interface where the _read method is
		always_ready.
PulseWire	B.4.6	RWire without any data.
ReadOnly	B.4.7	Interface which provides a value.
WriteOnly	B.4.8	Interface which writes a value.

B.4.1 Reg

The most elementary module available in BSV is the register, which has a Reg interface. Registers are polymorphic, i.e., in principle they can hold a value of any type but, of course, ultimately registers store bits. Thus, the provisos on register modules indicate that the type of the value stored in the register must be in the Bits type class, i.e., the operations pack and unpack are defined on the type to convert into bits and back.

Note that all Bluespec registers are considered atomic units, which means that even if one bit is updated (written), then all the bits are considered updated. This prevents multiple rules from updating register fields in an inconsistent manner.

When scheduling register modules, reads occur before writes. That is, any rule which reads from a register must be scheduled earlier than any other rule which writes to the register. The value read from the register is the value written in the previous clock cycle.

Interfaces and Methods

The Reg interface contains two methods, _write and _read.

```
interface Reg #(type a_type);
   method Action _write(a_type x1);
   method a_type _read();
endinterface: Reg
```

The _write and _read methods are rarely used. Instead, for writes, one uses the non-blocking assignment notation and, for reads, one just mentions the register interface in an expression.

Reg Interface					
	${ m M}\epsilon$	ethod	Arguments		
Name	Type	Description	Name Description		
_write	Action	writes a value x1	x1	data to be written	
_read	a_type	returns the value of the			
		register			

Modules

Prelude provides three modules to create a register: mkReg creates a register with a given reset value, mkRegU creates a register without any reset, and mkRegA creates a register with a given reset value and with asynchronous reset logic.

mkReg	Make a register with a given reset value. Reset logic is synchronous.
	<pre>module mkReg#(a_type resetval)(Reg#(a_type)) provisos (Bits#(a_type, sizea));</pre>

mkRegU	Make a register without any reset; initial simulation value is alternating 01 bits.
	<pre>module mkRegU(Reg#(a_type)) provisos (Bits#(a_type, sizea));</pre>

mkRegA	Make a register with a given reset value. Reset logic is asynchronous.
	<pre>module mkRegA#(a_type resetval)(Reg#(a_type)) provisos (Bits#(a_type, sizea));</pre>

Scheduling

When scheduling register modules, reads occur before writes. That is, any rule which reads from a register must be scheduled earlier than any other rule which writes to the register. The value read from the register is the value written in the previous clock cycle.

Scheduling Annotations				
mkReg, mkRegU, mkRegA				
read write				
read	CF	SB		
write	SA	SBR		

Functions

Three functions are provided for using registers: asReg returns the register interface instead of the value of the register; readReg reads the value of a register, useful when managing vectors or lists of registers; and writeReg to write a value into a register, also useful when managing vectors or lists of registers.

asReg	Treat a register as a register, i.e., suppress the normal behavior where the interface name implicitly represents the value that the register contains (the _read value). This function returns the register interface, not the value of the register.		
	<pre>function Reg#(a_type) asReg(Reg#(a_type) regIfc);</pre>		
readReg	Read the value out of a register. Useful for giving as the argument to higher-order vector and list functions.		
	<pre>function a_type readReg(Reg#(a_type) regIfc);</pre>		
writeReg	Write a value into a register. Useful for giving as the argument to higher-order vector and list functions.		
	<pre>function Action writeReg(Reg#(a_atype) regIfc, a_type din);</pre>		

Examples

```
Reg#(ta) res <- mkReg(0);

// create board[x][y]
Reg#(ta) pipe[depth];
for (Integer i=0; i<depth; i=i+1) begin
   Reg#(ta) c();
   mkReg#(0) xinst(c);
   pipe[i] = asReg(c);
end

function a readReg(Reg#(a) r);
   return(r);
endfunction</pre>
```

B.4.2 RWire

An RWire is a primitive stateless module whose purpose is to allow data transfer between methods and rules without the cycle latency of a register. That is, a RWire may be written in a cycle and that value can be read out in the same cycle; values are not stored across clock cycles.

When scheduling wire modules, since the value is read in the same cycle in which it is written, writes must occur before reads. That is, any rule which writes to a wire must be scheduled earlier than any other rule which reads from the wire. This is the reverse of how registers are scheduled.

Interfaces and Methods

The RWire interface is conceptually similar to a register's interface, but the output value is wrapped in a Maybe type. The wset method places a value on the wire and sets the valid signal. The read-like method, wget, returns the value and a valid signal in a Maybe type. The output is only Valid if a write has a occurred in the same clock cycle, otherwise the output is Invalid.

RWire Interface					
	Method Arguments				
Name	Type	Description	Name	Description	
wset	Action	writes a value and sets the valid signal	datain	data to be sent on the wire	
wget	Maybe	returns the value and the valid signal			

```
interface RWire#(type element_type) ;
  method Action wset(element_type datain) ;
  method Maybe#(element_type) wget() ;
endinterface: RWire
```

Modules

The mkRWire and mkUnsafeRWire modules are provided to create an RWire. The difference between the two RWire modules is the scheduling annotations.

mkRWire	Creates an RWire. Output is only valid if a write has occurred in the same clock cycle. The write (wset) must be sequenced before
	<pre>the read (wget) and they must be in different rules. module mkRWire(RWire#(element_type)) provisos (Bits#(element_type, element_width));</pre>

mkUnsafeRWire	Creates an RWire. Output is only valid if a write has occurred in	
	the same clock cycle. The write (wset) must be sequenced before	
	the read (wget) but they can be in the same rule.	
	<pre>module mkUnsafeRWire(RWire#(element_type)) provisos (Bits#(element_type, element_width));</pre>	

Scheduling

When scheduling wire modules, since the value is read in the same cycle in which it is written, writes must occur before reads. That is, any rule which writes to a wire must be scheduled earlier than any other rule which reads from the wire. This is the reverse of how registers are scheduled.

Scheduling Annotations				
mkRWire				
wget wset				
wget	CF	SAR		
wset	SBR	С		

Scheduling Annotations				
${ m mkUnsafeRWire}$				
wget wset				
wget	CF	SA		
wset	SB	С		

Examples

```
RWire#(int) rw_incr <- mkRWire();</pre>
rule doit;
   Maybe#(int) mbi = rw_incr.wget();
                   = fromMaybe (?, mbi);
           ((! isValid (mbi))
      noAction:
   else // ( isValid (mbi))
      value2 <= value2 + di ;</pre>
endrule
rule doitdifferently;
   case (rw_incr.wget()) matches
     { tagged Invalid } : noAction;
     { tagged Valid .di} : value <= value + di;
   endcase
endrule
method Action increment (int di);
   rw_incr.wset (di);
endmethod
```

B.4.3 Wire

The Wire interface and module are similar to RWire, but the valid bit is hidden from the user and the validity of the read is considered an implicit condition. The Wire interface works like the Reg interface, so mentioning the name of the wire gets (reads) its contents whenever they're valid, and using <= writes the wire. Wire is an RWire that is designed to be interchangeable with Reg. You can replace a Reg with a Wire without changing the syntax.

Interfaces and Methods

typedef Reg#(element_type) Wire#(type element_type);

Wire Interface					
Method Arguments					
Name	Type	Description	Name Description		
_write	Action	writes a value x1	x1	data to be written	
_read	a_type	returns the value of the			
		wire			

Modules

The mkWire and mkUnsafeWire modules are provided to create a Wire. The only difference between the two modules are the scheduling annotations. The mkWire version requires that the the write and the read be in different rules.

mkWire	Creates a Wire. Validity of the output is automatically checked as an implicit condition of the read method. The write and the read
	<pre>methods must be in different rules. module mkWire(Wire#(element_type)) provisos (Bits#(element_type, element_width));</pre>

mkUnsafeWire	Creates a Wire. Validity of the output is automatically checked as	
	an implicit condition of the read method. The write and the read	
	methods can be in the same rule.	
	<pre>module mkUnsafeWire(Wire#(element_type)) provisos (Bits#(element_type, element_width));</pre>	

Scheduling Annotations		
mkWire		
	_read	_write
_read	CF	SAR
_write	SBR	С

Scheduling Annotations		
${ m mkUnsafeWire}$		
	_read	_write
_read	CF	SA
_write	SB	С

Examples

```
module mkCounter_v2 (Counter);
  Reg#(int) value2 <- mkReg(0);
  Wire#(int) w_incr <- mkWire();

rule r_incr;
  value2 <= value2 + w_incr;
  endrule

method int read();
  return value2;
  endmethod

method Action increment (int di);
  w_incr <= di;
  endmethod
endmodule</pre>
```

B.4.4 BypassWire

BypassWire is an implementation of the Wire interface where the _write method is an always_enabled method. The compiler will issue a warning if the method does not appear to be called every clock cycle. The advantage of this tradeoff is that the _read method of this interface does not carry any implicit condition (so it can satisfy a no_implicit_conditions assertion or an always_ready method).

mkBypassWire	Creates a BypassWire. The write method is always_enabled.	
	<pre>module mkBypassWire(Wire#(element_type)) provisos (Bits#(element_type, element_width));</pre>	

Scheduling Annotations		
mkBypassWire		
	_read	_write
_read	CF	SAR
_write	SBR	С

Examples

```
module mkCounter_v2 (Counter);
  Reg#(int) value2 <- mkReg(0);
  Wire#(int) w_incr <- mkBypassWire();

rule r_incr;
  value2 <= value2 + w_incr;
  endrule

method int read();
  return value2;
  endmethod

method Action increment (int di);
  w_incr <= di;
  endmethod
endmodule</pre>
```

B.4.5 DWire

DWire is an implementation of the Wire interface where the <code>_read</code> method is an <code>always_ready</code> method and thus has no implicit conditions. Unlike the BypassWire however, the <code>_write</code> method need not be always enabled. On cycles when a DWire is written to, the <code>_read</code> method returns that value. On cycles when no value is written, the <code>_read</code> method instead returns a default value that is specified as an argument during instantiation.

There are two modules to create a DWire; the only difference being the scheduling annotations. A write is always scheduled before a read, however the mkDWire module requires that the write and read be in different rules.

mkDWire	Creates a DWire. The read method is always_ready.
	<pre>module mkDWire#(a_type defaultval)(Wire#(element_type)) provisos (Bits#(element_type, element_width));</pre>

mkUnsafeDWire	Creates a DWire. The read method is always_ready.	
	<pre>module mkUnsafeDWire#(a_type defaultval)(Wire#(element_type)) provisos (Bits#(element_type, element_width));</pre>	

Scheduling Annotations		
mkDWire		
	read	${ m write}$
_read	CF	SAR
_write	SBR	С

Scheduling Annotations		
mkUnsafeDWire		
	read	${ m write}$
_read	CF	SA
_write	SB	С

Examples

```
module mkCounter_v2 (Counter);
   Reg#(int) value2 <- mkReg(0);</pre>
```

```
Wire#(int) w_incr <- mkDWire (0);
rule r_incr;
   value2 <= value2 + w_incr;
endrule

method int read();
   return value2;
endmethod

method Action increment (int di);
   w_incr <= di;
endmethod
endmodule</pre>
```

B.4.6 PulseWire

Interfaces and Methods

The PulseWire interface is an RWire without any data. It is useful within rules and action methods to signal other methods or rules in the same clock cycle. Note that because the read method is called _read, the register shorthand can be used to get its value without mentioning the method _read (it is implicitly added).

PulseWire Interface		
Name Type		Description
send Action _read Bool		sends a signal down the wire
		returns the valid signal

```
interface PulseWire;
  method Action send();
  method Bool _read();
endinterface
```

Modules

Four modules are provided to create a PulseWire, the only difference being the scheduling annotations. In the OR versions the send method does not conflict with itself. Calling the send method for a mkPulseWire from 2 rules causes the two rules to conflict while in the mkPulseWireOR there is no conflict. In other words, the mkPulseWireOR acts a logical "OR". The Unsafe versions allow the send and _read methods to be in the same rule.

mkPulseWire	The writing to this type of wire is used in rules and action methods to send a single bit to signal other methods or rules in the same clock cycle. module mkPulseWire(PulseWire);
mkPulseWireOR	Returns a PulseWire which acts like a logical "Or". The send method of the same wire can be used in two different rules without conflict. module mkPulseWireOR(PulseWire);

mkUnsafePulseWire	The writing to this type of wire is used in rules and action methods
	to send a single bit to signal other methods or rules in the same
	clock cycle. The send and _read methods can be in the same rule.
	<pre>module mkUnsafePulseWire(PulseWire);</pre>

mkUnsafePulseWireOR	Returns a PulseWire which acts like a logical "Or". The send
	method of the same wire can be used in two different rules without
	conflict. The send and _read methods can be in the same rule.
	<pre>module mkUnsafePulseWireOR(PulseWire);</pre>

Scheduling Annotations		
mkPulseWire		
	_read	send
_read	CF	SAR
send	SBR	С

Scheduling Annotations			
mkUnsafePulseWire			
_read send			
_read	CF	SA	
send	SB	С	

Scheduling Annotations		
mkPulseWireOR		
	_read	send
_read	CF	SAR
send	SBR	SBR

Scheduling Annotations		
${\it mkUnsafePulseWireOR}$		
	_read	send
_read	CF	SA
send	SB	SBR

Counter Example - Using Reg and PulseWire

```
interface Counter#(type size_t);
   method Bit#(size_t) read();
   method Action load(Bit#(size_t) newval);
   method Action increment();
   method Action decrement();
endinterface
module mkCounter(Counter#(size_t));
   PulseWire increment_called <- mkPulseWire(); // define the PulseWires used</pre>
   PulseWire decrement_called <- mkPulseWire();</pre>
                                                // to signal other methods or rules
   // whether rules fire is based on values of PulseWires
   rule do_increment(increment_called && !decrement_called);
       value <= value + 1;</pre>
   endrule
   rule do_decrement(!increment_called && decrement_called);
       value <= value - 1;</pre>
   endrule
   method Bit#(size_t) read();
                                             // read the register
       return value;
   endmethod
```

B.4.7 ReadOnly

ReadOnly is an interface which provides a value. The _read shorthand can be used to read the value.

Interfaces and Methods

ReadOnly Interface			
Method			
Name Type Description			
_read a_type Reads the data			

```
interface ReadOnly #( type a_type ) ;
  method a_type _read() ;
endinterface
```

Functions

regToReadOnly	Converts a Reg interface into a ReadOnly interface. Useful for giving as the argument to higher-order vector and list functions.	
	<pre>function ReadOnly#(a_type) regToReadOnly(Reg#(a_type) regIfc);</pre>	

pulseWireToReadOnly	Converts a PulseWire interface into a ReadOnly interface.
	<pre>function ReadOnly#(Bool) pulseWireToReadOnly(PulseWire ifc)</pre>

readReadOnly	Takes a ReadOnly interface and returns a value.		
	<pre>function a_type readReadOnly(ReadOnly#(a_type) r);</pre>		

Examples

```
interface AHBSlaveIFC;
  interface AHBSlave
                                  bus;
  interface Put#(AHBResponse)
                                  response;
  interface ReadOnly#(AHBRequest) request;
endinterface
  interface ReadOnly request;
     method AHBRequest _read;
        let ctrl = AhbCtrl {command: write_wire,
                            size:
                                      size_wire,
                            burst:
                                      burst_wire,
                            transfer: transfer_wire,
                                      prot_wire,
                            prot:
                                      addr_wire};
                            addr:
        let value = AHBRequest {ctrl: ctrl, data: wdata_wire};
        return value;
      endmethod
   endinterface
```

B.4.8 WriteOnly

WriteOnly is an interface which writes a value. The _write shorthand is used to write the value.

Interfaces and Methods

	WriteOnly Interface				
Method				Arguments	
Name	Type	Description	Name Description		
_write	Action	Writes the data	х	Value to be written, of	
				datatype a_type.	

```
interface WriteOnly #( type a_type ) ;
  method Action _write (a_type x) ;
endinterface
Examples
interface WriteOnly#(type a);
  method Action _write(a v);
endinterface
// module with an always-enabled port to tie to a default value
   import "BVI" AlwaysWrite =
     module mkAlwaysWrite(WriteOnly#(a)) provisos(Bits#(a,sa));
        parameter width = valueof(sa);
        method _write(D_IN) enable((*inhigh*)EN);
        schedule _write C _write;
   endmodule
  module mkDefaultValue1();
     WriteOnly#(UInt#(7)) d1 <- mkAlwaysWrite(clocked_by primMakeDisabledClock);</pre>
     rule handle_d1;
          d1 <= 5;
     endrule
   endmodule
```

B.5 Miscellaneous Functions

B.5.1 Compile-time Messages

error	Generate a compile-time error message, s, and halt compilation			
	<pre>function a_type error(String s);</pre>			
warning	When applied to a value v of type a, generate a compile-time warning message, s, and continue compilation, returning v.			
	<pre>function a_type warning(String s, a_type v);</pre>			
	'			

message	When applied to a value v of type a, generate a compile-time informative message, s, and continue compilation, returning v.
	<pre>function a_type message(String s, a_type v);</pre>

errorM	Generate a compile-time error message, s , and halt compilation in a monad.
	<pre>function m#(void) errorM(String s) provisos (Monad#(m));</pre>

warningM	Generate a compilation warning in a monad.
	<pre>function m#(void) warningM(String s) provisos (Monad#(m));</pre>

messageM	Generate a compilation message in a monad.
	<pre>function m#(void) messageM(String s) provisos (Monad#(m));</pre>

B.5.2 Arithmetic Functions

max	Returns the maximum of two values, x and y.
	<pre>function a_type max(a_type x, a_type y) provisos (Ord#(a_type));</pre>

min	Returns the minimum of two values, x and y.
	<pre>function a_type min(a_type x, a_type y) provisos (Ord#(a_type));</pre>
abs	Returns the absolute value of x.
	<pre>function a_type abs(a_type x) provisos (Arith#(a_type), Ord#(a_type));</pre>
signedMul	Performs full precision multiplication on two Int#(n) operands of different sizes.
	<pre>function Int#(m) signedMul(Int#(n) x, Int#(k) y) provisos (Add#(n,k,m));</pre>
unsignedMul	Performs full precision multiplication on two unsigned UInt#(n) operands of different sizes.
	<pre>function UInt#(m) unsignedMul(UInt#(n) x, UInt#(k) y) provisos (Add#(n,k,m));</pre>
signedQuot	Performs full precision division on two Int#(n) operands of different sizes.
	<pre>function Int#(m) signedQuot(Int#(n) x, Int#(k) y);</pre>
	•
unsignedQuot	Performs full precision division on two unsigned $UInt#(n)$ operands of different sizes.
	<pre>function UInt#(m) unsignedQuot(UInt#(n) x, UInt#(k) y);</pre>

B.5.3 Operations on Functions

Higher order functions are functions which take functions as arguments and/or return functions as results. These are often useful with list and vector functions.

compose	Creates a new function, c, made up of functions, f and g. That is, c(a) = f(g(a))
	<pre>function (function c_type (a_type x0)) compose(function c_type f(b_type x1),</pre>

composeM	Creates a new monadic function, m#(c), made up of functions, f and g. That is, c(a) = f(g(a))
	<pre>function (function m#(c_type) (a_type x0)) composeM(function m#(c_type) f(b_type x1), function m#(b_type) g(a_type x2)) provisos # (Monad#(m));</pre>
id	Identity function, returns x when given x . This function is useful when the argument requires a function which doesn't do anything.
	function a_type id(a_type x);
constFn	Constant function, returns x.
	<pre>function a_type constFn(a_type x, b_type y);</pre>
flip	Flips the arguments x and y , returning a new function.
	<pre>function (function c_type new (b_type y, a_type x)) flip (function c_type old (a_type x, b_type y));</pre>
curry	This function converts a function on a pair (Tuple2) of arguments into a function which takes the arguments separately. The phrase to f(t1 x, t2 y) is the function returned by curry
	<pre>function (function t0 f(t1 x, t2 y)) curry (function t0 g(Tuple2#(t1, t2) x));</pre>
uncurry	This function does the reverse of curry; it converts a function of two arguments into a function which takes a single argument, a pair (Tuple2).
	<pre>function (function t0 g(Tuple2#(t1, t2) x)) uncurry (function t0 f(t1 x, t2 y));</pre>
	1

Examples

```
//using constFn to set the initial values of the registers in a list
  List#(Reg#(Resource)) items <- mapM( constFn(mkReg(initRes)),upto(1,numAdd) );

return(pack(map(compose(head0,toList),state)));

xs <- mapM(constFn(mkReg(False)),genList);</pre>
```

B.5.4 Bit Functions

The following functions operate on Bit#(n) variables.

parity	Returns the parity of the bit argument v. Example: parity(5'b1) = 1, parity(5'b3) = 0;
	<pre>function Bit#(1) parity(Bit#(n) v);</pre>

reverseBits	Reverses the order of the bits in the argument x.
	<pre>function Bit#(n) reverseBits(Bit#(n) x);</pre>
	function Bit#(n) reverseBits(Bit#(n) x);

countOnes	Returns the count of the number of 1's in the bit vector bin.
	<pre>function UInt#(lgn1) countOnes (Bit#(n) bin) provisos (Add#(1, n, n1), Log#(n1, lgn1),</pre>

countZerosMSB	For the bit vector bin, count the number of 0s until the first 1, starting from the most significant bit (MSB).
	<pre>function UInt#(lgn1) countZerosMSB (Bit#(n) bin) provisos (Add#(1, n, n1), Log#(n1, lgn1));</pre>

countZerosLSB	For the bit vector bin, count the number of 0s until the first 1, starting from the least significant bit (LSB).
	function UInt#(lgn1) countZerosLSB (Bit#(n) bin)
	provisos (Add#(1, n, n1), Log#(n1, lgn1));

truncateLSB	Truncates a Bit#(m) to a Bit#(n) by dropping bits starting with the LSB.
	<pre>function Bit#(n) truncateLSB(Bit#(m) x) provisos(Add#(n,k,m));</pre>

Examples

```
Bit#(6) f6 = truncateLSB(f);
let cmem=countZerosLSB(cfg.memoryAllocate);
let n = countOnes(neighbors);
```

B.5.5 Integer Functions

The following functions can only be used for static elaboration.

gcd	Calculate the greatest common divisor of two Integers.
	function Integer gcd(Integer a, Integer b);

lcm	Calculate the least common multiple of two Integers.
	<pre>function Integer lcm(Integer a, Integer b);</pre>

B.5.6 Control Flow Function

while	Repeat a function while a predicate holds.
	<pre>function a_type while(function Bool pred(a_type x1),</pre>

when	Adds an implicit condition onto an expression.
	<pre>function a when(Bool condition, a arg);</pre>

Example - adding the implicit condition readCount==0 to the action

B.6 Environment Values

The Environment section of the Prelude contains some value definitions that remain static within a compilation, but may vary between compilations.

Test whether the compiler is generating C.

genC	Returns True if the compiler is generating C.
	<pre>function Bool genC();</pre>

Test whether the compiler is generating Verilog.

genVerilog	Returns True if the compiler is generating Verilog.
	<pre>function Bool genVerilog();</pre>

Examples

```
if (genVerilog)
return (t + fromInteger(adj));
```

Return the version of the compiler.

compilerVersion	Returns a String containing the compiler version. This is the same string used with the -v flag.
	String compilerVersion;

Example:

```
The statement:
    $\display("compiler version = \%s", compilerVersion);
produces this output:
    compiler version = version 3.8.56 (build 7084, 2005-07-22)
```

Return the build number of the version of the compiler.

buildVersion	Returns a Bit#(32) containing the build number portion of the compiler version.
	Bit#(32) buildVersion;

Example:

```
The statement:
```

```
\ the compiler is %d", build
Version); produces this output:
```

"The build version of the compiler is 12345"

Get the current date and time.

date	Returns a String containing the date.
	String date;

Example:

```
The statement:
    $display("date = %s", date);
produces this output:
    "date = Mon Feb 6 08:39:59 EST 2006"
```

Returns the number of seconds from the epoch (1970-01-01 00:00:00) to now.

epochTime	Returns a Bit#(32) containing the number of seconds since the epoch, which is defined as 1970-01-01 00:00:00.
	Bit#(32) epochTime;

Example:

C AzureIP Foundation Libraries

Section B defined the standard Prelude package, which is automatically imported into every package. This section describes BSV's large and continuously growing collection of AzureIP Foundation libraries. To use any of these libraries in a package you must explicitly import the library package using an import clause (Section 3).

Bluespec's AzureIP intellectual property (IP) accelerates hardware design and modeling. All packages in the AzureIP Foundation library are provided as compiled code. Some of the packages are also provided as BSV source code to facilitate customization. When modifying these files, first copy them into a local directory and then modify your local copy. Use the -p flag when compiling, as described in the BSV Users Guide, to include the local directory in your path.

There are two AzureIP library families, Foundation and Premium:

- Foundation is an extensive family of components, types and functions that are included with the Bluespec toolsets for use in your models and designs they serve as a foundational base for your modeling and implementation work.
- Premium is the designation for Bluespec's fee-based AzureIP.

C.1 Storage Structures

C.1.1 Register File

Package

```
import RegFile :: * ;
```

Description

This package provides 5-read-port 1-write-port register array modules.

Note: In a design that uses RegFiles, some of the read ports may remain unused. This may generate a warning in various downstream tool. Downstream tools should be instructed to optimize away the unused ports.

Interfaces and Methods

The RegFile package defines one interface, RegFile. The RegFile interface provides two methods, upd and sub. The upd method is an Action method used to modify (or update) the value of an element in the register file. The sub method (from "sub"script) is a Value method which reads and returns the value of an element in the register file. The value returned is of a datatype data_t.

Interface Name	Parameter name	Parameter Description	Restrictions
RegFile	index_type	datatype of the index	must be in the Bits class
	$data_t$	datatype of the element values	must be in the Bits class

```
interface RegFile #(type index_t, type data_t);
   method Action upd(index_t addr, data_t d);
   method data_t sub(index_t addr);
endinterface: RegFile
```

Method		Arguments		
Name	Type	Description	Name Description	
upd	Action	Change or update an element within the register file.	addr d	index of the element to be changed, with a datatype of index_t new value to be stored, with a datatype of data_t
sub	data_t	Read an element from	addr	index of the element, with a
		the register file and return it.		datatype of index_t

Modules

The RegFile package provides three modules: mkRegFile creates a RegFile with registers allocated from the lo_index to the hi_index; mkRegFileFull creates a RegFile from the minimum index to the maximum index; and mkRegFileWCF creates a RegFile from lo_index to hi_index for which the reads and the write are scheduled conflict-free. There is a second set of these modules, the RegFileLoad variants, which take as an argument a file containing the initial contents of the array.

mkRegFile	Create a RegFile with registers allocated from lo_index to hi_index. lo_index and hi_index are of the index_t datatype and the elements are of the data_t datatype.		
	<pre>module mkRegFile#(index_t lo_index, index_t hi_index)</pre>		
mkRegFileFull	Create a RegFile from min to max index where the index is of a datatype index_t and the elements are of datatype data_t. The min and max are specified by the Bounded typeclass instance (0 to N-1 for N-bit numbers).		
	<pre>module mkRegFileFull#(RegFile#(index_t, data_t)) provisos (Bits#(index_t, size_index),</pre>		
mkRegFileWCF	Create a RegFile from lo_index to hi_index for which the reads and the write are scheduled conflict-free. For the implications of this scheduling, see the documentation for ConfigReg (Section C.1.2).		
	<pre>module mkRegFileWCF#(index_t lo_index, index_t hi_index)</pre>		

The RegFileLoad variants provide the same functionality as RegFile, but each constructor function takes an additional file name argument. The file contains the initial contents of the array using the Verilog hex memory file syntax, which allows white spaces (including new lines, tabs, underscores, and form-feeds), comments, binary and hexadecimal numbers. Length and base format must not be specified for the numbers.

```
mkRegFileLoad

Create a RegFile using the file to provide the initial contents of the array.

module mkRegFileLoad#

( String file, index_t lo_index, index_t hi_index)

( RegFile#(index_t, data_t) )

provisos (Bits#(index_t, size_index),

Bits#(data_t, size_data));
```

mkRegFileFullLoad

Create a RegFile from min to max index using the file to provide the initial contents of the array. The min and max are specified by the Bounded typeclass instance (0 to N-1 for N-bit numbers).

mkRegFileWCFLoad

Create a RegFile from lo_index to hi_index for which the reads and the write are scheduled conflict-free (see Section C.1.2), using the file to provide the initial contents of the array.

Examples

Use mkRegFileLoad to create Register files and then read the values.

```
Reg#(Cntr) count <- mkReg(0);

// Create Register files to use as inputs in a testbench
RegFile#(Cntr, Fp64) vecA <- mkRegFileLoad("vec.a.txt", 0, 9);
RegFile#(Cntr, Fp64) vecB <- mkRegFileLoad("vec.b.txt", 0, 9);

//read the values from the Register files
rule drivein (count < 10);
    Fp64 a = vecA.sub(count);
    Fp64 b = vecB.sub(count);
    uut.start(a, b);
    count <= count + 1;
endrule</pre>
```

Verilog Modules

RegFile modules correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Name	Defined in File
mkRegFile	RegFile	RegFile.v
mkRegFileFull		
mkRegFileWCF		
mkRegFileLoad	RegFileLoad	RegFileLoad.v
mkRegFileFullLoad		
mkRegFileWCFLoad		

C.1.2 ConfigReg

Package

```
import ConfigReg :: *;
```

Description

The ConfigReg package provides a way to create registers where each update clobbers the current value, but the precise timing of updates is not important. These registers are identical to the mkReg registers except that their scheduling annotations allows reads and writes to occur in either order during rule execution.

Rules which fire during the clock cycle where the register is written read a stale value (that is the value from the beginning of the clock cycle) regardless of firing order and writes which have occurred during the clock cycle. Thus if rule r1 writes to a ConfigReg cr and rule r2 reads cr later in the same cycle, the old or stale value of cr is read, not the value written in r1. If a standard register is used instead, rule r2's execution will be blocked by r1's execution or the scheduler may create a different rule execution order.

The hardware implementation is identical for the more common registers (mkReg, mkRegU and mkRegA), and the module constructors parallel these as well.

Interfaces

```
The ConfigReg interface is an alias of the Reg interface (section B.4.1). typedef Reg#(a_type) ConfigReg #(type a_type);
```

Modules

The ConfigReg package provides three modules; mkConfigReg creates a register with a given reset value and synchronous reset logic, mkConfigRegU creates a register without any reset, and mkConfigRegA creates a register with a given reset value and asynchronous reset logic.

mkConfigReg	Make a register with a given reset value. Reset logic is synchronous module mkConfigReg#(a_type resetval)(Reg#(a_type)) provisos (Bits#(a_type, sizea));
mkConfigRegU	Make a register without any reset; initial simulation value is alternating 01 bits. module mkConfigRegU(Reg#(a_type)) provisos (Bits#(a_type, sizea));

mkConfigRegA	Make a register with a given reset value. Reset logic is asynchronous.
	<pre>module mkConfigRegA#(a_type, resetval)(Reg#(a_type)) provisos (Bits#(a_type, sizea));</pre>

Scheduling Annotations				
mkConfigReg, mkConfigRegU, mkConfigRegA				
	read write			
read	CF	CF		
write	CF	SBR		

C.1.3 DReg

Package

import DReg :: * ;

Description

The DReg package allows a designer to create registers which store a written value for only a single clock cycle. The value written to a DReg is available to read one cycle after the write. If more than one cycle has passed since the register has been written however, the value provided by the register is instead a default value (that is specified during module instantiation). These registers are useful when wanting to send pulse values that are only asserted for a single clock cycle. The DReg is the register equivalent of a DWire B.4.5.

Modules

The DReg package provides three modules; mkDReg creates a register with a given reset/default value and synchronous reset logic, mkDRegU creates a register without any reset (but which still takes a default value as an argument), and mkDRegA creates a register with a given reset/default value and asynchronous reset logic.

	Ţ		
mkDReg	Make a register with a given reset/default value. Reset logic is synchronous		
	<pre>module mkDReg#(a_type dflt_rst_val)(Reg#(a_type)) provisos (Bits#(a_type, sizea));</pre>		
mkDRegU	Make a register without any reset but with a specified default; initial simulation value is alternating 01 bits.		
	<pre>module mkDRegU#(a_type dflt_val)(Reg#(a_type)) provisos (Bits#(a_type, sizea));</pre>		
mkDRegA	Make a register with a given reset/default value. Reset logic is asynchronous.		
	<pre>module mkDRegA#(a_type, dflt_rst_val)(Reg#(a_type)) provisos (Bits#(a_type, sizea));</pre>		

Scheduling Annotations			
mkDReg, mkDRegU, mkDRegA			
	read	write	
read	CF	SB	
write	SA	SBR	

C.1.4 RevertingVirtualReg

Package

```
import RevertingVirtualReg :: *;
```

Description

The RevertingVirtualReg package allows a designer to force a schedule when scheduling attributes cannot be used. Since scheduling attributes cannot be put on methods, this allows a designer to control the schedule between two methods, or between a method and a rule by adding a virtual register between the two. The module RevertingVirtualReg creates a virtual register; no actual state elements are generated.

Modules

The RevertingVirtualReg package provides the module mkRevertingVirtualReg. The properties of the module are:

- it schedules exactly like an ordinary register;
- it reverts to its reset value at the end of each clock cycle.

These imply that all allowed reads will return the reset value (since they precede any writes in the cycle); thus the module neither needs nor instantiates any actual state element.

mkRevertingVirtualReg	Creates a virtual register reverting to the reset value at the end of each clock cycle.
	<pre>module mkRevertingVirtualReg#(a_type rst)(Reg#(a_type)) provisos (Bits#(a_type, sizea));</pre>

Scheduling Annotations				
mkRevertingVirtualReg				
read write				
read	CF	SB		
write	SA	SBR		

Example Use mkRevertingVirtualReg to create the execution order of the_rule followed by the_method

```
Reg#(Bool) virtualReg <- mkRevertingVirtualReg(True);
rule the_rule (virtualReg); // reads virtualReg
...
endrule</pre>
```

```
method Action the_method;
  virtualReg <= False;  // writes virtualReg
  ...
endmethod</pre>
```

In a given cycle, reads always precede writes for a register. Therefore the reading of virtualReg by the_rule will precede the writing of virtualReg in the_method. The execution order will be the_rule followed by the_method.

C.1.5 BRAM

Package

```
import BRAM :: *;
```

Description

The BRAM package provides types, interfaces, and modules to support FPGA BlockRams. The BRAM modules include FIFO wrappers to provide implicit conditions for proper flow control for the BRAM latency. Specific tools may determine whether modules are mapped to appropriate BRAM cells during synthesis.

The BRAM package is open-sourced and can be modified by the user. The low-level wrappers to the BRAM Verilog and Bluesim modules, which are not open-sourced and cannot be modified, are provided in the BRAMCore package, Section C.1.6.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Types and type classes

BRAM_Configure The BRAM_Configure structure specifies the underlying modules and their attributes for instantiation. Default values for the BRAM are defined with the DefaultValue instance and can easily be modified.

	BRAM_Configure Structure				
Field	Type	Description	Allowed or		
			Recommended Values		
memorySize	Integer	Number of words in the BRAM			
latency	Integer	Number of stages in the read	1 (address is registered)		
			2 (address and data are		
			registered)		
loadFormat	LoadFormat	Describes the load file	None		
			tagged Hex $filename$		
			$oxed{tagged}$ Binary $\mathit{filename}$		
outFIFODepth	Integer	The depth of the BypassFIFO af-	latency+2		
		ter the BRAM for the BRAMServer			
		module			
allowWriteResponseBypass					
	Bool	Determines if write responses can di-			
		rectly be enqueued in the output fifo			
		(latency = 0 for write).			

The size of the BRAM is determined by the memorySize field given in number of words. The width of a word is determined by the polymorphic type data specified in the BRAM interface. If the memorySize field is 0, then memory size $= 2^n$, where n is the number of address bits determined from the address type.

The latency field has two valid values; 1 indicates that the address on the read is registered, 2 indicates that both the address on the read input and the data on the read output are registered. When latency = 2, the components in the dotted box in Figure 3 are included.

The outFIFODepth is used to determine the depth of the Bypass FIFO after the BRAM in the mkBRAMServer module. This value should be latency + 2 to allow full pipeline behavior.

The allowWriteResponseBypass field, when True, specifies that the write response is issued on the same cycle as the write request. If False, the write reponse is pipelined, which is the same behavior as the read request. When True, the schedule constraints between put and get are put SBR get. Otherwise, the annotation is get CF put (no constraint).

The LoadFormat defines the type of the load file (None, Hex or Binary). The type None is used when there is no load file. When the type is Hex or Binary, the name of the load file is provided as a String.

The default values are defined in this package using the DefaultValue instance for BRAM_Configure. You can modify the default values by changing this instance or by modifying specific fields in your design.

Values defined in defaultValue					
Field Type Value Meaning			Meaning		
memorySize	Integer	0	2^n , where n is the number of address		
			bits		
latency	Integer	1	address is registered		
outFIFODepth	Integer	3	latency + 2		
loadFormat	LoadFormat	None	no load file is used		
allowWriteResponseBypass	Bool	False	the write response is pipelined		

To modify a default configuration for your design, set the field you want to change to the new value. Example:

BRAMRequest The BRAM package defines 2 structures for a BRAM request: BRAMRequest, and the byte enabled version BRAMRequestBE.

BRAMRequest Structure			
Field	Type	Description	
write	Bool	ool Indicates whether this operation is a write (True) or	
		a read (False).	
responseOnWrite	Bool	Indicates whether a response should be received from	
		this write command	
address	addr	Word address of the read or write	
datain	data	Data to be written. This field is ignored for reads.	

BRAMRequestBE The structure BRAMRequestBE allows for the byte enable signal.

BRAMRequestBE Structure				
Field	Type Description			
writeen	Bit#(n)	Byte-enable indicating whether this operation is a		
		write $(n != 0)$ or a read $(n = 0)$.		
responseOnWrite	Bool	ol Indicates whether a response should be received from		
		this write command		
address	addr	Word address of the read or write		
datain	data	Data to be written. This field is ignored for reads.		

Interfaces and Methods

The interfaces for the BRAM are built on the Server interface defined in the ClientServer package, Section C.7.3. Some type aliases specific to the BRAM are defined here.

BRAM Server and Client interface types :

```
typedef Server#(BRAMRequest#(addr, data), data) BRAMServer#(type addr, type data);
typedef Client#(BRAMRequest#(addr, data), data) BRAMClient#(type addr, type data);
```

Byte-enabled BRAM Server and Client interface types:

The BRAM package defines 1 and 2 port interfaces, with write-enabled and byte-enabled versions. Each BRAM port interface contains a BRAMServer#(addr, data) subinterface and a clear action, which clears the output FIFO of any pending requests. The data in the BRAM is not cleared.

	BRAM1Port Interface				
	1 Port BRAM Interface				
Name	Type		Description		
portA	BRAMServer#(addr,	data)	Server subinterface		
portAClear	Action		Method to clear the portA output FIFO		

```
interface BRAM1Port#(type addr, type data);
  interface BRAMServer#(addr, data) portA;
  method Action portAClear;
endinterface: BRAM1Port
```

	BRAM1PortBE Interface				
Byte enabled 1 port BRAM Interface					
Name	e Type Description				
portA BRAMServerBE#(addr, data, n)		Byte-enabled server subinterface			
portAClear	Action	Method to clear the portA output FIFO			

```
interface BRAM1PortBE#(type addr, type data, numeric type n);
  interface BRAMServerBE#(addr, data, n) portA;
  method Action portAClear;
endinterface: BRAM1PortBE
```

BRAM2Port Interface					
	2 port BRAM Interface				
Name	Type	Description			
portA	BRAMServer#(addr, data)	Server subinterface for port A			
portB	BRAMServer#(addr, data)	Server subinterface for port B			
portAClear	Action	Method to clear the port A output FIFO			
portBClear	Action	Method to clear the port B output FIFO			

```
interface BRAM2Port#(type addr, type data);
  interface BRAMServer#(addr, data) portA;
  interface BRAMServer#(addr, data) portB;
  method Action portAClear;
  method Action portBClear;
endinterface: BRAM2Port
```

	BRAM2PortBE Interface				
	Byte enabled 2 port BRAM Interface				
Name	Type	Description			
portA	BRAMServerBE#(addr, data, n)	Byte-enabled server subinterface for port A			
portB	BRAMServerBE#(addr, data, n)	Byte-enabled server subinterface for port B			
portAClear	Action	Method to clear the portA output FIFO			
portBClear	Action	Method to clear the portB output FIFO			

```
interface BRAM2PortBE#(type addr, type data, numeric type n);
  interface BRAMServerBE#(addr, data, n) portA;
  interface BRAMServerBE#(addr, data, n) portB;
  method Action portAClear;
  method Action portBClear;
endinterface: BRAM2PortBE
```

Modules

The BRAM modules defined in the BRAMCore package (Section C.1.6) are wrapped with control logic to turn the BRAM into a server, as shown in Figure 3. The BRAM Server modules include an output FIFO and logic to control its loading and to avoid overflow. A single port, single clock byte-enabled version is provided as well as 2 port and dual clock write-enabled versions.




Figure 3: 1 port of a BRAM Server

mkBRAM1Server	BRAM Server module including an output FIFO and logic to control loading and to avoid overflow.	

Example: Using a BRAM

```
import BRAM::*;
import StmtFSM::*;
import Clocks::*;
function BRAMRequest#(Bit#(8), Bit#(8)) makeRequest(Bool write, Bit#(8) addr, Bit#(8) data);
  return BRAMRequest{
                       write: write,
                      responseOnWrite:False,
                      address: addr,
                      datain: data
                      };
endfunction
(* synthesize *)
module sysBRAMTest();
    BRAM_Configure cfg = defaultValue;
    cfg.allowWriteResponseBypass = False;
    BRAM2Port#(Bit#(8), Bit#(8)) dut0 <- mkBRAM2Server(cfg);</pre>
    cfg.loadFormat = tagged Hex "bram2.txt";
    BRAM2Port#(Bit#(8), Bit#(8)) dut1 <- mkBRAM2Server(cfg);</pre>
   //Define StmtFSM to run tests
   Stmt test =
   (seq
       delay(10);
       . . .
       action
          dut1.portA.request.put(makeRequest(False, 8'h02, 0));
          dut1.portB.request.put(makeRequest(False, 8'h03, 0));
       endaction
       action
          $display("dut1read[0] = %x", dut1.portA.response.get);
          $display("dut1read[1] = %x", dut1.portB.response.get);
       endaction
       delay(100);
    endseq);
```

```
mkAutoFSM(test);
endmodule
```

C.1.6 BRAMCore

Package

```
import BRAMCore :: * ;
```

Description

The BRAMCore package, along with the BRAM package (Section C.1.5) provides types, interfaces, and modules to support FPGA BlockRAMS. Specific tools may determine whether modules are mapped to appropriate BRAM cells during synthesis.

Most designs should use the the BRAM package instead of BRAMCore, as the BRAM package provides implicit conditions provided by FIFO wrappers. The BRAMCore package should be used only if you want the low-level core BRAM modules without implicit conditions.

The BRAMCore package contains the low-level wrappers to the BRAM Verilog and Bluesim modules. Components are provided for single and dual port, byte-enabled, loadable, and dual clock versions.

Interfaces and Methods

The BRAMCore package defines four variations of a BRAM interface to support single and dual port BRAMs, as well as byte-enabled BRAMs.

The BRAM_PORT interface declares two methods; an Action method put, and a value method read.

The BRAM_DUAL_PORT interface is defined as two BRAM_PORT subinterfaces, one for each port.

	BRAM_PORT Interface				
Method			Arguments		
Name	Type	Description	Name Description		
put	Action	Read or write values	write	Write enable for the port; if True the ac-	
		in the BRAM.		tion is write, if False, the action is read.	
			address	Index of the element, with a datatype of	
				addr.	
			datain	Value to be written, with a datatype of	
				data. This value is ignored if the action	
				is read.	
read	data	Returns a value of			
		type data.			

```
interface BRAM_PORT#(type addr, type data);
  method Action put(Bool write, addr address, data datain);
  method data    read();
endinterface: BRAM_PORT

interface BRAM_DUAL_PORT#(type addr, type data);
  interface BRAM_PORT#(addr, data) a;
  interface BRAM_PORT#(addr, data) b;
endinterface
```

Byte-enabled Interfaces

The BRAM_PORT_BE and BRAM_DUAL_PORT_BE interfaces are the byte-enabled versions of the BRAM interfaces. In this version, the argument writen is of type Bit#(n), where n is the number of byte-enables. Your synthesis tools and targeted technology determine the restriction of data size and byte enable size. If n = 0, the action is a read.

The BRAM DUAL POR	C BE interface	e is defined as two	BRAM PORT BE	subinterfaces.	one for each port.
-------------------	----------------	---------------------	--------------	----------------	--------------------

	BRAM_PORT_BE Interface				
Method			Arguments		
Name	Type	Description	Name Description		
put	Action	Read or write values	writeen	Byte-enable for the port; if n != 0 write	
		in the BRAM.		the specified bytes, if $n = 0$ read.	
			address Index of the elements to be read or writ		
				ten, with a datatype of addr.	
			datain	Value to be written, with a datatype of	
				data. This value is ignored if the action	
				is read.	
read	data	Returns a value of			
		type data.			

```
(* always_ready *)
interface BRAM_PORT_BE#(type addr, type data, numeric type n);
  method Action put(Bit#(n) writeen, addr address, data datain);
  method data read();
endinterface: BRAM_PORT_BE

interface BRAM_DUAL_PORT_BE#(type addr, type data, numeric type n);
  interface BRAM_PORT_BE#(addr, data, n) a;
  interface BRAM_PORT_BE#(addr, data, n) b;
endinterface
```

Modules

The BRAMCore package provides 1 and 2 port BRAM core modules, in both write-enabled and byte-enabled versions. Note that there are no implicit conditions on the methods of these modules; if these are required consider using the modules in the BRAM package (Section C.1.5).

The BRAMCore package requires the caller to ensure the correct cycle to capture the read data, as determined by the hasOutputRegister flag. If hasOutputRegister is True, both the read address and the read data are registered; if False, only the read address is registered.

- If the output is registered (hasOutputRegister is True), the latency is 2; the read data is available 2 cycles after the request.
- If the output is not registered (hasOutputRegister is False), the latency is 1; the read data is available 1 cycle after the request.

The other argument required is memSize, an Integer specifying the memory size in number of words of type data.

The loadable BRAM modules require two additional arguments:

- file is a String containing the name of the load file.
- binary is a Bool indicating whether the data type of the load file is binary (True) or hex (False).

mkBRAMCore1	Single port BRAM
	<pre>module mkBRAMCore1#(Integer memSize,</pre>

```
mkBRAMCore1BE

Byte-enabled, single port BRAM.

module mkBRAMCore1BE#(Integer memSize,
Bool hasOutputRegister)
(BRAM_PORT_BE#(addr, data, n))
provisos(Bits#(addr, addr_sz), Bits#(data, data_sz),
Div#(data_sz, n, chunk_sz),
Mul#(chunk_sz, n, data_sz));
```

```
Loadable, single port BRAM where the initial contents are in file.

The parameter binary indicates whether the contents of file are binary (True) or hex (False).

module mkBRAMCore1Load#(Integer memSize,

Bool hasOutputRegister,

String file, Bool binary)

(BRAM_PORT#(addr, data))

provisos(Bits#(addr, addr_sz), Bits#(data, data_sz));
```

```
mkBRAMCore1BELoad

Loadable, single port, byte-enabled BRAM.

module mkBRAMCore1BELoad#(Integer memSize,
Bool hasOutputRegister,
String file, Bool binary)
(BRAM_PORT_BE#(addr, data, n))
provisos(Bits#(addr, addr_sz), Bits#(data, data_sz),
Div#(data_sz, n, chunk_sz),
Mul#(chunk_sz, n, data_sz));
```

```
mkBRAMCore2

Dual port, single clock BRAM.

module mkBRAMCore2#(Integer memSize,
Bool hasOutputRegister)
(BRAM_DUAL_PORT#(addr, data))
provisos(Bits#(addr, addr_sz), Bits#(data, data_sz));
```

```
mkSyncBRAMCore2

Dual port, dual clock BRAM.

module mkSyncBRAMCore2#(Integer memSize,
Bool hasOutputRegister,
Clock clkA, Reset rstNA,
Clock clkB, Reset rstNB)
(BRAM_DUAL_PORT#(addr, data))
provisos(Bits#(addr, addr_sz),Bits#(data, data_sz));
```

```
Dual port, single clock, BRAM where the initial contents are in file.

The parameter binary indicates whether the contents of file are binary (True) or hex (False).

module mkBRAMCore2Load#(Integer memSize,
Bool hasOutputRegister,
String file, Bool binary)
(BRAM_DUAL_PORT#(addr, data))
provisos(Bits#(addr, addr_sz),Bits#(data, data_sz));
```

Dual port, single clock, byte-enabled BRAM where the initial contents are in file. The parameter binary indicates whether the contents of file are binary (True) or hex (False). module mkBRAMCore2BELoad#(Integer memSize, Bool hasOutputRegister, String file, Bool binary) (BRAM_DUAL_PORT_BE#(addr, data, n)) provisos(Bits#(addr, addr_sz), Bits#(data, data_sz), Div#(data_sz, n, chunk_sz), Mul#(chunk_sz, n, data_sz));

```
mkSyncBRAMCore2Load

Dual port, dual clock BRAM with initial contents in file.

module mkSyncBRAMCore2Load#(Integer memSize,
Bool hasOutputRegister,
Clock clkA, Reset rstNA,
Clock clkB, Reset rstNB,
String file, Bool binary)
(BRAM_DUAL_PORT#(addr, data))
provisos(Bits#(addr, addr_sz), Bits#(data, data_sz));
```

Verilog Modules

BRAM modules correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Names
mkBRAMCore1	BRAM1.v
mkBRAMCore1Load	BRAM1Load.v
mkBRAMCore1BE	BRAM1BE.v
mkBRAMCore1BELoad	BRAM1BELoad.v
mkBRAMCore2	BRAM2.v
mkSyncBRAMCore2	
mkBRAMCore2BE	BRAM2BE.v
mkSyncBRAMCore2BE	
mkBRAMCore2Load	BRAM2Load.v
mkSyncBRAMCore2Load	
mkBRAMCore2BELoad	BRAM2BELoad.v
mkSyncBRAMCore2BELoad	

C.2 FIFOs

C.2.1 FIFO Overview

The AzureIP Foundation library contains multiple FIFO packages. All library FIFO packages are supplied as compiled code. The FIFOs in the BRAMFIFO, SpecialFIFO, and AlignedFIFOs packages are also provided as BSV source code to facilate customization.

Package Name	Description	BSV Source provided	Section
FIFO	Defines the FIFO interface and module constructors. FI-		C.2.2
	FOs provided have implicit full and empty signals. Includes pipeline FIFO (mkLFIFO).		
FIFOF	Defines the FIFOF interface and module constructors. FI-		C.2.2
	FOs provided have explicit full and empty signals. Includes pipeline FIFOF (mkLFIFOF).		
FIFOLevel	Enhanced FIFO interfaces and modules which include		C.2.3
r ir OLevei	methods to indicate the level or current number of items		0.2.5
	stored in the FIFO. Single and dual clock versions are provided.		
BRAMFIFO	FIFOs which utilize the Xilinx Block RAMs.	$\sqrt{}$	C.2.4
SpecialFIFOs	Additional pipeline and bypass FIFOs	√	C.2.5
AlignedFIFOs	Parameterized FIFO module for creating synchronizing FI-FOs between clock domains with aligned edges.	V	C.2.6
Gearbox	FIFOs which change the frequency and data width of data across clock domains with aligned edges. The overall data rate stays the samme.	V	C.2.7
Clocks	Generalized FIFOs to synchronize data being sent across clock domains		C.9.7

C.2.2 FIFO and FIFOF packages

Packages

```
import FIFO :: * ;
import FIFOF :: * ;
```

Description

The FIFO package defines the FIFO interface and four module constructors. The FIFO package is for FIFOs with implicit full and empty signals.

The FIFOF package defines FIFOs with explicit full and empty signals. The standard version of FIFOF has FIFOs with the enq, deq and first methods guarded by the appropriate (notFull or notEmpty) implicit conditions for safety and improved scheduling. Unguarded (UG) versions of FIFOF are available for the rare cases when implicit conditions are not desired. Guarded (G) versions of FIFOF are available which allow more control over implicit conditions. With the guarded versions the user can specify whether the enqueue or dequeue side is guarded.

Interfaces and methods

The four common methods, enq, deq, first and clear are provided by both the FIFO and FIFOF interfaces.

FIFO methods				
Method		Argument		
Name	Type	Description	Name	Description
enq	Action	adds an entry to the FIFO	x1	variable to be added to the FIFO
				must be of type element_type
deq	Action	removes first entry from		
		the FIFO		
first	element_type	returns first entry		the entry returned is of ele-
				$ment_type$
clear	Action	clears all entries from the		
		FIFO		

```
interface FIFO #(type element_type);
  method Action enq(element_type x1);
  method Action deq();
  method element_type first();
  method Action clear();
endinterface: FIFO
```

FIFOF provides two additional methods, notFull and notEmpty.

	Additional FIFOF Methods		
Name	Type	Description	
notFull	Bool	returns a True value if there is space, you can enqueue an	
		entry into the FIFO	
notEmpty	Bool	returns a True value if there are elements the FIFO, you	
		can dequeue from the FIFO	

```
interface FIFOF #(type element_type);
  method Action enq(element_type x1);
  method Action deq();
  method element_type first();
  method Bool notFull();
  method Bool notEmpty();
  method Action clear();
endinterface: FIFOF
```

The FIFO and FIFOF interfaces belong to the ToGet and ToPut typeclasses. You can use the toGet and toPut functions to convert FIFO and FIFOF interfaces to Get and Put interfaces (Section C.7.1).

Modules

The FIFO and FIFOF interface types are provided by the module constructors: mkFIFO, mkFIFO1, mkSizedFIFO, mkDepthParamFIFO, and mkLFIFO. Each FIFO is safe with implicit conditions; they do not allow an enq when the FIFO is full or a deq or first when the FIFO is empty.

Most FIFOs do not allow simultaneous enqueue and dequeue operations when the FIFO is full or empty. The exceptions are pipeline and bypass FIFOs. A pipeline FIFO (provided as mklfifo in this package), allows simultaneous enqueue and dequeue operations when full. A bypass FIFO allows simultaneous enqueue and dequeue operations when empty. Additional pipeline and bypass FIFOs are provided in the SpecialFIFOs package (Section C.2.5). The FIFOs in the SpecialFIFOs package are provided as both compiled code and BSV source code, so they are customizable.

Allowed Simultaneous enq and deq			
by FIFO type			
	FII	FO Condition	-
FIFO type	empty	not empty	full
		not full	
mkFIFO			
mkFIFOF			
mkFIF01		NA	
mkFIF0F1			
mkLFIFO			
mkLFIFOF			
mkLFIF01		NA	
mkLFIF0F1			
Modules provided in SpecialFIFOs package C.2.5			
mkPipelineFIFO		NA	
mkPipelineFIFOF			
mkBypassFIFO		NA	
mkBypassFIFOF			
mkSizedBypassFIF0F			
mkBypassFIF0Level			

For creating a FIFOF interface (providing explicit notFull and notEmpty methods) use the "F" version of the module, for example use mkFIFOF instead of mkFIFO.

Module Name	BSV Module Declaration For all modules, width_any may be 0
FIFO or FIFOF of de	epth 2.
mkFIFO mkFIFOF	<pre>module mkFIFO (FIFO#(element_type)) provisos (Bits#(element_type, width_any));</pre>

FIFO or FIFOF of depth 1	
mkFIF01 mkFIF0F1	<pre>module mkFIF01(FIF0#(element_type)) provisos (Bits#(element_type, width_any));</pre>

FIFO or FIFOF of given depth n		
mkSizedFIF0 mkSizedFIF0F	<pre>module mkSizedFIFO(Integer n)(FIFO#(element_type)) provisos (Bits#(element_type, width_any));</pre>	

```
FIFO or FIFOF of given depth n where n is a Verilog parameter or computed from compile-time constants and Verilog parameters.

mkDepthParamFIFO
mkDepthParamFIFOF
mkDepthParam
```

Unguarded (UG) versions of FIF0F are available for the rare cases when implicit conditions are not desired. When using an unguarded FIFO, the implicit conditions for correct FIFO operations are NOT considered during rule and method processing, making it possible to enqueue when full and to dequeue when empty. These modules provide the FIF0F interface.

Unguarded FIFOF	of depth 2
mkUGFIF0F	<pre>module mkUGFIF0F (FIF0F#(element_type)) provisos (Bits#(element_type, width_any));</pre>

Unguarded FIF0F o	Unguarded FIF0F of depth 1		
mkUGFIF0F1	<pre>module mkUGFIF01(FIF0F#(element_type)) provisos (Bits#(element_type, width_any));</pre>		

Unguarded FIF0F of given depth n	
mkUGSizedFIF0F	<pre>module mkUGSizedFIF0F(Integer n)(FIF0F#(element_type)) provisos (Bits#(element_type, width_any));</pre>

```
Unguarded FIFO of given depth n where n is a Verilog parameter or computed from compile-time constants and Verilog parameters.

mkUGDepthParamFIFOF

module mkUGDepthParamFIFOF(UInt#(32) n)

(FIFOF#(element_type))

provisos (Bits#(element_type, width_any));
```

The guarded (G) versions of each of the FIF0Fs allow you to specify which implicit condition you want to guard. These modules takes two Boolean parameters; ugenq and ugdeq. Setting either parameter TRUE indicates the relevant methods (enq for ugenq, first and deq for ugdeq) are unguarded. If both are TRUE the FIF0F behaves the same as an unguarded FIF0F. If both are FALSE the behavior is the same as a regular FIF0F.

Guarded FIF0F of o	lepth 2.
mkGFIFOF	<pre>module mkGFIF0F (Bool ugenq, Bool ugdeq)(FIF0F#(element_type)) provisos (Bits#(element_type, width_any));</pre>

Guarded FIFOF of o	lepth 1
mkGFIF0F1	<pre>module mkGFIF0F1(Bool ugenq, Bool ugdeq)(FIF0F#(element_type)) provisos (Bits#(element_type, width_any));</pre>

Guarded FIF0F of g	given depth n
mkGSizedFIFOF	<pre>module mkGSizedFIF0F(Bool ugenq, Bool ugdeq, Integer n)</pre>

```
Guarded FIFOF of given depth n where n is a Verilog parameter or computed from compile-time constants and Verilog parameters.

mkGDepthParamFIFOF

(Bool ugenq, Bool ugdeq, UInt#(32) n)

(FIFOF#(element_type))

provisos (Bits#(element_type, width_any));
```

The LFIFOs (pipeline FIFOs) allow enq and deq in the same clock cycle when the FIFO is full. Additional BSV versions of the pipeline FIFO and also bypass FIFOs (allowing simultaneous enq and deq when the FIFO is empty) are provided in the SpecialFIFOs package (Section C.2.5). Both unguarded and guarded versions of the LFIFO are provided in the FIFOF package.

Pipeline FIFO of depth 1. deq and enq can be simultaneously applied in the same clock					
cycle when the	cycle when the FIFO is full.				
mkLFIFO mkLFIFOF mkUGLFIFOF	<pre>module mkLFIFO (FIFO#(element_type)) provisos (Bits#(element_type, width_any));</pre>				

Guarded pipeline FIFOF of depth 1. deq and enq can be simultaneously applied in the same clock cycle when the FIFOF is full.		
mkGLFIFOF	<pre>module mkGLFIFOF (Bool ugenq, Bool ugdeq)(FIFOF#(element_type)) provisos (Bits#(element_type, width_any));</pre>	

Functions

The FIFO package provides a function fifofToFifo to convert an interface of type FIFOF to an interface of type FIFO.

```
Converts a FIFOF interface to a FIFO interface.

fifofToFifo function FIFO#(a) fifofToFifo (FIFOF#(a) f);
```

Example using the FIFO package

This example creates 2 input FIFOs and moves data from the input FIFOs to the output FIFOs.

```
import FIF0::*;
typedef Bit#(24) DataT;
// define a single interface into our example block
interface BlockIFC;
   method Action push1 (DataT a);
   method Action push2 (DataT a);
   method ActionValue#(DataT) get();
endinterface
module mkBlock1( BlockIFC );
   Integer fifo_depth = 16;
   // create the first inbound FIFO instance
   FIFO#(DataT) inbound1 <- mkSizedFIFO(fifo_depth);</pre>
   // create the second inbound FIFO instance
   FIFO#(DataT) inbound2 <- mkSizedFIFO(fifo_depth);</pre>
   // create the outbound instance
   FIFO#(DataT) outbound <- mkSizedFIFO(fifo_depth);</pre>
   // rule for enqueue of outbound from inbound1
   // implicit conditions ensure correct behavior
   rule enq1 (True);
      DataT in_data = inbound1.first;
      DataT out_data = in_data;
      outbound.enq(out_data);
      inbound1.deq;
   endrule: enq1
   // rule for enqueue of outbound from inbound2
   // implicit conditions ensure correct behavior
   rule enq2 (True);
      DataT in_data = inbound2.first;
      DataT out_data = in_data;
      outbound.enq(out_data);
      inbound2.deq;
   endrule: enq2
   //Add an entry to the inbound1 FIFO
```

```
method Action push1 (DataT a);
    inbound1.enq(a);
endmethod

//Add an entry to the inbound2 FIFO
method Action push2 (DataT a);
    inbound2.enq(a);
endmethod

//Remove first value from outbound and return it
method ActionValue#(DataT) get();
    outbound.deq();
    return outbound.first();
endmethod
endmodule
```

Scheduling Annotations

Scheduling constraints describe how methods interact within the schedule. For example, a clear to a given FIFO must be sequenced after (SA) an enq to the same FIFO. That is, when both enq and clear execute in the same cycle, the resulting FIFO state is empty. For correct rule behavior the rule executing enq must be scheduled before the rule calling clear.

The table below lists the scheduling annotations for the FIFO modules mkFIFO, mkSizedFIFO, and mkFIFO1.

Scheduling Annotations					
mkFIFO, m	kSized	lFIFO,	mkFI	FO1	
enq first deq clear					
enq	С	CF	CF	SB	
first	CF	CF	SB	SB	
deq	CF	SA	С	SB	
clear	SA	SA	SA	SBR	

The table below lists the scheduling annotations for the pipeline FIFO module, mkLFIFO. The pipeline FIFO has a few more restrictions since there is a combinational path between the deq side and the enq side, thus restricting deq calls before enq.

Scheduling Annotations					
	$\operatorname{mkLFIFO}$				
enq first deq clear					
enq	С	SA	SAR	SB	
first SB CF SB SB					
deq SBR SA C SB					
clear	SA	SA	SA	SBR	

The FIFOF modules add the notFull and notEmpty methods. These methods have SB annotations with the Action methods that change FIFO state. These SB annotations model the atomic behavior of a FIFO, that is when enq, deq, or clear are called the state of notFull and notEmpty are changed. This is no different than the annotations on mkReg (which is read SB write), where actions are atomic and the execution module is one rule fires at a time. This does differ from a pure hardware module of a FIFO or register where the state does not change until the clock edge.

Scheduling Annotations mkFIFOF, mkSizedFIFOF, mkFIFOF1						
enq notFull first deq notEmpty clear						
enq	С	SA	CF	CF	SA	SB
notFull	SB	CF	CF	SB	CF	SB
first	CF	CF	CF	SB	CF	SB
deq	CF	SA	SA	С	SA	SB
notEmpty	SB	CF	CF	SB	CF	SB
clear	SA	SA	SA	SA	SA	SBR

Verilog Modules

 ${\tt FIFO and \ FIFOF \ modules \ correspond \ to \ the \ following \ Verilog \ modules, \ which \ are \ found \ in \ the \ Blue-spec \ Verilog \ library, $BLUESPECDIR/Verilog/.}$

BSV Module Name	Verilog Module Names		Comments
mkFIFO mkFIFOF mkUGFIFOF mkGFIFOF	FIF02.v	FIF020.v	
mkFIF01 mkFIF0F1 mkUGFIF0F1 mkGFIF0F1	FIF01.v	FIFO10.v	
mkSizedFIFO mkSizedFIFOF mkUGSizedFIFOF mkGSizedFIFOF	SizedFIFO.v FIF01.v FIF02.v	SizedFIF00.v FIF010.v FIF020.v	If the depth of the FIFO = 1, then FIF01.v and FIF010.v are used, if the depth = 2, then FIF02.v and FIF020.v are used.
mkDepthParamFIF0F mkUGDepthParamFIF0F mkGDepthParamFIF0F	SizedFIF0.v	SizedFIF00.v	
mkLFIFO mkLFIFOF mkUGLFIFOF mkGLFIFOF	FIFOL1.v	FIFOL10.v	

C.2.3 FIFOLevel

Package

import FIFOLevel :: * ;

Description

The BSV FIFOLevel library provides enhanced FIFO interfaces and modules which include methods to indicate the level or the current number of items stored in the FIFO. Both single clock and dual clock (separate clocks for the enqueue and dequeue sides) versions are included in this package.

Interfaces and methods

The FIFOLevelIfc interface defines methods to compare the current level to Integer constants for a single clock. The SyncFIFOLevelIfc defines the same methods for dual clocks; thus it provides methods for both the source (enqueue) and destination (dequeue) clock domains. Instead of methods to compare the levels, the FIFOCountIfc and SyncFIFOCountIfc define methods to return counts of the FIFO contents, for single clocks and dual clocks respectively.

Interface Name	Parameter name	Parameter Description	Requirements of modules implementing the ifc
FIFOLevelIfc	element_type	type of the elements stored in the FIF0	must be in Bits class
	fifoDepth	the depth of the FIFO	must be numeric type and >2
FIFOCountIfc	$element_type$	type of the elements stored in the FIF0	must be in Bits class
	fifoDepth	the depth of the FIFO	must be numeric type and >2
SyncFIF0LevelIfc	$element_type$	type of the elements stored in the FIFO	must be in Bits class
	fifoDepth	the depth of the FIFO	must be numeric type and must be a power of 2 and >=2
SyncFIF0CountIfc	$element_type$	type of the elements stored in the FIFO	must be in Bits class
	fifo Depth	the depth of the FIFO	must be numeric type and must be a power of 2 and >=2

In addition to common FIFO methods, the FIFOLevelIfc interface defines methods to compare the current level to Integer constants. See Section C.2.2 for details on enq, deq, first, clear, notFull, and notEmpty. Note that FIFOLevelIfc interface has a type parameter for the fifoDepth. This numeric type parameter is needed, since the width of the counter is dependent on the FIFO depth. The fifoDepth parameter must be > 2.

FIFOLevelIfc					
	Method			Argument	
Name	Type	Description	Name	Description	
isLessThan	Bool	Returns True if the depth of the FIFO is less than the Integer constant, c1.	c1	an Integer compile- time constant	
isGreaterThan	Bool	Returns True if the depth of the FIFO is greater than the Integer constant, c1.	c1	an Integer compile- time constant	

```
interface FIFOLevelIfc#( type element_type, numeric type fifoDepth );
  method Action enq( element_type x1 );
  method Action deq();
  method element_type first();
```

```
method Action clear();

method Bool notFull;
method Bool notEmpty;

method Bool isLessThan (Integer c1);
method Bool isGreaterThan(Integer c1);
endinterface
```

In addition to common FIFO methods, the FIFOCountIfc interface defines a method to return the current number of elements as an bit-vector. See Section C.2.2 for details on enq, deq, first, clear, notFull, and notEmpty. Note that the FIFOCountIfc interface has a type parameter for the fifoDepth. This numeric type parameter is needed, since the width of the counter is dependent on the FIFO depth. The fifoDepth parameter must be > 2.

	FIFOCountIfc				
	Method				
Name	Type	Description			
count	UInt#(TLog#(TAdd#(fifoDepth,1)))	Returns the number of items in the FIFO.			

```
interface FIFOCountIfc#( type element_type, numeric type fifoDepth) ;
  method Action enq ( element_type sendData ) ;
  method Action deq () ;
  method element_type first () ;

method Bool notFull ;
  method Bool notEmpty ;

method UInt#(TLog#(TAdd#(fifoDepth,1))) count;

method Action clear;
endinterface
```

The interfaces SyncFIFOLevelIfc and SyncFIFOCountIfc are dual clock versions of the FIFOLevelIfc and FIFOCountIfc. Methods are provided for both source and destination clock domains. The following table describes the dual clock notFull and notEmpty methods, as well as the dual clock clear methods, which are common to both interfaces. Note that the SyncFIFOLevelIfc and SyncFIFOCountIfc interfaces each have a type parameter for fifoDepth. This numeric type parameter is needed, since the width of the counter is dependent on the FIFO depth. The fifoDepth parameter must be a power of 2 and >= 2.

	Common Dual Clock Methods			
Name	Type	Description		
sNotFull	Bool	Returns True if the FIFO appears as not full from the		
		source side clock.		
sNotEmpty	Bool	Returns True if the FIFO appears as not empty from the		
		source side clock.		
dNotFull	Bool	Returns True if the FIFO appears as not full from the des-		
		tination side clock.		
dNotEmpty	Bool	Returns True if the FIFO appears as not empty from the		
		destination side clock.		
sClear	Action	Clears the FIFO from the source side.		
dClear	Action	Clears the FIFO from the destination side.		

In addition to common FIFO methods (Section C.2.2) and the common dual clock methods above, the SyncFIFOLevelIfc interface defines methods to compare the current level to Integer constants. Methods are provided for both the source (enqueue side) and destination (dequeue side) clock domains.

	SyncFIFOLevelIfc Methods				
Method			Argument		
Name	Type	Description	Name	Description	
sIsLessThan	Bool	Returns True if the depth of	c1	an Integer compile-	
		the FIFO, as appears on the		time constant	
		source side clock, is less than the			
		Integer constant, c1.			
sIsGreaterThan	Bool	Returns True if the depth of the	c1	an Integer compile-	
		FIFO, as it appears on the source		time constant.	
		side clock, is greater than the			
		Integer constant, c1.			
dIsLessThan	Bool	Returns True if the depth of the	c1	an Integer compile-	
		FIFO, as it appears on the desti-		time constant	
		nation side clock, is less than the			
		Integer constant, c1.			
dIsGreaterThan	Bool	Returns True if the depth of the	c1	an Integer compile-	
		FIFO, as appears on the destina-		time constant.	
		tion side clock, is greater than the			
		Integer constant, c1.			

```
interface SyncFIF0LevelIfc#( type element_type, numeric type fifoDepth );
  method Action enq ( element_type sendData ) ;
  method Action deq ();
  method element_type first () ;
  method Bool sNotFull ;
  method Bool sNotEmpty ;
  method Bool dNotFull ;
  method Bool dNotEmpty ;
  method Bool sIsLessThan
                            (Integer c1);
  method Bool sIsGreaterThan( Integer c1 );
  method Bool dIsLessThan
                            (Integer c1);
  method Bool dIsGreaterThan( Integer c1 );
  method Action sClear;
  method Action dClear;
endinterface
```

In addition to common FIFO methods (Section C.2.2) and the common dual clock methods above, the SyncFIFOCountIfc interface defines methods to return the current number of elements. Methods are provided for both the source (enqueue side) and destination (dequeue side) clock domains.

	SyncFIFOCountIfc				
	Method				
Name	me Type Description				
sCount	UInt#(TLog#(TAdd#(fifoDepth,1)))	Returns the number of items in the FIFO			
		from the source side.			
dCount	UInt#(TLog#(TAdd#(fifoDepth,1)))	Returns the number of items in the FIFO			
		from the destination side.			

```
interface SyncFIFOCountIfc#( type element_type, numeric type fifoDepth) ;
  method Action enq ( element_type sendData ) ;
  method Action deq () ;
  method element_type first () ;

method Bool sNotFull ;
  method Bool sNotEmpty ;
  method Bool dNotFull ;
  method Bool dNotEmpty ;

method UInt#(TLog#(TAdd#(fifoDepth,1))) sCount;
  method UInt#(TLog#(TAdd#(fifoDepth,1))) dCount;

method Action sClear;
  method Action dClear;
endinterface
```

The FIFOLevelIFC, SyncFIFOLevelIfc, FIFOCountIfc, and SyncFIFOCountIfc interfaces belong to the ToGet and ToPut typeclasses. You can use the toGet and toPut functions to convert these interfaces to Get and Put interfaces (Section C.7.1).

Modules

The module mkFIFOLevel provides the FIFOLevelIfc interface. Note that the implementation allows any number of isLessThan and isGreaterThan method calls. Each call with a unique argument adds an additional comparator to the design.

There is also available a guarded (G) version of FIFOLevel which takes three Boolean parameters; ugenq, ugdeq, and ugcount. Setting any of the parameters to TRUE indicates the method (enq for ugenq, deq for ugdeq, and isLessThan, isGreaterThan for ugcount) is unguarded. If all three are FALSE the behavior is the same as a regular FIFOLevel.

Module Name	BSV Module Declaration
mkFIFOLevel	<pre>module mkFIF0Level (</pre>

Module Name	BSV Module Declaration
mkGFIFOLevel	<pre>module mkGFIF0Level#(Bool ugenq, Bool ugdeq, Bool ugcount)</pre>

The module mkFIFOCount provides the interface FIFOCountIfc. There is also available a guarded (G) version of FIFOCount which takes three Boolean parameters; ugenq, ugdeq, and ugcount. Setting any of the parameters to TRUE indicates the method (enq for ugenq, deq for ugdeq, and count for ugcount) is unguarded. If all three are FALSE the behavior is the same as a regular FIFOCount.

Module Name	BSV Module Declaration
mkFIF0Count	<pre>module mkFIFOCount(</pre>
	Comment: width_element may be 0

Module Name	BSV Module Declaration
mkGFIFOCount	<pre>module mkGFIFOCount#(Bool ugenq, Bool ugdeq, Bool ugcount)</pre>

The modules mkSyncFIFOLevel and mkSyncFIFOCount are dual clock FIFOs, where enqueue and dequeue methods are in separate clocks domains, sClkIn and dClkIn respectively. Because of the synchronization latency, the flag indicators will not necessarily be identical between the source and the destination clocks. Note however, that the sNotFull and dNotEmpty flags always give proper (pessimistic) indications for the safe use of enq and deq methods; these are automatically included as implicit condition in the enq and deq (and first) methods.

The module mkSyncFIFOLevel provides the SyncFIFOLevelIfc interface.

Module Name	BSV Module Declaration
mkSyncFIF0Level	<pre>module mkSyncFIFOLevel(</pre>
	Comment: width_element may be 0

The module mkSyncFIFOCount, as shown in Figure 4 provides the SyncFIFOCountIfc interface. Because of the synchronization latency, the count reports may be different between the source and the destination clocks. Note however, that the sCount and dCount reports give pessimistic values with the appropriate side. That is, the count sCount (on the enqueue clock) will report the exact count of items in the FIFO or a larger count. The larger number is due to the synchronization delay in observing the dequeue action. Likewise, the dCount (on the dequeue clock) returns the exact count or a smaller count. The maximum disparity between sCount and dCount depends on the difference in clock periods between the source and destination clocks.

The module provides sclear and dclear methods, both of which cause the contents of the FIFO to be removed. Since the clears must be synchronized and acknowledged from one domain to the other, there is a non-trivial delay before the FIFO recovers from the clear and can accept additional enqueues or dequeues (depending on which side is cleared). The calling of either method immediately disables other activity in the calling domain. That is, calling sclear in cycle n causes the enqueue to become unready in the next cycle, n+1. Likewise, calling dclear in cycle n causes the dequeue to become unready in the next cycle, n+1.




Figure 4: SyncFIFOCount

After the sClear method is called, the FIFO appears empty on the dequeue side after three dClock edges. Three sClock edges later, the FIFO returns to a state where new items can be enqueued. The latency is due to the full handshaking synchronization required to send the clear signal to dClock and receive the acknowledgement back.

For the dClear method call, the enqueue side is cleared in three sClkIn edges and items can be enqueued at the fourth edge. All items enqueued at or before the clear are removed from the FIFO.

Note that there is a ready signal associated with both sClear and dClear methods to ensure that the clear is properly sent between the clock domains. Also, sRstIn must be synchronized with the sClkIn.

Module Name	BSV Module Declaration
mkSyncFIF0Count	<pre>module mkSyncFIFOCount(</pre>
	Comment: width_element may be 0

Example

The following example shows the use of SyncFIFOLevel as a way to collect data into a FIFO, and then send it out in a burst mode. The portion of the design shown, waits until the FIFO is almost full, and then sets a register, burstOut which indicates that the FIFO should dequeue. When the FIFO is almost empty, the flag is cleared, and FIFO fills again.

```
// Define a fifo of Int(#23) with 128 entries
SyncFIFOLevelIfc#(Int#(23),128) fifo <- mkSyncFIFOLevel(sclk, rst, dclk );</pre>
// Define some constants
let sFifoAlmostFull = fifo.sIsGreaterThan( 120 ) ;
let dFifoAlmostFull = fifo.dIsGreaterThan( 120 );
let dFifoAlmostEmpty = fifo.dIsLessThan( 12 );
// a register to indicate a burst mode
Reg#(Bool) burstOut <- mkReg( False, clocked_by (dclk)) ;</pre>
// Set and clear the burst mode depending on fifo status
rule timeToDeque( dFifoAlmostFull && ! burstOut ) ;
   burstOut <= True ;</pre>
endrule
rule moveData ( burstOut ) ;
   let dataToSend = fifo.first ;
   fifo.deq;
   burstOut <= !dFifoAlmostEmpty;</pre>
endrule
```

Scheduling Annotations

Scheduling constraints describe how methods interact within the schedule. The annotations for mkFIFOLevel and mkSyncFIFOLevel are the same, except that methods in different domains (source and destination) are always conflict free.

Scheduling Annotations mkFIF0Level, mkSyncFIF0Level								
	enq first deq clear notFull notEmpty isLessThan isGreaterThan							
enq	C	CF	CF	SB	SA	SA	SA	SA
first	CF	CF	SB	SB	CF	CF	CF	CF
deq	CF	SA	С	SB	SA	SA	SA	SA
clear	SA	SA	SA	SBR	SA	SA	SA	SA
notFull	SB	CF	SB	SB	CF	CF	CF	CF
notEmpty	SB	CF	SB	SB	CF	CF	CF	CF
isLessThan	SB	CF	SB	SB	CF	CF	CF	CF
isGreaterThan	SB	CF	SB	SB	CF	CF	CF	CF

The annotations for mkFIFOCount and mkSyncFIFOCount are the same, except that methods in different domains (source and destination) are always conflict free.

Scheduling Annotations								
	mkFIFOCount, mkSyncFIFOCount							
	enq	enq first deq clear notFull notEmpty count						
enq	С	CF	CF	SB	SA	SA	SA	
first	CF	CF	SB	SB	CF	CF	CF	
deq	CF	SA	С	SB	SA	SA	SA	
clear	SA	SA	SA	SBR	SA	SA	SA	
notFull	SB	CF	SB	SB	CF	CF	CF	
notEmpty	SB	CF	SB	SB	CF	CF	CF	
count	SB	CF	SB	SB	CF	CF	CF	

Verilog Modules

The modules described in this section correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Names		
mkFIF0Level mkFIF0Count	SizedFIF0.v SizedFIF00.v		
mkSyncFIF0Level mkSyncFIF0Count	SyncFIF0Level.v		

C.2.4 BRAMFIFO

Package

import BRAMFIFO :: * ;

Description

The BRAMFIFO package provides FIFO interfaces and are built around a BRAM memory. The BRAM is provided in the BRAMCore package described in Section C.1.6.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Interfaces

The BRAMFIFO package provides FIFOF, FIFO, and SyncFIFOIfc interfaces, as defined in the FIFOF, FIFO, (both in Section C.2.2) and Clocks (Section C.9.7) packages.

Modules

mkSizedBRAMFIF0F	Provides a FIF0F interface of a given depth, n.			
	<pre>module mkSizedBRAMFIF0F#(Integer n) (FIF0F#(element_type)) provisos (Bits(element_type, width_any),</pre>			

mkSizedBRAMFIF0	Provides a FIFO interface of a given depth, n.				
	<pre>module mkSizedBRAMFIFO#(Integer n)(FIFO#(element_type)) provisos(Bits#(t, width_element), Add#(1, z, width_element));</pre>				
mkSyncBRAMFIF0	Provides a SyncFifOifc interface to send data across clock domains. The enq method is in the source sClkIn domain, while the deq and first methods are in the destination dClkIn domain. The input and output clocks, along with the input and output resets, are explicitly provided. The default clock and reset are ignored.				
	<pre>module mkSyncBRAMFIFO#(Integer depth,</pre>				
mkSyncBRAMFIFOToCC	Provides a SyncFIF0Ifc interface to send data from a second clock domain into the current clock domain. The output clock and reset are the current clock and reset.				
	<pre>module mkSyncBRAMFIFOToCC#(Integer depth,</pre>				
mkSyncBRAMFIF0FromCC	Provides a SyncFIFOIfc interface to send data from the current clock domain into a second clock domain. The input clock and reset are the current clock and reset.				
	<pre>module mkSyncBRAMFIF0FromCC#(Integer depth,</pre>				

C.2.5 SpecialFIFOs

Package

```
import SpecialFIFOs :: * ;
```

Description

The SpecialFIFOs package contains various FIFOs provided as BSV source code, allowing users to easily modify them to their own specifications. Included in the SpecialFIFOs package are pipeline

and bypass FIFOs. The pipeline FIFOs are equivalent to the mkLFIFO (Section C.2.2); they allow simultaneous enqueue and dequeue operations in the same clock cycle when *full*. The bypass FIFOs allow simultaneous enqueue and dequeue in the same clock cycle when *empty*. FIFOF versions, with explicit full and empty signals, are provided for both pipeline and bypass FIFOs. The package also includes the DFIFOF, a FIFOF with unguarded dequeue and first methods (thus they have no implicit conditions).

FIFOs in Special FIFOs package				
Module name	Interface	Description		
mkPipelineFIF0	FIFO	1 element pipeline FIFO; can enq and deq simultane-		
		ously when full.		
mkPipelineFIF0F	FIFOF	1 element pipeline FIFO with explicit full and empty		
		signals.		
mkBypassFIFO	FIFO	1 element bypass FIFO; can enq and deq simultane-		
		ously when empty.		
mkBypassFIF0F	FIFOF	1 element bypass FIFO with explicit full and empty		
		signals.		
mkSizedBypassFIF0F	FIFOF	Bypass FIFO of given depth, with explicit full and		
		empty signals.		
mkBypassFIFOLevel	FIFOLevelIfc	Same as a FIFOLevel (Section C.2.3), but can enq		
		and deq when empty.		
mkDFIFOF	FIFOF	A FIFOF with unguarded deq and first methods		
		where the first method returns specified default		
		value when the FIFO is empty.		

Allowed Simultaneous enq and deq				
by FIFO t	by FIFO type			
FIFO Condition				
FIFO type	empty	not empty	full	
		not full		
mkPipelineFIFO		NA		
mkPipelineFIFOF				
mkBypassFIF0		NA		
mkBypassFIFOF				
mkSizedBypassFIF0F				
mkBypassFIFOLevel				
mkDFIF0F				

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Interfaces and methods

The modules defined in the SpecialFIFOs package provide the FIFO, FIFOF, and FIFOLevelIfc interfaces, as shown in the table above. These interfaces are described in Section C.2.2 (FIFO package) and Section C.2.3 (FIFOLevel package).

Modules

Module Name 1-element pipeline FIFO	BSV Module Declaration D; can enq and deq simultaneously when full.		
mkPipelineFIF0	<pre>module mkPipelineFIFO (FIFO#(element_type)) provisos (Bits#(element_type, width_any));</pre>		

1-element pipeline FIFOF; can enq and deq simultaneously when full.		
Has explicit full and empty signals.		
mkPipelineFIFOF module mkPipelineFIFOF (FIFOF#(element_type)) provisos (Bits#(element_type, width_any));		

1-element bypass FIFO; can enq and deq simultaneously when empty.	
mkBypassFIF0	<pre>module mkBypassFIFO (FIFO#(element_type)) provisos (Bits#(element_type, width_any));</pre>

1-element bypass FIFOF; can enq and deq simultaneously when empty. Has explicit full and empty signals.		
mkBypassFIF0F module mkBypassFIF0F (FIF0F#(element_type)) provisos (Bits#(element_type, width_any));		

Bypass FIFOF of given depth fifoDepth with explicit full and empty signals.		
mkSizedBypassFIF0F	<pre>module mkSizedBypassFIFOF#(Integer fifoDepth)</pre>	

Bypass FIFOLevel of given depth fifoDepth		
mkBypassFIFOLevel	<pre>module mkBypassFIF0Level(FIF0LevelIfc#(element_type,</pre>	

A FIFOF with unguarded deq and first methods (thus they have no implicit conditions). The first method returns a specified default value when the FIFO is empty		
mkDFIF0F	<pre>module mkDFIF0F#(element_type default_value)</pre>	

C.2.6 AlignedFIFOs

Package

```
import AlignedFIFOs :: * ;
```

Description

The AlignedFIFOs package contains a parameterized FIFO module intended for creating synchronizing FIFOs between clock domains with aligned edges for both types of clock domain crossings:

- slow-to-fast crossing every edge in the source domain implies the existence of a simultaneous edge in the destination domain
- fast-to-slow crossing every edge in the destination domain implies the existence of a simultaneous edge in the source domain

The FIFO is parameterized on the type of store used to hold the FIFO data, which is itself parameterized on the index type, value type, and read latency. Modules to construct stores based on a single register, a vector of registers and a BRAM are provided, and the user can supply their own store implementation as well.

The FIFO allows the user to control whether or not outputs are held stable during the full slow clock cycle or allowed to transition mid-cycle. Holding the outputs stable is the safest option but it slightly increases the minimum latency through the FIFO.

A primary design goal of this FIFO is to provide an efficient and flexible family of synchronizing FIFOs between aligned clock domains which are written in BSV and are fully compatible with Bluesim. These FIFOs (particularly ones using vectors of registers) may not be the best choice for ASIC synthesis due to the muxing to select the head value in the first method.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Interfaces and methods

Store Interface The AlignedFIFO is parameterized on the type of store used to hold the FIFO data. The three types of stores provided in the AlignedFIFO package (single-element, vector-of-registers, and BRAM) all return a Store interface.

The Store interface has a prefetch method which is used by some modules (the mkBRAMStore in this package). If a prefetch is used, the read method returns the value at the previously fetched index; the value of idx should be ignored. If a prefetch is not used, the read method index value determines the returned value.

Store Interface Methods		
Name	Type	Description
write	Action	Writes the value at index idx.
prefetch	Action	Initiates a prefetch of the value at index idx.
read	a	Returns the value of type a. If prefetch is not used, returns the value at index idx. When prefetch is used, returns the value at the previously fetched index; the value of idx should be ignored.

```
interface Store#(type i, type a, numeric type n);
  method Action write(i idx, a value);
  method Action prefetch(i idx);
  method a read(i idx);
endinterface: Store
```

AlignedFIFO Interface The AlignedFIFO interface provides methods for both source (enqueue) and destination (dequeue) clock domains.

AlignedFIFO Interface Methods		
Name	Type	Description
enq	Action	Adds an entry to the FIFO from the source clock domain.
first	a	Returns the first entry from the FIFO in the destination
		clock domain.
deq	Action	Removes the first entry from the FIFO in the destination
		clock domain.
dNotFull	Bool	Returns True if the FIFO appears not full from the desti-
		nation clock domain.
dNotEmpty	Bool	Returns True if the FIFO appears not empty from the
		destination clock domain.
sNotFull	Bool	Returns True if the FIFO appears not full from the source
		clock domain.
sNotEmpty	Bool	Returns True if the FIFO appears not empty from the
		source clock domain.
dClear	Action	Clears the FIFO from the destination side.
sClear	Action	Clears the FIFO from the source side.

```
interface AlignedFIFO#(type a);
  method Action enq(a x);
  method a first();
  method Action deq();
  method Bool dNotFull();
  method Bool sNotFull();
  method Bool sNotFull();
  method Bool sNotEmpty();
  method Action dClear();
  method Action sClear();
endinterface: AlignedFIFO
```

Modules

The AlignedFIFO module is parameterized on the type of store used to hold the FIFO data. The AlignedFIFOs package contains modules to construct stores based on a single register (mkRegStore),

a vector of registers (mkRegVectorStore), and a BRAM (mkBRAMStore). Users can supply their own store implementation as well.

The mkRegStore instantiates a single-element store. The module returns a Store interface and does not use a prefetch.

Module Name Implementation of a sing	BSV Module Declaration gle-element store
mkRegStore	<pre>module mkRegStore(Clock sClock, Clock dClock,</pre>

The mkRegVectorStore module instantiates a vector-of-registers store. The module returns a Store interface and does not use a prefetch.

Implementation of a vector-of-registers store		
mkRegVectorStore	<pre>module mkRegVectorStore(Clock sClock, Clock dClock,</pre>	

The mkBRAMStore2W1R module returns a Store interface and uses a prefetch. This model assumes the read clock is a 2x divided version of the write clock.

```
A BRAM-based store where the read clock is a 2x divided version of the write clock.

mkBRAMStore2W1R

module mkBRAMStore2W1R(Clock sClock, Reset sReset, Clock dClock, Reset dReset, Store#(i,a,1) ifc)

provisos(Bits#(a,a_sz), Bits#(i,w), Eq#(i));
```

The mkBRAMStore1W2R module returns a Store interface and uses a prefetch. This model assumes the write clock is a 2x divided version of the read clock.

```
A BRAM-based store where the write clock is a 2x divided version of read clock.

mkBRAMStore1W2R

module mkBRAMStore1W2R(Clock sClock, Reset sReset, Clock dClock, Reset dReset, Store#(i,a,1) ifc)

provisos(Bits#(a,a_sz), Bits#(i,w), Eq#(i));
```

The mkAlignedFIFO module makes a synchronizing FIFO for aligned clocks, based on the given backing store (determined by the type of store instantiated). The store is assumed to have 2^w slots addressed from 0 to $2^w - 1$. The store will be written in the source clock domain and read in the destination clock domain.

The enq and deq methods will only be callable when the allow_enq and allow_deq inputs are high. For a slow-to-fast crossing use:

```
allow_enq = constant True
allow_deq = pre-edge signal
```

For a fast-to-slow crossing, use:

```
allow_enq = pre-edge signal
allow_deq = constant True
```

The pre-edge signal is True when the slow clock will rise in the next clock cycle. The ClockNextRdy from the ClockDividerIfc (Section C.9.3) can be used as the pre-edge signal.

These settings ensure that the outputs in the slow clock domain are stable for the entire cycle. Setting both inputs to constant True reduces the minimum latency through the FIFO, but allows outputs in the slow domain to transition mid-cycle. This is less safe and can interact badly with the \$displays in a Verilog simulation.

It is not advisable to call both dClear and sClear simultaneously.

C.2.7 Gearbox

Package

```
import Gearbox :: *
```

Description

This package defines FIFO-like converters that convert N-wide data to and from 1-wide data at N-times the frequency. These converters change the frequency and the data width, while the overall data rate stays the same. The data width on the fast side is always 1, while the data width on the slow side is N. The converters are intended to be used between clock domains with aligned edges for both types of clock domain crossings (fast to slow and slow to fast). For example:

```
300 MHz at 8-bits converted to 100 MHz at 24-bits (fast to slow) 100 MHz at 24-bits converted to 300 MHz at 8-bits (slow to fast)
```

In both of these examples, the data type a is Bit#(8) and N=3.

These modules are written in pure BSV using a style that utilzies only mkNullCrossingReg to cross registered values between clock domains. Restricting the form of clock crossings is important to ensure that the module preserves atomic semantics and also that it is compatible with both Verilog and Bluesim backends.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Interfaces and methods

The Gearbox interface provides the following methods: enq, deq, first, notFull and notEmpty.

		Gearbox Interface
Method	Type	Description
Name		
enq	Action	Adds an entry to the converter of type Vector#(in, a),
		where a is the datatype. If the input is the fast domain then
		in = 1, if the input is the slow domain, $in = N$.
deq	Action	Removes the first entry from the converter.
first	Vector#(out, a)	Returns the first entry from the converter. If the output
		domain is the fast side, $out = 1$, if the output domain is the
		slow side, $out = N$.
notFull	Bool	Returns a True value if there is space to enqueue an entry
		into the FIFO.
notEmpty	Bool	Returns a True value if there is are elements in the FIFO
		and you can dequeue from the FIFO.

```
interface Gearbox#(numeric type in, numeric type out, type a);
  method
             Action
                              enq(Vector#(in, a) din);
  method
             Action
                              deq();
             Vector#(out, a) first();
  method
             Bool
                             notFull();
  method
                             notEmpty();
  method
             Bool
endinterface
```

Modules

The package provides two modules: mkNto1Gearbox for slow to fast domain crossings, and mk1toNGearbox to for fast to slow domain crossings. These are intended for use between clock domains with aligned edges for both types of clock domain crossings.

Note: for both modules the resets in the source and destination domains (sReset and dReset) should be asserted together, otherwise only half the unit will be in reset.

With the mkNto1Gearbox module, 2xN elements of data storage are provided, grouped into 2 blocks of N elements each. Each block is writable in the source (slow) domain and readable in the destination (fast) domain.

```
Moves data from a slow domain to a fast domain, changing the data width from a larger width to a smaller width. The data rate stays the same. The width of the output is 1, the width of the input is N.

module mkNto1Gearbox(Clock sClock, Reset sReset, Clock dClock, Reset dReset, Gearbox#(in, out, a) ifc)

provisos(Bits#(a, a_sz), Add#(out, 0, 1), Add#(out, z, in));
```

With the mkltoNGearbox module, 2xN elements of data storage are provided, grouped into 2 blocks of N elements each. Each block is writable in the source (fast) domain and readable in the destination (slow) domain.

C.3 Aggregation: Vectors

Package

```
import Vector :: *;
```

Description

The Vector package defines an abstract data type which is a container of a specific length, holding elements of one type. Functions which create and operate on this type are also defined within this package. Because it is abstract, there are no constructors available for this type (like Cons and Nil for the List type).

```
typedef struct Vector#(type numeric vsize, type element_type);
```

Here, the type variable element_type represents the type of the contents of the elements while the numeric type variable vsize represents the length of the vector.

If the elements are in the Bits class, then the vector is as well. Thus a vector of these elements can be stored into Registers or FIFOs; for example a Register holding a vector of type int. Note that a vector can also store abstract types, such as a vector of Rules or a vector of Reg interfaces. These are useful during static elaboration although they have no hardware implementation.

Typeclasses

Type Classes for Vector									
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit
								Reduction	Extend
Vector									

A vector can be turned into bits if the individual elements can be turned into bits. When packed and unpacked, the zeroth element of the vector is stored in the least significant bits. The size of the resulting bits is given by $tsize = vsize * SizeOf\#(element_type)$ which is specified in the provisos.

Vectors are zero-indexed; the first element of a vector v, is v[0]. When vectors are packed, they are packed in order from the LSB to the MSB.

Example. Vector#(5, Bit#(7)) v1;

From the type, you can see that this will back into a 35-bit vector (5 elements, each with 7 bits).

Example. A vector with a structure:

typedef struct { Bool a, UInt#(5) b} Newstruct deriving (Bits); Vector#(3, NewStruct) v2;

The structure, Newstruct packs into 6 bits. Therefore v2 will pack into an 18-bit vector. And its structure would look as follows:

	17	16 - 12	11	10 - 6	5	0	
MSB	v2[2].a	v2[2].b	v2[1].a	v2[1].b	v2[0].a	v2[0].b	LSB
		v2[2]		v2[1]		v2[0]	

Vectors can be compared for equality if the elements can. That is, the operators == and != are defined.

Vectors are bounded if the elements are.

C.3.1 Creating and Generating Vectors

The following functions are used to create new vectors, with and without defined elements. There are no Bluespec SystemVerilog constructors available for this abstract type (and hence no pattern-matching is available for this type) but the following functions may be used to construct values of the Vector type.

newVector	Generate a vector with undefined elements, typically used when vectors are declared.
	<pre>function Vector#(vsize, element_type) newVector();</pre>
genVector	Generate a vector containing integers 0 through n-1, vector[0] will have value 0.
	<pre>function Vector#(vsize, Integer) genVector();</pre>
replicate	Generate a vector of elements by replicating the given argument (c).
	<pre>function Vector#(vsize, element_type) replicate(element_type c);</pre>

genWith	Generate a vector of elements by applying the given function to 0 through n The argument to the function is another function which has one argument of ty Integer and returns an element_type.	
	<pre>function Vector#(vsize, element_type)</pre>	
cons	Adds an element to a vector creating a vector one element larger. The new element will be at the 0th position. This function can lead to large compile times, so it can be an inefficient way to create and populate a vector. Instead, the designer should build a vector, then set each element to a value.	
	<pre>function Vector#(vsize1, element_type) cons (element_type elem, Vector#(vsize, element_type) vect) provisos (Add#(1, vsize, vsize1));</pre>	
nil	Defines a vector of size zero.	
	<pre>function Vector#(0, element_type) nil;</pre>	
append	Append two vectors containing elements of the same type, returning the combined vector. The resulting vector result will contain all the elements of vecta followed by all the elements of vectb. result[0] = vecta[0], result[vsize-1] = vectb[v1size-1].	
	<pre>function Vector#(vsize, element_type) append(Vector#(v0size,element_type) vecta,</pre>	
concat	Append (concatenate) many vectors, that is a vector of vectors into one vector. concat(xss)[0] will be xss[0][0], provided m and n are non-zero.	
	<pre>function Vector#(mvsize,element_type)</pre>	

Examples - Creating and Generating Vectors

Create a new vector, my_vector, of 5 elements of datatytpe Int#(32), with elements which are undefined.

```
Vector #(5, Int#(32)) my_vector;
```

Create a new vector, my_vector, of 5 elements of datatytpe Integer with elements 0, 1, 2, 3 and 4.

```
Vector #(5, Integer) my_vector = genVector;
     // my_vector is a 5 element vector \{0,1,2,3,4\}
Create a vector, my_vector, of five 1's.
     Vector #(5,Int #(32)) my_vector = replicate (1);
     // my_vector is a 5 element vector {1,1,1,1,1}
Create a vector, my_vector, by applying the given function add2 to 0 through n-1.
     function Integer add2 (Integer a);
         Integer c = a + 2;
     return(c);
     endfunction
     Vector #(5,Integer) my_vector = genWith(add2);
     // a is the index of the vector, 0 to n-1
     // my_vector = \{2,3,4,5,6,\}
Add an element to my_vector, creating a bigger vector my_vector1.
     Vector#(3, Integer) my_vector = genVector();
     // my_vector = {0, 1, 2}
     let my_vector1 = cons(4, my_vector);
     // my_vector1 = {4, 0, 1, 2}
Append vectors, my_vector and my_vector1, resulting in a vector my_vector2.
     Vector#(3, Integer) my_vector = genVector();
     // my_vector = {0, 1, 2}
     Vector#(3, Integer) my_vector1 = genWith(add2);
     // my_vector1 = {2, 3, 4}
     let my_vector2 = append(my_vector, my_vector1);
     // my_vector2 = {0, 1, 2, 2, 3, 4}
```

C.3.2 Extracting Elements and Sub-Vectors

These functions are used to select elements or vectors from existing vectors, while retaining the input vector.

```
The square-bracket notation is available to extract an element from a vector or update an element within it. Extracts or updates the ith element, where the first element is [0]. Index i must be of an acceptable index type (e.g. Integer, Bit#(n), Int#(n) or UInt#(n)). The square-bracket notation for vectors can also be used with register writes.

anyVector[i];
anyVector[i] = newValue;
```

select

The select function is another form of the subscript notation ([i]), mainly provided for backwards-compatibility. The select function is also useful as an argument to higher-order functions. The subscript notation is generally recommended because it will report a more useful position for any selection errors.

function element_type
 select(Vector#(vsize,element_type) vect, idx_type index);

update

Update an element in a vector returning a new vector with one element changed/updated. This function does not change the given vector. This is another form of the subscript notation (see above), mainly provided for backwards compatibility. The update function may also be useful as an argument to a higher-order function. The subscript notation is generally recommended because it will report a more useful position for any update errors.

function Vector#(vsize, element_type)
 update(Vector#(vsize, element_type) vectIn,
 idx_type index,
 element_type newElem);

head

Extract the zeroth (head) element of a vector. The vector must have at least one element.

function element_type
 head (Vector#(vsize, element_type) vect)
provisos(Add#(1,xxx,vxize)); // vsize >= 1

last

Extract the highest (tail) element of a vector. The vector must have at least one element.

function element_type
 last (Vector#(vsize, element_type) vect)
provisos(Add#(1,xxx,vxize)); // vsize >= 1

tail

Remove the head element of a vector leaving its tail in a smaller vector.

function Vector#(vsize,element_type)
 tail (Vector#(vsize1, element_type) xs)
provisos (Add#(1, vsize, vsize1));

Remove the last element of a vector leaving its initial part in a smaller vector.

function Vector#(vsize,element_type)
 init (Vector#(vsize1, element_type) xs)
 provisos (Add#(1, vsize, vsize1));

take

Take a number of elements from a vector starting from index 0. The number of elements to take is indicated by the type of the context where this is called, and is not specified as an argument to the function.

```
function Vector#(vxize2,element_type)
     take (Vector#(vsize,element_type) vect)
provisos (Add#(vsize2,xxx,vsize)); // vsize2 <= vsize.</pre>
```

drop takeTail

Drop a number of elements from the vector starting at the 0th position. The elements in the result vector will be in the same order as the input vector.

```
function Vector#(vxize2,element_type)
    drop (Vector#(vsize,element_type) vect)
    provisos (Add#(vsize2,xxx,vsize)); // vsize2 <= vsize.

function Vector#(vxize2,element_type)
    takeTail (Vector#(vsize,element_type) vect)
    provisos (Add#(vsize2,xxx,vsize)); // vsize2 <= vsize.</pre>
```

takeAt

Take a number of elements starting at startPos. startPos must be a compiletime constant. If the startPos plus the output vector size extend beyond the end of the input vector, an error will be returned.

Examples - Extracting Elements and Sub-Vectors

Extract the element from a vector, my_vector, at the position of index.

```
// my_vector is a vector of elements {6,7,8,9,10,11}
// index = 3
// select or [ ] will generate a MUX

newvalue = select (my_vector, index);
newvalue = myvalue[index];
// newvalue = 9
```

Update the element of a vector, my_vector, at the position of index.

```
// my_vector is a vector of elements \{6,7,8,9,10,11\}
     // index = 3
     my_vector = update (my_vector, index, 0);
     my_vector[index] = 0;
     // \text{ my_vector} = \{6,7,8,0,10,11\}
Extract the zeroth element of the vector my_vector.
     // my_vector is a vector of elements \{6,7,8,9,10,11\}
     newvalue = head(my_vector);
     // newvalue = 6
Extract the last element of the vector my_vector.
     // my_vector is a vector of elements \{6,7,8,9,10,11\}
     newvalue = last(my_vector);
     // newvalue = 11
Create a vector, my_vector2, of size 4 by removing the head (zeroth) element of the vector my_vector1.
     // my_vector1 is a vector with 5 elements {0,1,2,3,4}
     Vector #(4, Int#(32)) my_vector2 = tail (my_vector1);
     // my_vector2 is a vector of 4 elements {1,2,3,4}
Create a vector, my_vector2, of size 4 by removing the tail (last) element of the vector my_vector1.
     // my_vector1 is a vector with 5 elements {0,1,2,3,4}
     Vector #(4, Int#(32)) my_vector2 = init (my_vector1);
     // my_vector2 is a vector of 4 elements {0,1,2,3}
Create a 2 element vector, my_vector2, by taking the first two elements of the vector my_vector1.
     // my_vector1 is vector with 5 elements {0,1,2,3,4}
     Vector #(2, Int#(4)) my_vector2 = take (my_vector1);
     // my_vector2 is a 2 element vector {0,1}
Create a 3 element vector, my_vector2, by taking the last 3 elements of vector, my_vector1. using
takeTail
     // my_vector1 is Vector with 5 elements {0,1,2,3,4}
     Vector #(3,Int #(4)) my_vector2 = takeTail (my_vector1);
     // my_vector2 is a 3 element vector {2,3,4}
Create a 3 element vector, my_vector2, by taking the 1st - 3rd elements of vector, my_vector1.
using takeAt
     // my_vector1 is Vector with 5 elements {0,1,2,3,4}
     Vector #(3,Int #(4)) my_vector2 = takeAt (1, my_vector1);
     // my_vector2 is a 3 element vector {1,2,3}
```

C.3.3 Vector to Vector Functions

The following functions generate a new vector by changing the position of elements within the vector.

rotate	Move the zeroth element to the highest and shift each element lower by one. For example, the element at index n moves to index n-1.			
	<pre>function Vector#(vsize,element_type) rotate (Vector#(vsize,element_type) vect);</pre>			
rotateR	Move last element to the zeroth element and shift each element up by one. For example, the element at index ${\tt n}$ moves to index ${\tt n+1}$.			
	<pre>function Vector#(vsize,element_type) rotateR (Vector#(vsize,element_type) vect);</pre>			
rotateBy	Shift each element n places. The last n elements are moved to the begining, the element at index 0 moves to index n , index 1 to index $n+1$, etc.			
	<pre>function Vector#(vsize, element_type) rotateBy (Vector#(vsize,element_type) vect, UInt#(log(v)) n) provisos (Log#(vsize, logv);</pre>			
shiftInAt0	Shift a new element into the vector at index 0, bumping the index of all other element up by one. The highest element is dropped.			
	<pre>function Vector#(vsize,element_type) shiftInAt0 (Vector#(vsize,element_type) vect,</pre>			
shiftInAtN	Shift a new element into the vector at index n, bumping the index of all other elements down by one. The 0th element is dropped.			
	<pre>function Vector#(vsize,element_type) shiftInAtN (Vector#(vsize,element_type) vect,</pre>			

shiftOutFromO

Shifts out amount number of elements from the vector starting at index 0, bumping the index of all remaining elements down by amount. The shifted elements are replaced with the value default. This function is similar to a >> bit operation. amt_type must be of an acceptable index type (Integer, Bit#(n), Int#(n) or UInt#(n)).

${\tt shiftOutFromN}$

Shifts out amount number of elements from the vector starting at index vsize-1 bumping the index of remaining elements up by amount. The shifted elements are replaced with the value default. This function is similar to a << bit operation. amt_type must be of an acceptable index type (Integer, Bit#(n), Int#(n) or UInt#(n)).

reverse

Reverse element order

function Vector#(vsize,element_type)
 reverse(Vector#(vsize,element_type) vect);

transpose

Matrix transposition of a vector of vectors.

transposeLN

Matrix transposition of a vector of Lists.

function Vector#(vsize, List#(element_type))
 transposeLN(List#(Vector#(vsize, element_type)) lvs);

Examples - Vector to Vector Functions

Create a vector by moving the last element to the first, then shifting each element to the right.

```
// my_vector1 is a vector of elements with values {1,2,3,4,5}
my_vector2 = rotateR (my_vector1);
// my_vector2 is a vector of elements with values {5,1,2,3,4}
```

```
Create a vector which is the input vector rotated by 2 places.
     // my_vector1 is a vector of elements {1,2,3,4,5}
     my_vector2 = rotateBy {my_vector1, 2};
     // my_vector2 = {4,5,1,2,3}
Create a vector which shifts out 3 elements starting from 0, replacing them with the value F
     // my_vector1 is a vector of elements \{5,4,3,2,1,0\}
     my_vector2 = shiftOutFromO (F, my_vector1, 3);
     // my_vector2 is a vector of elements {F,F,F,5,4,3}
Create a vector which shifts out 3 elements starting from n-1, replacing them with the value F
     // my_vector1 is a vector of elements \{5,4,3,2,1,0\}
     my_vector2 = shiftOutFromN (F, my_vector1, 3);
     // my_vector2 is a vector of elements {2,1,0,F,F,F}
Create a vector which is the reverse of the input vector.
     // my_vector1 is a vector of elements {1,2,3,4,5}
     my_vector2 = reverse (my_vector1);
     // my_vector2 is a vector of elements {5,4,3,2,1}
Use transpose to create a new vector.
     // my_vector1 is a Vector#(3, Vector#(5, Int#(8)))
     // the result, my_vector2, is a Vector #(5, Vector#(3, Int #(8)))
     // my_vector1 has the values:
     // {{0,1,2,3,4},{5,6,7,8,9},{10,11,12,13,14}}
     my_vector2 = transpose(my_vector1);
     // my_vector2 has the values:
     // {{0,5,10},{1,6,11},{2,7,12},{3,8,13},{4,9,14}}
```

C.3.4 Tests on Vectors

The following functions are used to test vectors. The first set of functions are Boolean functions, i.e. they return True or False values.

elem	Check if a value is an element of a vector.
	<pre>function Bool elem (element_type x,</pre>
any	Test if a predicate holds for any element of a vector.
	<pre>function Bool any(function Bool pred(element_type x1),</pre>

all	Test if a predicate holds for all elements of a vector.			
	<pre>function Bool all(function Bool pred(element_type x1),</pre>			
	,			
or	Combine all elements in a vector of Booleans with a logical or. Returns True if any elements in the Vector are True.			
	function Bool or (Vector#(vsize, Bool) vect);			
and	Combine all elements in a vector of Booleans with a logical and. Returns True if all elements in the Vector are True.			
	function Bool and (Vector#(vsize, Bool) vect);			

The following two functions return the number of elements in the vector which match a condition.

countElem	Returns the number of elements in the vector which are equal to a given value. The return value is in the range of 0 to vsize.
	<pre>function UInt#(logv1) countElem (element_type x,</pre>

countIf	Returns the number of elements in the vector which satisfy a given predicate function. The return value is in the range of 0 to vsize.
	<pre>function UInt#(logv1) countIf (function Bool pred(element_type x1)</pre>

```
Returns the first element that satisfies the predicate or Nothing if there is none.

function Maybe#(element_type)
find (function Bool pred(element_type),
Vector#(vsize, element_type) vect);
```

The following two functions return the index of an element.

Returns the index of the first element in the vector which equals a given value. Returns an Invalid if not found or Valid with a value of 0 to vsize-1 if found. function Maybe#(UInt#(logv)) findElem (element_type x, Vector#(vsize, element_type) vect) provisos (Eq#(element_type), Add#(xx1, 1, vsize), Log#(vsize, logv));

Returns the index of the first element in the vector which satisfies a given predicate. Returns an Invalid if not found or Valid with a value of 0 to vsize-1 if found. function Maybe#(UInt#(logv)) findIndex (function Bool pred(element_type x1) Vector#(vsize, element_type) vect) provisos (Add#(xx1,1,vsize), Log#(vsize, logv));

Examples -Tests on Vectors

Test that all elements of the vector my_vector1 are positive integers.

```
function Bool isPositive (Int #(32) a):
          return (a > 0)
     endfunction
     // function isPositive checks that "a" is a positive integer
     // if my_vector1 has n elements, n instances of the predicate
     // function isPositive will be generated.
     if (all(isPositive, my_vector1))
        $display ("Vector contains all negative values");
Test if any elements in the vector are positive integers.
     // function isPositive checks that "a" is a positive integer
     // if my_vector1 has n elements, n instances of the predicate
     // function isPositive will be generated.
     if (any(isPositive, my_vector1))
        $display ("Vector contains some negative values");
Check if the integer 5 is in my_vector.
     // if my_vector contains n elements, elem will generate n copies
     // of the eq test
     if (elem(5,my_vector))
        $display ("Vector contains the integer 5");
Count the number of elements which match the integer provided.
     // my_vector1 is a vector of \{1,2,1,4,3\}
     x = countElem ( 1, my_vector1);
     // x = 2
     y = countElem (4, my_vector1);
     // y = 1
```

Find the index of an element which equals a predicate.

```
let f = findIndex ( beIsGreaterThan( 3 ) , my_vector );
if ( f matches tagged Valid .indx )
   begin
     printBE ( my_vector[indx] ) ;
     $display ("Found data > 3 at index %d ", indx );
else
   begin
     $display ( "Did not find data > 3" ) ;
   end
```

C.3.5 Bit-Vector Functions

The following functions operate on bit-vectors.

```
Shift each bit to a higher index by n places. The last n bits are moved to the beginning and the bit at index (0) moves to index (n).

function Bit#(n) rotateBitsBy (Bit#(n) bvect, UInt#(logn) n) provisos (Log#(n,logn), Add#(1,xxx,n));

countOnesAlt

Returns the number of elements equal to 1 in a bit-vector. (This function differs slightly from the Prelude version of countOnes and has fewer provisos.)

function UInt#(logn1) countOnesAlt (Bit#(n) bvect) provisos (Add#(1,n,n1), Log#(n1,logn1));
```

C.3.6 Functions on Vectors of Registers

readVReg	Returns the values from reading a vector of registers (interfaces).
	function Vector#(n,a) readVReg (Vector#(n, Reg#(a)) vrin);
writeVReg	Returns an Action which is the write of all registers in vr with the data from vdin.
	<pre>function Action writeVReg (Vector#(n, Reg#(a)) vr,</pre>

C.3.7 Combining Vectors with Zip

The family of zip functions takes two or more vectors and combines them into one vector of Tuples. Several variations are provided for different resulting Tuples, as well as support for mis-matched vector sizes.

```
zip
            Combine two vectors into a vector of Tuples.
            function Vector#(vsize,Tuple2 #(a_type, b_type))
                   zip( Vector#(vsize, a_type) vecta,
                        Vector#(vsize, b_type) vectb);
zip3
             Combine three vectors into a vector of Tuple3.
            function Vector#(vsize,Tuple3 #(a_type, b_type, c_type))
                   zip3( Vector#(vsize, a_type) vecta,
                         Vector#(vsize, b_type) vectb,
                         Vector#(vsize, c_type) vectc);
zip4
             Combine four vectors into a vector of Tuple4.
            function Vector#(vsize,Tuple4 #(a_type, b_type, c_type, d_type))
                   zip4( Vector#(vsize, a_type) vecta,
                         Vector#(vsize, b_type) vectb,
                         Vector#(vsize, c_type) vectc,
                         Vector#(vsize, d_type) vectd);
zipAny
             Combine two vectors into one vector of pairs (2-tuples); result is as long as the
            smaller vector.
            function Vector#(vsize,Tuple2 #(a_type, b_type))
                   zipAny(Vector#(m,a_type) vect1,
                          Vector#(n,b_type) vect2);
               provisos (Max#(m,vsize,m), Max#(n, vsize, n));
unzip
            Separate a vector of pairs (i.e. a Tuple2#(a,b)) into a pair of two vectors.
            function Tuple2#(Vector#(vsize,a_type), Vector#(vsize, b_type))
                   unzip(Vector#(vsize,Tuple2 #(a_type, b_type)) vectab);
```

Examples - Combining Vectors with Zip

Combine two vectors into a vector of Tuples.

```
// my_vector1 is a vector of elements {0,1,2,3,4}
// my_vector2 is a vector of elements {5,6,7,8,9}

my_vector3 = zip(my_vector1, my_vector2);
// my_vector3 is a vector of Tuples {(0,5),(1,6),(2,7),(3,8),(4,9)}
```

Separate a vector of pairs into a Tuple of two vectors.

C.3.8 Mapping Functions over Vectors

A function can be applied to all elements of a vector, using high-order functions such as map. These functions take as an argument a function, which is applied to the elements of the vector.

```
Map a function over a vector, returning a new vector of results.

function Vector#(vsize,b_type)
map (function b_type func(a_type x),
Vector#(vsize, a_type) vect);
```

Example - Mapping Functions over Vectors

Consider the following code example which applies the extend function to each element of avector into a new vector, resultvector.

```
Vector#(13,Bit#(5)) avector;
Vector#(13,Bit#(10)) resultvector;
...
resultvector = map( extend, avector );

This is equivalent to saying:
    for (Integer i=0; i<13; i=i+1)
        resultvector[i] = extend(avector[i]);

Map a negate function over a Vector
    // my_vector1 is a vector of 5 elements {0,1,2,3,4}
    // negate is a function which makes each element negative

Vector #(5,Int #(32)) my_vector2 = map (negate, my_vector1);

// my_vector2 is a vector of 5 elements {0,-1,-2,-3,-4}</pre>
```

C.3.9 ZipWith Functions

The zipWith functions combine two or more vectors with a function and generate a new vector. These functions combine features of map and zip functions.

Examples - ZipWith

Create a vector by applying a function over the elements of 3 vectors.

```
// the function add3 adds 3 values
function Int#(n) add3 (Int #(n) a,Int #(n) b,Int #(n) c);
    Int#(n) d = a + b + c;
    return d:
endfunction
// Create the vector my_vector4 by adding the ith element of each of
// 3 vectors (my_vector1, my_vector2, my_vector3) to generate the ith
// element of my_vector4.
// my_vector1 = {0,1,2,3,4}
// my_vector2 = {5,6,7,8,9}
// my_vector3 = {10,11,12,13,14}
Vector #(5,Int #(8)) my_vector4 = zipWith3(add3, my_vector1, my_vector2, my_vector3);
// creates 5 instances of the add3 function in hardware.
// my_vector4 = {15,18,21,24,27}
// This is equivalent to saying:
   for (Integer i=0; i<5; i=i+1)</pre>
```

```
my_vector4[i] = my_vector1[i] + my_vector2[i] + my_vector3[i];
```

C.3.10 Fold Functions

The fold family of functions reduces a vector to a single result by applying a function over all its elements. That is, given a vector of element_type, $V_0, V_1, V_2, ..., V_{n-1}$, a seed of type b_type, and a function func, the reduction for foldr is given by

$$func(V_0, func(V_1, ..., func(V_{n-2}, func(V_{n-1}, seed))));$$

Note that foldr start processing from the highest index position to the lowest, while foldl starts from the lowest index (zero), i.e. foldl is:

$$func(...(func(func(seed, V_0), V_1), ...)V_{n-1})$$

foldr	Reduce a vector by applying a function over all its elements. Start processing from the highest index to the lowest.
	<pre>function b_type foldr(function b_type func(a_type x, b_type y),</pre>
foldl	Reduce a vector by applying a function over all its elements. Start processing from the lowest index (zero).
	<pre>function b_type foldl (function b_type func(b_type y, a_type x),</pre>

The functions foldr1 and foldl1 use the first element as the seed. This means they only work on vectors of at least one element. Since the result type will be the same as the element type, there is no b_type as there is in the foldr and foldl functions.

foldr1	foldr function for a non-zero sized vector, using element V_{n-1} as a seed. Vector must have at least 1 element. If there is only one element, it is returned.
	<pre>function element_type foldr1(</pre>
foldl1	foldl function for a non-zero sized vector, using element V_0 as a seed. Vector must have at least 1 element. If there is only one element, it is returned.
	<pre>function element_type foldl1 (</pre>

The fold function also operates over a non-empty vector, but processing is accomplished in a binary tree-like structure. Hence the depth or delay through the resulting function will be $O(log_2(vsize)$ rather than O(vsize).

```
fold
             Reduce a vector by applying a function over all its elements, using a binary tree-
             like structure. The function returns the same type as the arguments.
             function element_type fold (
                       function element_type func(element_type y, element_type x),
                       Vector#(vsize,element_type) vect )
               provisos (Add#(1, xxx, vsize));
mapPairs
              Map a function over a vector consuming two elements at a time. Any straggling
              element is processed by the second function.
              function Vector#(vsize2,b_type)
                        mapPairs (
                            function b_type func1(a_type x, a_type y),
                           function b_type func2(a_type x),
                           Vector#(vsize,a_type) vect )
                provisos (Div#(vsize, 2, vsize2));
joinActions
              Join a number of actions together. joinActions is used for static elaboration
              only, no hardware is generated.
              function Action joinActions (Vector#(vsize, Action) vactions);
joinRules
              Join a number of rules together.joinRules is used for static elaboration only,
              no hardware is generated.
              function Rules joinRules (Vector#(vsize,Rules) vrules);
```

Example - Folds

Use fold to find the sum of the elements in a vector.

```
// my_vector1 is a vector of five integers {1,2,3,4,5}
// \+ is a function which returns the sum of the elements
// make sure you leave a space after the \+ and before the ,

// This will build an adder tree, instantiating 4 adders, with a maximum
// depth or delay of 3. If foldr1 or foldl1 were used, it would
// still instantiate 4 adders, but the delay would be 4.

my_sum = fold (\+ , my_vector1));
// my_sum = 15
```

Use fold to find the element with the maximum value.

```
// my_vector1 is a vector of five integers {2,45,5,8,32}
my_max = fold (max, my_vector1);
// my_max = 45
```

Create a new vector using mapPairs. The function sum is applied to each pair of elements (the first and second, the third and fourth, etc.). If there is an uneven number of elements, the function pass is applied to the remaining element.

```
// sum is defined as c = a+b
function Int#(4) sum (Int #(4) a,Int #(4) b);
    Int#(4) c = a + b;
    return(c);
endfunction

// pass is defined as a
function Int#(4) pass (Int #(4) a);
    return(a);
endfunction

// my_vector1 has the elements {0,1,2,3,4}

my_vector2 = mapPairs(sum,pass,my_vector1);
// my_vector2 has the elements {1,5,4}
// my_vector2[0] = 0 + 1
// my_vector2[1] = 2 + 3
// my_vector2[3] = 4
```

C.3.11 Scan Functions

The scan family of functions applies a function over a vector, creating a new vector result. The scan function is similar to fold, but the intermediate results are saved and returned in a vector, instead of returning just the last result. The result of a scan function is a vector. That is, given a vector of element_type, $V_0, V_1, ..., V_{n-1}$, an initial value initb of type b_type, and a function func, application of the scanr functions creates a new vector W, where

```
\begin{array}{rcl} W_n & = & init; \\ W_{n-1} & = & func(V_{n-1}, W_n); \\ W_{n-2} & = & func(V_{n-2}, W_{n-1}); \\ & \dots \\ W_1 & = & func(V_1, W_2); \\ W_0 & = & func(V_0, W_1); \end{array}
```

scanr	Apply a function over a vector, creating a new vector result. Processes elements from the highest index position to the lowest, and fill the resulting vector in the same way. The result vector is 1 element longer than the input vector.
	<pre>function Vector#(vsize1,b_type)</pre>

The scanl function creates the resulting vector in a similar way as scanr except that the processing happens from the zeroth element up to the n^{th} element.

```
\begin{array}{rcl} W_0 & = & init; \\ W_1 & = & func(W_0,V_0); \\ W_2 & = & func(W_1,V_1); \\ & \cdots \\ W_{n-1} & = & func(W_{n-2},V_{n-2}); \\ W_n & = & func(W_{n-1},V_{n-1}); \end{array}
```

The sscanl function drops the first result, *init*, shifting the result index by one.

```
mapAccumL Map a function, but pass an accumulator from head to tail.

function Tuple2 #(a_type, Vector#(vsize,c_type))

mapAccumL (function Tuple2 #(a_type, c_type))

func(a_type x, b_type y), a_type x0,

Vector#(vsize,b_type) vect );
```

```
mapAccumR Map a function, but pass an accumulator from tail to head.

function Tuple2 #(a_type, Vector#(vsize,c_type))

mapAccumR(function Tuple2 #(a_type, c_type))

func(a_type x, b_type y), a_type x0,

Vector#(vsize,b_type) vect);
```

Examples - Scan

Create a vector of factorials.

```
// \* is a function which returns the result of a multiplied by b
function Bit #(16) \* (Bit #(16) b, Bit #(8) a);
    return (extend (a) * b);
endfunction

// Create a vector of factorials by multiplying each input list element
// by the previous product (the output list element), to generate
// the next product. The seed is a Bit#(16) with a value of 1.
// The elements are processed from the zeroth element up to the $n^{th}$ element.

// my_vector1 = {1,2,3,4,5,6,7}
Vector#(8,Bit #(16)) my_vector2 = scanl (\*, 16'd1, my_vector1);
// 7 multipliers are generated

// my_vector2 = {1,1,2,6,24,120,720,5040}
// foldr with the same arguments would return just 5040.
```

C.3.12 Monadic Operations

Within Bluespec, there are some functions which can only be invoked in certain contexts. Two common examples are: ActionValue, and module instantiation. ActionValues can only be invoked

within an Action context, such as a rule block or an Action method, and can be considered as two parts - the action and the value. Module instantiation can similarly be considered, modules can only be instantiated in the module context, while the two parts are the module instantiation (the action performed) and the interface (the result returned). These situations are considered *monadic*.

When a monadic function is to be applied over a vector using map-like functions such as map, zipWith, or replicate, the monadic versions of these functions must be used. Moreover, the context requirements of the applied function must hold. The common application for these functions is in the generation (or instantiation) of vectors of hardware components.

mapM_ Takes a monadic function and a vector, applies the function to all vector elements, and throws away the resulting vector leaving the action in its context.

zipWithM

Take a monadic function (which takes two arguments) and two vectors; the function applied to the corresponding element from each vector would return an action and result. Perform all those actions and return the vector of corresponding results.

zipWithM_

Take a monadic function (which takes two arguments) and two vectors; the function is applied to the corresponding element from each vector. This is the same as zipWithM but the resulting vector is thrown away leaving the action in its context.

```
zipWith3M
            Same as zipWithM but combines three vectors with a function. The function is
            applied to the corresponding element from each vector and returns an action and
            the vector of corresponding results.
            function m#(Vector#(vsize, c_type))
                  zipWith3M( function m#(d_type)
                              func(a_type x, b_type y, c_type z),
                              Vector#(vsize, a_type) vecta,
                              Vector#(vsize, b_type) vectb,
                              Vector#(vsize, c_type) vectc )
               provisos (Monad#(m));
             Generate a vector of elements by applying the given monadic function to 0 through
genWithM
            n-1.
            function m#(Vector#(vsize, element_type))
                      genWithM(function m#(element_type) func(Integer x))
               provisos (Monad#(m));
```

Examples - Creating a Vector of Registers

The following example shows some common uses of the Vector type. We first create a vector of registers, and show how to populate this vector. We then continue with some examples of accessing and updating the registers within the vector, as well as alternate ways to do the same.

```
// First define a variable to hold the register interfaces.
// Notice the variable is really a vector of Interfaces of type Reg,
// not a vector of modules.
Vector#(10,Reg#(DataT))
                          vectRegs ;
// Now we want to populate the vector, by filling it with Reg type
// interfaces, via the mkReg module.
// Notice that the replicateM function is used instead of the
// replicate function since mkReg function is creating a module.
vectRegs <- replicateM( mkReg( 0 ) );</pre>
// ...
// A rule showing a read and write of one register within the
// vector.
// The readReg function is required since the selection of an
// element from vectRegs returns a Reg#(DType) interface, not the
// value of the register. The readReg functions converts from a
```

```
// Reg#(DataT) type to a DataT type.
rule zerothElement ( readReg( vectRegs[0] ) > 20 );
   // set 0 element to 0
   // The parentheses are required in this context to give
   // precedence to the selection over the write operation.
   (vectRegs[0]) <= 0 ;
   // Set the 1st element to 5
   // An alternate syntax
   vectRegs[1]._write(5);
endrule
rule lastElement ( readReg( vectRegs[9] ) > 200 ) ;
   // Set the 9th element to -10000
   (vectRegs[9]) <= -10000;
endrule
// These rules defined above can execute simultaneously, since
// they touch independent registers
// Here is an example of dynamic selection, first we define a
// register to be used as the selector.
Reg#(UInt#(4)) selector <- mkReg(0);</pre>
// Now define another Reg variable which is selected from the
// vectReg variable. Note that no register is created here, just
// an alias is defined.
Reg#(DataT) thisReg = select(vectRegs, selector ) ;
//The above statement is equivalent to:
//Reg#(DataT) thisReg = vectRegs[selector] ;
// If the selected register is greater than 20'h7_0000, then its
// value is reset to zero. Note that the vector update function is
// not required since we are changing the contents of a register
// not the vector vectReg.
rule reduceReg( thisReg > 20'h7_0000 ) ;
   thisReg <= 0 ;</pre>
   selector <= ( selector < 9 ) ? selector + 1 : 0 ;</pre>
endrule
// As an alternative, we can define N rules which each check the
// value of one register and update accordingly. This is done by
// generating each rule inside an elaboration-time for-loop.
Integer i; // a compile time variable
for (i = 0; i < 10; i = i + 1) begin
   rule checkValue( readReg( vectRegs[i] ) > 20'h7_0000 ) ;
      (vectRegs[i]) <= 0 ;</pre>
   endrule
end
```

C.3.13 Converting to and from Vectors

There are functions which convert between Vectors and other types.

toList	Convert a Vector to a List.
	<pre>function List#(element_type) toList (Vector#(vsize, element_type) vect);</pre>
toVector	Convert a List to a Vector.
	<pre>function Vector#(vsize, element_type) toVector (List#(element_type) lst);</pre>
arrayToVector	Convert an array to a Vector.
	<pre>function Vector#(vsize, element_type) arrayToVector (element_type[] arr);</pre>
vectorToArray	Convert a Vector to an array.
	<pre>function element_type[] vectorToArray (Vector#(vsize, element_type) vect);</pre>
toChunks	Convert a value to a Vector of chunks, possibly padding the final chunk. The input type and size as well as the chunk type and size are determined from their types.
	<pre>function Vector#(n_chunk, chunk_type) toChunks(type_x x) provisos(Bits#(chunk_type, chunk_sz), Bits#(type_x, x_sz) , Div#(x_sz, chunk_sz, n_chunk));</pre>

Example - Converting to and from Vectors

Convert the vector my_vector to a list named my_list.

```
Vector#(5,Int#(13)) my_vector;
List#(Int#(13)) my_list = toList(my_vector);
```

C.3.14 ListN

Package name

```
import ListN :: * ;
```

Description

ListN is an alternative implementation of Vector which is preferred for sequential list processing functions, such as head, tail, map, fold, etc. All Vector functions are available, by substituting ListN for Vector. See the Vector documentation (C.3) for details. If the implementation requires random access to items in the list, the Vector construct is recommended. Using ListN where Vectors is recommended (and visa-versa) can lead to very long static elaboration times.

The ListN package defines an abstract data type which is a ListN of a specific length. Functions which create and operate on this type are also defined within this package. Because it is abstract, there are no constructors available for this type (like Cons and Nil for the List type).

```
struct ListN#(vsize,a_type) \cdots abstract \cdots
```

Here, the type variable "a_type" represents the type of the contents of the listN while type variable "vsize" represents the length of the ListN.

C.4 Aggregation: Lists

Package

```
import List :: *;
```

Description

The List package defines a data type and functions which create and operate on this data type. Lists are similar to Vectors, but are used when the number of items on the list may vary at compile-time or need not be strictly enforced by the type system. All elements of a list must be of the same type. The list type is defined as a tagged union as follows.

```
typedef union tagged {
   void Nil;
   struct {
        a head;
       List #(a) tail;
   } Cons;
} List #(type a);
```

A list is tagged Nil if it has no elements, otherwise it is tagged Cons. Cons is a structure of a single element and the rest of the list.

Lists are most often used during static elaboration (compile-time) to manipulate collections of objects. Since List#(element_type) is not in the Bits typeclass, lists cannot be stored in registers or other dynamic elements. However, one can have a list of registers or variables corresponding to hardware functions.

C.4.1 Creating and Generating Lists

```
Adds an element to a list. The new element will be at the 0th position.

function List#(element_type)
cons (element_type x, List#(element_type) xs);
```

upto	Create a list of Integers counting up over a range of numbers, from m to n. If m > n, an empty list (Nil) will be returned.
	List#(Integer) upto(Integer m, Integer n);
replicate	Generate a list of n elements by replicating the given argument, elem.
	<pre>function List#(element_type) replicate(Integer n, element_type elem);</pre>
append	Append two lists, returning the combined list. The elements of both lists must be the same datatype, element_type. The combined list will contain all the elements of xs followed in order by all the elements of ys.
	<pre>function List#(element_type) append(List#(element_type) xs, List#(element_type) ys);</pre>
concat	Append (concatenate) many lists, that is a list of lists, into one list.
	<pre>function List# (element_type) concat (List#(List#(element_type)) xss);</pre>

Examples - Creating and Generating Lists

Create a new list, my_list , of elements of datatytpe Int#(32) which are undefined

```
List #(Int#(32)) my_list;
```

Create a list, my_list, of five 1's

```
List #(Int #(32)) my_list = replicate (5,32'd1);
//my_list = {1,1,1,1,1}
```

Create a new list using the upto function

```
List #(Integer) my_list2 = upto (1, 5);
//my_list2 = {1,2,3,4,5}
```

C.4.2 Extracting Elements and Sub-Lists

[i]

The square-bracket notation is available to extract an element from a list or update an element within it. Extracts or updates the ith element, where the first element is [0]. Index i must be of an acceptable index type (e.g. Integer, Bit#(n), Int#(n) or UInt#(n)). The square-bracket notation for lists can also be used with register writes.

```
anyList[i];
anyList[i] = newValue;
```

select

The select function is another form of the subscript notation ([i]), mainly provided for backwards-compatibility. The select function is also useful as an argument to higher-order functions. The subscript notation is generally recommended because it will report a more useful position for any selection errors.

```
function element_type
     select(List#(element_type) alist, idx_type index);
```

update

Update an element in a list returning a new list with one element changed/updated. This function does not change the given list. This is another form of the subscript notation (see above), mainly provided for backwards compatibility. The update function may also be useful as an argument to a higher-order function. The subscript notation is generally recommended because it will report a more useful position for any update errors.

oneHotSelect

Select a list element with a Boolean list. The Boolean list should have exactly one element that is True, otherwise the result is undefined. The returned element is the one in the corresponding position to the True element in the Boolean list.

head	Extract the first element of a list. The input list must have at least 1 element, or an error will be returned.
	<pre>function element_type head (List#(element_type) listIn);</pre>
last	Extract the last element of a list. The input list must have at least 1 element, or an error will be returned.
	<pre>function element_type last (List#(element_type) alist);</pre>
tail	Remove the head element of a list leaving the remaining elements in a smaller list. The input list must have at least 1 element, or an error will be returned.
	<pre>function List#(element_type) tail (List#(element_type) alist);</pre>
init	Remove the last element of a list the remaining elements in a smaller list. The input list must have at least one element, or an error will be returned.
	<pre>function List#(element_type) init (List#(element_type) alist);</pre>
take	Take a number of elements from a list starting from index 0. The number to take is specified by the argument n. If the argument is greater than the number of elements on the list, the function stops taking at the end of the list and returns the entire input list.
	<pre>function List#(element_type) take (Integer n, List#(element_type) alist);</pre>
	1
drop	Drop a number of elements from a list starting from index 0. The number to drop is specified by the argument n. If the argument is greater than the number of elements on the list, the entire input list is dropped, returning an empty list.
	<pre>function List#(element_type) drop (Integer n, List#(element_type) alist);</pre>

Create a new list from a given list where the new list has only the elements which satisfy the predicate function.
<pre>function List#(element_type) filter (function Bool pred(element_type),</pre>
T
Return the first element that satisfies the predicate or Nothing if there is none.
<pre>function Maybe#(element_type) find (function Bool pred(element_type), List#(element_type) alist);</pre>
Returns the value in an association list or Nothing if there is no matching value.
<pre>function Maybe#(b_type) lookup (a_type key, List#(Tuple2#(a_type, b_type)) alist) provisos(Eq#(a_type));</pre>
Returns the first set of elements of a list which satisfy the predicate function.
<pre>function List#(element_type) takeWhile (function Bool pred(element_type x),</pre>
Returns the last set of elements on a list which satisfy the predicate function.
<pre>function List#(element_type) takeWhileRev (function Bool pred(element_type x),</pre>
Removes the first set of elements on a list which satisfy the predicate function, returning a list with the remaining elements.
<pre>function List#(element_type) dropWhile (function Bool pred(element_type x),</pre>

//result = 3

Removes the last set of elements on a list which satisfy the predicate function, returning a list with the remaining elements. function List#(element_type) dropWhileRev (function Bool pred(element_type x), List#(element_type) alist);

```
Examples - Extracting Elements and Sub-Lists
Extract the element from a list, my_list, at the position of index.
     //my_list = \{1,2,3,4,5\}, index = 3
     newvalue = select (my_list, index);
     //newvalue = 4
Extract the zeroth element of the list my_list.
     //mv_list = \{1,2,3,4,5\}
     newvalue = head(my_list);
     //newvalue = 1
Create a list, my_list2, of size 4 by removing the head (zeroth) element of the list my_list1.
     //my_list1 is a list with 5 elements, \{0,1,2,3,4\}
     List #(Int #(32)) my_list2 = tail (my_list1);
     List #(Int #(32)) my_list3 = tail(tail(tail(tail(tail(tail(my_list1);
     //my_list2 = \{1,2,3,4\}
     //my_list3 = Nil
Create a 2 element list, my_list2, by taking the first two elements of the list my_list1.
     //my_list1 is list with 5 elements, \{0,1,2,3,4\}
     List #(Int #(4)) my_list2 = take (2,my_list1);
     //my_list2 = {0,1}
The number of elements specified to take in take can be greater than the number of elements on
the list, in which case the entire input list will be returned.
     //my_list1 is list with 5 elements, \{0,1,2,3,4\}
     List \#(Int \#(4)) \text{ my_list2} = \text{take } (7, \text{my_list1});
     //my_list2 = {0,1,2,3,4}
Select an element based on a boolean list.
     //my_list1 is a list of unsigned integers, {1,2,3,4,5}
     //my_list2 is a list of Booleans, only one value in my_list2 can be True.
     //my_list2 = {False, False, True, False, False, False}.
     result = oneHotSelect (my_list2, my_list1));
```

Create a list by removing the initial segment of a list that meets a predicate.

```
//the predicate function is a < 2
function Bool lessthan2 (Int #(4) a);
    return (a < 2);
endfunction

//my_list1 = {0,1,2,0,1,7,8}

List #(Int #(4)) my_result = (dropWhile(lessthan2, my_list1));

//my_result = {2,0,1,7,8}</pre>
```

C.4.3 List to List Functions

rotate	Move the first element to the last and shift each element to the next higher index.
	<pre>function List#(element_type) rotate (List#(element_type) alist);</pre>
rotateR	Move last element to the beginning and shift each element to the next lower index.
	<pre>function List#(element_type) rotateR (List#(element_type) alist);</pre>
reverse	Reverse element order
	<pre>function List#(element_type) reverse(List#(element_type) alist);</pre>
transpos	e Matrix transposition of a list of lists.
	<pre>function List#(List#(element_type)) transpose (List#(List#(element_type)) matrix);</pre>
	- ·
sort	Uses the ordering defined for the element_type data type to return a list in ascending order. The type element_type must be in the Ord type class.
	<pre>function List#(element_type) sort(List#(element_type) alist)</pre>

provisos(Ord#(element_type));

sortBy

Generalizes the sort function to use an arbitrary ordering function defined by the comparison function comparef in place of the Ord instance for element_type.

group

Returns a list of the contiguous subsequences of equal elements (according to the Eq instance for element_type) found in its input list. Every element in the input list will appear in exactly one sublist of the result. Every sublist will be a non-empty list of equal elements. For any list, x, concat(group(x)) == x.

```
function List#(List#(element_type)) group (List#(element_type) alist)
  provisos(Eq#(element_type));
```

groupBy

Generalizes the group function to use an arbitrary equivalence relation defined by the comparison function eqf in place of the Eq instance for element_type.

Examples - List to List Functions

Create a list by moving the last element to the first, then shifting each element to the right.

Use sort to create a new list

```
//my_list1 has the values: {3,2,5,4,1}

my_list2 = sort(my_list1);

//my_list2 has the values: {1,2,3,4,5}

Use group to create a list of lists

//my_list1 is a list of elements {Mississippi}

my_list2 = group(my_list1);

//my_list2 is a list of lists:
{{M},{i},{ss},{i},{ss},{i},{pp},{i}}
```

C.4.4 Tests on Lists

== !=	Lists can be compared for equality if the elements in the list can be compared.
	<pre>instance Eq #(List#(element_type)) provisos(Eq#(element_type)) ;</pre>
elem	Check if a value is an element in a list.
	<pre>function Bool elem (element_type x, List#(element_type) alist) proviso (Eq#(element_type));</pre>
length	Determine the length of a list. Can be done at elaboration time only.
	<pre>function Integer length (List#(element_type) alist);</pre>
any	Test if a predicate holds for any element of a list.
	<pre>function Bool any(function Bool pred(element_type x1),</pre>
all	Test if a predicate holds for all elements of a list.
	<pre>function Bool all(function Bool pred(element_type x1),</pre>

or	Combine all elements in a Boolean list with a logical or. Returns True if any elements in the list are True.
	<pre>function Bool or (List# (Bool) bool_list);</pre>
and	Combine all elements in a Boolean list with a logical and. Returns True if all elements in the list are true.
	function Bool and (List# (Bool) bool_list);

Examples - Tests on Lists

```
Test that all elements of the list my_list1 are positive integers
     function Bool isPositive (Int #(32) a);
          return (a > 0)
     endfunction
    // function isPositive checks that "a" is a positive integer
    // if my_list1 has n elements, n instances of the predicate
    // function isPositive will be generated.
     if (all(isPositive, my_list1))
        $display ("List contains all negative values");
Test if any elements in the list are positive integers.
    // function isPositive checks that "a" is a positive integer
    // if my_list1 has n elements, n instances of the predicate
    // function isPositive will be generated.
     if (any(pos, my_list1))
        $display ("List contains some negative values");
Check if the integer 5 is in my_list
    // if my_list contains n elements, elem will generate n copies
    // of the eqt Test
    if (elem(5,my_list))
        $display ("List contains the integer 5");
```

C.4.5 Combining Lists with Zip Functions

The family of zip functions takes two or more lists and combines them into one list of Tuples. Several variations are provided for different resulting Tuples. All variants can handle input lists of different sizes. The resulting lists will be the size of the smallest list.

```
zip3
             Combine 3 lists into a list of Tuple3.
            function List#(Tuple3 #(a_type, b_type, c_type))
                      zip3( List#(a_type) lista,
                             List#(b_type) listb,
                             List#(c_type) listc);
zip4
             Combine 4 lists into a list of Tuple4.
            function List#(Tuple4 #(a_type, b_type, c_type, d_type))
                      zip4( List#(a_type) lista,
                             List#(b_type) listb,
                             List#(c_type) listc,
                             List#(d_type) listd);
            Separate a list of pairs (i.e. a Tuple2#(a,b)) into a pair of two lists.
unzip
            function Tuple2#(List#(a_type), List#(b_type))
                      unzip(List#(Tuple2 #(a_type, b_type)) listab);
```

Examples - Combining Lists with Zip

```
Combine two lists into a list of Tuples
    //my_list1 is a list of elements {0,1,2,3,4,5,6,7}
    //my_list2 is a list of elements {True,False,True,True,False}

my_list3 = zip(my_list1, my_list2);

//my_list3 is a list of Tuples {(0,True),(1,False),(2,True),(3,True),(4,False)}

Separate a list of pairs into a Tuple of two lists

//my_list is a list of pairs {(0,5),(1,6),(2,7),(3,8),(4,9)}

Tuple2#(List#(Int#(5)),List#(Int#(5))) my_list2 = unzip(my_list);

//my_list2 is ({0,1,2,3,4},{5,6,7,8,9})
```

C.4.6 Mapping Functions over Lists

A function can be applied to all elements of a list, using high-order functions such as map. These functions take as an argument a function, which is applied to the elements of the list.

```
Map a function over a list, returning a new list of results.

function List#(b_type) map (function b_type func(a_type),
List#(a_type) alist);
```

Example - Mapping Functions over Lists

Consider the following code example which applies the extend function to each element of alist creating a new list, resultlist.

```
List#(Bit#(5)) alist;
List#(Bit#(10)) resultlist;
...
resultlist = map( extend, alist );

This is equivalent to saying:
   for (Integer i=0; i<13; i=i+1)
        resultlist[i] = extend(alist[i]);

Map a negate function over a list
        //my_list1 is a list of 5 elements {0,1,2,3,4}
        //negate is a function which makes each element negative
        List #(Int #(32)) my_list2 = map (negate, my_list1);
        //my_list2 is a list of 5 elements {0,-1,-2,-3,-4}</pre>
```

C.4.7 ZipWith Functions

The zipWith functions combine two or more lists with a function and generate a new list. These functions combine features of map and zip functions.

Combine four lists with a function. The lists do not have to have the same number of elements. function List#(e_type) zipWith4 (function e_type func(a_type x, b_type y, c_type z, d_type w), List#(a_type) listx, List#(b_type) listy, List#(c_type) listz List#(d_type) listz List#(d_type) listw);

Examples - ZipWith

Create a list by applying a function over the elements of 3 lists.

```
//the function add3 adds 3 values
function Int#(8) add3 (Int #(8) a,Int #(8) b,Int #(8) c);
    Int#(8) d = a + b + c ;
    return(d);
endfunction
//Create the list my_list4 by adding the ith element of each of
//3 lists (my_list1, my_list2, my_list3) to generate the ith
//element of my_list4.
//my_list1 = \{0,1,2,3,4\}
//my_list2 = \{5,6,7,8,9\}
//my_list3 = \{10,11,12,13,14\}
List #(Int #(8)) my_list4 = zipWith3(add3, my_list1, my_list2, my_list3);
//my_list4 = \{15,18,21,24,27\}
// This is equivalent to saying:
   for (Integer i=0; i<5; i=i+1)</pre>
      my_list4[i] = my_list1[i] + my_list2[i] + my_list3[i];
```

C.4.8 Fold Functions

The fold family of functions reduces a list to a single result by applying a function over all its elements. That is, given a list of element_type, $L_0, L_1, L_2, ..., L_{n-1}$, a seed of type b_type, and a function func, the reduction for foldr is given by

```
func(L_0, func(L_1, ..., func(L_{n-2}, func(L_{n-1}, seed))));
```

Note that foldr start processing from the highest index position to the lowest, while foldl starts from the lowest index (zero), i.e.,

```
func(...(func(func(seed, L_0), L_1), ...)L_{n-1})
```

foldr	Reduce a list by applying a function over all its elements. Start processing from the highest index to the lowest.
	<pre>function b_type foldr(b_type function func(a_type x, b_type y),</pre>
foldl	Reduce a list by applying a function over all its elements. Start processing from the lowest index (zero).
	<pre>function b_type foldl (b_type function func(b_type y, a_type x),</pre>

The functions foldr1 and foldl1 use the first element as the seed. This means they only work on lists of at least one element. Since the result type will be the same as the element type, there is no b_type as there is in the foldr and foldl functions.

foldr1	foldr function for a non-zero sized list. Uses element L_{n-1} as the seed. List must have at least 1 element.
	<pre>function element_type foldr1 (element_type function func(element_type x, element_type y), List#(element_type) alist);</pre>
foldl1	fold1 function for a non-zero sized list. Uses element L_0 as the seed. List must have at least 1 element.
	<pre>function element_type foldl1 (element_type function func(element_type y, element_type x), List#(element_type) alist);</pre>

The fold function also operates over a non-empty list, but processing is accomplished in a binary tree-like structure. Hence the depth or delay through the resulting function will be $O(log_2(lsize)$ rather than O(lsize).

fold	fold	Reduce a list by applying a function over all its elements, using a binary tree-like structure. The function returns the same type as the arguments.
		<pre>function element_type fold (element_type function func(element_type y, element_type x), List#(element_type) alist);</pre>

```
joinActions

Join a number of actions together.

function Action joinActions (List#(Action) list_actions);

joinRules

Join a number of rules together.

function Rules joinRules (List#(Rules) list_rules);

mapPairs

Map a function over a list consuming two elements at a time. Any straggling element is processed by the second function.

function List#(b_type)
    mapPairs (
    function b_type func1(a_type x, a_type y),
    function b_type func2(a_type x),
    List#(a_type) alist);
```

Example - Folds

```
// my_list1 is a list of five integers {1,2,3,4,5}
// \+ is a function which returns the sum of the elements
my_sum = foldr (\+ , 0, my_list1));
// my_sum = 15

Use fold to find the element with the maximum value
// my_list1 is a list of five integers {2,45,5,8,32}
my_max = fold (max, my_list1);
// my_max = 45
```

Create a new list using mapPairs. The function sum is applied to each pair of elements (the first and second, the third and fourth, etc.). If there is an uneven number of elements, the function pass is applied to the remaining element.

```
//sum is defined as c = a+b
function Int#(4) sum (Int #(4) a,Int #(4) b);
    Int#(4) c = a + b;
        return(c);
endfunction

//pass is defined as a
function Int#(4) pass (Int #(4) a);
        return(a);
endfunction

//my_list1 has the elements {0,1,2,3,4}
```

```
my_list2 = mapPairs(sum,pass,my_list1);
//my_list2 has the elements {1,5,4}
//my_list2[0] = 0 + 1
//my_list2[1] = 2 + 3
//my_list2[3] = 4
```

C.4.9 Scan Functions

The scan family of functions applies a function over a list, creating a new List result. The scan function is similar to fold, but the intermediate results are saved and returned in a list, instead of returning just the last result. The result of a scan function is a list. That is, given a list of element_type, $L_0, L_1, ..., L_{n-1}$, an initial value initb of type b_type, and a function func, application of the scanr functions creates a new list W, where

```
\begin{array}{rcl} W_n & = & init; \\ W_{n-1} & = & func(L_{n-1}, W_n); \\ W_{n-2} & = & func(L_{n-2}, W_{n-1}); \\ & \cdots \\ W_1 & = & func(L_1, W_2); \\ W_0 & = & func(L_0, W_1); \end{array}
```

scanr

Apply a function over a list, creating a new list result. Processes elements from the highest index position to the lowest, and fills the resulting list in the same way. The result list is one element longer than the input list.

```
function List#(b_type)
     scanr(function b_type func(a_type x1, b_type x2),
          b_type initb,
          List#(a_type) alist);
```

sscanr

Apply a function over a list, creating a new list result. The elements are processed from the highest index position to the lowest. Drops the W_n element from the result. Input and output lists are the same size.

The scanl function creates the resulting list in a similar way as scanr except that the processing happens from the zeroth element up to the nth element.

```
W_0 = init;

W_1 = func(W_0, L_0);
```

```
W_2 = func(W_1, L_1);
...
W_{n-1} = func(W_{n-2}, L_{n-2});
W_n = func(W_{n-1}, L_{n-1});
```

The sscanl function drops the first result, *init*, shifting the result index by one.

```
Apply a function over a list, creating a new list result. Processes elements from
scanl
             the zeroth element up to the nth element. The result list is 1 element longer than
             the input list.
             function List#(a_type)
                       scanl(function a_type func(a_type x1, b_type x2),
                              a_type inita,
                             List#(b_type) alist);
sscanl
             Apply a function over a list, creating a new list result. Processes elements from
             the zeroth element up to the nth element. Drop the first result, init, shifting the
             result index by one. The length of the input and output lists are the same.
             function List#(a_type)
                       sscanl(function a_type func(a_type x1, b_type x2),
                              a_type inita,
                              List#(b) alist );
mapAccumL
             Map a function, but pass an accumulator from head to tail.
             function Tuple2 #(a_type, List#(c_type))
                       mapAccumL (function Tuple2 #(a_type, c_type)
                                   func(a_type x, b_type y),a_type x0,
                                   List#(b_type) alist );
mapAccumR
             Map a function, but pass an accumulator from tail to head.
             function Tuple2 #(a_type, List#(c_type))
                       mapAccumR(function Tuple2 #(a_type, c_type)
                                  func(a_type x, b_type y),a_type x0,
                                  List#(b_type) alist );
```

Examples - Scan

Create a list of factorials

```
//the function my_mult multiplies element a by element b
function Bit #(16) my_mult (Bit #(16) b, Bit #(8) a);
  return (extend (a) * b);
```

endfunction // Create a list of factorials by multiplying each input list element // by the previous product (the output list element), to generate // the next product. The seed is a Bit#(16) with a value of 1. // The elements are processed from the zeroth element up to the nth element. //my_list1 = {1,2,3,4,5,6,7} List #(Bit #(16)) my_list2 = scanl (my_mult, 16'd1, my_list1);

C.4.10 Monadic Operations

 $//my_list2 = \{1,1,2,6,24,120,720,5040\}$

Within Bluespec, there are some functions which can only be invoked in certain contexts. Two common examples are: ActionValue, and module instantiation. ActionValues can only be invoked within an Action context, such as a rule block or an Action method, and can be considered as two parts - the action and the value. Module instantiation can similarly be considered, modules can only be instantiated in the module context, while the two parts are the module instantiation (the action performed) and the interface (the result returned). These situations are considered monadic.

When a monadic function is to be applied over a list using map-like functions such as map, zipWith, or replicate, the monadic versions of these functions must be used. Moreover, the context requirements of the applied function must hold.

```
Takes a monadic function and a list, and applies the function to all list elements
mapM
             returning the list of corresponding results.
             function m#(List#(b_type))
                       mapM ( function m#(b_type) func(a_type x),
                                List#(a_type) alist )
                 provisos (Monad#(m));
             Takes a monadic function and a list, applies the function to all list elements, and
mapM_{-}
             throws away the resulting list leaving the action in its context.
             function m#(List#(b_type) mapM_(m#(b_type) c_type)
               provisos (Monad#(m));
zipWithM
             Take a monadic function (which takes two arguments) and two lists; the function
             applied to the corresponding element from each list would return an action and
             result. Perform all those actions and return the list of corresponding results.
             function m#(List#(c_type))
                       zipWithM( function m#(c_type) func(a_type x, b_type y),
                                   List#(a_type) alist,
                                   List#(b_type) blist )
               provisos (Monad#(m));
```

zipWith3M Same as zipWithM but combines three lists with a function. The function is applied to the corresponding element from each list and returns an action and the list of corresponding results. function m#(List#(d_type)) zipWith3M(function m#(d_type) func(a_type x, b_type y, c_type z), List#(a_type) alist , List#(b_type) blist, List#(c_type) clist) provisos (Monad#(m)); Generate a list of elements by using the given monadic value repeatedly. replicateM function m#(List#(element_type)) replicateM(Integer n, m#(element_type) c) provisos (Monad#(m));

C.5 Math

C.5.1 Real

Package

```
import Real :: *;
```

Description

The Real library package defines functions to operate on and manipulate real numbers. Real numbers are numbers with a fractional component. They are also of limited precision. The Real data type is described in section B.2.6.

Constants

The constant $pi(\pi)$ is defined.

pi	The value of the constant pi (π) .
	Real pi;

Trigonometric Functions

The following trigonometric functions are provided: sin, cos, tan, sinh, cosh, tanh, asin, acos, atan, asinh, acosh, atanh, and atan2.

sin	Returns the sine of x.
	function Real sin (Real x);

cos	Returns the cosine of x.
	function Real cos (Real x);
tan	Returns the tangent of x.
	function Real tan (Real x);
sinh	Returns the hyperbolic sine of x.
	function Real sinh (Real x);
cosh	Returns the hyperbolic cosine of x.
	function Real cosh (Real x);
tanh	Returns the hyperbolic tangent of x.
	function Real tanh (Real x);
asinh	Returns the inverse hyperbolic sine of x .
	<pre>function Real asinh (Real x);</pre>
acosh	Returns the inverse hyperbolic cosine of x.
	function Real acosh (Real x);

atanh	Returns the inverse hyperbolic tangent of x.
	function Real atanh (Real x);

atan2	Returns $atan(x/y)$. $atan2(1,x)$ is equivalent to $atan(x)$, but provides more precision when required by the division of x/y .
	function Real atan2 (Real y, Real x);

Arithmetic Functions

pow	The element x is raised to the y power. An alias for **. $pow(x,y) = x**y = x^y$.
	function Real pow (Real x, Real y);

sqrt	Returns the square root of x. Returns an error if x is negative.
	function Real sqrt (Real x);

Conversion Functions

The following four functions are used to convert a Real to an Integer.

trunc	Converts a Real to an Integer by removing the fractional part of x, which can be positive or negative. trunc(1.1) = 1, trunc(-1.1) = -1.
	function Integer trunc (Real x);

round	Converts a Real to an Integer by rounding to the nearest whole number5 rounds up in magnitude. round(1.5) = 2, round(-1.5)= -2.	
		function Integer round (Real x);

ceil	Converts a Real to an Integer by rounding to the higher number, regardless of sign. ceil(1.1) = 2, ceil(-1.1) = -1.
	function Integer ceil (Real x);

floor	Converts a Real to an Integer by rounding to the lower number, regardless of sign. floor(1.1) = 1, floor(-1.1) = -2.
	function Integer floor (Real x);

There are also two system functions \$realtobits and \$bitstoreal, defined in the Prelude (section B.2.6) which provide conversion to and from IEEE 64-bit vectors (Bit#(64)).

Introspection Functions

isInfinite	Returns True if the value of x is infinite, False if x is finite.
	<pre>function Bool isInfinite (Real x);</pre>

isNegativeZero	Returns True if the value of x is negative zero.
	function Bool isNegativeZero (Real x);

splitReal	Returns a Tuple containing the whole (n) and fractional (f) parts of x such that $n + f = x$. Both values have the same sign as x. The absolute value of the fractional part is guaranteed to be in the range $[0,1)$.
	<pre>function Tuple2#(Integer, Real) splitReal (Real x);</pre>

decodeReal	Returns a Tuple3 containing the sign, the fraction, and the exponent of a real number. The second part (the first Integer) represents the fractional part as a signed Integer value. This can be converted to an Int#(54) (52 bits, plus hidden bit, plus the sign bit). The last value is a signed Integer representing the exponent, which can be be converted to an Int#(11). The real number is represented exactly as $(fractional \times 2^{exp})$. The Bool represents the sign and is True for positive and positive zero, False for negative and negative zero. Since the second value is a signed value, the Bool is redundant except for zero values.
	function Tuple3#(Bool, Integer, Integer) decodeReal (Real x);

C.5.2 Complex

Package

```
import Complex :: *;
```

Description

The Complex package provides a representation for complex numbers plus functions to operate on variables of this type. The basic representation is the Complex structure, which is polymorphic on the type of data it holds. For example, one can have complex numbers of type Int or of type FixedPoint. A Complex number is represented in two part, the real part (rel) and the imaginary part (img). These fields are accessible though standard structure addressing, i.e., foo.rel and foo.img where foo is of type Complex.

```
typedef struct {
        any_t rel;
        any_t img;
        } Complex#(type any_t)
deriving ( Bits, Eq );
```

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Types and type classes

The Complex type belongs to the Arith, Literal, SaturatingArith, and FShow type classes. Each type class definition includes functions which are then also defined for the data type. The Prelude library definitions (Section B) describes which functions are defined for each type class.

Type Classes used by Complex									
	Bits	Eq	Literal	Arith	Ord	Bounded	Bit	Bit	Bit
							wise	Reduction	Extend
Complex			√						

Arith The type Complex belongs to the Arith type class, hence the common infix operators (+, -, *, and /) are defined and can be used to manipulate variables of type Complex. The remaining arithmetic operators are not defined for the Complex type. Note however, that some functions generate more hardware than may be expected. The complex multiplication (*) produces four multipliers in a combinational function; some other modules could accomplish the same function with less hardware but with greater latency. The complex division operator (/) produces 6 multipliers, and a divider and may not always be synthesizable with downstream tools.

```
instance Arith#( Complex#(any_type) )
    provisos( Arith#(any_type) );
```

Literal The Complex type is a member of the Literal class, which defines a conversion from the compile-time Integer type to Complex type with the fromInteger function. This function converts the Integer to the real part, and sets the imaginary part to 0.

```
instance Literal#( Complex#(any_type) )
  provisos( Literal#(any_type) );
```

SaturatingArith The SaturatingArith class provides the functions satPlus, satMinus, boundedPlus, and boundedMinus. These are modified plus and minus functions which saturate to values defined by the SaturationMode when the operations would otherwise overflow or wrap-around. The type of the complex value (any_type) must be in the SaturatingArith class.

```
instance SaturatingArith#(Complex#(any_type))
provisos (SaturatingArith#(any_type));
```

FShow The **FShow** class provides the function **fshow** which can be applied to a type to create an associated **Fmt** representation.

```
instance FShow#(Complex#(a))
  provisos (FShow#(a));
```

Functions

cmplx	A simple constructor function is provided to set the fields.	
	<pre>function Complex#(a_type) cmplx(a_type realA, a_type imagA);</pre>	

```
Applies a function to each part of the complex structure. This is useful for operations such as extend, truncate, etc.

function Complex#(b_type) cmplxMap(
function b_type mapFunc(a_type x),
Complex#(a_type) cin );
```

```
Displays a complex number given a prefix string, an infix string, a postscript string, and an Action function which writes each part. cmplxWrite is of type Action and can only be invoked in Action contexts such as Rules and Actions methods.

function Action cmplxWrite(String pre,
String infix,
String post,
function Action writeaFunc(a_type x),
Complex#(a_type) cin);
```

Examples - Complex Numbers

```
// The following utility function is provided for writing data
// in decimal format. An example of its use is show below.

function Action writeInt( Int#(n) ain );
    $write( "%od", ain );
endfunction

// Set the fields of the complex number using the constructor function cmplx
Complex#(Int#(6)) complex_value = cmplx(-2,7);

// Display complex_value as ( -2 + 7i ).

// Note that writeInt is passed as an argument to the cmplxWrite function.
cmplxWrite( "( ", " + ", "i)", writeInt, complex_value );

// Swap the real and imaginary parts.
swap_value = cmplxSwap( complex_value );

// Display the swapped values. This will display ( -7 + 2i).
cmplxWrite( "( ", " + ", "i)", writeInt, swap_value );
```

C.5.3 FixedPoint

Package

```
import FixedPoint :: * ;
```

Description

The FixedPoint library package defines a type for representing fixed-point numbers and corresponding functions to operate and manipulate variables of this type.

A fixed-point number represents signed numbers which have a fixed number of binary digits (bits) before and after the binary point. The type constructor for a fixed-point number takes two numeric types as argument; the first (isize) defines the number of bits to the left of the binary point (the integer part), while the second (fsize) defines the number of bits to the right of the binary point, (the fractional part).

The following data structure defines this type, while some utility functions provide the reading of the integer and fractional parts.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Types and type classes

The FixedPoint type belongs to the following type classes; Bits, Eq, Literal, RealLiteral, Arith, Ord, Bounded, Bitwise, SaturatingArith, and FShow. Each type class definition includes functions which are then also defined for the data type. The Prelude library definitions (Section B) describes which functions are defined for each type class.

Type Classes used by FixedPoint										
Bits Eq Literal Real Arith Ord Bounded Bit Bit Bit									Bit	
				Literal				wise	Reduce	Extend
FixedPoint			√	√			√			

Bits The type FixedPoint belongs to the Bits type class, which allows conversion from type Bits to type FixedPoint.

```
instance Bits#(FixedPoint#(isize, fsize), bsize )
provisos (Add#(isize, fsize, bsize));
```

Literal The type FixedPoint belongs to the Literal type class, which allows conversion from (compile-time) type Integer to type FixedPoint. Note that only the integer part is assigned.

```
instance Literal#( FixedPoint#(isize, fsize) )
  provisos( Add#(isize, fsize, bsize) );
```

RealLiteral The type FixedPoint belongs to the RealLiteral type class, which allows conversion from type Real to type FixedPoint.

```
instance RealLiteral#( FixedPoint# (isize, fsize) )
```

Example:

```
FixedPoint#(4,10) mypi = 3.1415926; //Implied fromReal
FixedPoint#(2,14) cx = fromReal(cos(pi/4));
```

Arith The type FixedPoint belongs to the Arith type class, hence the common infix operators (+, -, *, and /) are defined and can be used to manipulate variables of type FixedPoint. The arithmetic operator % is not defined.

```
instance Arith#( FixedPoint#(isize, fsize) )
  provisos( Add#(isize, fsize, bsize) );
```

For multiplication (*) and quotient (/), the operation is calculated in full precision and the result is then rounded and saturated to the resulting size. Both operators use the rounding function fxptTruncateRoundSat, with mode Rnd_Zero, Sat_Bound.

Ord In addition to equality and inequality comparisons, FixedPoint variables can be compared by the relational operators provided by the Ord type class. i.e., <, >, <=, and >=.

```
instance Ord#( FixedPoint#(isize, fsize) )
  provisos( Add#(isize, fsize, bsize) );
```

Bounded The type FixedPoint belongs to the Bounded type class. The range of values, v, representable with a signed fixed-point number of type FixedPoint#(isize, fsize) is $+(2^{isize-1} - 2^{-fsize}) \le v \le -2^{isize-1}$. The function epsilon returns the smallest representable quantum by a specific type, 2^{-fsize} . For example, a variable v of type FixedPoint#(2,3) type can represent numbers from 1.875 $(1\frac{7}{8})$ to -2.0 in intervals of $\frac{1}{8} = 0.125$, i.e. epsilon is 0.125. The type FixedPoint#(5,0) is equivalent to Int#(5).

```
instance Bounded#( FixedPoint#(isize, fsize) )
  provisos( Add#(isize, fsize, bsize) );
```

epsilon	Returns the value of epsilon which is the smallest representable
	quantum by a specific type, $2^{-f size}$.
	<pre>function FixedPoint#(isize, fsize) epsilon ();</pre>

Bitwise Left and right shifts are provided for FixedPoint variables as part of the Bitwise type class. Note that the shift right (>>) function does an arithmetic shift, thus preserving the sign of the operand. Note that a right shift of 1 is equivalent to a division by 2, except when the operand is equal to -epsilon. The functions msb and lsb are also provided. The other methods of Bitwise type class are not provided since they have no operational meaning on FixedPoint variables; the use of these generates an error message.

```
instance Bitwise#( FixedPoint#(isize, fsize) )
  provisos( Add#(isize, fsize, bsize) );
```

SaturatingArith The SaturatingArith class provides the functions satPlus, satMinus, boundedPlus, and boundedMinus. These are modified plus and minus functions which saturate to values defined by the SaturationMode when the operations would otherwise overflow or wrap-around.

```
instance SaturatingArith#(FixedPoint#(isize, fsize));
```

FShow The FShow class provides the function fshow which can be applied to a type to create an associated Fmt representation.

instance FShow#(FixedPoint#(i,f));

Functions

Utility functions are provided to extract the integer and fractional parts.

fxptGetInt	Extracts the integer part of the FixedPoint number.
	<pre>function Int#(isize) fxptGetInt (FixedPoint#(isize, fsize) x);</pre>

```
fxptGetFrac Extracts the fractional part of the FixedPoint number.

function UInt#(fsize) fxptGetFrac ( FixedPoint#(isize, fsize) x );
```

To convert run-time Int and UInt values to type FixedPoint, the following conversion functions are provided. Both of these functions invoke the necessary extension of the source operand.

```
fromInt
Converts run-time Int values to type FixedPoint.

function FixedPoint#(ir,fr) fromInt( Int#(ia) inta )
    provisos ( Add#(ia, xxA, ir ) ); // ir >= ia
```

Non-integer compile time constants may be specified by a rational number which is a ratio of two integers. For example, one-third may be specified by fromRational(1,3).

At times, full precision Arithmetic functions may be required, where the operands are not the same type (sizes), as is required for the infix Arith operators. These functions do not overflow on the result.

fxptTruncate is a general truncate function which converts variables to FixedPoint#(ai,af) to type FixedPoint#(ri,rf), where $ai \ge ri$ and $af \ge rf$. This function truncates bits as appropriate from the most significant integer bits and the least significant fractional bits.

Two saturating fixed-point truncation functions are provided: fxptTruncateSat and fxptTruncateRoundSat. They both use the SaturationMode, defined in Section B.1.12, to determine the final result.

```
typedef enum { Sat_Wrap
    ,Sat_Bound
    ,Sat_Zero
    ,Sat_Symmetric
} SaturationMode deriving (Bits, Eq);
```

```
A saturating fixed point truncation. If the value cannot be represented in its truncated form, an alternate value, minBound or maxBound, is selected based on smode.

function FixedPoint#(ri,rf) fxptTruncateSat (
SaturationMode smode, FixedPoint#(ai,af) din)
provisos (Add#(ri,idrop,ai)
,Add#(rf,_f,af));
```

The function fxptTruncateRoundSat rounds the saturated value, as determined by the value of rmode of type RoundMode. The rounding only applies to the truncation of the fractional component of the fixed-point number, though it may cause a wrap or overflow to the integer component which requires saturation.

```
A saturating fixed point truncate function which rounds the truncated fractional component as determined by the value of rmode (RoundMode). If the final value cannot be represented in its truncated form, the minBound or maxBound value is returned.

function FixedPoint#(ri,rf) fxptTruncateRoundSat

(RoundMode rmode, SaturationMode smode,

FixedPoint#(ai,af) din)

provisos (Add#(ri,idrop,ai)

,Add#(rf,fdrop,af));
```

```
typedef enum {
          Rnd_Plus_Inf
          ,Rnd_Zero
          ,Rnd_Minus_Inf
          ,Rnd_Inf
          ,Rnd_Conv
          ,Rnd_Truncate
          ,Rnd_Truncate_Zero
} RoundMode deriving (Bits, Eq);
```

These modes are equivalent to the SystemC values shown in the table below. The rounding mode determines how the value is rounded when the truncated value is equidistant between two representable values.

	Rounding Modes							
RoundMode	SystemC	Description	Action when truncated value					
	Equivalent		equidistant between values					
Rnd_Plus_Inf	SC_RND	Round to plus infinity	Always increment					
Rnd_Zero	SC_RND_ZERO	Round to zero	Move towards reduced mag-					
			nitude (decrement positive					
			value, increment negative					
			value)					
Rnd_Minus_Inf	SC_RND_MIN_INF	Round to minus infinity	Always decrement					
Rnd_Inf	SC_RND_INF	Round to infinity	Always increase magnitude					
Rnd_Conv	SC_RND_CONV	Round to convergence	Alternate increment and					
			decrement based on even and					
			odd values					
Rnd_Truncate	SC_TRN	Truncate, no rounding						
Rnd_Truncate_Zero	SC_TRN_ZERO	Truncate to zero	Move towards reduced magni-					
			tude					

Consider what happens when you apply the function fxptTruncateRoundSat to a fixed-point number. The least significant fractional bits are dropped. If the dropped bits are non-zero, the remaining fractional component rounds towards the nearest representable value. If the remaining component is exactly equidistant between two representable values, the rounding mode (rmode) determines whether the value rounds up or down.

The following table displays the rounding value added to the LSB of the remaining fractional component. When the value is equidistant (1/2), the algorithm may be dependent on whether the value of the variable is positive or negative.

Rounding Value added to LSB of Remaining Fractional Component							
RoundMode	7	Value of Truncated		Bits			
	< 1/2	1	/2	> 1/2			
		Pos	Neg				
Rnd_Plus_Inf	0	1	1	1			
Rnd_Zero	0	0	1	1			
Rnd_Minus_Inf	0	0	0	1			
Rnd_Inf	0	1	0	1			
Rnd_Conv							
Remaining $LSB = 0$	0	0	0	1			
Remaining $LSB = 1$	0	1	1	1			

The final two modes are truncates and are handled differently. The Rnd_Truncate mode simply drops the extra bits without changing the remaining number. The Rnd_Truncate_Zero mode decreases the magnitude of the variable, moving the value closer to 0. If the number is positive, the function simply drops the extra bits, if negative, 1 is added.

RoundMode	Sign of A	Argument	Description
	Positive	Negative	
Rnd_Truncate	0	0	Truncate extra bits, no rounding
Rnd_Truncate_Zero	0	1	Add 1 to negative number if trun-
			cated bits are non-zero

Example: Truncated values by Round type, where argument is FixedPoint#(2,3) type and result is a FixedPoint#(2,1) type. In this example, we're rounding to the nearest 1/2, as determined by RoundMode.

	Result by RoundMode when SaturationMode = Sat_Wrap										
Argument Round!					ndMoo	de					
Binary	Decimal	Plus_Inf	Zero	Minus_Inf	Inf	Conv	Trunc	Trunc_Zero			
10.001	-1.875	-2.0	-2.0	-2.0	-2.0	-2.0	-2.0	-1.5			
10.110	-1.250	-1.0	-1.0	-1.5	-1.5	-1.0	-1.5	-1.0			
11.101	-0.375	-0.5	-0.5	-0.5	-0.5	-0.5	-0.5	0.0			
00.011	0.375	0.5	0.5	0.5	0.5	0.5	0.0	0.0			
01.001	1.250	1.5	1.0	1.0	1.5	1.0	1.0	1.0			
01.111	1.875	-2.0	-2.0	-2.0	-2.0	-2.0	1.5	1.5			

```
fxptSignExtend A general sign extend function which converts variables of type FixedPoint#(ai,af) to type FixedPoint#(ri,rf), where ai \leq ri and af \leq rf. The integer part is sign extended, while additional 0 bits are added to least significant end of the fractional part.

function FixedPoint#(ri,rf) fxptSignExtend(
	FixedPoint#(ai,af) a)
	provisos( Add#(xxA,ai,ri), // ri >= ai
	Add#(fdiff,af,rf)); // rf >= af
```

Displaying FixedPoint values in a simple bit notation would result in a difficult to read pattern. The following write utility function is provided to ease in their display. Note that the use of this function adds many multipliers and adders into the design which are only used for generating the output and not the actual circuit.

Examples - Fixed Point Numbers

A Real value can automatically be converted to a FixedPoint value:

```
FixedPoint#(3,10) foo = 2e-3;
FixedPoint#(2,3) x = 1.625;
```

C.5.4 OInt

Package

```
import OInt :: *;
```

Description

The OInt#(n) type is an abstract type that can store a number in the range "0..n-1". The representation of a OInt#(n) takes up n bits, where exactly one bit is a set to one, and the others are zero, i.e., it is a *one-hot* decoded version of the number. The reason to use a OInt number is that the select operation is more efficient than for a binary-encoded number; the code generated for select takes advantage of the fact that only one of the bits may be set at a time.

Types and type classes

Definition of OInt

```
typedef ... OInt #(numeric type n) ...;
```

	Type Classes used by OInt									
	Bits Eq Literal Arith Ord Bounded Bit Bit Bit									
							wise	Reduction	Extend	
OInt										

Functions

A binary-encoded number can be converted to an OInt.

toOInt	Converts from a bit-vector in unsigned binary format to an OInt. An out-of-range number gives an unspecified result.
	<pre>function OInt#(n) toOInt(Bit#(k) k) provisos(Log#(n,k)) ;</pre>

An OInt can be converted to a binary-encoded number.

fromOInt	Converts an OInt to a bit-vector in unsigned binary format.
	<pre>function Bit#(k) fromOInt(OInt#(n) o) provisos(Log#(n,k)) ;</pre>

An OInt can be used to select an element from a Vector in an efficient way.

select	The Vector select function, where the type of the index is an
	OInt.
	<pre>function a_type select(Vector#(vsize, a_type) vecta,</pre>

C.5.5 NumberTypes

Package

```
import NumberTypes :: * ;
```

Description

The NumberTypes package defines two new number types for use as index types: BuffIndex and WrapNumber.

A BuffIndex#(sz, ln) is an unsigned integer which wraps around, where sz is the number of bits in its representation and ln is the size of the buffer it is to index. Often sz will be TLog#(ln). BuffIndex is intended to be used as the index type for buffers of arbitrary size. The values of BuffIndex are not ordered; you cannot determine which of two values is ahead of the other because of the wrap-around.

A WrapNumber#(sz) is an unsigned integer which wraps around, where sz is the number of bits in its representation. The range is the entire value space (i.e.2 sz), but should be used in situations where at any time all valid values are in at most half of that space. The ordering of values can be defined taking wrap-around into account, so that the nearer distance apart is used to determine which value is ahead of the other.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Types and type classes

A BuffIndex has two numeric type parameters: the size in bits of the representation (sz), and the length of the buffer it is to index (ln).

```
typedef struct { UInt#(sz) bix; } BuffIndex#(numeric type sz, numeric type ln)
  deriving (Bits, Eq);
```

A WrapNumber#(sz) has a single numeric type parameter, sz, which is the size in bits of the representation.

Both types belong to the Bits, Eq. Arith, and Literal type classes. The WrapNumber type also belongs to the Ord type class. Each type class definition includes functions which are then also defined for the data type. The Prelude library definitions (Section B) describes which functions are defined for each type class.

Type Classes used by BuffIndex and WrapNumber										
Bits Eq Literal Arith Ord Bounded Bit Bit Bit										
							wise	Reduction	Extend	
WrapNumber										
BuffIndex										

Literal Both BuffIndex and WrapNumber belong to the Literal typeclass, which allows conversion from (compile-time) type Integer to these types.

For the BuffIndex type, the fromInteger and inLiteralRange functions are defined as:

```
instance Literal#(BuffIndex#(sz,ln));
  function fromInteger(i) = BuffIndex {bix: fromInteger(i) };
  function inLiteralRange(x,i) = (i>=0 && i < valueof(ln));
endinstance</pre>
```

Arith The type class **Arith** defines the common infix operators. Addition and subtraction are the only meaningful arithmetic operations for **WrapNumber** and **BuffIndex**.

Ord WrapNumber belongs to the Ord typeclass, so values of WrapNumber can be compared by the relational operators <, >, <=, and >=. Since the ordering of WrapNumber types takes into account wrap-around, the nearer distance apart is used to determine which value is ahead of the other.

Functions

Utility functions to convert a BuffIndex to a UInt and for adding and subtracting BuffIndex and UInt values are provided.

unwrapBI	Converts a BuffIndex to a UInt function UInt#(sz) unwrapBI(BuffIndex#(sz,ln) x);
addBIUInt	Adds a UInt to a BuffIndex, returning a BuffIndex function BuffIndex#(sz,ln) addBIUInt(BuffIndex#(sz,ln) bin, UInt#(sz) i);

sbtrctBIUInt	Subtracts a UInt from a BuffIndex, returning a BuffIndex
	<pre>function BuffIndex#(sz,ln) sbtrctBIUInt(BuffIndex#(sz,ln) bin,</pre>

Utility functions to convert between a WrapNumber and a UInt, and a function to add a UInt to a WrapNumber are provided.

wrap	Converts a UInt to a WrapNumber function WrapNumber#(sz) wrap(UInt#(sz) x);				
unwrap	Converts a WrapNumber to a UInt function UInt#(sz) unwrap (WrapNumber#(sz) x);				
addUInt	Adds a UInt to a WrapNumber, returning a WrapNumber function WrapNumber#(sz) addUInt(WrapNumber#(sz) wn,				

C.6 FSM

C.6.1 StmtFSM

Package

```
import StmtFSM :: * ;
```

Description

The StmtFSM package provides a procedural way of defining finite state machines (FSMs) which are automatically synthesized.

First, one uses the Stmt sublanguage to compose the actions of an FSM using sequential, parallel, conditional and looping structures. This sublanguage is within the *expression* syntactic category, i.e., a term in the sublanguage is an expression whose value is of type Stmt. This value can be bound to identifiers, passed as arguments and results of functions, held in static data structures, etc., like any other value. Finally, the FSM can be instantiated into hardware, multiple times if desired, by passing the Stmt value to the module constructor mkFSM. The resulting module interface has type FSM, which has methods to start the FSM and to wait until it completes.

The Stmt sublanguage

The state machine is automatically constructed from the procedural description given in the Stmt definition. Appropriate state counters are created and rules are generated internally, corresponding to the transition logic of the state machine. The use of rules for the intermediate state machine generation ensures that resource conflicts are identified and resolved, and that implicit conditions are properly checked before the execution of any action.

The names of generated rules (which may appear in conflict warnings) have suffixes of the form "1<nn>c<nn>", where the <nn> are line or column numbers, referring to the statement which gave rise to the rule.

A term in the Stmt sublanguage is an expression, introduced at the outermost level by the keywords seq or par. Note that within the sublanguage, if, while and for statements are interpreted as statements in the sublanguage and not as ordinary statements, except when enclosed within action/endaction keywords.

```
seqFsmStmt \mid parFsmStmt
exprPrimary
fsmStmt
                         exprFsmStmt
                         seqFsmStmt
                         parFsmStmt
                         ifFsmStmt
                         while FsmStmt
                         repeatFsmStmt
                         for FsmStmt
                         returnFsmStmt
                         regWrite;
exprFsmStmt
                         expression;
seqFsmStmt
                        seq fsmStmt \{ fsmStmt \} endseq
parFsmStmt
                        par fsmStmt \{ fsmStmt \} endpar
ifFsmStmt
                         if expression fsmStmt
                         [ else fsmStmt ]
whileFsmStmt
                        while ( expression )
                             loopBodyFsmStmt
for FsmStmt
                    ::= for (fsmStmt; expression; fsmStmt)
                             loopBodyFsmStmt
returnFsmStmt
                        return;
repeatFsmStmt
                         repeat ( expression )
                             loopBodyFsmStmt
loopBodyFsmStmt
                         fsmStmt
                         break;
                         continue;
```

The simplest kind of statement is an *exprFsmStmt*, which can be a register assignment or, more generally, any expression of type Action (including action method calls and action-endaction blocks or of type Stmt. Statements of type Action execute within exactly one clock cycle, but of course the scheduling semantics may affect exactly which clock cycle it executes in. For example, if the actions in a statement interfere with actions in some other rule, the statement may be delayed by the schedule until there is no interference. In all the descriptions of statements below, the descriptions of time taken by a construct are minimum times; they could take longer because of scheduling semantics.

Statements can be composed into sequential, parallel, conditional and loop forms. In the sequential form (seq-endseq), the contained statements are executed one after the other. The seq block terminates when its last contained statement terminates, and the total time (number of clocks) is equal to the sum of the individual statement times.

In the parallel form (par-endpar), the contained statements ("threads") are all executed in parallel. Statements in each thread may or may not be executed simultaneously with statements in other threads, depending on scheduling conflicts; if they cannot be executed simultaneously they will be

interleaved, in accordance with normal scheduling. The entire par block terminates when the last of its contained threads terminates, and the minimum total time (number of clocks) is equal to the maximum of the individual thread times.

In the conditional form (if (b) s_1 else s_2), the boolean expression b is first evaluated. If true, s_1 is executed, otherwise s_2 (if present) is executed. The total time taken is t cycles, if the chosen branch takes t cycles.

In the while (b) s loop form, the boolean expression b is first evaluated. If true, s is executed, and the loop is repeated. Each time the condition evaluates true, the loop body is executed, so the total time is $n \times t$ cycles, where n is the number of times the loop is executed (possibly zero) and t is the time for the loop body statement.

The for $(s_1;b;s_2)$ s_B loop form is equivalent to:

```
s_1; while (b) seq s_B; s_2 endseq
```

i.e., the initializer s_1 is executed first. Then, the condition b is executed and, if true, the loop body s_B is executed followed by the "increment" statement s_2 . The b, s_B , s_2 sequence is repeated as long as b evaluates true.

Similarly, the repeat (n) s_B loop form is equivalent to:

```
while (repeat\_count < n) seq s_B; repeat\_count <= repeat\_count + 1 endseq
```

where the value of $repeat_count$ is initialized to 0. During execution, the condition ($repeat_count < n$) is executed and, if true, the loop body s_B is executed followed by the "increment" statement $repeat_count <= repeat_count + 1$. The sequence is repeated as long as $repeat_count < n$ evaluates true

In all the loop forms, the loop body statements can contain the keywords continue or break, with the usual semantics, i.e., continue immediately jumps to the start of the next iteration, whereas break jumps out of the loop to the loop sequel.

It is important to note that this use of loops, within a Stmt context, expresses time-based (temporal) behavior.

Interfaces and Methods

Two interfaces are defined with this package, FSM and Once. The FSM interface defines a basic state machine interface while the Once interface encapsulates the notion of an action that should only be performed once. A Stmt value can be instatiated into a module that presents an interface of type FSM.

There is a one clock cycle delay after the start method is asserted before the FSM starts. This insulates the start method from many of the FSM schedule constraints that change depending on what computation is included in each specific FSM. Therefore, it is possible that the StmtFSM is enabled when the start method is called, but not on the next cycle when the FSM actually starts. In this case, the FSM will stall until the conditions allow it to continue.

Interfaces			
Name	Description		
FSM	The state machine interface		
Once	Used when an action should only be performed once		

• FSM Interface

The FSM interface provides four methods; start, waitTillDone, done and abort. Once instantiated, the FSM can be started by calling the start method. One can wait for the FSM to

stop running by waiting explicitly on the boolean value returned by the done method. Alternatively, one can use the waitTillDone method in any action context (including from within another FSM), which (because of an implicit condition) cannot execute until this FSM is done. The user must not use waitTillDone until after the FSM has been started because the FSM comes out of a reset as done. The abort method immediately exits the execution of the FSM.

```
interface FSM;
  method Action start();
  method Action waitTillDone();
  method Bool done();
  method Action abort();
endinterface: FSM
```

FSM Interface					
	Methods				
Name	Name Type Description				
start	Action Begins state machine execution. This can only be called				
	when the state machine is not executing.				
waitTillDone	one Action Does not do any action, but is only ready when the state				
machine is done.					
done	Bool	Asserted when the state machine is done and is ready to			
		rerun.			
abort	Action	Exits execution of the state machine.			

• Once Interface

The Once interface encapsulates the notion of an action that should only be performed once. The start method performs the action that has been encapuslated in the Once module. After start has been called start cannot be called again (an implicit condition will enforce this). If the clear method is called, the start method can be called once again.

```
interface Once;
  method Action start();
  method Action clear();
  method Bool done();
endinterface: Once
```

Once Interface				
	Methods			
Name	Name Type Description			
start	Action	Performs the action that has been encapsulated in the		
		Once module, but once start has been called it cannot		
		be called again (an implicit condition will enforce this).		
clear	Action	If the clear method is called, the start method can be		
		called once again.		
done	Bool	Asserted when the state machine is done and is ready to		
		rerun.		

Modules

Instantiation is performed by passing a Stmt value into the module constructor mkFSM. The state machine is automatically constructed from the procedural decription given in the definition described by state machine of type Stmt named seq_stmt. During construction, one or more registers of appropriate widths are created to track state execution. Upon start action, the registers are loaded and subsequent state changes then decrement the registers.

```
module mkFSM#( Stmt seq_stmt ) ( FSM );
```

The mkFSMwithPred module is like mkFSM above, except that the module constructor takes an additional boolean argument (the predicate). The predicate condition is added to the condition of each rule generated to create the FSM. This capability is useful when using the FSM in conjuction with other rules and/or FSMs. It allows the designer to explicitly specify to the compiler the conditions under which the FSM will run. This can be used to eliminate spurious rule conflict warnings (between rules in the FSM and other rules in the design).

```
module mkFSMWithPred#( Stmt seq_stmt, Bool pred ) ( FSM );
```

The mkAutoFSM module is also like mkFSM above, except the state machine runs automatically immediately after reset and a \$finish(0) is called upon completion. This is useful for test benches. Thus, it has no interface, that is, it has an empty interface.

```
module mkAutoFSM#( seq_stmt ) ();
```

The mkOnce function is used to create a Once interface where the action argument has been encapsulated and will be performed when start is called.

```
module mkOnce#( Action a ) ( Once );
```

The implementation for Once is a 1 bit state machine (with a state register named onceReady) allowing the action argument to occur only one time. The ready bit is initially True and then cleared when the action is performed. It might not be performed right away, because of implicit conditions or scheduling conflicts.

Name	BSV Module Declaration	Description
mkFSM	<pre>module mkFSM#(Stmt seq_stmt)(FSM);</pre>	Instantiate a Stmt value into a module that presents an interface of type FSM.
mkFSMWithPred	<pre>module mkFSMWithPred#(Stmt seq_stmt,</pre>	Like mkFSM, except that the module constructor takes an additional predicate condition as an argument. The predicate condition is added to the condition of each rule generated to create the FSM.
mkAutoFSM	<pre>module mkAutoFSM#(Stmt seq_stmt)();</pre>	Like mkFSM, except that state machine simulation is automatically started and a \$finish(0)) is called upon completion.
mkOnce	<pre>module mkOnce#(Action a)(Once);</pre>	Used to create a Once interface where the action argument has been encap- sulated and will be performed when start is called.

Functions

There are two functions, await and delay, provided by the StmtFSM package.

The await function is used to create an action which can only execute when the condition is True. The action does not do anything. await is useful to block the execution of an action until a condition becomes True.

The delay function is used to execute noAction for a specified number of cycles. The function is provided the value of the delay and returns a Stmt.

Name	Function Declaration	Description
await	function Action await(Bool cond);	Creates an Action which does nothing, but can only execute when the condition is True.
delay	<pre>function Stmt delay(a_type value);</pre>	Creates a Stmt which executes noAction for value number of cycles. a_type must be in the Arith class and Bits class and < 32 bits.

Example - Initializing a single-ported SRAM.

Since the SRAM has only a single port, we can write to only one location in each clock. Hence, we need to express a temporal sequence of writes for all the locations to be initialized.

```
Reg#(int) i <- mkRegU;</pre>
                              // instantiate register with interface i
Reg#(int) j <- mkRegU;</pre>
                              // instantiate register with interface j
// Define fsm behavior
Stmt s = seq
             for (i \le 0; i \le M; i \le i + 1)
                 for (j \le 0; j \le N; j \le j + 1)
                      sram.write (i, j, i+j);
         endseq
FSM fsm();
                    // instantiate FSM interface
mkFSM#(s) (fsm);
                    // create fsm with interface fsm and behavior s
rule initSRAM (start_reset);
    fsm.start:
                   // Start the fsm
endrule
```

When the start_reset signal is true, the rule kicks off the SRAM initialization. Other rules can wait on fsm.done, if necessary, for the SRAM initialization to be completed.

In this example, the seq-endseq brackets are used to enter the Stmt sublanguage, and then for represents Stmt sequencing (instead of its usual role of static generation). Since seq-endseq contains only one statement (the loop nest), par-endpar brackets would have worked just as well.

Example - Defining and instantiating a state machine.

```
import StmtFSM :: *;
import FIFO :: *;
module testSizedFIFO();
```

```
// Instantiation of DUT
 FIFO#(Bit#(16)) dut <- mkSizedFIFO(5);</pre>
 // Instantiation of reg's i and j
 Reg#(Bit#(4))
                  i <- mkRegA(0);</pre>
 Reg#(Bit#(4))
                      j <- mkRegA(0);</pre>
 // Action description with stmt notation
 Stmt driversMonitors =
   (seq
     // Clear the fifo
     dut.clear;
     // Two sequential blocks running in parallel
       // Enque 2 times the Fifo Depth
        for(i <= 1; i <= 10; i <= i + 1)
        seq
          dut.enq({0,i});
          $display(" Enque %d", i);
        endseq
       // Wait until the fifo is full and then deque
       seq
         while (i < 5)
         seq
           noAction;
         endseq
         while (i <= 10)
         action
           dut.deq;
           $display("Value read %d", dut.first);
         endaction
       endseq
     endpar
     $finish(0);
   endseq);
  // stmt instantiation
  FSM test <- mkFSM(driversMonitors);</pre>
   // A register to control the start rule
  Reg#(Bool) going <- mkReg(False);</pre>
  // This rule kicks off the test FSM, which then runs to completion.
  rule start (!going);
      going <= True;</pre>
      test.start;
   endrule
endmodule
```

Example - Defining and instantiating a state machine to control speed changes

```
import StmtFSM::*;
import Common::*;
interface SC_FSM_ifc;
  method Speed xcvrspeed;
  method Bool devices_ready;
  method Bool out_of_reset;
endinterface
module mkSpeedChangeFSM(Speed new_speed, SC_FSM_ifc ifc);
   Speed initial_speed = FS;
  Reg#(Bool) outofReset_reg <- mkReg(False);</pre>
  Reg#(Bool) devices_ready_reg <- mkReg(False);</pre>
  Reg#(Speed) device_xcvr_speed_reg <- mkReg(initial_speed);</pre>
   // the following lines define the FSM using the Stmt sublanguage
   // the state machine is of type Stmt, with the name speed_change_stmt
  Stmt speed_change_stmt =
   (seq
       action outofReset_reg <= False; devices_ready_reg <= False; endaction
      noAction; noAction; // same as: delay(2);
       device_xcvr_speed_reg <= new_speed;</pre>
       noAction; noAction; // same as: delay(2);
       outofReset_reg <= True;</pre>
       if (device_xcvr_speed_reg==HS)
          seq noAction; noAction; endseq
          // or seq delay(2); endseq
       else
          seq noAction; noAction; noAction; noAction; noAction; endseq
         // or seq delay(6); endseq
       devices_ready_reg <= True;</pre>
    endseq);
   // end of the state machine definition
  // the statemachine is instantiated using mkFSM
  FSM speed_change_fsm <- mkFSM(speed_change_stmt);</pre>
  // the rule change_speed starts the state machine
   // the rule checks that previous actions of the state machine have completed
  rule change_speed ((device_xcvr_speed_reg != new_speed || !outofReset_reg) &&
      speed_change_fsm.done);
      speed_change_fsm.start;
   endrule
  method xcvrspeed = device_xcvr_speed_reg;
  method devices_ready = devices_ready_reg;
  method out_of_reset = outofReset_reg;
endmodule
```

Example - Defining a state machine and using the await function

```
// This statement defines this brick's desired behavior as a state machine:
// the subcomponents are to be executed one after the other:
Stmt brickAprog =
  seq
     // Since the following loop will be executed over many clock
     // cycles, its control variable must be kept in a register:
     for (i \le 0; i \le 0-1; i \le i+1)
        // This sequence requests a RAM read, changing the state;
        // then it receives the response and resets the state.
        seq
           action
              // This action can only occur if the state is Idle
              // the await function will not let the statements
              // execute until the condition is met
              await(ramState==Idle);
              ramState <= DesignReading;</pre>
              ram.request.put(tagged Read i);
           endaction
           action
              let rs <- ram.response.get();</pre>
              ramState <= Idle;</pre>
              obufin.put(truncate(rs));
           endaction
        endsea
     // Wait a little while:
     for (i \le 0; i \le 200; i \le i+1)
        action
        endaction
     // Set an interrupt:
     action
        inrpt.set;
     endaction
  endseq
  );
// end of the state machine definition
FSM brickAfsm <- mkFSM#(brickAprog); //instantiate the state machine
// A register to remember whether the FSM has been started:
Reg#(Bool) notStarted();
mkReg#(True) the_notStarted(notStarted);
// The rule which starts the FSM, provided it hasn't been started
// previously and the brick is enabled:
rule start_Afsm (notStarted && enabled);
   brickAfsm.start;
                                    //start the state machine
   notStarted <= False;</pre>
endrule
```

Creating FSM Server Modules

Instantiation of an FSM server module is performed in a manner analogous to that of a standard FSM module constructor (such as mkFSM). Whereas mkFSM takes a Stmt value as an argument, howver, mkFSMServer takes a function as an argument. More specifically, the argument to mkFSMServer is a function which takes an argument of type a and returns a value of type RStmt#(b).

```
module mkFSMServer#(function RStmt#(b) seq_func (a input)) ( FSMServer#(a, b) );
```

The RStmt type is a polymorphic generalization of the Stmt type. A sequence of type RStmt#(a) allows valued return statements (where the return value is of type a). Note that the Stmt type is equivalent to RStmt#(Bit#(0)).

```
typedef RStmt#(Bit#(0)) Stmt;
```

The mkFSMServer module constructor provides an interface of type FSMServer#(a, b).

```
interface FSMServer#(type a, type b);
  interface Server#(a, b) server;
  method Action abort();
endinterface
```

The FSMServer interface has one subinterface of type Server#(a, b) (from the ClientServer package) as well as an Action method called abort; The abort method allows the FSM inside the FSMServer module to be halted if the client FSM is halted.

An FSMServer module is accessed using the callServer function from within an FSM statement block. callServer takes two arguments. The first is the interface of the FSMServer module. The second is the input value being passed to the module.

```
result <- callServer(serv_ifc, value);
```

Note the special left arrow notation that is used to pass the server result to a register (or more generally to any state element with a Reg interface). A simple example follows showing the definition and use of a mkFSMServer module.

Example - Defining and instantiating an FSM Server Module

```
// State elements to provide inputs and store results
Reg#(Bit#(8)) count
                        <- mkReg(0);
Reg#(Bit#(16)) partial <- mkReg(0);</pre>
Reg#(Bit#(16)) result <- mkReg(0);</pre>
// A function which creates a server sequence to scale a Bit#(8)
// input value by and integer scale factor. The scaling is accomplished
// by a sequence of adds.
function RStmt#(Bit#(16)) scaleSeq (Integer scale, Bit#(8) value);
   seq
      partial <= 0;</pre>
      repeat (fromInteger(scale))
            partial <= partial + {0,value};</pre>
         endaction
      return partial;
   endseq;
endfunction
// Instantiate a server module to scale the input value by 3
FSMServer#(Bit#(8), Bit#(16)) scale3_serv <- mkFSMServer(scaleSeq(3));
```

C.7 Connectivity

The packages in this section provide useful components, primarily interfaces, to connect hardware elements in a design.

The basic interfaces, Get and Put are defined in the package GetPut. The typeclass Connectable indicates that two related types can be connected together. The package ClientServer provides interfaces using Get and Put for modules that have a request-response type of interface. The package CGetPut defines a type of the Get and Put interfaces that is implemented with a credit based FIFO.

C.7.1 GetPut

Package

```
import GetPut :: *;
```

Description

A common paradigm between two blocks is the get/put mechanism: one side *gets* or retrieves an item from an interface and the other side *puts* or gives an item to an interface. These types of interfaces are used in *Transaction Level Modeling* or TLM for short. This pattern is so common in system design that BSV provides the GetPut library package for this purpose.

The GetPut package provides basic interfaces to implement the TLM paradigm, along with interface transformer functions and modules to transform to/from FIFO implementations. The ClientServer package in Section C.7.3 defines more complex interfaces based on the Get and Put interfaces to support request-response interfaces. The GetPut package must be imported when using the ClientServer package.

Typeclasses

The GetPut package defines two typeclasses: ToGet and ToPut. The types with instances defined in these typeclasses provide the functions toGet and toPut, used to create associated Get and Put interfaces from these other types.

To Get defines the class to which the function to Get can be applied to create an associated Get interface.

```
typeclass ToGet#(a, b);
  function Get#(b) toGet(a ax);
endtypeclass
```

ToPut defines the class to which the function toPut can be applied to create an associated Put interface.

```
typeclass ToPut#(a, b);
  function Put#(b) toPut(a ax);
endtypeclass
```

Instances of ToGet and ToPut are defined for the following interfaces:

Defined Instances for ToGet and ToPut				
Type (Interface) toGet toPut Comments		Comments		
a	✓		toGet returns value a	
ActionValue#(a)	✓		toGet performs the Action and returns the value	
function Action fn(a)		✓	toPut calls Action function fn with argument a	
Get#(a)	✓		identity function: returns Get#(a)	
Put#(a)		✓	identity function: returns Put#(a)	
Reg#(a)	✓	✓	toGet returns _read, toPut calls _write	
RWire#(a)	✓	✓	toGet returns wget, toPut calls wset	
ReadOnly#(a)	✓	toGet returns _read		
FIFO#(a)	✓	✓	toGet calls deq returns first, toPut calls enq	
FIFOF#(a)	✓	✓	toGet calls deq returns first, toPut calls enq	
SyncFIFOIfc#(a)	✓	✓	toGet calls deq returns first, toPut calls enq	
FIFOLevelIfc#(a)	✓	✓	toGet calls deq returns first, toPut calls enq	
SyncFIFOLevelIfc#(a)	✓	✓	toGet calls deq returns first, toPut calls enq	
FIF0CountIfc#(a)	✓	✓	toGet calls deq returns first, toPut calls enq	
SyncFIFOCountIfc#(a)	✓	✓	toGet calls deq returns first, toPut calls enq	

Example - Using toPut

```
module mkTop (Put#(UInt#(64)));
  Reg#(UInt#(64)) inValue <- mkReg(0);
  Reg#(Bool) startit <- mkReg(True);
  ...
  StimIfc    stim_gen <- mkStimulusGen;
  rule startTb (startit && inValue!=0);
    // Get the value
    let val = inValue;
    stim_gen.start(val);
    startit <= False;
  endrule
    ...
  return (toPut(asReg(inValue)));
endmodule: mkTop</pre>
```

Interfaces and methods

The Get interface defines the get method, similar to a dequeue, which retrieves an item from an interface and removes it at the same time. The Put interface defines the put method, similar to an

enqueue, which gives an item to an interface. Also provided is the GetS interface, which defines separate methods for the dequeue (deq) and retreiving the item (first) from the interface.

You can design your own Get and Put interfaces with implicit conditions on the get/put to ensure that the get/put is not performed when the module is not ready. This would ensure that a rule containing get method would not fire if the element associated with it is empty and that a rule containing put method would not fire if the element is full.

The following interfaces are defined in the GetPut package. They each take a single parameter, element_type which must be in the Bits typeclass.

	Interfaces defined in GetPut				
Interface	Description	Methods	Type		
Name					
Get	Retrieves item from an interface	get	ActionValue		
Put	Adds an item to an interface	put	Action		
GetS	Retrieves an item from an interface with 2 methods,	first	Value		
	separating the return of the value from the dequeue	deq	ActionValue		
GetPut	Combination of a Get and a Put in a Tuple2	get	ActionValue		
		put	Action		

Get

The Get interface is where you retrieve (get) data from an object. The Get interface is provides a single ActionValue method, get, which retrieves an item of data from an interface and removes it from the object. A get is similar to a dequeue, but it can be associated with any interface. A Get interface is more abstract than a FIFO interface; it does not describe the underlying hardware.

	Get					
Method				Argument		
Name	Type	Description	Name	Description		
get	ActionValue	returns an item from an				
		interface and removes it from the object				

```
interface Get#(type element_type);
    method ActionValue#(element_type) get();
endinterface: Get

Example - adding your own Get interface:
module mkMyFifoUpstream (Get#(int));
...
    method ActionValue#(int) get();
        f.deq;
        return f.first;
endmethod
```

Put

The Put interface is where you can give (put) data to an object. The Put interface provides a single Action method, put, which gives an item to an interface. A put is similar to an enqueue, but it can be associated with any interface. A Put interface is more abstract than a FIFO interface; it does not describe the underlying hardware.

Put					
		Method		Argument	
Name Type Description		Name	Description		
put Action gives an item to an interface		x1	data to be added to the object		
				must be of type element_type	

```
interface Put#(type element_type);
    method Action put(element_type x1);
endinterface: Put

Example - adding your own Put interface:
module mkMyFifoDownstream (Put#(int));
...
    method Action put(int x);
    F.enq(x);
endmethod
```

GetS

The GetS interface is like a Get interface, but separates the get method into two methods: a first and a deq.

	GetS				
Method			Argument		
Name	Name Type Description			Description	
first	Value	returns an item from the interface			
deq	Action	Removes the item from the interface			

```
interface GetS#(type element_type);
   method element_type first();
   method Action deq();
endinterface: GetS
```

GetPut

The library also defines an interface GetPut which associates Get and Put interfaces into a Tuple2. typedef Tuple2#(Get#(element_type), Put#(element_type)) GetPut#(type element_type);

Type classes

The class Connectable (Section C.7.2) is meant to indicate that two related types can be connected in some way. It does not specify the nature of the connection.

A Get and Put is an example of connectable items. One object will put an element into the interface and the other object will get the element from the interface.

```
instance Connectable#(Get#(element_type), Put#(element_type));
```

Modules

There are three modules provided by the GetPut package which provide the GetPut interface with a type of FIFO. These FIFOs use Get and Put interfaces instead of the usual enq interfaces. To use any of these modules the FIFO package must be imported. You can also write your own modules providing a GetPut interface for other hardware structures.

mkGPFIFO	Creates a FIFO of depth 2 with a GetPut interface. module mkGPFIFO (GetPut#(element_type)) provisos (Bits#(element_type, width_elem));
mkGPFIF01	Creates a FIFO of depth 1 with a GetPut interface. module mkGPFIF01 (GetPut#(element_type)) provisos (Bits#(element_type, width_elem));
mkGPSizedFIF0	Creates a FIFO of depth n with a GetPut interface.
	<pre>module mkGPSizedFIFO# (Integer n) (GetPut#(element_type)) provisos (Bits#(element_type, width_elem));</pre>

Functions

There are three functions defined in the GetPut package that change a FIFO interface to a Get, GetS or Put interface. Given a FIFO we can use the function fifoToGet to obtain a Get interface, which is a combination of deq and first. Given a FIFO we can use the function fifoToPut to obtain a Put interface using enq. The functions toGet and toPut (C.7.1) are recommended instead of the fifoToGet and fifoToPut functions. The function fifoToGetS returns the GetS methods as fifo methods.

fifoToGet	Returns a Get interface. It is recommended that you use the function toGet (C.7.1) instead of this function.
	<pre>function Get#(element_type) fifoToGet(FIFO#(element_type) f);</pre>
fifoToGetS	Returns a GetS interface.
	<pre>function GetS#(element_type) fifoToGet(FIFO#(element_type) f);</pre>
fifoToPut	Returns a Put interface. It is recommended that you use the function toPut (C.7.1) instead of this function.
	<pre>function Put#(element_type) fifoToPut(FIFO#(element_type) f);</pre>

Example of creating a FIFO with a GetPut interface

```
import GetPut::*;
import FIFO::*;
...
module mkMyModule (MyInterface);
   GetPut#(StatusInfo) aFifoOfStatusInfoStructures <- mkGPFIFO;
...
endmodule: mkMyModule</pre>
```

Example of a protocol monitor

This is an example of how you might write a protocol monitor that watches bus traffic between a bus and a bus target device

```
import GetPut::*;
import FIF0::*;
// Watch bus traffic beteween a bus and a bus target
interface ProtocolMonitorIfc:
   // These subinterfaces are defined inside the module
   interface Put#(Bus_to_Target_Request) bus_to_targ_req_ifc;
   interface Put#(Target_to_Bus_Response) targ_to_bus_resp_ifc;
endinterface
module mkProtocolMonitor (ProtocolMonitorIfc);
   // Input FIFOs that have Put interfaces added a few lines down
   FIFO#(Bus_to_Target_Request) bus_to_targ_reqs <- mkFIFO;</pre>
   FIFO#(Target_To_Bus_Response) targ_to_bus_resps <- mkFIFO;</pre>
   // Define the subinterfaces: attach Put interfaces to the FIFOs, and
   // then make those the module interfaces
   interface bus_to_targ_req_ifc = fifoToPut (bus_to_targ_reqs);
   interface targ_to_bus_resp_ifc = fifoToPut (targ_to_bus_resps);
end module: mkProtocolMonitor
// Top-level module: connect mkProtocolMonitor to the system:
module mkSys (Empty);
   ProtocolMonitorIfc pmon <- mkProtocolInterface;</pre>
   rule pass_bus_req_to_interface;
       let x <- bus.bus_ifc.get;</pre>
                                      // definition not shown
       pmon.but_to_targ_ifc.put (x);
   endrule
endmodule: mkSys
```

C.7.2 Connectable

Package

```
import Connectable :: *;
```

Description

The Connectable package contains the definitions for the class Connectable and instances of Connectables.

Types and Type-Classes

The class Connectable is meant to indicate that two related types can be connected in some way. It does not specify the nature of the connection. The Connectables type class defines the module mkConnection, which is used to connect the pairs.

```
typeclass Connectable#(type a, type b);
    module mkConnection#(a x1, b x2)(Empty);
endtypeclass
```

Instances

Get and Put One instance of the typeclass of Connectable is Get and Put. One object will put an element into an interface and the other object will get the element from the interface.

```
instance Connectable#(Get#(a), Put#(a));
```

Tuples If we have **Tuple2** of connectable items then the pair is also connectable, simply by connecting the individual items.

```
instance Connectable#(Tuple2#(a, c), Tuple2#(b, d))
provisos (Connectable#(a, b), Connectable#(c, d));
```

The proviso shows that the first component of one tuple connects to the first component of the other tuple, likewise, the second components connect as well. In the above statement, a connects to b and c connects to d. This is used by ClientServer (Section C.7.3) to connect the Get of the Client to the Put of the Server and visa-versa.

This is extensible to all Tuples (Tuple3, Tuple4, etc.). As long as the items are connectable, the Tuples are connectable.

Vector Two **Vectors** are connectable if their elements are connectable.

```
instance Connectable#(Vector#(n, a), Vector#(n, b))
provisos (Connectable#(a, b));
```

ListN Two ListNs are connectable if their elements are connectable.

```
instance Connectable#(ListN#(n, a), ListN#(n, b))
provisos (Connectable#(a, b));
```

Action, ActionValue An ActionValue method (or function) which produces a value can be connected to an Action method (or function) which takes that value as an argument.

```
instance Connectable#(ActionValue#(a), function Action f(a x));
```

```
instance Connectable#(function Action f(a x), ActionValue#(a));
```

A Value method (or value) can be connected to an Action method (or function) which takes that value as an argument.

```
instance Connectable#(a, function Action f(a x));
instance Connectable#(function Action f(a x), a);
```

Inout Inouts are connectable via the Connectable typeclass. The use of mkConnection instantiates a Verilog module InoutConnect. The Inouts must be on the same clock and the same reset. The clock and reset of the Inouts may be different than the clock and reset of the parent module of the mkConnection.

```
instance Connectable#(Inout#(a, x1), Inout#(a, x2))
provisos (Bit#(a,sa));
```

C.7.3 ClientServer

Package

```
import ClientServer :: * ;
```

Description

The ClientServer package provides two interfaces, Client and Server which can be used to define modules which have a request-response type of interface. The GetPut package must be imported when using this package because the Get and Put interface types are used.

Interfaces and methods

The interfaces Client and Server can be used for modules that have a request-response type of interface (e.g. a RAM). The server accepts requests and generates responses, the client accepts responses and generates requests. There are no assumptions about how many (if any) responses a request generates

Interfaces				
Interface Name	Parameter name	Parameter Description	Restrictions	
Client	req_type	type of the client request	must be in the Bits class	
	resp_type	type of the client response	must be in the Bits class	
Server	req_type	type of the server request	must be in the Bits class	
	resp_type	type of the server response	must be in the Bits class	

Client

The Client interface provides two sub-interfaces, request and response. From a Client, one gets a request and puts a response.

Client SubInterface		
Name	Type Description	
request	Get#(req_type)	the interface through which the outside world
	retrieves (gets) a request	
response Put#(resp_type) the interface through which the outside wor		
returns (puts) a response		

```
interface Client#(type req_type, type resp_type);
  interface Get#(req_type) request;
  interface Put#(resp_type) response;
endinterface: Client
```

Server

The Server interface provides two sub-interfaces, request and response. From a Server, one puts a request and gets a response.

Server SubInterface		
Name	Type	Description
request	Put#(req_type)	the interface through which the outside world returns (puts) a request
response	Get#(resp_type)	the interface through which the outside world retrieves (gets) a response

```
interface Server#(type req_type, type resp_type);
  interface Put#(req_type) request;
  interface Get#(resp_type) response;
endinterface: Server
```

ClientServer

A Client can be connected to a Server and vice versa. The request (which is a Get interface) of the client will connect to response (which is a Put interface) of the Server. By making the ClientServer tuple an instance of the Connectable typeclass, you can connect the Get of the client to the Put of the server, and the Put of the client to the Get of the server.

```
instance Connectable#(Client#(req_type, resp_type), Server#(req_type, resp_type));
instance Connectable#(Server#(req_type, resp_type), Client#(req_type, resp_type));
```

This Tuple2 can be redefined to be called ClientServer

Example Connecting a bus to a target

```
interface Bus_Ifc;
   interface Server#(RQ, RS) to_initor;
   interface Client#(RQ, RS) to_targ;
endinterface
typedef Server#(RQ, RS) Target_Ifc;
typedef Client#(RQ, RS) Initiator_Ifc;
module mkSys (Empty);
  // Instantiate subsystems
  Bus_Ifc
             bus
                                <- mkBus;
  Target_Ifc
                      targ
                                <- mkTarget;
  Initiator_Ifc initor
                                <- mkInitiator;
  // Connect bus and targ (to_targ is a Client ifc, targ is a Server ifc)
  Empty x <- mkConnection (bus.to_targ, targ);</pre>
  // Connect bus and initiator (to_initor is a Server ifc, initor is a Client ifc)
  mkConnection (bus.to_initor, initor);
  // Since mkConnection returns an interface of type Empty, it does
  // not need to be specified (but may be as above)
endmodule: mkSys
```

C.7.4 CGetPut

Package

```
import CGetPut :: * ;
```

Description

The interfaces CGet and CPut are similar to Get and Put, but the interconnection of them (via Connectable) is implemented with a credit-based FIFO. This means that the CGet and CPut interfaces have completely registered input and outputs, and furthermore that additional register buffers can be introduced in the connection path without any ill effect (except an increase in latency, of course).

In the absence of additional register buffers, the round-trip time for communication between the two interfaces is 4 clock cycles. Call this number r. The first argument to the type, n, specifies that transfers will occur for a fraction n/r of clock cycles (note that the used cycles will not necessarily be evenly spaced). n also specifies the depth of the buffer used in the receiving interface (the transmitter side always has only a single buffer). So (in the absence of additional buffers) use n=4 to allow full-bandwidth transmission, at the cost of sufficient registers for quadruple buffering at one end; use n=1 for minimal use of registers, at the cost of reducing the bandwidth to one quarter; use intermediate values to select the optimal trade-off if appropriate.

Interfaces and methods

The interface types are abstract to avoid any improper use of the credit signaling protocol.

Interfaces				
Interface Name	Parameter	Parameter Description	Restrictions	
	name			
CGet	n	depth of the buffer used in the re-	must be a numeric	
		ceiving interface	type	
	$element_type$	type of the element	must be in Bits class	
		being retrieved by the CGet		
CPut	n	depth of the buffer used in the re-	must be a numeric	
		ceiving interface	type	
	$element_type$	type of the element	must be in Bits class	
		being added by the CPut		

• CGet

```
interface CGet#(numeric type n, type element_type);
    ...Abstract...
```

• CPut

```
interface CPut#(numeric type n, type element_type);
    ...Abstract...
```

• Connectables

```
The CGet and CPut interfaces are connectable.
instance Connectable#(CGet#(n, element_type), CPut#(n, element_type));
instance Connectable#(CPut#(n, element_type), CGet#(n, element_type));
```

• CClient and CServer

The same idea may be extended to clients and servers.

```
interface CClient#(type n, type req_type, type resp_type);
interface CServer#(type n, type req_type, type resp_type);
```

Modules

mkCGetPut	Create an n depth FIFO with a CGet interface on the dequeue side and a Put interface on the enqueue side.
	<pre>module mkCGetPut(Tuple2#(CGet#(n, element_type),</pre>

C.7.5 CommitIfc

Package

```
import CommitIfc :: *;
```

Description

The CommitIfc package defines a Commit/Accept protocol and interfaces to implement a combinational connection between two modules without adding an AND gate in the connection. The protocols implemented by FIFO and Get/Put connections add an AND gate between the modules being connected. This combinational loop in the connection of the interfaces can cause complications in FPGA applications and in partitioning for FPGAs. Additionally, some synthesis tools require a connection level without any gates. By using the CommitIfc protocol the AND gate is moved out of the connection and into the connecting modules.

The CommitIfc package defines two interfaces, SendCommit and RecvCommit, which model the opposit ends of a FIFO. The protocol does not apply an execution order between the dataout and ack or datain and accept methods. That is, one can signal accept before the data arrives.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Interfaces

The Committifc package defines two interfaces: SendCommit and RecvCommit.

The SendCommit interface declares two methods: a value method dataout and an Action method ack. No execution order is applied between the dataout and the ack; one can signal that the data is accepted before the data rrives.

		SendCommit Interface
Name	Type	Description
dataout	a_type	The data being sent. There is an implicit RDY indicating the data is valid.
ack	Action	Signal that data has been accepted.

```
interface SendCommit#(type a_type);
  method a_type dataout;
  (*always_ready*)
  method Action ack;
endinterface
```

The RecvCommit interface declares two methods: an Action method with the data, datain, and a value method accept, returning a Bool indicating if the interface can accept data (comparable to a notFull).

	RecvCommit Interface		
Name	Type	Description	
datain	Action	Receives, or enqueues, the value din, of type a_type.	
accept	Bool	A boolean indicating if the interface can accept data, comparable to a	
		notFull.	

```
interface RecvCommit#(type a_type);
   (*always_ready*)
   method Action datain (a_type din);
   (*always_ready*)
   method Bool accept ;
endinterface
```

Connectble Instances

The Committifc package defines instances of the Connectable type class for the SendCommit and RecvCommit interfaces, defining how the types can be connected. The Connectable type class defines a mkConnection module for each set of pairs.

```
instance Connectable#(SendCommit#(a_type), RecvCommit#(a_type));
instance Connectable#(RecvCommit#(a_type), SendCommit#(a_type));
```

FIFOF The SendCommit and RecvCommit interfaces can be connected to FIFOF interfaces.

```
instance Connectable#(SendCommit#(a_type), FIFOF#(a_type))
   provisos (Bits#(a_type, size_a));

instance Connectable#(FIFOF#(a_type), SendCommit#(a_type))
   provisos (Bits#(a_type, size_a));

instance Connectable#(RecvCommit#(a_type), FIFOF#(a_type))
   provisos (Bits#(a_type, size_a));

instance Connectable#(FIFOF#(a_type), RecvCommit#(a_type))
   provisos (Bits#(a_type, size_a));
```

SyncFIFOIfc The SendCommit and RecvCommit interfaces can be connected to SyncFIFOIfc interfaces.

```
instance Connectable#(SendCommit#(a_type), SyncFIFOIfc#(a_type))
    provisos (Bits#(a_type, size_a));
instance Connectable#(SyncFIFOIfc#(a_type), SendCommit#(a_type))
    provisos (Bits#(a_type, size_a));
instance Connectable#(RecvCommit#(a_type), SyncFIFOIfc#(a_type))
    provisos (Bits#(a_type, size_a));
instance Connectable#(SyncFIFOIfc#(a_type), RecvCommit#(a_type))
    provisos (Bits#(a_type, size_a));
```

Typeclasses

The CommitIfc package defines typeclasses for converting to these interfaces from other interface types. These must use a module since rules and wires are required.

```
typeclass ToSendCommit#(type a_type , type b_type)
  dependencies (a_type determines b_type);
  module mkSendCommit#(a_type x) (SendCommit#(b_type));
endtypeclass

typeclass ToRecvCommit#(type a_type , type b_type)
  dependencies (a_type determines b_type);
  module mkRecvCommit#(a_type x) (RecvCommit#(b_type));
endtypeclass
```

Instances

Instances for the ToSendCommit and ToRecvCommit type classes are defined to convert to convert from FIFO, FIFOF, SyncFIFOIfc, Get and Put interfaces.

FIFO

```
instance ToSendCommit#(FIFO#(a), a);
```

Note: ToRecvCommit#(FIFO#(a_type), a_type) is not possible, because it would need to have a notFull signal.

FIFOF The FIFOF instances assume that the fifo has proper implicit conditions.

```
instance ToSendCommit#(FIFOF#(a_type), a_type);
  module mkSendCommit #(FIFOF#(a) f) (SendCommit#(a));
instance ToRecvCommit#(FIFOF#(a_type), a_type)
  provisos(Bits#(a,sa));
  module mkRecvCommit #(FIFOF#(a) f) (RecvCommit#(a));
```

SyncFIFOIfc The SyncFIFOIfc instances assume that the fifo has proper implicit conditions.

```
instance ToSendCommit#(SyncFIFOIfc#(a_type), a_type);
  module mkSendCommit #(SyncFIFOIfc#(a) f) (SendCommit#(a));
instance ToRecvCommit#(SyncFIFOIfc#(a_type), a_type)
  provisos(Bits#(a,sa));
  module mkRecvCommit #(SyncFIFOIfc#(a) f) (RecvCommit#(a));
```

Get and Put These convert from Get and Put interfaces but introduce additional latency:

```
instance ToSendCommit#(Get#(a_type), a_type)
    provisos ( Bits#(a,sa));
    module mkSendCommit #(Get#(a_type) g) (SendCommit#(a_type));

instance ToRecvCommit#(Put#(a_type), a_type)
    provisos(Bits#(a,sa));
    module mkRecvCommit #(Put#(a_type) p) (RecvCommit#(a_type));

These add FIFOs, but maintain loopless behavior:

instance Connectable#(SendCommit#(a_type), Put#(a_type))
    provisos (ToRecvCommit#(Put#(a_type), a_type));

instance Connectable#(Put#(a_type), SendCommit#(a_type))
    provisos (ToRecvCommit#(Put#(a_type), a_type));

instance Connectable#(RecvCommit#(a_type), Get#(a_type))
    provisos (ToSendCommit#(Get#(a_type), RecvCommit#(a_type))
    provisos (ToSendCommit#(Get#(a_type), a_type));
```

Client/Server Variations

The SendCommit and RecvCommit interfaces can be combined into ClientCommit and ServerCommit type interfaces, similar to the Client and Server interfaces described in Section C.7.3.

A Client provides two subinterfaces, a Get and a Put The ClientCommit interface combines a SendCommit request with a RecvCommit response.

```
interface ClientCommit#(type req, type resp);
  interface SendCommit#(req) request;
  interface RecvCommit#(resp) response;
endinterface
```

The mkClientfromClientCommit module takes a ClientCommit interface and provides a Client interface:

A Server interface provides a Put request with a Get response. The ServerCommit interface combines a RecvCommit request with a SendCommit response.

```
interface ServerCommit#(type req, type resp);
   interface RecvCommit#(req) request;
   interface SendCommit#(resp) response;
endinterface
ClientCommit and ServerCommit interfaces are connectable to each other.
instance Connectable#(ClientCommit#(req,resp), ServerCommit#(req,resp));
instance Connectable#( ServerCommit#(req,resp), ClientCommit#(req,resp));
ClientCommit and ServerCommit interfaces are connectable to Clients and Servers.
instance Connectable #(ClientCommit#(req,resp), Server#(req,resp))
  provisos ( Bits#(resp,_x), Bits#(req,_y));
instance Connectable #(Server#(req,resp), ClientCommit#(req,resp))
  provisos ( Bits#(resp,_x), Bits#(req,_y));
instance Connectable #(ServerCommit#(req,resp), Client#(req,resp))
  provisos ( Bits#(resp,_x), Bits#(req,_y));
instance Connectable #( Client#(req,resp), ServerCommit#(req,resp))
  provisos ( Bits#(resp,_x), Bits#(req,_y));
```

The SendCommit and RecvCommit can be defined as instances of ToGet and ToPut. These functions introduce a combinational loop between the Commit interface methods.

```
instance ToGet#(SendCommit#(a_type, a_type);
instance ToPut#(RecvCommit#(a_type, a_type);
```

C.8 Utilities

C.8.1 LFSR

Package

```
import LFSR :: * ;
```

Description

The LFSR package implements Linear Feedback Shift Registers (LFSRs). LFSRs can be used to obtain reasonable pseudo-random numbers for many purposes (though not good enough for cryptography). The seed method must be called first, to prime the algorithm. Then values may be read using the value method, and the algorithm stepped on to the next value by the next method. When a LFSR is created the start value, or seed, is 1.

Interfaces and Methods

The LFSR package provides an interface, LFSR, which contains three methods; seed, value, and next. To prime the LFSR the seed method is called with the parameter seed_value, of datatype a_type. The value is read with the value method. The next method is used to shift the register on to the next value.

LFSR Interface				
		Method	Arguments	
Name	Type	Description	Name	Description
seed	Action	Sets the value of the shift register.	a_type	datatype of the
				seed value
			seed_value	the initial value
value	a_type	returns the value of the shift register		
next	Action	signals the shift register to shift to		
		the next value.		

```
interface LFSR #(type a_type);
   method Action seed(a_type seed_value);
   method a_type value();
   method Action next();
endinterface: LFSR
```

Modules

The module mkFeedLFSR creates a LFSR where the polynomial is specified by the mask used for feedback.

mkFeedLFSR	Creates a LFSR where the polynomial is specified by the mask (feed) used for feedback.
	<pre>module mkFeedLFSR#(Bit#(n) feed)(LFSR#(Bit#(n)));</pre>

For example, the polynominal $x^7+x^3+x^2+x+1$ is defined by the expression mkFeedLFSR#(8'b1000_1111) Using the module mkFeedLFSR, the following maximal length LFSR's are defined in this package.

Module Name	feed	Module Definition
mkLFSR_4	$4'h9$ $x^3 + 1$	<pre>module mkLFSR_4 (LFSR#(Bit#(4)));</pre>
mkLFSR_8	8'h8E	<pre>module mkLFSR_8 (LFSR#(Bit#(8)));</pre>
mkLFSR_16	16'h8016	module mkLFSR_16 (LFSR#(Bit#(16)));
mkLFSR_32	32'h80000057	module mkLFSR_32 (LFSR#(Bit#(32)));

For example,

```
mkLFSR_4 = mkFeedLFSR(4'h9);
```

The module mkLFSR_4 instantiates the interface LFSR with the value Bit#(4) to produce a 4 bit shift register. The module uses the polynomial defined by the mask 4'h9 $(x^3 + 1)$ and the module mkFeedLFSR.

The mkRCounter function creates a counter with a LFSR interface. This is useful during debugging when a non-random sequence is desired. This function can be used in place of the other mkLFSR module constructors, without changing any method calls or behavior.

mkRCounter	Creates a counter with a LFSR interface.
	<pre>module mkRCounter#(Bit#(n) seed) (LFSR#(Bit#(n)));</pre>

Example - Random Number Generator

```
import GetPut::*;
import FIF0::*;
import LFSR::*;
// We want 6-bit random numbers, so we will use the 16-bit version of
// LFSR and take the most significant six bits.
// The interface for the random number generator is parameterized on bit
// length. It is a "get" interface, defined in the GetPut package.
typedef Get#(Bit#(n)) RandI#(type n);
module mkRn_6(RandI#(6));
  // First we instantiate the LFSR module
 LFSR#(Bit#(16)) lfsr <- mkLFSR_16 ;</pre>
  // Next comes a FIFO for storing the results until needed
  FIFO#(Bit#(6)) fi <- mkFIFO ;</pre>
  // A boolean flag for ensuring that we first seed the LFSR module
  Reg#(Bool) starting <- mkReg(True) ;</pre>
  // This rule fires first, and sends a suitable seed to the module.
 rule start (starting);
```

```
starting <= False;
    lfsr.seed('h11);
endrule: start

// After that, the following rule runs as often as it can, retrieving
// results from the LFSR module and enqueing them on the FIFO.
rule run (!starting);
    fi.enq(lfsr.value[10:5]);
    lfsr.next;
endrule: run

// The interface for mkRn_6 is a Get interface. We can produce this from a
// FIFO using the fifoToGet function. We therefore don't need to define any
// new methods explicitly in this module: we can simply return the produced
// Get interface as the "result" of this module instantiation.
return fifoToGet(fi);
endmodule</pre>
```

C.8.2 Randomizable

Package

```
import Randomizable :: *;
```

Description

The Randomizable package includes interfaces and modules to generate random values of a given data type.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Typeclasses

The Randomizable package includes the Randomizable typeclass.

```
typeclass Randomizable#(type t);
  module mkRandomizer (Randomize#(t));
endtypeclass
```

Interfaces and Methods

Randomize Interface		
Name	Type	Description
cntrl Interface		Control interface provided by the module.
next	ActionValue	Returns the next value of type a.

```
interface Randomize#(type a);
  interface Control cntrl;
  method ActionValue#(a) next();
endinterface
```

Control Interface			
Name	Name Type Description		
init	Control	Action method to initialize the randomizer.	

```
interface Control ;
  method Action init();
endinterface
```

Modules

The Randomizable package includes two modules which return random values of type a. The difference between the two modules is how the min and max values are determined. The module mkGenericRandomizer uses the min and max values of the type, while the module mkConstrainedRandomizer uses arguments to set the min and max values. The type a must be in the Bounded class for both modules.

mkGenericRandomizer	This module provides a Randomize interface, which will return the next random value when the next method is invoked. The min and max values are the values defined by the type a which must be in the Bounded class.
	<pre>module mkGenericRandomizer (Randomize#(a)) provisos (Bits#(a, sa), Bounded#(a));</pre>

mkConstrainedRandomizer	This module provides a Randomize interface, which will give the next random value when the next method is invoked. When instantiated, the min and max values are provided as arguments. Type a must be in the Bounded class.
	<pre>module mkConstrainedRandomizer#(a min, a max) (Randomize#(a)) provisos (Bits#(a, sa), Bounded#(a));</pre>

Example

The mkTLMRandomizer module, defined within the TLM2 package (Section C.11.1), uses the Randomize package to generate random values for TLM packets. The mkConstrainedRandomizer module is for fields with specific allowed values or ranges, while the mkGenericRandomizer module is for field where all values of the type are allowed.

```
module mkTLMRandomizer#(Maybe#(TLMCommand) m_command) (Randomize#(TLMRequest#('TLM_TYPES)))
    provisos(Bits#(RequestDescriptor#('TLM_TYPES), s0),
        Bounded#(RequestDescriptor#('TLM_TYPES)),
        Bits#(RequestData#('TLM_TYPES), s1),
        Bounded#(RequestData#('TLM_TYPES))
    );
    ...
    // Use mkGeneric Randomizer - entire range valid
    Randomize#(RequestDescriptor#('TLM_TYPES)) descriptor_gen <- mkGenericRandomizer;</pre>
```

```
Randomize#(Bit#(2)) log_wrap_gen <- mkGenericRandomizer;
Randomize#(RequestData#('TLM_TYPES)) data_gen <- mkGenericRandomizer;

// Use mkConstrainedRandomizer to Avoid UNKNOWN
Randomize#(TLMCommand) command_gen <- mkConstrainedRandomizer(READ, WRITE);
Randomize#(TLMBurstMode) burst_mode_gen <- mkConstrainedRandomizer(INCREMENT, WRAP);

// Use mkConstrainedRandomizer to set legal sizes between 1 and 16
Randomize#(TLMUInt#('TLM_TYPES)) burst_length_gen <- mkConstrainedRandomizer(1,16);
```

C.8.3 Arbiter

Package

```
import Arbiter :: *;
```

Description

The Arbiter package includes interfaces and modules to implement two different arbiters: a fair arbiter with changing priorities (round robin) and a sticky arbiter, also round robin, but which gives the current owner priority.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Interfaces and Methods

The Arbiter package includes three interfaces: a arbiter client interface, an arbiter request interface and an arbiter interface which is a vector of client interfaces.

ArbiterClient_IFC The **ArbiterClient_IFC** interface has two methods: an Action method to make the request and a Boolean value method to indicate the request was granted. The lock method is unused in this implementation.

```
interface ArbiterClient_IFC;
  method Action request();
  method Action lock();
  method Bool grant();
endinterface
```

ArbiterRequest_IFC The ArbiterRequest_IFC interface has two methods: an Action method to grant the request and a Boolean value method to indicate there is a request. The lock method is unused in this implementation.

```
interface ArbiterRequest_IFC;
  method Bool request();
  method Bool lock();
  method Action grant();
endinterface
```

The ArbiterClient_IFC interface and the ArbiterRequest_IFC interface are connectable.

```
instance Connectable#(ArbiterClient_IFC, ArbiterRequest_IFC);
```

Arbiter_IFC The Arbiter_IFC has a subinterface which is a vector of ArbiterClient_IFC interfaces. The number of items in the vector equals the number of clients.

```
interface Arbiter_IFC#(type count);
  interface Vector#(count, ArbiterClient_IFC) clients;
endinterface
```

Modules

The mkArbiter module is a fair arbiter with changing priorities (round robin). The mkStickyArbiter gives the current owner priority - they can hold priority as long as they keep requesting it. The modules all provide a Arbiter_IFC interface.

mkArbiter	This module is a fair arbiter with changing priorities (round robin). If fixed is True, the current client holds the priority, if fixed is False, it moves to the next client. mkArbiter provides a Arbiter_IFC interface. Initial priority is given to client 0.
	<pre>module mkArbiter#(Bool fixed) (Arbiter_IFC#(count));</pre>

mkStickyArbiter	As long as the client currently with the grant continues to assert request, it can hold the grant. It provides a Arbiter_IFC interface.	
	<pre>module mkStickyArbiter (Arbiter_IFC#(count));</pre>	

C.8.4 GrayCounter

Package

```
import GrayCounter :: * ;
```

Description

The GrayCounter package provides an interface and a module to implement a gray-coded counter with methods for both binary and Gray code. This package is designed for use in the BRAMFIFO module, Section C.2.4. Since BRAMs have registered address inputs, the binary outputs are not registered. The counter has two domains, source and destination. Binary and Gray code values are written in the source domain. Both types of values can be read from the source and the destination domains.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Types

The GrayCounter package uses the type Gray, defined in the Gray package, Section C.8.5. The Gray package is imported by the GrayCounter package.

Interfaces and Methods

The GrayCounter package includes one interface, GrayCounter.

GrayCounter Interface Methods		
Name	Type	Description
incr	Action	Increments the counter by 1
decr	Action	Decrements the counter by 1
sWriteBin	Action	Writes a binary value into the counter in the source
		domain.
sReadBin	Bit#(n)	Returns a binary value from the source domain of
		the counter. The output is not registered
sWriteGray	Action	Writes a Gray code value into the counter in the
		source domain.
sReadGray	Gray#(n)	Returns the Gray code value from the source do-
		main of the counter. The output is registered.
dReadBin	Bit#(n)	Returns the binary value from the destination do-
		main of the counter. The output is not registered.
dReadGray	Gray#(n)	Returns the Gray code value from the destination
		domain of the counter. The output is registered.

```
interface GrayCounter#(numeric type n);
  method
            Action
                        incr;
  method
            Action
                        decr;
  method
            Action
                        sWriteBin(Bit#(n) value);
  method
            Bit#(n)
                        sReadBin;
                        sWriteGray(Gray#(n) value);
  method
            Action
  method
            Gray#(n)
                        sReadGray;
            Bit#(n)
                        dReadBin;
  method
  method
            Gray#(n)
                        dReadGray;
endinterface: GrayCounter
```

Modules

The module mkGrayCounter instantiates a Gray code counter with methods for both binary and Gray code.

mkGrayCounter	Instantiates a Gray counter with an initial value initval.
	<pre>module mkGrayCounter#(Gray#(n) initval,</pre>

C.8.5 Gray

Package

```
import Gray :: *;
```

Description

The Gray package defines a datatype, Gray and functions for working with the Gray type. This type is used by the GrayCounter package.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Types and type classes

The datatype **Gray** is a representation for Gray code values. The basic representation is the **Gray** structure, which is polymorphic on the size of the value.

The Gray type belongs to the Literal and Bounded type classes. Each type class definition includes functions which are then also defined for the data type. The Prelude library definitions (Section B) describes which functions are defined for each type class.

	Type Classes used by Gray								
	Bits	Eq	Literal	Arith	Ord	Bounded	Bit	Bit	Bit
							wise	Reduction	Extend
Gray									

Literal The Gray type is a member of the Literal class, which defines an encoding from the compile-time Integer type to Gray type with the fromInteger and grayEncode functions. The fromInteger converts the value to a bit pattern, and then calls grayEncode.

```
instance Literal #( Gray#(n) )
   provisos(Add#(1, msb, n));
```

Bounded The Gray type is a member of the Bounded class, which provides the functions minBound and maxBound to define the minimum and maximum Gray code values.

```
minimum: 'b0
maximum: 'b10...0
instance Bounded # ( Gray#(n) )
provisos(Add#(1, msb, n));
```

Functions

grayEncode	This function takes a binary value of type Bit#(n) and returns a Gray type with the Gray code value.
	<pre>function Gray#(n) grayEncode(Bit#(n) value) provisos(Add#(1, msb, n));</pre>

grayDecode	This function takes a Gray code value of size n and returns the binary value. function Bit#(n) grayDecode(Gray#(n) value) provisos(Add#(1, msb, n));
grayIncrDecr	This functions takes a Gray code value and a Boolean, decrement. If decrement is True, the value returned is one less than the input value. If decrement is False, the value returned is one greater.
	<pre>function Gray#(n) grayIncrDecr(Bool decrement,</pre>
grayIncr	Takes a Gray code value and returns a Gray code value incremented by 1.
	<pre>function Gray#(n) grayIncr(Gray#(n) value) provisos(Add#(1, msb, n));</pre>
grayDecr	Takes a Gray code value a returns a Gray code value decremented by 1.
	<pre>function Gray#(n) grayDecr(Gray#(n) value) provisos(Add#(1, msb, n));</pre>

C.8.6 CompletionBuffer

Package

```
import CompletionBuffer :: *;
```

Description

A CompletionBuffer is like a FIFO except that the order of the elements in the buffer is independent of the order in which the elements are entered. Each element obtains a token, which reserves a slot in the buffer. Once the element is ready to be entered into the buffer, the token is used to place the element in the correct position. When removing elements from the buffer, the elements are delivered in the order specified by the tokens, not in the order that the elements were written.

Completion Buffers are useful when multiple tasks are running, which may complete at different times, in any order. By using a completion buffer, the order in which the elements are placed in the buffer can be controlled, independent of the order in which the data becomes available.

Interface and Methods

The CompletionBuffer interface provides three subinterfaces. The reserve interface, a Get, allows the caller to reserve a slot in the buffer by returning a token holding the identity of the slot. When data is ready to be placed in the buffer, it is added to the buffer using the complete interface of type Put. This interface takes a pair of values as its argument - the token identifying its slot, and the

data itself. Finally, using the drain interface, of type Get, data may be retrieved from the buffer in the order in which the tokens were originally allocated. Thus the results of quick tasks might have to wait in the buffer while a lengthy task ahead of them completes.

The type of the elements to be stored is element_type. The type of the required size of the buffer is a numeric type n, which is also the type argument for the type for the tokens issued, CBToken. This allows the type-checking phase of the synthesis to ensure that the tokens are the appropriate size for the buffer, and that all the buffer's internal registers are of the correct sizes as well.

CompletionBuffer Interface			
Name	Type	Description	
reserve	Get	Used to reserve a slot in the buffer. Returns a token, CBToken #(n), identifying the slot in the buffer.	
complete	Put	Enters the element into the buffer. Takes as arguments the slot in the buffer, CBToken#(n), and the element to be stored in the buffer.	
drain	Get	Removes an element from the buffer. The elements are returned in the order the tokens were allocated.	

Datatypes

```
The CBToken type is abstract to avoid misuse.

typedef union tagged { ... } CBToken #(numeric type n) ...;
```

Modules

The mkCompletionBuffer module is used to instantiate a completion buffer. It takes no size arguments, as all that information is already contained in the type of the interface it produces.

mkCompletionBuffer	Creates a completion buffer.
	<pre>module mkCompletionBuffer(CompletionBuffer#(n, element_type)) provisos (Bits#(element_type, sizea))</pre>

Example- Using a Completion Buffer in a server farm of multipliers

A server farm is a set of identical servers, which can each perform the same task, together with a controller. The controller allocates incoming tasks to any server which happens to be available (free), and sends results back to its caller.

The time needed to complete each task depends on the value of the multiplier argument; there is therefore no guarantee that results will become available in the order the tasks were started. It is required, however, that the controller return results to its caller in the order the tasks were received. The controller accordingly must instantiate a special mechanism for this purpose. The appropriate mechanism is a Completion Buffer.

```
import List::*;
import FIF0::*;
import GetPut::*;
import CompletionBuffer::*;
typedef Bit#(16) Tin;
typedef Bit#(32) Tout;
// Multiplier interface
interface Mult_IFC;
    method Action start (Tin m1, Tin m2);
    method ActionValue#(Tout)
                                 result();
endinterface
typedef Tuple2#(Tin,Tin) Args;
typedef 8 BuffSize;
typedef CBToken#(BuffSize) Token;
// This is a farm of multipliers, mkM. The module
// definition for the multipliers mkM is not provided here.
// The interface definition, Mult_IFC, is provided.
module mkFarm#( module#(Mult_IFC) mkM ) ( Mult_IFC );
   // make the buffer twice the size of the farm
   Integer n = div(valueof(BuffSize),2);
   // Declare the array of servers and instantiate them:
   Mult_IFC mults[n];
   for (Integer i=0; i<n; i=i+1)</pre>
      begin
         Mult_IFC s <- mkM;</pre>
         mults[i] = s;
      end
   FIFO#(Args) infifo <- mkFIFO;
   // instantiate the Completion Buffer, cbuff, storing values of type Tout
   // buffer size is Buffsize, data type of values is Tout
   CompletionBuffer#(BuffSize,Tout) cbuff <- mkCompletionBuffer;</pre>
   // an array of flags telling which servers are available:
   Reg#(Bool) free[n];
   // an array of tokens for the jobs in progress on the servers:
   Reg#(Token) tokens[n];
   \ensuremath{//} this loop instantiates n free registers and n token registers
   // as well as the rules to move data into and out of the server farm
   for (Integer i=0; i<n; i=i+1)</pre>
      begin
         // Instantiate the elements of the two arrays:
         Reg#(Bool) f <- mkReg(True);</pre>
         free[i] = f;
         Reg#(Token) t <- mkRegU;</pre>
         tokens[i] = t;
```

```
Mult_IFC s = mults[i];
         // The rules for sending tasks to this particular server, and for
         // dealing with returned results:
         rule start_server (f); // start only if flag says it's free
            // Get a token
            CBToken#(BuffSize) new_t <- cbuff.reserve.get;</pre>
            Args a = infifo.first;
            Tin a1 = tpl_1(a);
            Tin a2 = tpl_2(a);
            infifo.deq;
            f <= False;
            t <= new_t;
            s.start(a1,a2);
         endrule
         rule end_server (!f);
            Tout x <- s.result;</pre>
            // Put the result x into the buffer, at the slot t
            cbuff.complete.put(tuple2(t,x));
            f <= True;
         endrule
      end
  method Action start (m1, m2);
      infifo.enq(tuple2(m1,m2));
   endmethod
  // Remove the element from the buffer, returning the result
  // The elements will be returned in the order that the tokens were obtained.
  method result = cbuff.drain.get;
endmodule
```

C.8.7 UniqueWrappers

Package

```
import UniqueWrappers :: *;
```

Description

The UniqueWrappers package takes a piece of combinational logic which is to be shared and puts it into its own protective shell or *wrapper* to prevent its duplication. This is used in instances where a separately synthesized module is not possible. It allows the designer to use a piece of logic at several places in a design without duplicating it at each site.

There are times where it is desired to use a piece of logic at several places in a design, but it is too bulky or otherwise expensive to duplicate at each site. Often the right thing to do is to make the piece of logic into a separately synthesized module – then, if this module is instantiated only once, it will not be duplicated, and the tool will automatically generate the scheduling and multiplexing logic to share it among the sites which use its methods. Sometimes, however, this is not convenient. One reason might be that the logic is to be incorporated into a sub-module of the design which is

itself polymorphic – this will probably cause difficulties in observing the constraints necessary for a module which is to be separately synthesized. And if a module is *not* separately synthesized, the tool will inline its logic freely wherever it is used, and thus duplication will not be prevented as desired.

This package covers the case where the logic to be shared is combinational and cannot be put into a separately synthesized module. It may be thought of as surrounding this combinational function with a protective shell, a *unique wrapper*, which will prevent its duplication. The module mkUniqueWrapper takes a one-argument function as a parameter; both the argument type a and the result type b must be representable as bits, that is, they must both be in the Bits typeclass.

Interfaces

The UniqueWrappers package provides an interface, Wrapper, with one actionvalue method, func, which takes an argument of type a and produces a method of type ActionValue#(b). If the module is instantiated only once, the logic implementing its parameter will be instantiated just once; the module's method may, however, be used freely at several places.

Although the function supplied as the parameter is purely combinational and does not change state, the method is of type ActionValue. This is because actionvalue methods have enable signals and these signals are needed to organize the scheduling and multiplexing between the calling sites.

Variants of the interface Wrapper are also provided for handling functions of two or three arguments; the interfaces have one and two extra parameters respectively. In each case the result type is the final parameter, following however many argument type parameters are required.

	Wrapper Interfaces			
Wrapper	This interface has one actionvalue method, func, which takes an argument of type a_type and produces an actionvalue of type ActionValue#(b_type). interface Wrapper#(type a_type, type b_type); method ActionValue#(b_type) func (a_type x);			

```
Wrapper2 Similar to the Wrapper interface, but it takes two arguments.

interface Wrapper2#(type a1_type, type a2_type, type b_type);
method ActionValue#(b_type) func (a1_type x, a2_type y);
```

```
Wrapper3 Similar to the Wrapper interface, but it takes three arguments.

interface Wrapper3#(type a1_type, type a2_type, type a3_type, type b_type);

method ActionValue#(b_type) func (a1_type x, a2_type y, a3_type z);
```

Modules

The interfaces Wrapper, Wrapper2, and Wrapper3 are provided by the modules mkUniqueWrapper, mkUniqueWrapper2, and mkUniqueWrapper3. These modules vary only in the number of aguments in the parameter function.

If a function has more than three arguments, it can always be rewritten or wrapped as one which takes the arguments as a single tuple; thus the one-argument version mkUniqueWrapper can be used with this function.

mkUniqueWrapper

```
Takes a function, func, with a single parameter x and provides the interface Wrapper.
```

mkUniqueWrapper2

Takes a function, func, with a two parameters, x and y, and provides the interface Wrapper2.

mkUniqueWrapper3

Takes a function, func, with a three parameters, x, y, and z, and provides the interface Wrapper3.

Example: Complex Multiplication

```
// This module defines a single hardware multiplier, which is then
// used by multiple method calls to implement complex number
// multiplication (a + bi)(c + di)

typedef Int#(18) CFP;

module mkComplexMult1Fifo( ArithOpGP2#(CFP) );
  FIFO#(ComplexP#(CFP)) infifo1 <- mkFIFO;
  FIFO#(ComplexP#(CFP)) infifo2 <- mkFIFO;
  let arg1 = infifo1.first;
  let arg2 = infifo2.first;

FIFO#(ComplexP#(CFP)) outfifo <- mkFIFO;

Reg#(CFP) rr <- mkReg(0);
  Reg#(CFP) ii <- mkReg(0);
  Reg#(CFP) ir <- mkReg(0);
  Reg#(CFP) ir <- mkReg(0);
  Reg#(CFP) ir <- mkReg(0);</pre>
```

```
// and returns the result. It is a Wrapper2 because there are 2 arguments.
 Wrapper2#(CFP,CFP, CFP) smult <- mkUniqueWrapper2( \* );</pre>
 // Define a sequence of actions
 // Since smult is a UnqiueWrapper the method called is smult.func
 Stmt multSeq =
 seq
     action
        let mr <- smult.func( arg1.rel, arg2.rel );</pre>
        rr <= mr ;
     endaction
     action
        let mr <- smult.func( arg1.img, arg2.img );</pre>
        ii <= mr ;
     endaction
     action
        // Do the first add in this step
        let mr <- smult.func( arg1.img, arg2.rel );</pre>
        ir <= mr ;
        rr <= rr - ii ;
     endaction
     action
        let mr <- smult.func( arg1.rel, arg2.img );</pre>
        // We are done with the inputs so deq the in fifos
        infifo1.deq ;
        infifo2.deq;
     endaction
     action
        let ii2 = ri + ir;
        let res = Complex{ rel: rr , img: ii2 } ;
        outfifo.enq( res );
     endaction
 endseq;
 // Now convert the sequence into a FSM ;
 // Bluespec can assign the state variables, and pick up implict
 // conditions of the actions
 FSM multfsm <- mkAutoFSM;
 rule startFSM;
    multfsm.start;
 endrule
endmodule
```

C.8.8 FShow

Package

```
import FShow :: *;
```

Description

The FShow package defines the typeclass FShow. FShow includes a single member function, fshow. When applied to an object which is an instance of FShow, the fshow function returns an object of type Fmt (Section B.2.8).

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Typeclasses

FShow defines the class of types to which the function fshow can be applied to create an associated fmt representation.

```
typeclass FShow#(type t);
  function Fmt fshow(t value);
endtypeclass
```

The package defines instances of FShow for many commonly used datatypes. Users can create their own FShow instances for other types (or redefine the instances included in the FShow package).

	FShow Instances
String	Returns a Fmt object showing the value of the string.
	<pre>instance FShow#(String);</pre>
Bool	Returns a Fmt object showing True or False.
	<pre>instance FShow#(Bool);</pre>
Maybe#(a)	Returns a Fmt object showing Valid and the value, or just Invalid.
	<pre>instance FShow#(Maybe#(a)) provisos(FShow#(a));</pre>
Int#(n)	Returns a Fmt object showing n in a decimal format.
1110# (11)	
	<pre>instance FShow#(Int#(n));</pre>
Bit#(n)	Returns a Fmt object showing n in a hexadecimal format.
	<pre>instance FShow#(Bit#(n));</pre>
FIFOF_#(a) FIFOF#(a)	Returns a Fmt object showing the first element and Empty/Full state of the FIFO.
	<pre>instance FShow#(FIFOF_#(a)) provisos(FShow#(a));</pre>

Vector#(n, a)	Returns a Fmt object showing $<$ V elem1 elem2>, where the elemn are the elements of the vector.
	<pre>instance FShow#(Vector#(n, a)) provisos(FShow#(a));</pre>
List#(a)	Returns a Fmt object showing <list elem1="" elem2="">, where the elemn are the elements of the list.</list>
	<pre>instance FShow#(List#(a)) provisos(FShow#(a));</pre>
FixedPoint#(i,f)	Returns a Fmt object showing FP int.frac where int is the integer part and frac is the fractional part of the fixed point number.
FixedPoint#(i,f)	<pre>provisos(FShow#(a));</pre> Returns a Fmt object showing FP int.frac where int is the integer

rixedroint#(1,1)	returns a rmc object showing refine. Trac where fire is the integer part
	and frac is the fractional part of the fixed point number.
	<pre>instance FShow#(FixedPoint#(i,f));</pre>

Complex#(a)	Returns a Fmt object showing <c x.img="" x.rel,=""> where x.rel is the real</c>
	and x.img is the imaginary part of x.
	<pre>instance FShow#(Complex#(a)) provisos (FShow#(a));</pre>

Tuple2#(a,b)	Returns a Fm	t object showing Tuple2(a, b).		
	<pre>instance FShow#(Tuple2#(a, b)) provisos(FShow#(a), FShow#(b)); function Fmt fshow (Tuple2#(a, b) value); return \$format("Tuple2(", fshow(tpl_1(value)), ",",</pre>			
Tuple3#(a,b,c)		Returns a Fmt object showing Tuple3(a,b,c).		
Tuple4#(a,b,c,d)		Returns a Fmt object showing Tuple4(a,b,c,d).		
Tuple5#(a,b,c,d,e)		Returns a Fmt object showing Tuple5(a,b,c,d,e).		
<pre>Tuple6#(a,b,c,d,</pre>	e,f)	Returns a Fmt object showing Tuple6(a,b,c,d,e,f).		
<pre>Tuple7#(a,b,c,d,</pre>	e,f,g)	Returns a Fmt object showing Tuple7(a,b,c,d,e,f,g).		
<pre>Tuple8#(a,b,c,d,</pre>	e,f,g,h)	Returns a Fmt object showing Tuple8(a,b,c,d,e,f,g,h).		

Functions

fshow	Returns a Fmt representation when applied to a value		
	<pre>function Fmt fshow(t value);</pre>		
concatWith	Concantenates a String (x) with two other arguments a and b, both of type Fmt.		
	<pre>function Fmt concatWith(String x, Fmt a, Fmt b); return (a + \$format(x) + b);</pre>		

Modules

dbgProbe	This module is used like a Probe except that the sampled value (to be viewed in waves) is the ascii representation of fshow(value).
	<pre>module dbgProbe (Probe#(a)) provisos(FShow#(a));</pre>

Example

```
package FShowExample;
import Probe::*;
import FShow::*;
import Vector::*;
/// Define some types ....
typedef Vector#(3,Bool) VOB;
typedef Tuple2#(Bit#(2), Bit#(2)) TUP;
typedef enum {READ, WRITE, UNKNOWN} OpCommand deriving(Bounded, Bits, Eq);
typedef struct {OpCommand command;
Bit#(8)
         addr;
Bit#(8)
          data;
Bit#(8)
         length;
Bool
         lock;
} Header deriving (Eq, Bits, Bounded);
typedef union tagged {Header Descriptor;
      Bit#(8) Data;
      } Request deriving(Eq, Bits, Bounded);
/// Define FShow instances for the ones that aren't already in FShow.bsv
instance FShow#(OpCommand);
  function Fmt fshow (OpCommand label);
      case (label)
READ:
       return fshow("READ ");
WRITE: return fshow("WRITE");
UNKNOWN: return fshow("UNKNOWN");
      endcase
   endfunction
endinstance
instance FShow#(Header);
  function Fmt fshow (Header value);
      return ($format("<HEAD ")</pre>
      fshow(value.command)
      $format(" (%0d)", value.length)
```

```
$format(" A:%h", value.addr)
      $format(" D:%h>", value.data));
   endfunction
endinstance
instance FShow#(Request);
  function Fmt fshow (Request request);
      case (request) matches
tagged Descriptor .a:
    return fshow(a);
 tagged Data .a:
    return $format("<DATA %h>", a);
      endcase
   endfunction
endinstance
(* synthesize *)
module mkFShowExample (Empty);
  Reg#(Bit#(32)) value <- mkReg(1234);</pre>
  Reg#(Bit#(16)) count <- mkReg(0);</pre>
   // Probes to send "fshow" strings to waves
  Probe#(VOB) vob_probe <- dbgProbe;</pre>
  Probe#(TUP)
                  tup_probe <- dbgProbe;</pre>
  Probe#(Request) req_probe <- dbgProbe;</pre>
  rule every;
      // generate some values
      VOB v_of_bools = unpack(truncate(count));
      TUP a_tuple
                   = unpack(truncate(count));
      Request request = unpack(truncate(value));
      // send signals to waves.
      vob_probe <= v_of_bools;</pre>
      tup_probe <= a_tuple;</pre>
      req_probe <= request;</pre>
      // show use with $display
      $display(" A Vector: ", fshow(v_of_bools));
      $display(" A Tuple: ", fshow(a_tuple));
      $display(" A Request: ", fshow(request));
      $display("----");
      // update values
      value <= (value << 1) | {0, (value[31] ^ value[21] ^ value[1] ^ value[01])};</pre>
      count <= count + 1;</pre>
      if (count == 30) $finish;
   endrule
endmodule
```

C.8.9 DefaultValue

Package

```
import DefaultValue :: * ;
```

Description

This package defines a type class of DefaultValue and instances of the type class for many commonly used datatypes. Users can create their own default value instances for other types. This type class is particularly useful for defining default values for user-defined structures.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Typeclasses

```
typeclass DefaultValue #( type t );
    t defaultValue ;
endtypeclass
```

The following instances are defined in the **DefaultValue** package. You can define your own instances for user-defined structures and other types.

DefaultValue Instances				
Literal#(t)	Any type t in the Literal class can have a default value which is defined here as 0. The types in the Literal class include Bit#(n), Int#(n), UInt#(n), Real, Integer, FixedPoint, and Complex. instance DefaultValue # (t) provisos (Literal#(t)); defaultValue = fromInteger (0);			

Bool	The default value for a Bool is defined as False.				
	<pre>instance DefaultValue #(Bool); defaultValue = False ;</pre>				

void	The default value for a void is defined as ?.
	<pre>instance DefaultValue #(void); defaultValue = ?;</pre>

Maybe	The default value for a Maybe is defined as tagged Invalid.
	<pre>instance DefaultValue #(Maybe#(t)); defaultValue = tagged Invalid ;</pre>

The default value for a Tuple is composed of the default values of each member type. Instances are defined for Tuple2 through Tuple8.

Examples

Example 1: Specifying the initial or reset values for a structure.

Example 2: Using default values to replace the unsafe use of unpack.

```
import DefaultValue :: *;
typedef struct {
  UInt#(4) size;
  UInt#(3) depth;
  } MyStruct
deriving (Bits, Eq);
instance DefaultValue #( MyStruct );
  defaultValue = MyStruct { size : 0,
                            depth : 1 };
endinstance
then you can use:
   Reg#(MyStruct)
                                 mstr <- mkReg(defaultValue);</pre>
instead of:
   Reg#(MyStruct)
                                  mybad <- mkReg(unpack(0)); // Bad use of unpack</pre>
```

Example 3: Module instantiation which requires a large structure as an argument.

```
ModParam modParams = defaultValue ;  // generate default value
modParams.field1 = 5 ;  // override some default values
modParams.field2 = 1.4 ;
ModIfc <- mkMod (modArgs) ;  // construct the module</pre>
```

C.8.10 TieOff

Package

```
import TieOff :: * ;
```

Description

This package provides a typeclass TieOff#(t) which may be userful to provide default enable methods of some interface t, some of which must be always_enabled or require some action.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Typeclasses

```
typeclass TieOff #(type t);
  module mkTieOff#(t ifc) (Empty);
endtypeclass
```

Example: Defining a TieOff for a Get interface

This is a sink module which pulls data from the Get interface and displays the data.

C.8.11 Assert

Package

```
import Assert :: *;
```

Description

The Assert package contains definitions to test assertions in the code. The check-assert flag must be set during compilation. By default the flag is set to False and assertions are ignored. The flag, when set, instructs the compiler to abort compilation if an assertion fails.

Functions

staticAssert	Compile time assertion. Can be used anywhere a compile-time statement is valid.
	<pre>module staticAssert(Bool b, String s);</pre>

dynamicAssert	Run time assertion. Can be used anywhere an Action is valid, and is tested whenever it is executed.
	function Action dynamicAssert(Bool b, String s);
continuousAssert	Continuous run-time assertion (expected to be True on each clock). Can be used anywhere a module instantiation is valid.
	<pre>function Action continuousAssert(Bool b, String s);</pre>

Examples using Assertions:

```
import Assert:: *;
module mkAssert_Example ();
  // A static assert is checked at compile-time
  // This code checks that the indices are within range
 for (Integer i=0; i<length(cs); i=i+1)</pre>
        Integer new_index = (cs[i]).index;
        staticAssert(new_index < valueOf(n),</pre>
            strConcat("Assertion index out of range: ", integerToString(new_index)));
      end
  rule always_fire (True);
       counter <= counter + 1;</pre>
  endrule
  // A continuous assert is checked on each clock cycle
  continuousAssert (!fail, "Failure: Fail becomes True");
  // A dynamic assert is checked each time the rule is executed
  rule test_assertion (True);
     dynamicAssert (!fail, "Failure: Fail becomes True");
  endrule
endmodule: mkAssert_Example
```

C.8.12 Probe

Package

```
import Probe :: *;
```

Description

A Probe is a primitive used to ensure that a signal of interest is not optimized away by the compiler and that it is given a known name. In terms of BSV syntax, the Probe primitive it used just like a register except that only a write method exists. Since reads are not possible, the use of a Probe has no effect on scheduling. In the generated Verilog, the associated signal will be named just like the port of any Verilog module, in this case <instance_name>\$PROBE. No actual Probe instance will be created however. The only side effects of a BSV Probe instantiation relate to the naming and retention of the associated signal in the generated Verilog.

Interfaces

```
interface Probe #(type a_type);
   method Action _write(a_type x1);
endinterface: Probe
```

Modules

The module mkProbe is used to instantiate a Probe.

mkProbe	Instantiates a Probe
	<pre>module mkProbe(Probe#(a_type)) provisos (Bits#(a_type, sizea));</pre>

Example - Creating and writing to registers and probes

```
import FIF0::*;
import ClientServer::*;
import GetPut::*;
import Probe::*;
typedef Bit#(32) LuRequest;
typedef Bit#(32) LuResponse;
module mkMesaHwLpm(ILpm);
   // Create registers for requestB32 and responseB32
   Reg#(LuRequest) requestB32 <- mkRegU();</pre>
   Reg#(LuResponse) responseB32 <- mkRegU();</pre>
   // Create a probe responseB32_probe
   Probe#(LuResponse) responseB32_probe <- mkProbe();</pre>
   // Define the interfaces:
      interface Get response;
         method get() ;
            actionvalue
               let resp <- completionBuffer.drain.get();</pre>
               // record response for debugging purposes:
               let {r,t} = resp;
               responseB32 <= r;  // a write to a register</pre>
               responseB32_probe <= r; // a write to a probe</pre>
               // count responses in status register
               return(resp);
            endactionvalue
         endmethod: get
      endinterface: response
    . . . . .
endmodule
```

C.8.13 Reserved

Package

```
import Reserved :: *;
```

Description

The Reserved package defines three abstract data types which only have the purpose of taking up space. They are useful when defining a struct where you need to enforce a certain layout and want to use the type checker to enforce that the value is not accidently used. One can enforce a layout unsafely with Bit#(n), but Reserved#(n) gives safety. A value of type Reserved#(n) takes up exactly n bits.

```
typedef ··· abstract ··· Reserved#(type n);
```

Types and Type classes

There are three types defined in the Reserved package: Reserved, ReservedZero, and ReservedOne. The Reserved type is an abstract data type which takes up exactly n bits and always returns an unspecified value. The ReservedZero and ReservedOne data types are equivalent to the Reserved type except that ReservedZero always returns '0 and ReservedOne always returns '1.

Type Classes used by Reserved									
	Bits	Eq	Literal	Arith	Ord	Bounded	Bit	Bit	Bit
							wise	Reduction	Extend
Reserved									
ReservedZero									
ReservedOne									

• Bits The only purpose of these types is to allow the value to exist in hardware (at port boundaries and in states). The user should have no reason to use pack/unpack directly.

Converting Reserved to or from Bits returns a don't care (?).

Converting ReservedZero to or from Bits returns a '0.

Converting ReservedOne to or from Bits returns a '1.

• Eq and Ord

Any two Reserved, ReservedZero, or ReservedOne values are considered to be equal.

• Bounded

The upper and lower bound return don't care (?), '1 or '0 values depending on the type.

Example: Structure with a 8 bits reserved.

header	payload0	payload1	dummy	trailer
8	8	8	8	8

C.8.14 TriState

Package

```
import TriState :: *;
```

Description

The TriState package implements a tri-state buffer, as shown in Figure 5. Depending on the value of the output_enable, inout can be an input or an output.




Figure 5: TriState Buffer

The buffer has two inputs, an input of type value_type and a Boolean output_enable which determines the direction of inout. If output_enable is True, the signal is coming in from input and out through inout and output. If output_enable is False, then a value can be driven in from inout, and the output value will be the value of inout. The behavior is described in the tables below.

$ output_enable = 0 $ $ output = inout $					
Inputs					
input	inout	output			
0	0	0			
0	0 1				
1	0	0			
1	1	1			

$output_enable = 1$					
output = in					
inout = in					
	Outputs				
input	inout output				
0	0 0				
1	1 1				

This module is not supported in Bluesim.

Interfaces and Methods

The TriState interface is composed of an Inout interface and a _read method. The _read method is similar to the _read method of a register in that to read the method you reference the interface in an expression.

TriState Interface							
Name Type Description							
io	Inout#(value_type) Inout subinterface providing a value of type value_type						
_read	value_type Returns the value of output						

```
(* always_ready, always_enabled *)
interface TriState#(type value_type);
  interface Inout#(value_type) io;
  method value_type __read;
endinterface: TriState
```

Modules and Functions

The TriState package provides a module constructor function, mkTriState, which provides the TriState interface. The interface includes an Inout subinterface and the value of output.

mkTriState	Creates a module which provides the TriState interface.
	<pre>module mkTriState#(Bool output_enable, value_type input)</pre>

Verilog Modules

The TriState module is implemented by the Verilog module TriState.v which can be found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

C.8.15 ZBus

Package

```
import ZBus :: * ;
```

Description

BSV provides the ZBus library to allow users to implement and use tri-state buses. Since BSV does not support high-impedance or undefined values internally, the library encapsulates the tri-state bus implementation in a module that can only be accessed through predefined interfaces which do not allow direct access to internal signals (which could potentially have high-impedance or undefined values).

The Verilog implementation of the tri-state module includes a number of primitive sub-modules that are implemented using Verilog tri-state wires. The BSV representation of the bus, however, only models the values of the bus at the associated interfaces and thus the need to represent high-impedance or undefined values in BSV is avoided.

A ZBus consists of a series of clients hanging off of a bus. The combination of the client and the bus is provided by the ZBusDualIFC interface which consists of 2 subinterfaces, the client and the bus. The client subinterface is provided by the ZBusClientIFC interface. The bus subinterface is provided by the ZBusBusIFC interface. The user never needs to manipulate the bus side, this is all done internally. The user builds the bus out of ZBusDualIFCs and then drives values onto the bus and reads values from the bus using the ZBusClientIFC.

Interfaces and Methods

There are three interfaces are defined in this package; ZBusDualIFC, ZBusClientIFC, and ZBusBusIFC.

The ZBusDualIFC interface provides two subinterfaces; a ZBusBusIFC and a ZBusClientIFC. For a given bus, one ZBusDualIFC interface is associated with each bus client.

	ZBusDualIFC				
Name Type Description					
busIFC	The subinterface providing the bus side of ZBus.				
clientIFC ZBusClientIFC#(t) The subinterface providing the client side to ZBus.					

```
interface ZBusDualIFC #(type value_type) ;
  interface ZBusBusIFC#(value_type) busIFC;
  interface ZBusClientIFC#(value_type) clientIFC;
endinterface
```

The ZBusClientIFC allows a BSV module to connect to the tri-state bus. The drive method is used to drive a value onto the bus. The get() and fromBusValid() methods allow each bus client to access the current value on the bus. If the bus is in an invalid state (i.e. has a high-impedance value or an undefined value because it is being driven by more than one client simultaneously), then the get() method will return 0 and the fromBusValid() method will return False. In all other cases, the fromBusValid() method will return True and the get() method will return the current value of the bus.

ZBusClientIFC					
	Metho		Argument		
Name	Type	Description	Name	Description	
drive	Action	Drives a current value on	value	The value being put on	
		to the bus		the bus, datatype of	
				value_type.	
get	value_type	Returns the current			
		value on the bus.			
fromBusValid	Bool	Returns False if the bus			
		has a high-impedance			
		value or is undefined.			

The ZBusBusIFC interface connects to the bus structure itself using tri-state values. This interface is never accessed directly by the user.

Modules and Functions

The library provides a module constructor function, mkZBusBuffer, which allows the user to create a module which provides the ZBusDualIFC interface. This module provides the functionality of a tri-state buffer.

```
mkZBusBuffer

Creates a module which provides the ZBusDualIFC interface.

module mkZBusBuffer (ZBusDualIFC #(value_type))
provisos (Eq#(value_type), Bits#(value_type, size_value));
```

The mkZBus module constructor function takes a list of ZBusBusIFC interfaces as arguments and creates a module which ties them all together in a bus.

```
mkZBus

Ties a list of ZBusBusIFC interfaces together in a bus.

module mkZBus#(List#(ZBusBusIFC#(value_type)) ifc_list)(Empty)
provisos (Eq#(value_type), Bits#(value_type, size_value));
```

Examples - ZBus

Creating a tri-state buffer for a 32 bit signal. The interface is named buffer_0.

```
ZBusDualIFC#(Bit#(32)) buffer_0();
mkZBusBuffer inst_buffer_0(buffer_0);
```

Drive a value of 12 onto the associated bus.

```
buffer_0.clientIFC.drive(12);
```

The following code fragment demonstrates the use of the module ${\tt mkZBus}$.

C.8.16 CRC

Package

```
import CRC :: * ;
```

Description

CRC's are designed to protect against common types of errors on communication channels. The CRC package defines modules to calculate a check value for each 8-bit block of data, which can then be verified to determine if data was transmitted and/or received correctly. There are many commonly used and standardized CRC algorithms. The CRC package provides both a generalized CRC module as well as module implementations for the CRC-CCITT, CRC-16-ANSI, and CRC-32 (IEEE 802.3) standards. The size of the CRC polynomial is polymorphic and the data size is a byte (Bit#(8)), which is relevant for many applications. The generalized module uses five arguments to define the CRC algorithm: the CRC polynomial, the initial CRC value, a fixed bit pattern to Xor with the remainder, a boolean indicating whether to reverse the data bit order and a boolean indicating whether to reverse the result bit order. By specifying these arguments, you can implement many CRC algorithms. This package provides modules for three specific algorithms by defining the arguments for those algorithms.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Interfaces and Methods

The CRC modules provide the CRC interface. The add method is used to calculate the check value on the data argument. In this package, the argument is always a Bit#(8).

CRC Interface					
	Method		Argu	iments	
Name	Type	Description	Name	Description	
add	Action	Update the CRC	Bit#(8) data	8-bit data block	
clear Action		Reset to the initial value			
result	esult Bit#(n) Returns the current value of the check value			value	
complete	ActionValue(Bit#(n))	Return the result and reset			

```
interface CRC#(numeric type n);
  method    Action    add(Bit#(8) data);
  method    Action    clear();
  method    Bit#(n) result();
  method    ActionValue#(Bit#(n)) complete();
endinterface
```

Modules

The implementation of the generalized CRC module takes the following five arguments:

- Bit#(n) polynomial: the crc operation polynomial, for example $x^{16} + x^{12} + x^5 + 1$ is written as 'h1021
- Bit#(n) initval: the initial CRC value

- Bit#(n) finalXor: the result is xor'd with this value if desired
- Bool reflectData: if True, reverse the data bit order
- Bool reflectRemainder: if True, reverse the result bit order

mkCRC	The generalized CRC module. The provisos enforce the requirement that polynomial and initial value must be at least 8 bits.			
	module mkCRC#(Bit#(n) polynomial			
	, Bit#(n) initval			
	, Bit#(n) finalXor			
	, Bool reflectData			
	, Bool reflectRemainder			
)(CRC#(n))			
	provisos(Add#(8, n8, n));			
	-			

CRC Arguments for Common Standards						
Name	polynomial	initval	finalXor	reflectData	reflectRemainder	
CRC-CCITT	'h1021	'hFFFF	'h0000	False	False	
CRC-16-ANSI	'h8005	'h0000	'h0000	True	True	
CRC-32 (IEEE 802.3)	'h04C11DB7	'hFFFFFFF	'hFFFFFFF	True	True	

mkCRC_CCIT	Implements the 16-bit CRC-CCITT standard. $(x^{16} + x^{15} + x^2 + 1)$.
	<pre>module mkCRC_CCITT(CRC#(16));</pre>

mkCRC16	Implementation of the 16-bit CRC-16-ANSI standard. $(x^{16} + x^{15} + x^2 + 1)$.	
	<pre>module mkCRC16(CRC#(16));</pre>	

mkCRC32	Implementation of the 32-bit CRC-32 (IEEE 802.3) standard. $(x^{32} + x^{26} + x^{23} + x^{22} + x^{16} + x^{12} + x^{11} + x^{10} + x^8 + x^7 + x^5 + x^4 + x^2 + x^1 + 1)$	
	module mkCRC32(CRC#(32));	

```
The reflect function reverses the data bits if the value of reflectData is True.

function Bit#(a) reflect(Bool doIt, Bit#(a) data);
return (doIt) ? reverseBits(data) : data;
endfunction
```

C.8.17 OVLAssertions

Package

```
import OVLAssertions :: *;
```

Description

The OVLAssertions package provides the BSV interfaces and wrapper modules necessary to allow BSV designs to include assertion checkers from the Open Verification Library (OVL). The OVL includes a set of assertion checkers that verify specific properties of a design. For more details on the complete OVL, refer to the Accellera Standard OVL Library Reference Manual (http://www.accellera.org).

Interfaces and Methods

The following interfaces are defined for use with the assertion modules. Each interface has one or more Action methods. Each method takes a single argument which is either a Bool or polymorphic.

AssertTest_IFC Used for assertions that check a test expression on every clock cycle.

AssertTest_IFC				
Method Argument				
Name	Type	Name	Type	Description
test	Action	test_value	a_type	Expression to be checked.

```
interface AssertTest_IFC #(type a_type);
  method Action test(a_type test_value);
endinterface
```

AssertSampleTest_IFC Used for assertions that check a test expression on every clock cycle only if the sample, indicated by the boolean value sample_test is asserted.

AssertSampleTest_IFC				
Method				Argument
Name	Type	Name Type Description		
sample	Action	sample_test	Bool	Assertion only checked if sample_test is asserted.
test	Action	test_value	a_type	Expression to be checked.

```
interface AssertSampleTest_IFC #(type a_type);
  method Action sample(Bool sample_test);
  method Action test(a_type test_value);
endinterface
```

AssertStartTest_IFC Used for assertions that check a test expression only subsequent to a start_event, specified by the Boolean value **start_test**.

	AssertStartTest_IFC				
Method		Argument			
Name	Type	Name Type Description			
start	Action	start_test	Bool	Assertion only checked after start is asserted.	
test	Action	test_value	a_type	Expression to be checked.	

```
interface AssertStartTest_IFC #(type a_type);
  method Action start(Bool start_test);
  method Action test(a_type test_value);
endinterface
```

AssertStartStopTest_IFC Used to check a test expression between a start_event and a stop_event.

	AssertStartStopTest_IFC				
Method		Argument			
Name	Type	Name Type Description		Description	
start	Action	start_test	Bool	Assertion only checked after start is asserted.	
stop	Action	stop_test	Bool	Assertion only checked until the stop is asserted.	
test	Action	test_value	a_type	Expression to be checked.	

```
interface AssertStartStopTest_IFC #(type a_type);
  method Action start(Bool start_test);
  method Action stop(Bool stop_test);
  method Action test(a_type test_value);
endinterface
```

AssertTransitionTest_IFC Used to check a test expression that has a specified start state and next state, i.e. a transition.

	AssertTransitionTest_IFC				
Metl	nod	Argument			
Name	Type	Name	Type	Description	
test	Action	test_value	a_type	Expression that should transition to the	
				next_value.	
start	Action	start_test	a_type	Expression that indicates the start state for the assertion check. If the value of start_test equals the value of test_value, the check is performed.	
next	Action	next_value	a_type	Expression that indicates the only valid next state for the assertion check.	

```
interface AssertTransitionTest_IFC #(type a_type);
  method Action test(a_type test_value);
  method Action start(a_type start_value);
  method Action next(a_type next_value);
endinterface
```

AssertQuiescentTest_IFC Used to check that a test expression is equivalent to the specified expression when the sample state is asserted.

	AssertQuiescentTest_IFC				
Metl	Method		Argument		
Name	Type	Name	Type	Description	
sample	Action	sampe_test	Bool	Expression which initiates the quiescent assertion check when it transistions to true.	
state	Action	state_value	a_type	Expression that should have the same value as check_value	
check	Action	check_value	a_type	Expression state_value is compared to.	

```
interface AssertQuiescentTest_IFC #(type a_type);
  method Action sample(Bool sample_test);
  method Action state(a_type state_value);
  method Action check(a_type check_value);
endinterface
```

AssertFifoTest_IFC Used with assertions checking a FIFO structure.

	AssertFifoTest_IFC				
Met	hod	Argument			
Name	Type	Name	Type	Description	
push	Action	push_value	a_type	Expression which indicates the number of push operations that will occur during the current cycle.	
pop	Action	pop_value	a_type	Expression which indicates the number of pop operations that will occur during the current cycle.	

```
interface AssertFifoTest_IFC #(type a_type, type b_type);
  method Action push(a_type push_value);
  method Action pop(b_type pop_value);
endinterface
```

Datatypes

The parameters severity_level, property_type, msg, and coverage_level are common to all assertion checkers.

Common Parameters for all Assertion Checkers		
Parameter	Valid Values	
	* indicates default value	
severity_level	OVL_FATAL	
	*OVL_ERROR	
	OVL_WARNING	
	OVL_Info	
property_type	*OVL_ASSERT	
	OVL_ASSUME	
	OVL_IGNORE	
msg	*VIOLATION	
coverage_level	OVL_COVER_NONE	
	*OVL_COVER_ALL	
	OVL_COVER_SANITY	
	OVL_COVER_BASIC	
	OVL_COVER_CORNER	
	OVL_COVER_STATISTIC	

Each assertion checker may also use some subset of the following parameters.

Other Parameters for Assertion Checkers		
Parameter	Valid Values	
action_on_new_start	OVL_IGNORE_NEW_START	
	OVL_RESET_ON_NEW_START	
	OVL_ERROR_ON_NEW_START	
edge_type	OVL_NOEDGE	
	OVL_POSEDGE	
	OVL_NEGEDGE	
	OVL_ANYEDGE	
necessary_condition	OVL_TRIGGER_ON_MOST_PIPE	
	OVL_TRIGGER_ON_FIRST_PIPE	
	OVL_TRIGGER_ON_FIRST_NOPIPE	
inactive	OVL_ALL_ZEROS	
	OVL_ALL_ONES	
	OVL_ONE_COLD	

Other Parameters for Assertion Checkers			
Parameter	Valid Values		
num_cks	Int#(32)		
min_cks	Int#(32)		
max_cks	Int#(32)		
min_ack_cycle	Int#(32)		
max_ack_cycle	Int#(32)		
max_ack_length	Int#(32)		
req_drop	Int#(32)		
deassert_count	Int#(32)		
depth	Int#(32)		
value	a_type		
min	a_type		
max	a_type		
check_overlapping	Bool		
check_missing_start	Bool		
simultaneous_push_pop	Bool		

Setting Assertion Parameters

Each assertion checker module has a set of associated parameter values that can be customized for each module instantiation. The values for these parameters are passed to each checker module in the form of a single struct argument of type OVLDefaults#(a) A typical use scenario is illustrated below:

```
let defaults = mkOVLDefaults;
defaults.min_clks = 2;
defaults.max_clks = 3;
AssertTest_IFC#(Bool) assertWid <- bsv_assert_width(defaults);</pre>
```

The defaults struct (created by mkOVLDefaults) includes one field for each possible parameter. Initially each field includes the associated default value. By editing fields of the struct, individual

parameter values can be modified as needed to be non-default values. The modified <code>defaults</code> struct is then provided as a module argument during instantiation.

Modules

Each module in this package corresponds to an assertion checker from the Open Verification Library (OVL). The BSV name for each module is the same as the OVL name with <code>bsv_</code> appended to the beginning of the name.

Module	bsv_assert_always
Description	Concurrent assertion that the value of the expression is always True.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_always#(OVLDefaults#(Bool) defaults)</pre>

Module	bsv_assert_always_on_edge
Description	Checks that the test expression evaluates True whenever the sample
	method is asserted.
Interface Used	AssertSampleTest_IFC
Parameters	common assertion parameters
	<pre>edge_type (default value = OVL_NOEDGE)</pre>
Module Declaration	<pre>module bsv_assert_always_on_edge#(OVLDefaults#(Bool)</pre>

Module	bsv_assert_change	
Description	Checks that once the start method is asserted, the expression will change	
	value within num_cks cycles.	
Interface Used	AssertStartTest_IFC	
Parameters	common assertion parameters	
	action_on_new_start (default value = OVL_IGNORE_NEW_START)	
	num_cks (default value = 1)	
Module Declaration	<pre>module bsv_assert_change#(OVLDefaults#(a_type) defaults)</pre>	

Module	bsv_assert_cycle_sequence
Description	Ensures that if a specified necessary condition occurs, it is followed by a
	specified sequence of events.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
	${\tt necessary_condition} \ ({\tt default} \ {\tt value} = {\tt OVL_TRIGGER_ON_MOST_PIPE})$
Module Declaration	<pre>module bsv_assert_cycle_sequence#(OVLDefaults#(a_type)</pre>

Module	bsv_assert_decrement
Description	Ensures that the expression decrements only by the value specified R.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
	value (default value = 1)
Module Declaration	<pre>module bsv_assert_decrement#(OVLDefaults#(a_type) defaults)</pre>

Module	bsv_assert_delta
Description	Ensures that the expression always changes by a value within the range
	specified by min and max.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
	min (default value = 1)
	$\max (\text{default value} = 1)$
Module Declaration	<pre>module bsv_assert_delta#(OVLDefaults#(a_type) defaults)</pre>

Module	bsv_assert_even_parity
Description	Ensures that value of a specified expression has even parity, that is an
	even number of bits in the expression are active high.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_even_parity#(OVLDefaults#(a_type)</pre>

Module	bsv_assert_fifo_index
Description	Ensures that a FIFO-type structure never overflows or underflows. This
	checker can be configured to support multiple pushes (FIFO writes) and
	pops (FIFO reads) during the same clock cycle.
Interface Used	AssertFifoTest_IFC
Parameters	common assertion parameters
	depth (default value = 1)
	$simultaneous_push_pop (default value = True)$
Module Declaration	<pre>module bsv_assert_fifo_index#(OVLDefaults#(Bit#(0))</pre>

Module	bsv_assert_frame
Description	Checks that once the start method is asserted, the test expression eval-
	uates true not before min_cks clock cycles and not after max_cks clock
	cycles.
Interface Used	AssertStartTest_IFC
Parameters	common assertion parameters
	action_on_new_start (default value = OVL_IGNORE_NEW_START)
	min_cks (default value = 1)
	$max_cks (default value = 1)$
Module Declaration	<pre>module bsv_assert_frame#(OVLDefaults#(Bool) defaults)</pre>

Module	bsv_assert_handshake
Description	Ensures that the specified request and acknowledge signals follow a spec-
	ified handshake protocol.
Interface Used	AssertStartTest_IFC
Parameters	common assertion parameters
	$action_on_new_start (default value = OVL_IGNORE_NEW_START)$
	$min_ack_cycle (default value = 1)$
	$max_ack_cycle (default value = 1)$
Module Declaration	<pre>module bsv_assert_handshake#(OVLDefaults#(Bool) defaults)</pre>

Module	bsv_assert_implication
Description	Ensures that a specified consequent expression is True if the specified
	antecedent expression is True.
Interface Used	AssertStartTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_implication#(OVLDefaults#(Bool) defaults)</pre>

Module	bsv_assert_increment
Description	ensure that the test expression always increases by the value of specified
	by value.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
	value (default value = 1)
Module Declaration	<pre>module bsv_assert_increment#(OVLDefaults#(a_type) defaults)</pre>

Module	bsv_assert_never
Description	Ensures that the value of a specified expression is never True.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_never#(OVLDefaults#(Bool) defaults)</pre>

Module	bsv_assert_never_unknown
Description	Ensures that the value of a specified expression contains only 0 and 1
	bits when a qualifying expression is True.
Interface Used	AssertStartTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_never_unknown#(OVLDefaults#(a_type)</pre>

Module	bsv_assert_never_unknown_async
Description	Ensures that the value of a specified expression always contains only 0
	and 1 bits
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_never_unknown_async#(OVLDefaults#(a_type)</pre>

Module	bsv_assert_next
Description	Ensures that the value of the specified expression is true a specified
	number of cycles after a start event.
Interface Used	AssertStartTest_IFC
Parameters	common assertion parameters
	$num_cks (default value = 1)$
	$check_overlapping (default value = True)$
	${\tt check_missing_start} \ ({\tt default} \ {\tt value} = {\tt False})$
Module Declaration	<pre>module bsv_assert_next#(OVLDefaults#(Bool) defaults)</pre>

Module	bsv_assert_no_overflow
Description	Ensures that the value of the specified expression does not overflow.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
	min (default value = minBound)
	$\max (\text{default value} = \max \text{Bound})$
Module Declaration	<pre>module bsv_assert_no_overflow#(OVLDefaults#(a_type)</pre>

Module	bsv_assert_no_transition
Description	Ensures that the value of a specified expression does not transition from
	a start state to the specified next state.
Interface Used	AssertTransitionTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_no_transition#(OVLDefaults#(a_type)</pre>

Module	bsv_assert_no_underflow
Description	Ensures that the value of the specified expression does not underflow.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
	min (default value = minBound)
	$\max (\text{default value} = \max \text{Bound})$
Module Declaration	<pre>module bsv_assert_no_underflow#(OVLDefaults#(a_type)</pre>

Module	bsv_assert_odd_parity
Description	Ensures that the specified expression had odd parity; that an odd num-
	ber of bits in the expression are active high.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_odd_parity#(OVLDefaults#(a_type)</pre>

Module	bsv_assert_one_cold
Description	Ensures that exactly one bit of a variable is active low.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
	<pre>inactive (default value = OLV_ONE_COLD)</pre>
Module Declaration	<pre>module bsv_assert_one_cold#(OVLDefaults#(a_type) defaults)</pre>

Module	bsv_assert_one_hot
Description	Ensures that exactly one bit of a variable is active high.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_one_hot#(OVLDefaults#(a_type) defaults)</pre>

Module	bsv_assert_proposition
Description	Ensures that the test expression is always combinationally True. Like
	assert_always except that the test expression is not sampled by the
	clock.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_proposition#(OVLDefaults#(Bool) defaults)</pre>

Module	bsv_assert_quiescent_state
Description	Ensures that the value of a specified state expression equals a corre-
	sponding check value if a specified sample event has transitioned to
	TRUE.
Interface Used	AssertQuiescentTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_quiescent_state#(OVLDefaults#(a_type)</pre>

Module	bsv_assert_range
Description	Ensure that an expression is always within a specified range.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
	min (default value = minBound)
	max (default value = maxBound)
Module Declaration	<pre>module bsv_assert_range#(OVLDefaults#(a_type) defaults)</pre>

Module	bsv_assert_time
Description	Ensures that the expression remains True for a specified number of clock
	cycles after a start event.
Interface Used	AssertStartTest_IFC
Parameters	common assertion parameters
	$\verb action_on_new_start (default value = OVL_IGNORE_NEW_START)$
	$num_cks (default value = 1)$
Module Declaration	<pre>module bsv_assert_time#(OVLDefaults#(Bool) defaults)</pre>

Module	bsv_assert_transition
Description	Ensures that the value of a specified expression transitions properly
	from start state to the specified next state.
Interface Used	AssertTransitionTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_transition#(OVLDefaults#(a_type)</pre>

Module	bsv_assert_unchange
Description	Ensures that the value of the specified expression does not change during
	a specified number of clock cycles after a start event initiates checking.
Interface Used	AssertStartTest_IFC
Parameters	common assertion parameters
	action_on_new_start (default value = OVL_IGNORE_NEW_START)
	$num_cks (default value = 1)$
Module Declaration	<pre>module bsv_assert_unchange#(OVLDefaults#(a_type) defaults)</pre>

Module	bsv_assert_width			
Description	Ensures that when the test expression goes high it stays high for at least			
	min and at most max clock cycles.			
Interface Used	AssertTest_IFC			
Parameters	common assertion parameters			
	min_cks (default value = 1)			
	$max_cks (default value = 1)$			
Module Declaration	<pre>module bsv_assert_width#(OVLDefaults#(Bool) defaults)</pre>			

Module	bsv_assert_win_change			
Description	Ensures that the value of a specified expression changes in a specified			
	window between a start event and a stop event.			
Interface Used	AssertStartStopTest_IFC			
Parameters	common assertion parameters			
Module Declaration	<pre>module bsv_assert_win_change#(OVLDefaults#(a_type)</pre>			

Module	bsv_assert_win_unchange			
Description	Ensures that the value of a specified expression does not change in a			
	specified window between a start event and a stop event.			
Interface Used	AssertStartStopTest_IFC			
Parameters	common assertion parameters			
Module Declaration	<pre>module bsv_assert_win_unchange#(OVLDefaults#(a_type)</pre>			

Module	bsv_assert_window			
Description	Ensures that the value of a specified event is True between a specifie			
	window between a start event and a stop event.			
Interface Used	AssertStartStopTest_IFC			
Parameters	common assertion parameters			
Module Declaration	<pre>module bsv_assert_window#(OVLDefaults#(Bool) defaults)</pre>			

Module	bsv_assert_zero_one_hot
Description	ensure that exactly one bit of a variable is active high or zero.
Interface Used	AssertTest_IFC
Parameters	common assertion parameters
Module Declaration	<pre>module bsv_assert_zero_one_hot#(OVLDefaults#(a_type)</pre>

Example using bsv_assert_increment

This example checks that a test expression is always incremented by a value of 3. The assertion passes for the first 10 increments and then starts failing when the increment amount is changed from 3 to 1.

```
// import the OVL Assertions package
import OVLAssertions::*;
module assertIncrement (Empty);
   Reg#(Bit#(8)) count <- mkReg(0);</pre>
   Reg#(Bit#(8)) test_expr <- mkReg(0);</pre>
   // set the default values
   let defaults = mkOVLDefaults;
   // override the default increment value and set = 3
   defaults.value = 3;
   // instantiate an instance of the module bsv_assert_increment using
   // the name assert_mod and the interface AssertTest_IFC
   AssertTest_IFC#(Bit#(8)) assert_mod <- bsv_assert_increment(defaults);</pre>
                                    // Every clock cycle
   rule every (True);
      assert_mod.test(test_expr); // the assertion is checked
   endrule
   rule increment (True);
      count <= count + 1;</pre>
      if (count < 10)
                                       // for 10 cycles
          test_expr <= test_expr + 3; // increment the expected amount</pre>
      else if (count < 15)
          test_expr <= test_expr + 1; // then start incrementing by 1</pre>
      else
          $finish;
   endrule
endmodule
```

Using The Library

In order to use the OVLAssertions package, a user must first download the source OVL library from Accellera (http://www.accellera.org). In addition, that library must be made available when building a simulation executable from the BSV generated Verilog.

If the bsc compiler is being used to generate the Verilog simulation executable, the BSC_VSIM_FLAGS environment variable can be used to set the required simulator flags that enable use of the OVL library.

For instance, if the iverilog simulator is being used and the OVL library is located in the directory shared/std_ovl, the BSC_VSIM_FLAGS environment variable can be set to "I shared/std_ovl -Y .vlib -y shared/std_ovl -DOVL_VERILOG=1 -DOVL_ASSERT_ON=1". These flags:

- Add shared/std_ovl to the Verilog and include search paths.
- Set .vlib as a possible file suffix.
- Set flags used in the OVL source code.

The exact flags to be used will differ based on what OVL behavior is desired and which Verilog simulator is being used.

C.9 Multiple Clock Domains and Clock Generators

Package

```
import Clocks :: * ;
```

Description

The BSV Clocks library provide features to access and change the default clock. Moreover, there are hardware primitives to generate clocks of various shapes, plus several primitives which allow the safe crossing of signals and data from one clock domain to another.

The Clocks package uses the data types Clock and Reset as well as clock functions which are described below but defined in the Prelude package.

Each section describes a related group of modules, followed by a table indicating the Verilog modules used to implement the BSV modules.

Types and typeclasses

The Clocks package uses the abstract data types Clock and Reset, which are defined in the Prelude package. These are first class objects. Both Clock and Reset are in the Eq type class, meaning two values can be compared for equality.

Clock is an abstract type of two components: a single Bit oscillator and a Bool gate.

```
typedef ... Clock ;
Reset is an abstract type.
typedef ... Reset ;
```

Type Classes for Clock and Reset									
	Bits	Eq	Literal	Arith	Ord	Bounded	Bitwise	Bit	Bit
								Reduction	Extend
Clock									
Reset									

Example: Declaring a new clock

Clock clk0;

Example: Instantiating a register with clock and reset

```
Reg#(Byte) a <- mkReg(0, clocked_by clks0, reset_by rst0);</pre>
```

Functions

The following functions are defined in the Prelude package but are used with multiple clock domains.

Clock Functions				
exposeCurrentClock	This function returns a value of type Clock, which is the current clock of the module.			
	<pre>module exposeCurrentClock (Clock c);</pre>			

exposeCurrentReset	This function returns a value of type Reset, which is the current reset of the module.
	<pre>module exposeCurrentReset (Reset r);</pre>

Both exposeCurrentClock and exposeCurrentReset use the module instantiation syntax (<-) to return the value. Hence these can only be used from within a module.

Example: setting a reset to the current reset

Reset reset_value <- exposeCurrentReset;</pre>

Example: setting a clock to the current clock

Clock clock_value <- exposeCurrentClock;</pre>

sameFamily	A Boolean function which returns True if the clocks are in the same family, False if the clocks are not in the same family. Clocks in the same family have the same oscillator but may have different gate conditions.
	function Bool sameFamily (Clock clka, Clock clkb);

isAncestor	A Boolean function which returns True if clka is an ancestor of clkb, that is clkb is a gated version of clka (clka itself may be gated) or if clka and clkb are the same clock. The ancestry relation is a partial order (ie., reflexive, transitive and antisymmetric).		
	function Bool isAncestor (Clock clka, Clock clkb);		

clockOf	Returns the current clock of the object obj.
	<pre>function Clock clockOf (a_type obj);</pre>
noClock	Specifies a <i>null</i> clock, a clock where the oscillator never rises.
	function Clock noClock();
resetOf	Returns the current reset of the object obj.
	<pre>function Reset resetOf (a_type obj);</pre>
noReset	Specifies a <i>null</i> reset, a reset which is never asserted.
	<pre>function Reset noReset();</pre>
invertCurrentClock	Returns a value of type Clock, which is the inverted current clock of the module.
	<pre>module invertCurrentClock(Clock);</pre>
invertCurrentReset	Returns a value of type Reset, which is the inverted current reset of the module.
	<pre>module invertCurrentReset(Reset);</pre>

C.9.1 Clock Generators and Clock Manipulation

Description

This section provides modules to generate new clocks and to modify the existing clock.

The modules mkAbsoluteClock, mkAbsoluteClockFull, mkClock, and mkUngatedClock all define a new clock, one not based on the current clock. Both mkAbsoluteClock and mkAbsoluteClockFull define new oscillators and are not synthesizable. mkClock and mkUngatedClock use an existing oscillator to create a clock, and is synthesizable. The modules, mkGatedClock and mkGatedClockFromCC use existing clocks to generate another clock in the same family.

Interfaces and Methods

The MakeClockIfc supports user-defined clocks with irregular waveforms created with mkClock and mkUngatedClock, as opposed to the fixed-period waveforms created with the mkAbsoluteClock family.

MakeClockIfc Interface						
Method and subinterfaces				Arguments		
Name	Type	Description	Name	Description		
setClockValue	Action	Changes the value of the	value	Value the clock will		
		clock at the next edge of		be set to, must be a		
		the clock		one bit type		
getClockValue	one_bit_type	Retrieves the last value of				
		the clock				
setGateCond	Action	Changes the gating condi-	gate	Must be of the type		
		tion		Bool		
getGateCond	Bool	Retrieves the last gating				
		condition set				
new_clk	Interface Clock interface provided					
		by the module				

The GatedClockIfc is used for adding a gate to an existing clock.

GatedClockIfc Interface				
Method and subinterfaces		Arguments		
Name	Name Type Description		Name	Description
setGateCond	Action	Changes the gating condi-	gate	Must be of the type
		tion		Bool
getGateCond	Bool	Retrieves the last gating		
		condition set		
new_clk	Interface	Clock interface provided		
		by the module		

```
interface GatedClockIfc ;
  method    Action setGateCond(Bool gate) ;
  method    Bool   getGateCond() ;
  interface Clock   new_clk ;
endinterface
```

Modules

The mkClock module creates a Clock type from a one-bit oscillator and a Boolean gate condition. There is no family relationship between the current clock and the clock generated by this module. The initial values of the oscillator and gate are passed as parameters to the module. When the module is out of reset, the oscillator value can be changed using the setClockValue method and the gate condition can be changed by calling the setGateCond method. The oscillator value and gate condition can be queried with the getClockValue and getGateCond methods, respectively. The clock created by mkClock is available as the new_clk subinterface. When setting the gate condition, the change does not affect the generated clock until it is low, to prevent glitches.

The mkUngatedClock module is an ungated version of the mkClock module. It takes only an oscillator argument (no gate argument) and returns the same new_clock interface. Since there is no gate, an error is returned if the design calls the setGetCond method. The getGateCond method always returns True.




Figure 6: Clock Generator

mkClock	Creates a Clock type from a one-bit oscillator input, and a Boolean gate condition. There is no family relationship between the current clock and the clock generated by this module.
	<pre>module mkClock #(one_bit_type initVal, Bool initGate)</pre>

```
mkUngatedClock

Creates an ungated Clock type from a one-bit oscillator input. There is no family relationship between the current clock and the clock generated by this module.

module mkUngatedClock #( one_bit_type initVal)

( MakeClockIfc#(one_bit_type) ifc )

provisos( Bits#(one_bit_type, 1) );
```

The mkGatedClock module adds (logic and) a Boolean gate condition to an existing clock, thus creating another clock in the same family. The source clock is provided as the argument clk_in. The gate condition is controlled by an asynchronously-reset register inside the module. The register is set with the setGateCond Action method of the interface and can be read with getGateCond method. The reset value of the gate condition register is provided as an instantiation parameter. The clock for the register (and thus these set and get methods) is the default clock of the module; to specify a clock other than the default clock, use the clocked_by directive.

mkGatedClock	Creates another clock in the same family by adding logic and a Boolean gate condition to the current clock.
	<pre>module mkGatedClock#(Bool v) (Clock clk_in, GatedClockIfc ifc);</pre>

For convenience, we provide an alternate version in which the source clock is the default clock of the module






Figure 7: Gated Clock Generator

mkGatedClockFromCC	An alternate interface for the module mkGatedClock in which the source clock is the default clock of the module.	
	<pre>module mkGatedClockFromCC#(Bool v) (GatedClockIfc ifc);</pre>	

The modules mkAbsoluteClock and mkAbsoluteClockFull provide parametizable clock generation modules which are *not* synthesizable, but may be useful for testbenches. In mkAbsoluteClock, the first rising edge (start) and the period are defined by parameters. These parameters are measured in Verilog delay times, which are usually specified during simulation with the timescale directive. Refer to the Verilog LRM for more details on delay times. s Additional parameters are provided by mkAbsoluteClockFull.





Verilog Modules

The BSV modules correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Name
mkAbsoluteClock	ClockGen.v
mkAbsoluteClockFull	
mkClock	MakeClock.v
mkUngatedClock	
mkGatedClock	GatedClock.v
mkGatedClockFromCC	

C.9.2 Clock Multiplexing

Description

Bluespec provides two gated clock multiplexing primitives: a simple combinational multiplexor and a stateful module which generates an appropriate reset signal when the clock changes. The first multiplexor uses the interface MuxClockIfc, which includes an Action method to select the clock along with a Clock subinterface. The second multiplexor uses the interface SelectClockIfc which also has a Reset subinterface.

Ungated versions of these modules are also provided. The ungated versions are identical to the gated versions, except that the input and output clocks are ungated.

Interfaces and Methods

MuxClockIfc Interface				
Method and subinterfaces				Arguments
Name Type Description		Name	Description	
select	Action	Method used to select the clock based on the Boolean value ab	ab	if True, clock_out is taken from aclk
clock_out	Interface	Clock interface		

```
interface MuxClkIfc ;
  method   Action select ( Bool ab ) ;
  interface Clock clock_out ;
endinterface
```

	SelectClockIfc Interface			
Method and subinterfaces		Arguments		
Name Type Description		Name	Description	
select	Action	Method used to select the clock based on the Boolean value ab	ab	if True, clock_out is taken from aclk
clock_out	Interface	Clock interface		
reset_out	Interface	Reset interface		

```
interface SelectClkIfc ;
  method   Action select ( Bool   ab ) ;
  interface Clock   clock_out ;
  interface Reset   reset_out ;
endinterface
```

Modules

The mkClockMux module is a simple combinational multiplexor with a registered clock selection signal, which selects between clock inputs aClk and bClk. The provided Verilog module does not provide any glitch detection or removal logic; it is the responsibility of the user to provide additional logic to provide glitch-free behavior. The mkClockMux module uses two arguments and provides a Clock interface. The aClk is selected if ab is True, while bClk is selected otherwise.

The mkUngatedClockMux module is identical to the mkClockMux module except that the input and output clocks are ungated. The signals aClkgate, bClkgate, and outClkgate in figure 8 don't exist.




Figure 8: Clock Multiplexor

mkClockMux	Simple combinational multiplexor, which selects between aClk and bClk.
	module mkClockMux (Clock aClk, Clock bClk)

mkUngatedClockMux	Simple combinational multiplexor, which selects between aClk and bClk. None of the clocks are gated.
	<pre>module mkUngatedClockMux (Clock aClk, Clock bClk)</pre>

The mkClockSelect module is a clock multiplexor containing additional logic which generates a reset whenever a new clock is selected. As such, the interface for the module includes an Action method to select the clock (if ab is True clock_out is taken from aClk), provides a Clock interface, and also a Reset interface.

The constructor for the module uses two clock arguments, and provides the MuxClockIfc interface. The underlying Verilog module is ClockSelect.v; it is expected that users can substitute their own modules to meet any additional requirements they may have. The parameter stages is the number of clock cycles in which the reset is asserted after the clock selection changes.

The mkUngatedClockSelect module is identical to the mkClockSelect module except that the input and output clocks are ungated. The signals aClkgate, bClkgate, and outClk_gate in figure 9 don't exist.




Figure 9: Clock Multiplexor with reset

mkClockSelect	Clock Multiplexor containing additional logic which generates a reset whenever a new clock is selected.
	<pre>module mkClockSelect #(Integer stages,</pre>
mkUngatedClockSelect	Clock Multiplexor containing additional logic which generates a reset whenever a new clock is selected. The input and output clocks are ungated.
	<pre>module mkUngatedClockSelect #(Integer stages,</pre>

Verilog Modules

The BSV modules correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Name
mkClockMux	ClockMux.v
mkClockSelect	ClockSelect.v
mkUngatedClockMux	UngatedClockMux.v
mkUngatedClockSelect	UngatedClockSelect.v

C.9.3 Clock Division

Description

A clock divider provides a derived clock and also a ClkNextRdy signal, which indicates that the divided clock will rise in the next cycle. This signal is associated with the input clock, and can only be used within that clock domain.

The AlignedFIFOs package (Section C.2.6) contains parameterized FIFO modules for creating synchronizing FIFOs between clock domains with aligned edges.

Data Types

The ClkNextRdy is a Boolean signal which indicates that the slow clock will rise in the next cycle.

```
typedef Bool ClkNextRdy ;
```

Interfaces and Methods

ClockDividerIfc Interface		
Name	Type	Description
fastClock	Interface	The original clock
slowClock	Interface	The derived clock
clockReady	Bool	Boolean value which indicates that the slow clock will rise
		in the next cycle. The method is in the clock domain of the
		fast clock.

```
interface ClockDividerIfc ;
  interface Clock    fastClock ;
  interface Clock    slowClock ;
  method    ClkNextRdy clockReady() ;
endinterface
```

Modules

The divider parameter may be any integer greater than 1. For even dividers the generated clock's duty cycle is 50%, while for odd dividers, the duty cycle is (divider/2)/divider. Since divisor is an integer, the remainder is truncated when divided. The current clock (or the clocked_by argument) is used as the source clock.




Figure 10: Clock Divider

mkClockDivider	Basic clock divider.
	<pre>module mkClockDivider #(Integer divisor)</pre>

mkGatedClockDivider	A gated verison of the basic clock divider.	
	<pre>module mkGatedClockDivider #(Integer divisor</pre>	

The mkClockDividerOffset module provides a clock divider where the rising edge can be defined relative to other clock dividers which have the same divisor. An offset of value 2 will produce a rising edge one fast clock after a divider with offset 1. mkClockDivider is just mkClockDividerOffset with an offset of value 0.

mkClockDividerOffset	Provides a clock divider, where the rising edge can be defined relative to other clock dividers which have the same divisor.	
	<pre>module mkClockDividerOffset #(Integer divisor,</pre>	

The mkClockInverter and mkGatedClockInverter modules generate an inverted clock having the same period but opposite phase as the current clock. The mkGatedClockInverter is a gated version of mkClockInverter. The output clock includes a gate signal derived from the gate of the input clock.

mkClockInverter	Generates an inverted clock having the same period but opposite phase as the current clock.
	<pre>module mkClockInverter (ClockDividerIfc);</pre>

mkGatedClockInverter	A gated version of mkClockInverter.	
	<pre>module mkGatedClockInverter (ClockDividerIfc ifc) ;</pre>	

Verilog Modules

The BSV modules correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Name
mkClockDivider	ClockDiv.v
mkClockDividerOffset	
mkGatedClockDivider	GatedClockDiv.v
mkClockInverter	ClockInverter.v
mkGatedClockInverter	GatedClockInverter.v

C.9.4 Bit Synchronizers

Description

Bit synchronizers are used to safely transfer one bit of data from one clock domain to another. More complicated synchronizers are provided in later sections.

Interfaces and Methods

The SyncBitIfc interface provides a send method which transmits one bit of information from one clock domain to the read method in a second domain.

SyncBitIfc Interface				
Methods		Arguments		
Name	ame Type Description		Name	Description
send	Action	Transmits information from one clock domain to the sec- ond domain	bitData	One bit of information transmitted
read	one_bit_type	Reads one bit of data sent from a different clock domain		

Modules

The mkSyncBit, mkSyncBitFromCC and mkSyncBitToCC modules provide a SyncBitIfc across clock domains. The send method is in one clock domain, and the read method is in a second clock domain, as shown in Figure 11. The FromCC and ToCC versions differ in that the FromCC module moves data from the current clock (module's clock), while the ToCC module moves data to the current clock domain. The hardware implementation is a two register synchronizer, which can be found in SyncBit.v in the Bluespec Verilog library directory.




Figure 11: Bit Synchronizer

mkSyncBit	Moves data across clock domains. The in and out clocks, along with the input reset, are explicitly provided. The default clock and reset are ignored.	
	<pre>module mkSyncBit #(Clock sClkIn, Reset sRst,</pre>	

The mkSyncBit15 module (one and a half) and its variants provide the same interface as the mkSyncBit modules, but the underlying hardware is slightly modified, as shown in Figure 12. For these synchronizers, the first register clocked by the destination clock triggers on the falling edge of the clock.




Figure 12: Bit Synchronizer 1.5 - first register in destination domain triggers on falling edge

mkSyncBit15	Similar to mkSyncBit except it triggers on the falling edge of the clock. The in and out clocks, along with the input reset, are explicitly provided. The default clock and reset are ignored.	
	<pre>module mkSyncBit15 #(Clock sClkIn, Reset sRst,</pre>	

```
Moves data from the current clock and is triggered on the falling edge of the clock. The input clock and reset are the current clock and reset.

module mkSyncBit15FromCC #(Clock dClkIn)

(SyncBitIfc #(one_bit_type))

provisos( Bits#(one_bit_type, 1));
```

The mkSyncBit1 module, shown in Figure 13, also provides the same interface but only uses one register in the destination domain. Synchronizers like this, which use only one register, are not generally used since meta-stable output is more probable. However, one can use this synchronizer provided special meta-stable resistant flops are selected during physical synthesis or (for example) if the output is immediately registered.




Figure 13: Bit Synchronizer 1.0 - single register in destination domain

mkSyncBit1	Moves data from one clock domain to another clock domain, with only one register in the destination domain. The in and out clocks, along with the input reset, are explicitly provided. The default clock and reset are ignored.
	<pre>module mkSyncBit1 #(Clock sClkIn, Reset sRst,</pre>

The mkSyncBit05 module is similar to mkSyncBit1, but the destination register triggers on the falling edge of the clock, as shown in Figure 14.




Figure 14: Bit Synchronizer .5 - first register in destination domain triggers on falling edge

mkSyncBitO5	Moves data from one clock domain to another clock domain, with only one register in the destination domain. The destination register triggers on the falling edge of the clock. The in and out clocks, along with the input reset, are explicitly provided. The default clock and reset are ignored. module mkSyncBit05 #(Clock sClkIn, Reset sRst, Clock dClkIn)
-------------	--

```
Moves data from the current clock domain, with only one register in the destination domain, the destination register triggers on the falling edge of the clock. The input clock and reset are the current clock and reset.

module mkSyncBitO5FromCC #( Clock dClkIn )

(SyncBitIfc #(one_bit_type) )

provisos( Bits#(one_bit_type, 1)) ;
```

mkSyncBit05ToCC	Moves data into the current clock domain, with only one register in the destination domain, the destination register triggers on the falling edge of the clock. The output clock is the current clock. The current reset is ignored.
	<pre>module mkSyncBit05ToCC #(Clock sClkIn, Reset sRstIn)</pre>

Verilog Modules

The BSV modules correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Name
mkSyncBit	SyncBit.v
mkSyncBitFromCC	
mkSyncBitToCC	
mkSyncBit15	SyncBit15.v
mkSyncBit15FromCC	
mkSyncBit15ToCC	
mkSyncBit1	SyncBit1.v
mkSyncBit1FromCC	
mkSyncBit1ToCC	
mkSyncBit05	SyncBit05.v
mkSyncBitO5FromCC	
mkSyncBitO5ToCC	

C.9.5 Pulse Synchronizers

Description

Pulse synchronizers are used to transfer a pulse from one clock domain to another.

Interfaces and Methods

The SyncPulseIfc interface provides an Action method, send, which when invoked generates a True value on the pulse method in a second clock domain.

SyncPulseIfc Interface			
	Methods		
Name Type Description			
send	Action Starts transmittling a pulse from one clock domain to the		
	second clock domain.		
pulse	pulse Bool Where the pulse is received in the second domain. pulse is		
	True if a pulse is recieved in this cycle.		

```
interface SyncPulseIfc ;
  method Action send () ;
  method Bool pulse () ;
endinterface
```

Modules

The mkSyncPulse, mkSyncPulseFromCC and mkSyncPulseToCC modules provide clock domain crossing modules for pulses. When the send method is called from the one clock domain, a pulse will be seen on the read method in the second. Note that there is no handshaking between the domains, so when sending data from a fast clock domain to a slower one, not all pulses sent may be seen in the slower receiving clock domain. The pulse delay is two destination clocks cycles.





Figure 15: Pulse Synchronizer - no handshake

mkSyncPulse	Sends a pulse from one clock domain to another. The in and out clocks, along with the input reset, are explicitly provided. The default clock and reset are ignored. module mkSyncPulse #(Clock sClkIn, Reset sRstIn, Clock dClkIn)
-------------	--

mkSyncPulseFromCC	Sends a pulse from the current clock domain to the other clock domain. The input clock and reset are the current clock and reset.
	<pre>module mkSyncPulseFromCC #(Clock dClkIn)</pre>



The mkSyncHandshake, mkSyncHandshakeFromCC and mkSyncHandshakeToCC modules provide clock domain crossing modules for pulses in a similar way as mkSyncPulse modules, except that a handshake is provided in the mkSyncHandshake versions. The handshake enforces that another send does not occur before the first pulse crosses to the other domain. Note that this only guarantees that the pulse is seen in one clock cycle of the destination; it does not guarantee that the system on that side reacted to the pulse before it was gone. It is up to the designer to ensure this, if necessary. The modules are not ready in reset.







Figure 16: Pulse Synchronizer with handshake

The pulse delay from the send method to the read method is two destination clocks. The send method is re-enabled in two destination clock cycles plus two source clock cycles after the send method is called.







Verilog Modules

The BSV modules correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Name
mkSyncPulse	SyncPulse.v
mkSyncPulseFromCC	
mkSyncPulseToCC	
mkSyncHandshake	SyncHandshake.v
mkSyncHandshakeFromCC	
mkSyncHandshakeToCC	

C.9.6 Word Synchronizers

Description

Word synchronizers are used to provide word synchronization across clock domains. The crossings are handshaked, such that a second write cannot occur until the first is acknowledged (that the data has been received, but the value may not have been read) by the destination side. The destination read is registered.

Interfaces and Methods

Word synchronizers use the common Reg interface (redescribed below), but there are a few subtle differences which the designer should be aware. First, the <code>_read</code> and <code>_write</code> methods are in different clock domains and, second, the <code>_write</code> method has an implicit "ready" condition which means that some synchronization modules cannot be written every clock cycle. Both of these conditions are handled automatically by the Bluespec compiler relieving the designer of these tedious checks.

Reg Interface				
Method Arguments			Arguments	
Name Type Description			Name	Description
_write Action Writes a value x1		x1	Data to be written	
_read a_type Returns the value of the reg-				
		ister		

```
interface Reg #(a_type);
   method Action _write(a_type x1);
   method a_type _read();
endinterface: Reg
```

Modules

The mkSyncReg, mkSyncRegToCC and mkSyncRegFromCC modules provide word synchronization across clock domains.

mkSyncReg	Provides word synchronization across clock domains. The in and out clocks, along with the input reset, are explicitly provided. The default clock and reset are ignored.	
	<pre>module mkSyncReg #(a_type initValue,</pre>	




Figure 17: Register Synchronization Module (see Figure 16 for the pulse synchronizer with handshake)

mkSyncRegFromCC	Provides word synchronization from the current clock domain. The input clock and reset are the current clock and reset.
	<pre>module mkSyncRegFromCC #(a_type initValue,</pre>

Verilog Modules

The BSV modules correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Name
mkSyncReg mkSyncRegFromCC mkSyncRegToCC	SyncRegister.v

C.9.7 FIFO Synchronizers

Description

The SyncFIFO modules use FIFOs to synchronize data being sent across clock domains, providing registered full and empty signals (notFull and notEmpty). Additional FIFO synchronizers, SyncFIFOLevel and SyncFIFOCount can be found in the FIFOLevel package (Section C.2.3).

Interfaces and Methods

The SyncFiFOifc interface defines an interface similar to the FIFOF interface, except it does not have a clear method.

SyncFiF0ifc Interface				
Method		Arguments		
Name	Type	Description	Name	Description
enq	Action	Adds an entry to the FIFO	sendData	Data to be added
deq	Action	Removes the first entry from		
		the FIFO		
first	a_type	Returns the first entry		
notFull	Bool	Returns True if there is space		
		and you can enq into the		
		FIFO		
notEmpty	Bool	Returns True if there are el-		
		ements in the FIFO and you		
		can deq from the FIFO		

```
interface SyncFIFOIfc #(type a_type) ;
  method Action enq ( a_type sendData ) ;
  method Action deq () ;
  method a_type first () ;
  method Bool notFull () ;
  method Bool notEmpty () ;
endinterface
```

Modules




Figure 18: Synchronization FIFOs

The mkSyncFIFO, mkSyncFIFOFromCC and mkSyncFIFOToCC modules provide FIFOs for sending data across clock domains. Data items enqueued on the source side will arrive at the destination side and remain there until they are dequeued. The depth of the FIFO is specified by the depth parameter. The full and empty signals are registered. The module mkSyncFIF01 is a 1 element synchronized FIFO.

mkSyncFIF0	Provides a FIFO for sending data across clock domains. The enq method is in the source (sClkIn) domain, while the deq and first methods are in the destination (dClkIn) domain. The in and out clocks, along with the input reset, are explicitly provided. The default clock and reset are ignored.	
	<pre>module mkSyncFIFO #(Integer depth,</pre>	

```
Provides a 1 element FIFO for sending data across clock domains.

The 1 element module does not have a dedicated output register and registers for full and empty, as in the depth > 1 module. This module should be used in clock crossing applications where complete FIFO handshaking is required, but data throughput or storage is minimal.

module mkSyncFIFO #( Clock sClkIn, Reset sRstIn, Clock dClkIn )

( SyncFIFOIfc #(a_type) )

provisos (Bits#(a_type, sa));
```

Verilog Modules

The BSV modules correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Name
mkSyncFIF0	SyncFIFO.v
mkSyncFIFOFromCC	
mkSyncFIFOToCC	
mkSyncFIF01	SyncFIF01.v

C.9.8 Asynchronous RAMs

Description

An asynchronous RAM provides a domain crossing by having its read and write methods in separate clock domains.

Interfaces and Methods

DualPortRamIfc Interface				
Method		Arguments		
Name	Name Type Description		Name	Description
write	Action	Writes data to a an ad-	wr_addr	Address of datatype addr_t
	dress in a RAM			
			din	Data of datatype data_t
read	data_d	Reads the data from the	rd_addr	Address to be read from
		RAM		

```
interface DualPortRamIfc #(type addr_t, type data_t);
  method Action    write( addr_t wr_addr, data_t din );
  method data_t    read ( addr_t rd_addr);
endinterface: DualPortRamIfc
```




Figure 19: Ansynchronous RAM

mkDualRam	Provides an asynchronous RAM for when the read and the write methods are in separate clock domains. The write method is clocked by the default clock, the read method is not clocked.	
	<pre>module mkDualRam(DualPortRamIfc #(addr_t, data_t)) provisos (Bits#(addr_t, sa),</pre>	

Verilog Modules

The BSV modules correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Name
mkDualRam	DualPortRam.v

C.9.9 Null Crossing Primitives

Description

In these primitives, no synchronization is actually done. It is up to the designer to verify that it is safe for the signal to be used in the other domain. The mkNullCrossingWire is a wire synchronizer. The mkNullCrossingReg modules are equivalent to a register (mkReg, mkRegA, or mkRegU depending on the module) followed by a mkNullCrossingWire.

The older mkNullCrossing primitive is deprecated.

Interfaces

The mkNullCrossingWire module, shown in Figure 20, provides the ReadOnly interface which is defined in the Prelude library B.4.7.

The mkNullCrossingReg modules provide the CrossingReg interface.

Interfaces and Methods

CrossingReg Interface				
	Method		Arguments	
Name	Type Description		Name	Description
_write	Action	Writes a value datain	datain	Data to be written.
_read	a_type	Returns the value of the		
	register in the source clock			
		domain		
crossed	a_type	Returns the value of the		
	register in the destination			
		clock domain		

```
interface CrossingReg #( type a_type ) ;
  method Action _write(a datain) ;
  method a_type _read() ;
  method a_type crossed() ;
endinterface
```

Modules

mkNullCrossingWire	Defines a synchronizer that contains only a wire. It is left up to the designer to ensure the clock crossing is safe.
	<pre>module mkNullCrossingWire #(Clock dClk, a_type dataIn)</pre>




Figure 20: Wire synchronizer





Figure 21: Register with wire synchronizer

mkNullCrossingReg	efines a synchronizer that contains a register with a synchronous reset lue, followed by a wire synchronizer. It is left up to the designer to sure the clock crossing is safe.	
	<pre>module mkNullCrossingReg(Clock dClk, a_type resetval,</pre>	



Example: instantiating a null synchronizer

```
// domain2sig is domain1sig synchronized to clk0 with just a wire.
ReadOnly#(Bit#(2)) domain2sig <- mkNullCrossingWire (clk0, domain1sig);</pre>
```

Note: no synchronization is actually done. This is purely a way to tell BSC that it is safe to use the signal in the other domain. It is the responsibility of the designer to verify that this is correct.

There are some restrictions on the use of a mkNullCrossingWire. The expression used as the data argument must not have an implicit condition, and there cannot be another rule which is required to schedule before any method called in the expression.

mkNullCrossingWires may not be used in sequence to pass a signal across multiple clock boundaries without synchronization. Once a signal has been crossed from one domain to a second domain without synchronization, it cannot be subsequently passed unsynchronized to a third domain (or back to the first domain).

Verilog Modules

The BSV modules correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Name	
mkNullCrossingWire	BypassWire.v	

C.9.10 Reset Synchronization and Generation

Description

This section describes the interfaces and modules used to synchronize reset signals from one clock domain to another and to create reset signals. Reset generation converts a Boolean type to a Reset type, where the reset is associated with the default or clocked_by clock domain.

Interfaces and Methods

The MakeResetIfc interface is provided by the reset generators mkReset and mkResetSync.

MakeResetIfc Interface			
Method			
Name Type Description			
assertReset Action Method used to assert the reset		Method used to assert the reset	
isAsserted Bool Indicates whether the reset is asserted		Indicates whether the reset is asserted	
new_rst Reset Generated output reset			

```
interface MakeResetIfc;
  method Action assertReset();
  method Bool isAsserted();
  interface Reset new_rst;
endinterface
```

The interface MuxRstIfc is provided by the mkResetMux module.

MuxRstIfc Interface				
Method			Arguments	
Name	e Type Description		Name	Description
select	Action	Method used to select	ab	Value determines which
		the reset based on the		input reset to select
		Boolean value ab		
reset_out	Reset	Generated output reset		

```
interface MuxRstIfc;
  method Action select ( Bool ab );
  interface Reset reset_out;
endinterface
```

Modules

Reset Synchronization To synchronize resets from one clock domain to another, both synchronous and asynchronous modules are provided. The stages argument is the number of full clock cycles the output reset is held for after the input reset is deasserted. This is shown as the number of flops in figures 22 and 23. Specifying a 0 for the stages argument results in the creation of a simple wire between sRst and dRstOut.




Figure 22: Module for asynchronous resets

mkAsyncReset	Provides synchronization of a source reset (sRst) to the destination domain. The output reset occurs immediately once the source reset is asserted. module mkAsyncReset #(Integer stages, Reset sRst, Clock dClkIn) (Reset) ;
--------------	--

mkAsyncResetFromCR	Provides synchronization of the current reset to the destination domain. There is no source reset sRst argument because it is taken from the current reset. The output reset occurs immediately once the current reset is asserted.
	<pre>module mkAsyncResetFromCR #(Integer stages,</pre>

The less common mkSyncReset modules are provided for convenience, but these modules require that sRst be held during a positive edge of dClkIn for the reset assertion to be detected. Both mkSyncReset and mkSyncResetFromCR use the model in figure 23.




Figure 23: Module for synchronous resets

Example: instantiating a reset synchronizer

```
// 2 is the number of stages
Reset rstn2 <- mkAsyncResetFromCR (2, clk0);

// if stages = 0, the default reset is used directly
Reset rstn0 <- mkAsyncResetFromCR (0, clk0);</pre>
```

Reset Generation Two modules are provided for reset generation, mkReset and mkResetSync, where each module has one parameter, stages. The stages parameter is the number of full clock cycles the output reset is held after the inRst, as seen in figure 24, is deasserted. Specifying a 0 for the stages parameter results in the creation of a simple wire between the input register and the output reset. That is, the reset is asserted immediately and not held after the input reset is deasserted. It becomes the designer's responsibility to ensure that the input reset is asserted for sufficient time to allow the design to reset properly. The reset is controlled using the assertReset method of the MakeResetIfc interface.

The difference between mkReset and mkResetSync is that for the former, the assertion of reset is immediate, while the later asserts reset at the next rising edge of the clock. Note that use of mkResetSync is less common, since the reset requires clock edges to take effect; failure to assert reset for a clock edge will result in a reset not being seen at the output reset.




Figure 24: Module for generating resets

mkReset

Provides conversion of a Boolean type to a Reset type, where the reset is associated with dClkIn. This module uses the model in figure 24. startInRst indicates the reset value of the register. If startInRst is True, the reset value of the register is 0, which means the output reset will be asserted whenever the currentReset (sRst) is asserted. rst_out will remain asserted for the number of clock cycles given by the stages parameter after sRst is deasserted. If startInRst is False, the output reset will not be asserted when sRst is asserted, but only when the assert_reset method is invoked. At the start of simulation rst_out will only be asserted if startInRst is True and sRst is initially asserted.

mkResetSync

Provides conversion of a Boolean type to a Reset type, where the reset is associated with dClkIn and the assertion of reset is at the next rising edge of the clock. This module uses the model in figure 24. startInRst indicates the reset value of the register. If startInRst is True, the reset value of the register is 0, which means the output reset will be asserted whenever the currentReset (sRst) is asserted. rst_out will remain asserted for the number of clock cycles given by the stages parameter after sRst is deasserted. If startInRst is False, the output reset will not be asserted when sRst is asserted, but only when the assert_reset method is invoked. At the start of simulation rst_out will only be asserted if startInRst is True and sRst is initially asserted.

A reset multiplexor mkResetMux, as seen in figure 25, creates one reset signal by selecting between two existing reset signals.




Figure 25: Reset Multiplexor

mkResetMux	Multiplexor which selects between two input resets, aRst and bRst, to create a single output reset rst_out. The reset is selected through a Boolean value provided to the select method where True selects aRst.
	<pre>module mkResetMux #(Reset aRst, Reset bRst)</pre>

For testbenches, in which an absolute clock is being created, it is helpful to generate a reset for that clock. The module mkInitialReset is available for this purpose. It generates a reset which is asserted at the start of simulation. The reset is asserted for the number of cycles specified by the parameter cycles, counting the start of time as 1 cycle. Therefore, a cycles value of 1 will cause the reset to turn off at the first clock tick. This module is not synthesizable.

```
Generates a reset for cycles cycles, where the cycles parameter must be greater than zero. The clocked_by clause indicates the clock the reset is associated with. This module is not synthesizable.

module mkInitialReset #( Integer cycles )

( Reset );
```

Example:

```
Clock c <- mkAbsoluteClock (10, 5);
// a reset associated with clock c:
Reset r <- mkInitialReset (2, clocked_by c);</pre>
```

When two reset signals need to be combined so that some logic can be reset when either input reset is asserted, the mkResetEither module can be used.

mkResetEither	Generates a reset which is asserted whenever either input reset is asserted.
	<pre>module mkResetEither (Reset aRst,</pre>



Figure 26: Reset Either

Example:

Reset r <- mkResetEither(rst1, rst2);</pre>

mkResetInverter	Generates an inverted Reset.
	<pre>module mkResetInverter#(Reset in)</pre>

isResetAsserted	Tests whether a Reset is asserted, providing a Boolean value in the clock domain associated with the Reset.
	<pre>module isResetAsserted(ReadOnly#(Bool) ifc);</pre>

Verilog Modules

The BSV modules correspond to the following Verilog modules, which are found in the Bluespec Verilog library, \$BLUESPECDIR/Verilog/.

BSV Module Name	Verilog Module Name	Comments
mkASyncReset	SyncReset0.v	when stages==0
mkASyncResetFromCR	SyncResetA.v	
mkSyncReset	SyncReset0.v	when stages==0
mkSyncResetFromCR	SyncReset.v	
mkReset	MakeReset0.v	when stages==0
	MakeResetA.v	instantiates SyncResetA
mkResetSync	MakeReset0.v	when stages==0
	MakeReset.v	instantiates SyncReset
mkResetMux	ResetMux.v	
mkResetEither	ResetEither.v	
mkResetInverter	ResetInverter.v	
isResetAsserted	ResetToBool.v	

C.10 Special Collections

C.10.1 ModuleContext

Package

```
import ModuleContext :: * ;
```

Description

An ordinary Bluespec module, when instantiated, adds state elements and rules to the growing accumulation of elements and rules already in the design. In some designs, items other than state elements and rules must be accumulated as well. While there is a need to add these items, it is also desirable to keep these additional design details separate from the main design, keeping the natural structure of the design intact.

The ModuleContext package provides the capability of accumulating items and maintaining the compile-time state of additional items, in such a way that it doesn't change the structure of the original design.

The ModuleContext mechanism allows the designer to hide the details of the additional interfaces. Before the module can be synthesized, it must be converted (or exposed) into a module containing only rules and state elements, as the compiler does not know how to handle the other items. The ModuleContext package provides the mechanisms to allow additional items to be collected, processed, and exposed.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Contexts directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Types and Type Classes

The default BSV module type is Module, but you can define other BSV module types as well. The ModuleContext type is a variation on the Module type that allows additional items, other than states and rules, to be collected while elaborating the module structure.

The ModuleContext package defines the typeclass Context, which includes functions getContext and putContext. A Context typeclass has two type parameters: a module type (mc1) and the context (c2).

```
typeclass Context#(type mc1, type c2);
  module [mc1] getContext(c2) provisos (IsModule#(mc1, a));
  module [mc1] putContext#(c2 s)(Empty) provisos (IsModule#(mc1, a));
endtypeclass
```

A regular module type (Module) will have a context of void:

```
instance Context#(Module, void);
```

A module type of ${\tt ModuleContext}$ will return the context of the module:

```
instance Context#(ModuleContext#(st1), st1);
```

An instance is defined where the context type st1 of the ModuleContext and the context type st2 are different, but Gettable (as defined in Hlist Section C.10.4):

```
instance Context#(ModuleContext#(st1), st2)
provisos (Gettable#(st1, st2));
```

The modules applyToContext and applyToContextM are used to apply a function over a context. The applyToContextM modules is used for monadic functions.

applyToContext	Applies a function over a context.
	<pre>module [mc1] applyToContext#(function c2 f(c2 c))(Empty) provisos (IsModule#(mc1, a), Context#(mc1, c2));</pre>
applyToContextM	Applies a monadic function over a context.
	module [mc1] applyToContextM#(function module#(c2) m(c2 c)) (Empty)
	provisos (IsModule#(mc1, a), Context#(mc1, c2));

ClockContext

The structure ClockContext is defined to be comprised of two clocks: clk1 and clk2 and two resets: rst1 and rst2.

```
typedef struct {
        Clock clk1;
        Clock clk2;
        Reset rst1;
        Reset rst2;
        ClockContext;
```

An initClockContext is defined with the values of both clocks set to noClock and both resets set to noReset:

```
ClockContext initClockContext = ClockContext {
   clk1: noClock, clk2: noClock, rst1: noReset, rst2: noReset };
```

Expose

The Expose typeclass converts a context to an interface for a synthesis boundary, converting it to a module type of Module. The Expose typeclass provides the modules unburyContext and unburyContextWithClocks.

```
typeclass Expose#(type c, type ifc)
  dependencies (c determines ifc);
```

An HList of contexts is convertible if its elements are, and results in a Tuple of subinterfaces.

```
instance Expose#(HList1#(ct1), ifc1)
  provisos (Expose#(ct1,ifc1));

instance Expose#(HCons#(c1,c2), Tuple2#(ifc1,ifc2))
  provisos (Expose#(c1,ifc1), Expose#(c2,ifc2));

instance Expose#(ClockContext, Empty);
```

The unburyContext module is for use at the top level of a module to be separately synthesized. It takes as an argument a module which is to be instantiated in a particular context, and an initial state for that context. The module is instantiated, and the final context converted into an extra interface, returned in pair with the intantiated module's own interface.

```
UnburyContext

Converts a context to an interface for a synthesis boundary. An HList of contexts is convertible if its elements are, and results in a tuple of subinterfaces.

module unburyContext#(c x)(ifc);

module unburyContext#(HList1#(ct1) c1)(ifc1);

module unburyContext#(HCons#(c1,c2) c12)(Tuple2#(ifc1,ifc2));

module unburyContext#(ClockContext x)();
```

The unburyContextWithClocks takes a ClockContext along with the Context it is specifically handling

unburyContextWithClocks	Converts a context to an interface for a synthesis boundary and takes a ClockContext as a second argument.
	<pre>module unburyContextWithClocks#(c x, ClockContext cc)</pre>
	<pre>module unburyContextWithClocks#(HList1#(ct1) c1,</pre>
	<pre>module unburyContextWithClocks#(HCons#(c1,c2) c12,</pre>
	<pre>module unburyContextWithClocks#(ClockContext x,</pre>

Hide

The Hide typeclass provides the module reburyContext, which takes an interface as an argument (and provides an Empty interface). It is intended to be run in a context which can absorb the information from the interface. As with Expose, a Tuple of interfaces can be hidden if each element can be hidden.

reburyContext	Connects the provided interface with the surrounding context.
	<pre>module [mc] reburyContext#(ifc i)(Empty);</pre>
	<pre>module [mc] reburyContext#(Empty i)(Empty);</pre>
	<pre>module [mc] reburyContext#(Tuple2#(ifc1,ifc2) i12)(Empty);</pre>

ContextRun

The ContextRun and ContextsRun typeclasses provides modules to run modules in contexts. The module runWithContext runs a module with an entirely new context.

```
typeclass ContextRun#(type m, type c1, type ctx2)
  dependencies ((m, c1) determines ctx2);

typeclass ContextsRun#(type m, type c1, type ctx2)
  dependencies ((m, c1) determines ctx2);
```

runWithContext	Runs a module with an entirely new context.
	<pre>module [m] runWithContext #(c1 initState,</pre>
	<pre>module [ModuleContext#(ctx)] runWithContext#(c1 initState,</pre>
	<pre>module [Module] runWithContext#(c1 initState,</pre>

runWithContexts	Runs a module with an entirely new context.
	<pre>module [m] runWithContexts#(c1 initState,</pre>
	<pre>module [ModuleContext#(ctx)] runWithContexts#(c1 initState,</pre>
	<pre>module [Module] runWithContexts#(c1 initState,</pre>

Contexts.defines

Bluespec provides macros in the Context.defines file to handle the treatment of the module contexts at synthesis boundaries.

- 1. The designer defines a leaf or intermediate node module, with module type [ErrorReporter] or [ErrorReporterA], appending a 0 to its name (e.g. mkM0). Elsewhere in the package the appropriate macro is chosen from the macros SynthBoundary and SynthBoundaryWithClocks.
- 2. The macro defines a synthesizable version of the module, mkMV, which provides the original interface together with an error-reporting subinterface. It also defines a module with the original name mkM to be used for instantiating the original module. It uses the Context mechanism to re-bury the error-reporting plumbing and returns the original interface of the original mkM) module

These macros assume that the complete module context (such as an HList of individual contexts) is named CompleteContext and that its initial value may be obtained from either mkInitialCompleteContext or mkInitialCompleteContextWithClocks.

Example Without Clocks

```
SynthBoundary (mkM, IM)
Becomes
(*synthesize*)
module [Module] mkMV(Tuple2#(CompleteContextIfc,IM));
   let init <- mkInitialCompleteContext;</pre>
   let _ifc <- unbury(init, mkMO);</pre>
   return _ifc;
endmodule
module [ModuleContext#(CompleteContext)] mkM(IM);
   let _ifc <- rebury(mkMV);</pre>
   return _ifc;
endmodule
Example With Clocks
SynthBoundaryWithClocks(mkM,IM)
Becomes
(*synthesize*)
module [Module] mkMV#(Clock c1,Reset r1,Clock c2,Reset r2)(Tuple2#(CompleteContextIfc,IM));
   let init <- mkInitialCompleteContextWithClocks(c1, r1, c2, r2);</pre>
   let _ifc <- unburyWithClocks(initialCompleteContext, c1, r1, c2, r2, mkM0);</pre>
   return _ifc;
endmodule
module [ModuleContext#(CompleteContext)] mkM(IM);
   let _ifc <- reburyWithClocks(mkMV);</pre>
   return _ifc;
endmodule
C.10.2 ModuleCollect
Package
import ModuleCollect :: * ;
```

Description

The ModuleCollect package provides the capability of adding additional items, such as configuration bus connections, to a design in such a way that it does not change the structure of the design. This section provides a brief overview of the package. For a more detailed description of its usage, see the CBus package (C.10.3), which utilizes ModuleCollect. There is also a detailed example and more complete discussion of the CBus package in the configuration in the BSV/tutorials directory.

An ordinary Bluespec module, when instantiated, adds its own state elements and rules to the growing accumulation of state elements and rules defined in the design. In some designs, for example a configuration bus, additional items, such as the logic for the bus address decoding must be accumulated as well. While there is a need to add these items, it is also desirable to keep these additional design details separate from the main design, keeping the natural structure of the design intact.

The ModuleCollect mechanism allows the designer to *hide* the details of the additional interfaces. A module which is going to be synthesized must contain only rules and state elements, as the compiler does not know how to handle the additional items. Therefore, the collection must be brought into the open, or exposed, before the module can be synthesized. The ModuleCollect package provides the mechanisms to allow these additional items to be collected, processed and exposed.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Contexts directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Types and Type Classes

The ModuleCollect type is a variation on the Module type that allows additional items, other than states and rules, to be collected while elaborating the module structure. A module defining the accumulation of a special collection will have the type of ModuleCollect which is defined as a type of ModuleContext (Section C.10.1):

```
typedef ModuleContext#(HList1#(UAList#(a))) ModuleCollect#(type a_type);
```

where a_type defines the type of the items being collected. The collection is kept as an HList, therefore each item in the collection does not have the same type.

Your new type of module is a ModuleCollect defined to collect a specific type. It is often convenient to give a name to your new type of module using the typedef keyword.

For example:

specifies a type named MyModuleType.

An ordinary module, one defined with the keyword module without a type in square brackets immediately after it, can be of any module type. It is polymorphic, and when instantiated takes the type of the surrounding module context. Only modules of type Module can be synthesized, so the *synthesize* attribute forces the type to be Module. This is equivalent to writing:

```
module [Module]...
```

Normally, all the modules instantiated inside a synthesized module take the type Module.

A module which is accumulating a collection must have the appropriate type, specified in square brackets immedately after the keyword, as shown in the following example:

```
module [AssertModule] mkAssertionReg...
```

The complete example is found later in this section. This implies that any module instantiating mkAssertionReg is no longer polymorphic, its type is constrained by the inner module, so it will have to be explicitly given the AssertModule type too. Note, however, that you can continue to instantiate other modules not concerned with the collection (for example, mkReg, mkFIFO, etc.) alongside mkAssertReg just as before. But now they will take the type AssertModule from the context instead of the type Module.

Since only modules of type Module can be synthesized, before this group of AssertModule instantiations can be synthesized, you must use exposeCollection to contain the collection in a top-level module of type Module.

Interfaces

The IWithCollection interface couples the normal module interface (the device interface) with the collection of collected items (the collection interface). This is the interface provided by the exposeCollection function. It separates the collection list and the device module interface, to allow the module to be synthesized.

```
interface IWithCollection #(type a, type i);
    method i device();
    method List#(a) collection();
endinterface: IWithCollection

OLD:

interface IWithCollection #(type collection_type, type item_type);
    interface item_type device();
    interface List#(collection_type) collection();
endinterface: IWithCollection
```

Modules and Functions

In the course of evaluating a module body during its instantiation, an item may be added to the current collection by using the function addToCollection.

```
addToCollection Adds an item to the collection.

function ModuleCollect#(a_type, ifc)
addToCollection(a_type item);
```

Once a set of items has been collected, those items must be exposed before synthesis. The exposeCollection module constructor is used to bring the collection out into the open. The exposeCollection module takes as an argument a ModuleCollect module (m) with interface ifc, and provides an IWithCollection interface.

```
exposeCollection Expose the collection to allow the module to be synthesized.

module exposeCollection#(ModuleCollect#(a_type, ifc) m)

(IWithCollection#(a_type, ifc));
```

Finally, the ModuleCollect package provides a function, mapCollection, to apply a function to each item in the current collection.

```
Apply a function to each item added to the collection within the second argument.

function ModuleCollect#(a_type, ifc)
mapCollection(function a_type x1(a_type x1),
ModuleCollect#(a_type, ifc) x2);
```

Example - Assertion Wires

```
// This example shows excerpts of a design which places various
// test conditions (Boolean expressions) at random places in a design,
// and lights an LED (setting an external wire to 1), if the condition
// is ever satisfied.
import ModuleCollect::*;
import List::*;
import Vector::*;
import Assert::*;
// The desired interface at the top level is:
interface AssertionWires#(type n);
  method Bit#(n) wires;
  method Action clear;
endinterface
// The "wires" method tells which conditions have been set, and the
// "clear" method resets them all to 0.
// The items in our extra collection will be interfaces of the
// following type:
interface AssertionWire;
  method Integer index; //Indicates which wire is to be set if
  method Bool fail:
                           // fail method ever returns true.
  method Action clear;
endinterface
// We next define the "AssertModule" type. This is to behave like an
// ordinary module providing an interface of type "i", except that it
// also can collect items of type "AssertionWire":
typedef ModuleCollect#(AssertionWire, i) AssertModule#(type i);
typedef Tuple2#(AssertionWires#(n), i) AssertIfc#(type i, type n);
. . .
// The next definition shows how items are added to the collection.
// This is the module which will be instantiated at various places in
// the design, to test various conditions. It takes one static
// parameter, "ix", to specify which wire is to carry this condition,
// and one dynamic parameter (one varying at run-time) "c", giving the
// value of the condition itself.
interface AssertionReg;
  method Action set;
   method Action clear;
endinterface
module [AssertModule] mkAssertionReg#(Integer ix)(AssertionReg);
  Reg#(Bool) cond <- mkReg(False);</pre>
   // an item is defined and added to the collection
```

```
let item = (interface AssertionWire;
                 method index;
                    return (ix);
                 endmethod
                 method fail;
                    return(cond);
                 endmethod
                 method Action clear;
                     cond <= False;</pre>
                 endmethod
               endinterface);
  addToCollection(item);
endmodule
// the collection must be exposed before synthesis
module [Module] exposeAssertionWires#(AssertModule#(i) mkI)(AssertIfc#(i, n));
   IWithCollection#(AssertionWire, i) ecs <- exposeCollection(mkI);</pre>
   ...(c_ifc is created from the list ecs.collection)
  // deliver the array of values in the registers
  let dut_ifc = ecs.device;
  // return the values in the collection, and the ifc of the device
  return(tuple2(c_ifc, dut_ifc));
endmodule
C.10.3 CBus
Package
import CBus :: * ;
```

Description

The CBus package provides the interface, types and modules to implement a configuration bus capability providing access to the control and status registers in a given module hierarchy. This package utilizes the ModuleCollect package and functionality, as described in section C.10.2. The ModuleCollect package allows items in addition to usual state elements and rules to be accumulated. This is required to collect up the interfaces of the control status registers included in a module and to add the associated logic and ports required to allow them to be accessed via a configuration bus.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

For a more complete discussion of the CBus package, consult the configbus tutorial in the BSV/tutorials directory.

Types and Type Classes

The type CBusItem defines the type of item to be collected by ModuleCollect. The items to be collected are the same as the ifc which we will later expose, so we use a type alias:

The type ModWithCBus defines the type of module which is collecting CBusItems. An ordinary module, one not collecting anything other than state elements and rules, has the type Module. Since CBusItems are being collected, a module type ModWithCBus is defined. When the module type is not Module, the type must be specified in square brackets immediately after the module keyword in the module definition.

Interface and Methods

The CBus interface provides read and write methods to access control status registers. It is polymorphic in terms of the size of the address bus (size_address) and size of the data bus (size_data).

CBus Interface	
Name	Description
write	Writes the data value to the register if and only if the value of addr matches the address of the register.
read	Returns the value of the associated register if and only if addr matches the register address. In all other cases the read method returns an Invalid value.

```
interface CBus#(type size_address, type size_data);
  method Action write(Bit#(size_address) addr, Bit#(size_data) data);
  (* always_ready *)
  method ActionValue#(Bit#(size_data)) read(Bit#(size_address) addr);
endinterface
```

The IWithCBus interface combines the CBus interface with a normal module interface. It is defined as a structured interface with two sub-interfaces: cbus_ifc (the associated configuration bus interface) and device_ifc (the associated device interface). It is polymorphic in terms of the type of the configuration bus interface and the type of the device interface.

```
interface IWithCBus#(type cbus_IFC, type device_IFC);
  interface cbus_IFC cbus_ifc;
  interface device_IFC device_ifc;
endinterface
```

Modules

The collectCBusIFC module takes as an argument a module with an IWithCBus interface, adds the associated CBus interface to the current collection (using addToCollection from the ModuleCollect package), and returns a module with the normal interface. Note that collectCBusIFC is of module type ModWithCBus.

collectCBusIFC	Adds the CBus to the collection and returns a module with just the device interface.
	<pre>module [ModWithCBus#(size_address, size_data)]</pre>

The exposeCBusIFC module is used to create an IWithCBus interface given a module with a normal interface and an associated collection of CBusItems. This module takes as an argument a module of type ModWithCBus and provides an interface of type IWithCBus. The exposeCBusIFC module exposes the collected CBusItems, processes them, and provides a new combined interface. This module is synthesizable, because it is of type Module.

```
A module wrapper that takes a module with a normal interface, processes the collected CBusItems and provides an IWithCBus interface.

module [Module] exposeCBusIFC#(ModWithCBus#(size_address, size_data, item) sm)

(IWithCBus#(CBus#(size_address, size_data), item));
```

The CBus package provides a set of module primitives each of which adds a CBus interface to the collection and provides a normal Reg interface from the local block point of view. These modules are used in designs where a normal register would be used, and can be read and written to as registers from within the design.

```
A wrapper to provide a read only CBus interface to the collection and a normal Reg interface to the local block.

module [ModWithCBus#(size_address, size_data)]

mkCBRegR#(CRAddr#(size_address2) addr, r x)

(Reg#(r))

provisos (Bits#(r, sr), Add#(k, sr, size_data),

Add#(ignore, size_address2, size_address));
```

```
A wrapper to provide a read/write CBus interface to the collection and a normal Reg interface to the local block.

module [ModWithCBus#(size_address, size_data)]

mkCBRegRW#(CRAddr#(size_address2) addr, r x)

(Reg#(r))

provisos (Bits#(r, sr), Add#(k, sr, size_data),

Add#(ignore, size_address2, size_address));
```

```
A wrapper to provide a write only CBus interface to the collection and a normal Reg interface to the local block.

module [ModWithCBus#(size_address, size_data)]

mkCBRegW#(CRAddr#(size_address2) addr, r x)

(Reg#(r))

provisos (Bits#(r, sr), Add#(k, sr, size_data),

Add#(ignore, size_address2, size_address));
```

```
A wrapper to provide a read/clear CBus interface to the collection and a normal Reg interface to the local block. This register can read from the config bus but the write is clear mode; for each write bit a 1 means clear, while a 0 means don't clear.

module [ModWithCBus#(size_address, size_data)]

mkCBRegRC#(CRAddr#(size_address2) addr, r x)

(Reg#(r))

provisos (Bits#(r, sr), Add#(k, sr, size_data),

Add#(ignore, size_address2, size_address));
```

The mkCBRegFile module wrapper adds a CBus interface to the collection and provides a RegFile interface to the design. This module is used in designs as a normal RegFile would be used.

```
A wrapper to provide a normal RegFile interface and automatically add the CBus interface to the collection.

module [ModWithCBus#(size_address, size_data)]

mkCBRegFile#(Bit#(size_address) reg_addr,

Bit#(size_address) size)

(RegFile#(Bit#(size_address), r))

provisos (Bits#(r, sr), Add#(k, sr, size_data));
```

Example

Provided here is a simple example of a CBus implementation. The example is comprised of three packages: CfgDefines, Block, and Tb. The CfgDefines package contains the definition for the configuration bus, Block is the design block, and Tb is the testbench which executes the block.

The Block package contains the local design. As seen in Figure 27, the configuration bus registers look like a single field from the CBus (cfgResetAddr, cfgStateAddr, cfgStatusAddr), while each field (reset, init, cnt, etc.) in the configuration bus registers looks like a regular register from from the local block point of view.




Figure 27: CBus Registers used in Block example

```
import CBus::*;  // this is a Bluespec library
```

```
import CfgDefines::*; // user defines - address,registers, etc
  // TODO: normally this block would have at least a few methods
   // Cbus interface is hidden, but it is there
endinterface
// In order to access the CBus at this parent, we need to expose the bus.
// Only modules of type [Module] can be synthesized.
module [Module] mkBlock(IWithCBus#(DCBus, Block));
  let ifc <- exposeCBusIFC( mkBlockInternal );</pre>
  return ifc;
endmodule
// Within this module the CBus looks like normal Registers.
// This module can't be synthesized directly.
// How these registers are combined into CBus registers is
// defined in the CfgDefines package.
module [DModWithCBus] mkBlockInternal( Block );
   // all registers are read/write from the local block point of view
   // config register interface types can be
        mkCBRegR -> read only from config bus
   //
        mkCBRegRW -> read/write from config bus
   //
   // mkCBRegW -> write only from config bus
   // mkCBRegRC -> read from config bus, write is clear mode
   //
                     i.e. for each bit a 1 means clear, 0 means don't clear
   // reset bit is write only from config bus
   // we presume that you use this bit to fire some local rules, etc
                                                                        0 /* init val */);
  Reg#(TCfgReset) reg_reset_reset <- mkCBRegW(cfg_reset_reset,</pre>
  Reg#(TCfgInit) reg_setup_init <- mkCBRegRW(cfg_setup_init, 0 /* init val */);</pre>
                                       <- mkCBRegRW(cfg_setup_tz,
<- mkCBRegRW(cfg_setup_cnt,</pre>
  Reg#(TCfgTz)
                    reg_setup_tz
                                                                        0 /* init val */);
  Reg#(TCfgCnt)
                    reg_setup_cnt
                                                                        1 /* init val */);
  Reg#(TCfgOnes) reg_status_ones
                                       <- mkCBRegRC(cfg_status_ones, 0 /* init val */);</pre>
  Reg#(TCfgError) reg_status_error <- mkCBRegRC(cfg_status_error, 0 /* init val */);</pre>
   // USER: you know have registers, so do whatever it is you do with registers :)
   // for instance
  rule bumpCounter ( reg_setup_cnt != unpack('1) );
      reg_setup_cnt <= reg_setup_cnt + 1;</pre>
  rule watch4ones ( reg_setup_cnt == unpack('1) );
      reg_status_ones <= 1;</pre>
   endrule
endmodule
The CfgDefines package contains the user defines describing how the local registers are combined
into the configuration bus.
package CfgDefines;
import CBus::*;
```

```
/// basic defines
// width of the address bus, it's easiest to use only the width of the bits needed
// but you may have other reasons for passing more bits around (even if some address
// bits are always 0)
typedef 2 DCBusAddrWidth; // roof( log2( number_of_config_registers ) )
// the data bus width is probably defined in your spec
typedef 32 DCBusDataWidth; // how wide is the data bus
// Define the CBus
typedef CBus#( DCBusAddrWidth,DCBusDataWidth)
                                     DCBus;
typedef CRAddr#(DCBusAddrWidth,DCBusDataWidth)
                                     DCAddr;
typedef ModWithCBus#(DCBusAddrWidth, DCBusDataWidth, i) DModWithCBus#(type i);
/// Configuration Register Types
// these are configuration register from your design. The basic
// idea is that you want to define types for each individual field
// and later on we specify which address and what offset bits these
// go to. This means that config register address fields can
// actually be split across modules if need be.
//
typedef bit
           TCfgReset;
typedef Bit#(4) TCfgInit;
typedef Bit#(6)
           TCfgTz;
typedef UInt#(8) TCfgCnt;
typedef bit
           TCfgOnes;
typedef bit
           TCfgError;
/// configuration bus addresses
Bit#(DCBusAddrWidth) cfgResetAddr = 0; //
Bit#(DCBusAddrWidth) cfgStateAddr = 1; //
Bit#(DCBusAddrWidth) cfgStatusAddr = 2; // maybe you really want this to be 0,4,8 ???
/// Configuration Register Locations
// DCAddr is a structure with two fields
//
    DCBusAddrWidth a ; // this is the address
//
                 // this does a pure comparison
//
    Bit#(n)
              o ; // this is the offset that this register
//
                 // starts reading and writting at
DCAddr cfg_reset_reset = DCAddr {a: cfgResetAddr, o: 0}; // bits 0:0
```

```
DCAddr cfg_setup_init = DCAddr {a: cfgStateAddr, o: 0}; // bits 0:0
DCAddr cfg_setup_tz = DCAddr {a: cfgStateAddr, o: 4}; // bits 9:4
DCAddr cfg_setup_cnt = DCAddr {a: cfgStateAddr, o: 16}; // bits 24:16
DCAddr cfg_status_ones = DCAddr {a: cfgStatusAddr, o: 0}; // bits 0:0
DCAddr cfg_status_error = DCAddr {a: cfgStatusAddr, o: 0}; // bits 1:1
endpackage
The Tb package executes the block.
import CBus::*;
                    // bluespec library
import CfgDefines::*; // address defines, etc
                 // test block with cfg bus
import Block::*;
(* synthesize *)
module mkTb ();
  // In order to access this cfg bus we need to use IWithCBus type
  IWithCBus#(DCBus,Block) dut <- mkBlock;</pre>
  Stmt test =
  seq
     // write the bits need to the proper address
     // generally this comes from software or some other packing scheme
     // you can, of course, create functions to pack up several fields
     // and drive that to bits of the correct width
     // For that matter, you could have your own shadow config registers
     // up here in the testbench to do the packing and unpacking for you
     dut.cbus_ifc.write( cfgResetAddr, unpack('1) );
     // put some ones in the status bits
     dut.cbus_ifc.write( cfgStateAddr, unpack('1) );
     // show that only the valid bits get written
     $display("TOP: state = %x at ", dut.cbus_ifc.read( cfgStateAddr ), $time);
     // clear out the bits
     dut.cbus_ifc.write( cfgStateAddr, 0 );
     // but the 'ones' bit was set when it saw all ones on the count
     // so read it to see that...
     $display("TOP: status = %x at ", dut.cbus_ifc.read( cfgStatusAddr ), $time);
     // now clear it
     dut.cbus_ifc.write( cfgStatusAddr, 1 );
     // see that it's clear
     $display("TOP: status = %x at ", dut.cbus_ifc.read( cfgStatusAddr ), $time);
```

```
// and if we had other interface methods, that where not part of CBUS
// we would access them via dut.device_ifc
endseq;
mkAutoFSM( test );
endmodule

C.10.4 HList
Package
import HList :: *;
```

Description

The HList package defines a datatype HList which stores a list of data of different types. The package also provides typeclasses and functions to perform various list operations on the HList type.

The primitive data structures for an HList are HNil and the polymorphic HCons. The various functions are provided by typeclasses, one for each function.

The package defines a typeclass Gettable for finding (getIt) and replacing (putIt) items in an HList. This requires that all the items in the HList are different types. If two types are the same, they must be disambiguated by encapsulating at least one of them (but preferably each of them) in a new struct type. The functions of the Gettable typeclass require that the HList be flat (no nested HLists) and well-formed (terminating in HNil). That is, the target of a recursive search must be either the complete hHead or found within the hTail.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Types and type classes

The HList packages defines a typeclass HList:

```
typeclass HList#(type 1);
```

The HNil datatype defines a nil instance, the empty set. An HList is usually terminated by a HNil.

```
typedef struct {} HNil deriving (Eq);
```

The HCons datatype is a structure with two members, a head of datatype e and a tail of datatype 1.

```
typedef struct {
  e hd;
  l tl;
} HCons#(type e, type l) deriving (Eq);
```

Functions

The various functions for heterogenous lists are provided by typeclasses, one for each functions.

```
HHead

Returns the first element of the list.

typeclass HHead#(type 1, type h)
    dependencies (1 determines h);
    function h hHead(1 x);
    endtypeclass

instance HHead#(HCons#(e, 1), e);
```

```
HTail

Returns the tail element from the list.

typeclass HTail#(type 1, type 1t)
    dependencies (1 determines 1t);
    function 1t hTail(1 xs);
    endtypeclass

instance HTail#(HCons#(e, 1), 1);
```

```
Returns a numeric value with the length of the list. For a HNil, will return 0.

typeclass HLength#(type 1, numeric type n); endtypeclass

instance HLength#(HNil, 0);

instance HLength#(HCons#(e, 1), nPlus1)
    provisos (HLength#(l, n), Add#(n,1,nPlus1));
```

```
Appends two lists, returning the combined list. The elements do not have to be of the same data type. The combined list will be of type 12, and will contain all the elements of xs followed in order by all the elements of ys.

typeclass HAppend#(type 1, type 11, type 12)
    dependencies ((1, 11) determines 12);
    function 12 hAppend(1 xs, 11 ys);

instance HAppend#(HNil, 1, 1);

instance HAppend#(HCons#(e, 1), 11, HCons#(e, 12))
    provisos (HList#(1), HAppend#(1, 11, 12));
```

The hSplit function takes an HList of type 1 and returns a Tuple2 of two HLists. This function is the inverse of hAppend. typeclass HSplit#(type 1, type 11, type 12); function Tuple2#(11,12) hSplit(1 xs); endtypeclass instance HSplit#(HNil, HNil, HNil); instance HSplit#(1, HNil, 1); instance HSplit#(HCons#(hd,tl), HCons#(hd,l3), 12) provisos (HSplit#(tl,l3,l2));

Gettable

This typeclass is for finding (getIt) and replacing (putIt) a particular element in an HList. All items in the HList must be of different types. If two types are the same, they should be disambiguated by encapsulating at least one of them (and preferably both of them) in a new struct type.

```
typeclass Gettable#(type c1, type c2);
  function c2 getIt(c1 x);
  function c1 putIt(c1 x, c2 y);
endtypeclass
instance Gettable#(HCons#(t1, t2), t1);
instance Gettable#(HCons#(t1, t2), t3)
  provisos (Gettable#(t2, t3));
```

Small Lists

The HList packcage provides type definitions for small lists, ranging from 1 element to 8 elements, along with constructor functions to build the lists.

HList1

```
function HList3#(t1, t2, t3) hList3(t1 x1, t2 x2, t3 x3)
     = hCons(x1, hCons(x2, hCons(x3, hNil)));
HList4
typedef HCons#(t1, HCons#(t2, HCons#(t3, HCons#(t4, HNil))))
       HList4#(type t1, type t2, type t3, type t4);
function HList4#(t1, t2, t3, t4) hList4(t1 x1, t2 x2, t3 x3, t4 x4)
     = hCons(x1, hCons(x2, hCons(x3, hCons(x4, hNil))));
HList5
typedef HCons#(t1, HCons#(t2, HCons#(t3, HCons#(t4, HCons#(t5, HNil)))))
       HList5#(type t1, type t2, type t3, type t4, type t5);
function HList5#(t1, t2, t3, t4, t5) hList5(t1 x1, t2 x2, t3 x3, t4 x4, t5 x5)
     = hCons(x1, hCons(x2, hCons(x3, hCons(x4, hCons(x5, hNil)))));
HList6
typedef HCons#(t1, HCons#(t2, HCons#(t3, HCons#(t4, HCons#(t5, HCons#(t6, HNil))))))
       HList6#(type t1, type t2, type t3, type t4, type t5, type t6);
function HList6#(t1, t2, t3, t4, t5, t6)
  hList6(t1 x1, t2 x2, t3 x3, t4 x4, t5 x5, t6 x6)
     = hCons(x1, hCons(x2, hCons(x3, hCons(x4, hCons(x5, hCons(x6, hNil))))));
HList7
typedef HCons#(t1, HCons#(t2, HCons#(t3, HCons#(t4, HCons#(t5,
               HCons#(t6, HCons#(t7, HNil))))))
        HList7#(type t1, type t2, type t3, type t4, type t5, type t6, type t7);
function HList7#(t1, t2, t3, t4, t5, t6, t7)
  hList7(t1 x1, t2 x2, t3 x3, t4 x4, t5 x5, t6 x6, t7 x7)
     = hCons(x1, hCons(x2, hCons(x3, hCons(x4, hCons(x5, hCons(x6, hCons(x7, hNil))))));
HList8
typedef HCons#(t1, HCons#(t2, HCons#(t3, HCons#(t4, HCons#(t5,
               HCons#(t6, HCons#(t7, HCons#(t8, HNil)))))))
       HList8#(type t1, type t2, type t3, type t4, type t5, type t6, type t7, type t8);
function HList8#(t1, t2, t3, t4, t5, t6, t7, t8)
  hList8(t1 x1, t2 x2, t3 x3, t4 x4, t5 x5, t6 x6, t7 x7, t8 x8)
      = hCons(x1, hCons(x2, hCons(x3, hCons(x4, hCons(x5, hCons(x6,
             hCons(x7, hCons(x8, hNil))))));
```

C.10.5 UnitAppendList

Package

```
import UnitAppendList :: * ;
```

Description

This provides a representation of lists for which append(x,y) is O(1), rather than $O(\operatorname{length}(x))$ as in the normal representation; the downside is that there is no longer a unique representation for a given list. These lists are useful for situations in which the length is constructed by recursively amalgamating lists from sub-computations, and then subsequently processed. Functions for map and mapM are provided for processing sublists during construction. For final processing it is almost always preferable first to flatten the list (by a function also provided) into the conventional representation, thus eliminating empty subtrees.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource/Misc directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Types and type classes

The UnitAppendList package defines the structure UAList:

```
typedef union tagged {
   void NoItems;
   a One;
   Tuple2#(UAList#(a),UAList#(a)) Append;
} UAList#(type a);
```

UAList is a member of the DefaultValue typeclass, which defines a default value for user defined structures. The default value for UAList is defined as:

```
instance DefaultValue#(UAList#(a));
  defaultValue = NoItems;
endinstance
```

Functions

flatten0	Given a UAList#(a) and a List#(a), returns a conventional list of type List. function List#(a) flattenO(UAList#(a) c, List#(a) xs);
flatten	Converts a list of type UAList into a conventional list of type List. function List#(a) flatten(UAList#(a) c) = flattenO(c, Nil);
uaMap	Maps a function of a list of type UAList, returning a UAList. function UAList#(b) uaMap(function b f(a x), UAList#(a) c);

uaMapM	Maps a monadic function of a list of type UAList, returning a UAList.
	<pre>module uaMapM#(function module#(b) f(a x), UAList#(a) c)(UAList#(b));</pre>

C.11 Bus Fabric Libraries

This section describes the Bluespec AzureIP bus fabric library components. These components can be used to build complex, fully synthesizable designs. Each component is provided in one or more BSV packages, defining the interfaces and data structures used to communicate with other components.

The TLM library package allows users to create bus-based protocol-independent designs. This package is provided as part of the Bluespec Foundation library, and is available to all users.

Bluespec also provides packages to implement AXI and AHB protocols. These packages are AzureIP Premium offerings and are not provided as part of the Foundation library. If you are interested in obtaining these packages, please contact your sales representative or sales@bluespec.com. Customers licensed under release 2009.10.B or earlier still have access to the AXI and AHB libraries as part of the standard offering. Please contact support@bluespec.com if you cannot access the latest libraries.

C.11.1 TLM2

Packages

```
import TLM2 :: * ;
```

Description

The TLM2 package includes definitions of interfaces, data structures, and module constructors which allow users to create and modify bus-based designs in a manner that is independent of any one specific bus protocol. Bus operations are defined in terms of generic bus payload data structures. Other protocol specific packages include transactor modules that convert a stream of TLM bus operations into corresponding operations in a specific bus protocol. Designs created using the TLM package are thus more portable (because that they allow the core design to be easily applied to multiple bus protocols). In addition, since the specific signalling details of each bus protocol are encapsulated in pre-designed transactors, users are not required to learn, re-implement, and re-verify existing standard protocols.

This package is provided as both a compiled library package and as BSV source code to facilitate customization. The source code file can be found in the \$BLUESPECDIR/BSVSource directory. To customize a package, copy the file into a local directory and then include the local directory in the path when compiling. This is done by specifying the search path with the -p option as described in the BSV Users Guide.

Data Structures

The two basic data structures defined in the TLM package are TLMRequest and TLMResponse. By using these types in a design, the underlying bus protocol can be changed without having to modify the interactions with the TLM objects.

TLMRequest A TLM request contains either control information and data, or data alone. A TLMRequest is tagged as either a RequestDescriptor or RequestData. A RequestDescriptor contains control information and data while a RequestData contains only data.

RequestDescriptor The table below describes the components of a RequestDescriptor and the valid values for each of its members.

RequestDescriptor		
Member Name	DataType	Valid Values
command	TLMCommand	READ, WRITE, UNKNOWN
mode	TLMMode	REGULAR, DEBUG, CONTROL, UNKNOWN
addr	TLMAddr#('TLM_PRM)	Bit#(addr_size)
data	TLMData#('TLM_PRM)	Bit#(data_size)
burst_length	TLMUint#('TLM_PRM)	UInt#(uint_size)
byte_enable	TLMByteEn#('TLM_PRM)	Bit#(TDiv#(data_size, 8))
burst_mode	TLMBurstMode	INCR, WRAP, CNST, UNKNOWN
burst_size	TLMBurstSize#('TLM_PRM)	<pre>Bit#(TLog#(TDiv#(data_size, 8)))</pre>
prty	TLMUInt#('TLM_PRM)	UInt#(uint_size)
lock	Bool	True, False
thread_id	TLMId#('TLM_PRM)	Bit#(id_size)
transaction_id	TLMId#('TLM_PRM)	Bit#(id_size)
export_id	TLMId#('TLM_PRM)	Bit#(id_size)
custom	TLMCustom#('TLM_PRM)	cstm_type

```
typedef struct {TLMCommand
                                         command;
                TLMMode
                                         mode;
                TLMAddr#('TLM_PRM)
                                         addr;
                TLMData#('TLM_PRM)
                                         data;
                                         burst_length;
                TLMUInt#('TLM_PRM)
                TLMByteEn#('TLM_PRM)
                                         byte_enable;
                TLMBurstMode
                                         burst_mode;
                TLMBurstSize#('TLM_PRM) burst_size;
                TLMUInt#('TLM_PRM)
                                         prty;
                Bool
                                         lock;
                TLMId#('TLM_PRM)
                                         thread_id;
                TLMId#('TLM_PRM)
                                         transaction_id;
                TLMId#('TLM_PRM)
                                         export_id;
                                         custom;
                TLMCustom#('TLM_PRM)
                } RequestDescriptor#('TLM_PRM_DCL) deriving (Eq, Bits, Bounded);
```

RequestData The table below describes the components of a RequestData and the valid values for its members.

RequestData		
Member Name	DataType	Valid Values
data	TLMData#('TLM_PRM)	Bit#(data_size)
transaction_id	TLMId#('TLM_PRM)	Bit#(id_size)
custom	TLMCustom#('TLM_PRM)	cstm_type

TLMResponse The table below describes the components of a TLMResponse and the valid values for its members.

TLMResponse		
Member Name	DataType	Valid Values
command	TLMCommand	READ, WRITE, UNKNOWN
data	TLMData#('TLM_PRM)	Bit#(data_size)
status	TLMStatus	SUCCESS, ERROR, NO_RESPONSE,
		UNKNOWN
prty	TLMUInt#('TLM_PRM)	UInt#(uint_size)
thread_id	TLMId#('TLM_PRM)	Bit#(id_size)
transaction_id	TLMId#('TLM_PRM)	Bit#(id_size)
export_id	TLMId#('TLM_PRM)	Bit#(id_size)
custom	TLMCustom#('TLM_PRM)	cstm_type

```
typedef struct {TLMCommand
                                      command;
                TLMData#('TLM_PRM)
                                      data;
                TLMStatus
                                      status;
                TLMUInt#('TLM_PRM)
                                      prty;
                TLMId#('TLM_PRM)
                                      thread_id;
                TLMId#('TLM_PRM)
                                      transaction_id;
                TLMId#('TLM_PRM)
                                      export_id;
                TLMCustom#('TLM_PRM) custom;
                } TLMResponse#('TLM_PRM_DCL) deriving (Eq, Bits, Bounded);
```

typedef TLMResponse#('TLM_PRM_STD) TLMResponseStd;

Configurable Parameters

In the above BSV code definitions the compiler macros 'TLM_PRM_DCL and 'TLM_PRM are used in the typedef statements. A 'define statement is a preprocessor construct used to place prepackaged text values into a file, as described in Section 2.7.1. In this case, the macros contain parameters to be used in the data definitions. Placing the parameters in a separate file allows them to be easily modified for different protocol requirements. For convenience, we have predefined a few useful definitions for use in the TLM package.

The TLM_PRM_DCL macro contains type definition parameters which are used in the interface definitions or as arguments to TLM types and interfaces.

The TLM_PRM macro is used when providing the interface or using the data type. TLM_PRM is still polymorphic.

The macro TLM_PRM_STD provides specific values for the polymorphic values defined above. The values defined in TLM_PRM_STD are common values. The user can change any of the values or define other corresponding macros (with different values) as appropriate for a given design.

The macros are found in the file TLM.defines. A sample of the contents of the file are displayed below.

```
'define TLM_PRM_DCL numeric type id_size,
                    numeric type addr_size, \
                    numeric type data_size, \
                    numeric type uint_size, \
                    type cstm_type
'define TLM_PRM
                   id_size,
                   addr_size, \
                   data_size, \
                   uint_size, \
                   cstm_type
'define TLM_PRM_STD 4, \
                    32, \
                    32, \
                    10, \
                    Bit#(0)
```

The following macros are used to define requests and responses. The format follows the TLM_PRM (parameters), but these are TLM_RR (request response). The TLM_RR_DCL macro contains type definitions for requests and responses used in interface definitions or as arguments to TLM types and interfaces. The TLM_RR macro is polymorphic, while the TLM_RR_STD macro provides specific values.

The following macros combine the request and response type definitions into transactor definitions.

```
'define TLM_XTR_DCL 'TLM_RR_DCL, 'TLM_PRM_DCL
'define TLM_XTR 'TLM_RR, 'TLM_PRM
'define TLM_XTR_STD 'TLM_RR_STD, 'TLM_PRM_STD
```

Default Values

Both the RequestDescriptor#('TLM_PRM) and TLMResponse#('TLM_PRM) structures are instances of the DefaultValue typeclass allowing the definition of default values for the structures.

```
instance DefaultValue #(RequestDescriptor#('TLM_PRM))
```

```
provisos(DefaultValue#(cstm_type));
  function defaultValue ();
     RequestDescriptor#('TLM_PRM) request;
     request.command
                          = READ;
     request.mode
                           = REGULAR;
                           = 0;
     request.addr
     request.data
                            = 0:
     request.burst_length = 1;
     request.byte_enable
                           = '1:
     request.burst_mode = INCR;
     request.burst_size = 3; // assume 32 bits for now.
                          = 0;
     request.prty
                           = False;
     request.lock
                          = 0;
     request.thread_id
     request.transaction_id = 0;
     request.export_id = 0;
                          = defaultValue;
     request.custom
     return request;
   endfunction
endinstance
instance DefaultValue #(TLMResponse#('TLM_PRM))
  provisos(DefaultValue#(cstm_type));
  function defaultValue ();
     TLMResponse#('TLM_PRM) response;
                         = READ;
     response.command
                            = 0;
     response.data
                           = SUCCESS;
     response.status
     response.prty
                             = 0;
     response.thread_id
                             = 0;
     response.transaction_id = 0;
     response.export_id = 0;
     response.custom
                            = defaultValue;
     return response;
   endfunction
endinstance
Typeclasses
typeclass TLMRequestTC#(type a, 'TLM_PRM_DCL)
   dependencies (a determines ('TLM_PRM));
  function TLMRequest#('TLM_PRM) toTLMRequest(a value);
                                 fromTLMRequest(TLMRequest#('TLM_PRM) value);
  function a
endtypeclass
instance TLMRequestTC#(TLMRequest#('TLM_PRM), 'TLM_PRM);
   function toTLMRequest = id;
   function fromTLMRequest = id;
endinstance
typeclass TLMResponseTC#(type a, 'TLM_PRM_DCL)
   dependencies (a determines ('TLM_PRM));
   function TLMResponse#('TLM_PRM) toTLMResponse(a value);
                                  fromTLMResponse(TLMResponse#('TLM_PRM) value);
  function a
endtypeclass
```

```
instance TLMResponseTC#(TLMResponse#('TLM_PRM), 'TLM_PRM);
  function toTLMResponse = id;
  function fromTLMResponse = id;
endinstance
```

Interfaces

The TLM interfaces define how TLM blocks interconnect and communicate. The TLM package includes two basic interfaces: The TLMSendIFC interface and the TLMRecvIFC interface. These interfaces use basic Get and Put subinterfaces as the requests and responses, as described in Section C.7.1. The TLMSendIFC interface generates (Get) requests and receives (Put) responses. The TLMRecvIFC interface receives (Put) requests and generates (Get) responses. Additional TLM interfaces are built up from these basic blocks.

TLMSendIFC The TLMSendIFC interface transmits the requests and receives the responses.

TLMSendIFC Interface		
Name	Type	Description
tx	Get#(req)	Transmits a request through the Get interface
rx	Put#(resp)	Receives a response through the Put interface

```
interface TLMSendIFC#(type req, type resp);
  interface Get#(req) tx;
  interface Put#(resp) rx;
endinterface
```

TLMRecvIFC The TLMRecvIFC interface receives the requests and transmits the responses.

TLMRecvIFC Interface		
Name	Type	Description
tx	Get#(resp)	Transmits the response through the Get interface
rx	Put#(req)	Receives the request through the Put interface

```
interface TLMRecvIFC#(type req, type resp);
  interface Get#(resp) tx;
  interface Put#(req) rx;
endinterface
```

As illustrated in Figure 28, a TLMSendIFC is connectable to a TLMRecvIFC, just as a Get is connectable to a Put. A transmitted request (tx) from a TLMSendIFC is received (rx) by the TLMRecvIFC and visa versa.

```
instance Connectable#(TLMSendIFC#(req, resp), TLMRecvIFC#(req, resp));
```

A module with a TLMSendIFC interface creates a stream of requests. A module with a TLMRecvIFC interface receives the requests and transmits responses. Some bus protocols have separate channels for read and write operations. In these cases it is useful to have interfaces which bundle together two sends or two receives. The TLMReadWriteSendIFC interface includes two send interfaces while the TLMReadWriteRecvIFC interface bundles two receives.




Figure 28: Connecting TLM Send And Receive Interfaces

TLMReadWriteSendIFC The TLMReadWriteSendIFC interface is composed of two TLMSendIFC subinterfaces, one for a read channel and one for a write channel.

```
interface TLMReadWriteSendIFC#(type req, type resp);
  interface TLMSendIFC#(req, resp) read;
  interface TLMSendIFC#(req, resp) write;
endinterface
```

TLMReadWriteRecvIFC The TLMReadWriteRecvIFC interface is composed of two TLMRecvIFC subinterfaces, one for a read channel and one for a write channel.

```
interface TLMReadWriteRecvIFC#(type req, type resp);
  interface TLMRecvIFC#(req, resp) read;
  interface TLMRecvIFC#(req, resp) write;
endinterface
```

As illustrated in Figure 29, the TLMReadWriteSendIFC and TLMReadWriteRecvIFC interfaces are connectable as well.




Figure 29: TLM Read/Write Interfaces

instance Connectable#(TLMRecvIFC#(req, resp), TLMSendIFC#(req, resp));




Figure 30: TLMTransformIFC Interface


TLMTransformIFC The TLMTransformIFC provides a single TLMRecvIFC interface and a single TLMSendIFC interface. This interface is useful in modules which convert one stream of TLM operations into another. It is the interface provided by mkTLMReducer module for instance.

```
interface TLMTransformIFC#(type req, type resp);
  interface TLMRecvIFC#(req, resp) in;
  interface TLMSendIFC#(req, resp) out;
endinterface
```

Modules

The TLM package includes modules for creating and modifying TLM objects: mkTLMRandomizer, mkTLMSource, and mkTLMReducer. Two TLM RAM modules are also provided: mkTLMRam which provides a single read/write port and mkTLMReadWriteRam which provides two ports, a separate one for reads and a separate one for writes.

mkTLMRandomizer	Creates a stream of random TLM operations. The argument m_command is a Maybe type which determines the value of the TLMRequest. A valid value of READ will generate only reads, a valid value of WRITE will generate only writes, and an invalid value will generate both reads and writes. The Randomize interface is defined in the Randomizable package (Section C.8.2).
	<pre>module mkTLMRandomizer#(Maybe#(TLMCommand) m_command) (Randomize#(a)) provisos(TLMRequestTC#(a, 'TLM_PRM), Bits#(RequestDescriptor#('TLM_PRM), s0), Bounded#(RequestDescriptor#('TLM_PRM)), Bits#(RequestData#('TLM_PRM), s1), Bounded#(RequestData#('TLM_PRM)));</pre>






Figure 31: TLMRAM

mkTLMRam

Creates a TLM RAM with a single port for read and write operations. Provides the TLMRecvIFC interface. The verbose argument controls whether or not \$display output is provided when performing a memory operation. The id argument provides an identifier for the instantiation which is used in the \$display output if the verbose flag is asserted.




Figure 32: TLMReadWriteRAM

mkTLMReadWriteRam

Creates a RAM with separate ports for read and write operations. Provides the TLMReadWriteRecvIFC interface. The verbose argument controls whether or not \$display output is provided when performing a memory operation. The id argument provides an identifier for the instantiation which is used in the \$display output if the verbose flag is asserted.

The modules mkTLMBRAM and mkTLMBRAMBE allows BRAMs (Section C.1.5) to be accessed via a TLM interface.

mkTLMBRAM

The mkTLMBRAM module provides a TLMRecv interface and is built on any module that provides a BRAMServer interface, for example, a mkBRAM1Server module (Section C.1.5). byte_size needs to be a power of 2 (i.e. 1, 2, 4...)

```
module mkTLMBRAM (BRAMServer#(Bit#(anx), Bit#(dn)) bramifc,
                  TLMRecvIFC#(reqt, respt) ifc)
  provisos(Bits#(respt, sr),
            DefaultValue#(TLMResponse#('TLM_PRM)),
            Div#(data_size, 8, byte_size),
            Add#(anx, TLog#(byte_size), an),
            Add#(anx, iax, addr_size),
            Add#(an, ia, addr_size),
            Add#(dn, id, data_size),
            Add#(TDiv#(dn,8), xn, byte_size),
            Div#(data_size,8,TDiv#(data_size,8)),
                                  'TLM_PRM),
            TLMRequestTC#(reqt,
            TLMResponseTC#(respt, 'TLM_PRM),
            FShow#(TLMRequest#('TLM_PRM)),
            FShow#(RequestData#('TLM_PRM)));
```

mkTLMBRAMBE The mkTLMBRAMBE module provides a TLMRecv interface and is built on any module that provides a BRAMServerBE interface, for example, a mkBRAM1ServerBE module (Section C.1.5). byte_size needs to be a power of 2 (i.e. 1, 2, 4 ..) module mkTLMBRAMBE (BRAMServerBE#(Bit#(anx), Bit#(dn), nn) bramifc, TLMRecvIFC#(reqt, respt) ifc) provisos(Bits#(respt, sr), DefaultValue#(TLMResponse#('TLM_PRM)), Div#(data_size, 8, byte_size), Add#(anx, TLog#(byte_size), an), Add#(anx, iax, addr_size), Add#(an, ia, addr_size), Add#(dn, id, data_size), Add#(nn, xn, byte_size), Div#(data_size,8,TDiv#(data_size,8)), TLMRequestTC#(reqt, 'TLM_PRM), TLMResponseTC#(respt, 'TLM_PRM), FShow#(TLMRequest#('TLM_PRM)), FShow#(RequestData#('TLM_PRM)));

The mkTLMCBusAdapter module creates an adapter which allows the CBus (Section C.10.3) to be accessed via a TLM interface.

```
typedef CBus#(caddr_size, data_size) TLMCBus#('TLM_PRM_DCL, numeric type caddr_size);
typedef ModWithCBus#(caddr_size, data_size, i) ModWithTLMCBus#('TLM_PRM_DCL, numeric type caddr_size
typedef CRAddr#(caddr_size, data_size) TLMCRAddr#('TLM_PRM_DCL, numeric type caddr_size);
```

Takes a TLMCBus interface as an argument. Provides the TLMReadWriteRecvIFC interface. This configuration provides separate ports for read and write operations. module mkTLMCBusAdapterToReadWrite#(function Bit#(caddr_size) mapTLMAddr(Bit#(addr_size) addr), TLMCBus#('TLM_PRM, caddr_size) cfg) (TLMReadWriteRecvIFC#(req_t, resp_t)) provisos(TLMRequestTC#(req_t, 'TLM_PRM), TLMResponseTC#(resp_t, 'TLM_PRM), DefaultValue#(TLMResponse#('TLM_PRM)), Bits#(TLMRequest#('TLM_PRM), s0), Bits#(resp_t, s1), Add#(ignore, caddr_size, addr_size));

Functions

getTLMByteEn

getTLMCycleCount	Returns a 1 if the command is a read, otherwise returns the burst_length.
	<pre>function TLMUInt#('TLM_PRM)</pre>
getTLMBurstSize	Returns the size of the burst (burst_size + 1) as a Bit#(n).
	<pre>function Bit#(n) getTLMBurstSize (RequestDescriptor#('TLM_PRM) desc) provisos(Add#(SizeOf#(TLMBurstSize#('TLM_PRM)), 1, n));</pre>
getTLMIncr	Returns the TLM increment (burst_size + 1) as a Bit#(n). Returns 0 if the burst mode is constant.
	<pre>function Bit#(n) getTLMIncr (RequestDescriptor#('TLM_PRM) desc) provisos(Add#(SizeOf#(TLMBurstSize#('TLM_PRM)), 1, n));</pre>
	1

function TLMByteEn#('TLM_PRM) getTLMByteEn (

RequestDescriptor#('TLM_PRM) tlm_descriptor);

Returns the byte enable.

Returns a TLM Address.
<pre>function RequestDescriptor#('TLM_PRM) incrTLMAddr(RequestDescriptor#('TLM_PRM) desc);</pre>
Returns the number of LSB zeros.
<pre>function Bit#(n) countLSBZeros (Bit#(n) value);</pre>
Returns the data from a TLM request.
<pre>function TLMData#('TLM_PRM)</pre>

createBasicRequestDescriptor	Returns a generic TLM request with default values.
	<pre>function RequestDescriptor#('TLM_PRM)</pre>

createBasicTLMResponse	Returns a generic TLM response with default values.
	<pre>function TLMResponse#('TLM_PRM) createBasicTLMResponse() provisos(Bits#(TLMResponse#('TLM_PRM), s0));</pre>

C.12 Premium Bus Fabric Libraries

The Axi and AHB packages support development of bus-based designs implementing AXI and AHB protocols. These packages are AzureIP Premium offerings and are not provided as part of the Foundation library. If you are interested in obtaining these packages, please contact your sales representative or sales@bluespec.com. Customers licensed under release 2009.10.B or earlier still have access to the AXI and AHB libraries as part of the standard offering. Please contact support@bluespec.com if you cannot access the latest libraries.

C.12.1 Axi

Packages

import Axi :: * ;

Description

The AXI library includes interface, transactor, module and function definitions to implement the Advanced eXtensible Interface (AXI) protocol with Bluespec SystemVerilog. The BSV AXI library groups the AXI data and protocols into reusable, parameterized interfaces, which interact with TLM interfaces. An AXI bus is implemented using AXI transactors to connect TLM interfaces on one side with AXI interfaces on the other side. The TLM interfaces used by the Axi package are defined in the TLM2 package.

The AXI library supports the following AXI Bus protocol features:

- Basic and Burst Transfers
- Aligned and Unaligned Transfers

The AXI library does not support the following AXI Bus protocol features:

- Exclusive/Locked Access
- Low Power Interface
- Cache Transaction Attributes

The basic structure of an AXI write bus is show in figure 33. The structure of a read bus is similar. (Note that the nature of the AXI protocol is such that the read and write buses operate totally independently of each other).




Figure 33: AXI Write Bus Example

The corresponding BSV AXI implementation is shown in figure 34. TLM Write requests are received via the TLMRecvIFC interfaces of the master transactors. The request is then transmitted via the AxiWrMaster interface out onto the AXI bus and on to the appropriate slave transactor. The slave transactor receives the request via the AxiWrSlave interface, translates the request back into a stream of TLM objects, and then transmits those objects via the TLMSendIFC interface. The TLM response from the write operation follows the same path in reverse.




Figure 34: BSV AXI Write Bus Implementation Using TLM Transactors

This package is an AzureIP Premium offering and is not provided as part of the Foundation library. If you are interested in obtaining this package, please contact your sales representative or sales@bluespec.com. Customers licensed under release 2009.10.B or earlier still have access to this library as part of the standard offering. Please contact support@bluespec.com if you cannot access the latest library.

Data Structures

Inside the transactor modules, the AXI data is organized into the following data structures: the address data is defined by AxiAddrCmd, the read response is defined by AxiRdResp, the write data is defined by AxiWrData and the write response is defined by AxiWrResp.

AxiAddrCmd The AXI Address Bus is defined by a structure, **AxiAddrCmd**, the components of which are described in the following table.

$\operatorname{AxiAddrCmd}$		
Member Name	DataType	Valid Values
id	AxiId#('TLM_PRM)	Bit#(id_size)
len	AxiLen	Bit#(4)
size	AxiSize	Bit#(3)
burst	AxiBurst	FIXED, INCR, WRAP
lock	AxiLock	NORMAL, EXCLUSIVE, LOCKED
cache	AxiCache	Bit#(4)
prot	AxiProt	Bit#(3)
addr	AxiAddr#('TLM_PRM)	Bit#(addr_size)

```
typedef struct {
                 AxiId#('TLM_PRM)
                                     id;
                 AxiLen
                                       len;
                 AxiSize
                                       size;
                 AxiBurst
                                       burst;
                 AxiLock
                                       lock;
                 AxiCache
                                       cache;
                 AxiProt
                                       prot;
                 AxiAddr#('TLM_PRM) addr;
                 } AxiAddrCmd#('TLM_PRM_DCL) deriving(Bits,Eq);
```

AxiRdResp The AXI Read Bus is defined by the AxiRdResp structure, the components of which are described in the following table.

AxiRdResp		
Member Name DataType Valid Value		Valid Values
id	AxiId#('TLM_PRM)	Bit#(id_size)
data	AxiData#('TLM_PRM)	Bit#(data_size)
resp	AxiResp	OKAY, EXOKAY, SLVERR, DECERR
last	Bool	True, False

```
typedef struct {
          AxiId#('TLM_PRM) id;
          AxiData#('TLM_PRM) data;
          AxiResp resp;
          Bool last;
        } AxiRdResp#('TLM_PRM_DCL) deriving(Bits,Eq);
```

The AXI Write Bus is defined by two structures, AxiWrData and AxiWrResp.

AxiWrData The components of AxiWrData are described in the following table.

AxiWrData		
Member Name DataType Valid Values		Valid Values
id	AxiId#('TLM_PRM)	Bit#(id_size)
data	AxiData#('TLM_PRM)	Bit#(data_size)
strb	AxiByteEn#('TLM_PRM)	Bit#(TDiv#(data_size, 8))
last	Bool	True, False

AxiWrResp The components of AxiWrResp are described in the following table.

	$\operatorname{AxiWrResp}$		
Member Name DataType Valid Values		Valid Values	
id	AxiId#('TLM_PRM)	Bit#(id_size)	
resp	AxiResp	OKAY, EXOKAY, SLVERR, DECERR	

Bus Interfaces

This section describes the AXI bus master and slave interfaces used by the AXI transactor modules. Since the AXI protocol supports read and write operations on separate buses, two flavors of each interface exist, one for reads and one for writes.

AxiRdMaster The **AxiRdMaster** interface issues AXI read requests and receives AXI read responses.

```
interface AxiRdMaster#('TLM_PRM_DCL);
   // Address Outputs
  method AxiId#('TLM_PRM)
                             arID;
  method AxiAddr#('TLM_PRM) arADDR;
  method AxiLen
                               arLEN;
  method AxiSize
                               arSIZE;
  method AxiBurst
                               arBURST;
  method AxiLock
                               arLOCK;
  method AxiCache
                               arCACHE;
  method AxiProt
                               arPROT;
  method Bool
                               arVALID;
  // Address Inputs
  method Action arREADY(Bool value);
  // Response Outputs
  method Bool
                                 rREADY;
  // Response Inputs
  method Action rID
                       (AxiId#('TLM_PRM)
                                           value);
  method Action rDATA (AxiData#('TLM_PRM) value);
  method Action rRESP (AxiResp
                                             value);
  method Action rLAST (Bool
                                             value);
  method Action rVALID(Bool
                                             value);
endinterface
```

AxiWrMaster The **AxiWrMaster** interface issues AXI write requests and receives AXI write responses.

```
interface AxiWrMaster#('TLM_PRM_DCL);
  // Address Outputs
  method AxiId#('TLM_PRM)
                             awID;
  method AxiAddr#('TLM_PRM) awADDR;
  method AxiLen
                               awLEN;
  method AxiSize
                               awSIZE;
  method AxiBurst
                               awBURST;
  method AxiLock
                               awLOCK;
  method AxiCache
                               awCACHE;
  method AxiProt
                               awPROT;
  method Bool
                               awVALID;
  // Address Inputs
  method Action awREADY(Bool value);
  // Data Outputs
  method AxiId#('TLM_PRM)
                               wID;
  method AxiData#('TLM_PRM)
                               wDATA;
  method AxiByteEn#('TLM_PRM) wSTRB;
  method Bool
                                 wLAST;
  method Bool
                                 wVALID;
```

```
// Data Inputs
  method Action wREADY(Bool value);
   // Response Outputs
  method Bool
                                 bREADY;
   // Response Inputs
  method Action bID
                       (AxiId#('TLM_PRM) value);
  method Action bRESP (AxiResp
                                           value);
  method Action bVALID(Bool
                                           value);
endinterface
AxiRdSlave The AxiRdSlave interface receives AXI read requests and returns AXI read re-
sponses.
interface AxiRdSlave#('TLM_PRM_DCL);
  // Address Inputs
                        (AxiId#('TLM_PRM)
  method Action arID
                                            value);
  method Action arADDR (AxiAddr#('TLM_PRM) value);
  method Action arLEN (AxiLen
                                              value);
  method Action arSIZE (AxiSize
                                              value);
  method Action arBURST(AxiBurst
                                              value);
  method Action arLOCK (AxiLock
                                              value);
  method Action arCACHE(AxiCache
                                              value);
  method Action arPROT (AxiProt
                                              value);
  method Action arVALID(Bool
                                              value);
   // Address Outputs
  method Bool arREADY;
  // Response Inputs
  method Action rREADY(Bool value);
  // Response Outputs
  method AxiId#('TLM_PRM)
                             rID;
  method AxiData#('TLM_PRM) rDATA;
  method AxiResp
                               rRESP;
  method Bool
                               rLAST:
  method Bool
                               rVALID;
endinterface
AxiWrSlave The AxiWrSlave interface receives AXI write requests and returns AXI write re-
sponses.
interface AxiWrSlave#('TLM_PRM_DCL);
  // Address Inputs
                       (AxiId#('TLM_PRM)
  method Action awID
                                            value);
  method Action awADDR (AxiAddr#('TLM_PRM) value);
  method Action awLEN (AxiLen
                                              value);
  method Action awSIZE (AxiSize
                                              value);
```

value);

method Action awBURST(AxiBurst

```
method Action awLOCK (AxiLock
                                               value);
  method Action awCACHE(AxiCache
                                               value);
  method Action awPROT (AxiProt
                                               value);
  method Action awVALID(Bool
                                               value);
  // Address Outputs
  method Bool awREADY;
  // Data Inputs
                       (AxiId#('TLM_PRM)
  method Action wID
                                              value);
  method Action wDATA (AxiData#('TLM_PRM)
                                              value);
  method Action wSTRB (AxiByteEn#('TLM_PRM) value);
  method Action wLAST (Bool
                                                value);
  method Action wVALID(Bool
                                                value);
  // Data Ouptuts
  method Bool wREADY;
  // Response Inputs
  method Action bREADY(Bool value);
  // Response Outputs
  method AxiId#('TLM_PRM) bID;
  method AxiResp
                             bRESP:
  method Bool
                             bVALID;
endinterface
```

The AxiRdMaster and AxiRdSlave interfaces as well as the AxiWrMaster and AxiWrSlave interfaces are connectable.

```
instance Connectable#(AxiRdMaster#('TLM_PRM), AxiRdSlave#('TLM_PRM));
instance Connectable#(AxiWrMaster#('TLM_PRM), AxiWrSlave#('TLM_PRM));
```

Fabric Interfaces

When used in the context of a bus or switch, AXI transactor modules must communicate with address decoding logic. As with the BSV implementation of the AHB bus, bus fabric interfaces are provided to support this communication. Unlike the AHB protocol however, with the AXI bus protocol no explicit communication between the arbiter and the master transactor modules is required. Thus the AxiRdFabricMaster and AxiWrFabricMaster interfaces are simply wrappers around the bus interfaces themselves.

```
interface AxiRdFabricMaster#('TLM_PRM_DCL);
   (* prefix = "" *)
   interface AxiRdMaster#('TLM_PRM) bus;
endinterface

interface AxiWrFabricMaster#('TLM_PRM_DCL);
   (* prefix = "" *)
   interface AxiWrMaster#('TLM_PRM) bus;
endinterface
```

The AxiRdFabricSlave and AxiWrFabricSlave interfaces each provide an addrMatch method which given an AXI address returns an Boolean value indicating whether the given address maps to the associated slave. By polling this method for each slave on the bus, the decoding logic can determine the appropriate destination for each bus transaction.

```
interface AxiRdFabricSlave#('TLM_PRM_DCL);
    (* prefix = "" *)
    interface AxiRdSlave#('TLM_PRM) bus;
    method Bool addrMatch(AxiAddr#('TLM_PRM) value);
endinterface

interface AxiWrFabricSlave#('TLM_PRM_DCL);
    (* prefix = "" *)
    interface AxiWrSlave#('TLM_PRM) bus;
    method Bool addrMatch(AxiAddr#('TLM_PRM) value);
endinterface
```

Transactor Interfaces

Each AXI transactor module provides AXI and TLM interfaces to implement a translation between a stream of TLM operations and the AXI bus protocol. Each transactor has two subinterfaces: a subinterface for the connection with the AXI bus and a subinterface to send and receive TLM objects. The AXI library package includes two master transactor interfaces and two slave transactor interfaces; The AXIRdMasterXActor and AXIWrMasterXActor interfaces for masters and the AXIRdSlaveXActor and AXIWrSlaveXActor interfaces for slaves. Since the AXI protocol supports read and write transaction on separate buses, two transactor implementations are required for masters and two implementations for slaves. The AXI subinterface definitions can be found in section C.12.1. The TLM interfaces are described in Section C.11.1.

AxiRdMasterXActorIFC The AxiRdMasterXActorIFC has two subinterfaces: an AxiRdFabricMaster subinterface and a TLMRecvIFC subinterface. The associated transactor converts TLM read requests into the AXI protocol, and converts the AXI response back into TLM.

AxiWrMasterXActorIFC The AxiWrMasterXActorIFC has two subinterfaces: an AxiWrFabricMaster subinterface and a TLMRecvIFC subinterface. The associated transactor converts TLM write requests into the AXI protocol, and converts the AXI response back into TLM.




Figure 35: AXIMasterXActor Interfaces (Read and Write Versions)

AxiRdSlaveXActorIFC The AxiRdSlaveXActorIFC has two subinterfaces: an AxiRdFabricSlave subinterface and a TLMSendIFC subinterface. The associated transactor converts an AXI read request into TLM and the TLM response back into the AXI protocol.

AxiWrSlaveXActorIFC The AxiWrSlaveXActorIFC has two subinterfaces: an AxiWrFabricSlave subinterface and a TLMSendIFC subinterface. The associated transactor converts an AXI write request into TLM and the TLM response back into the AXI protocol.



Figure 36: AXISlaveXActor Interfaces (Read and Write Versions)

Modules

The following constructors are used to create AXI transactor modules. Versions with associated synthesis boundaries are also available. These versions are called mkAxiRdMasterStd, mkAxiWrMasterStd, mkAxiWrMasterStd, and mkAxiWrSlaveStd. The specific TLM parameter values for these synthesized versions are as specified by the preprocessor macro TLM_STD_TYPES (see section C.11.1).

```
Treates an AXI master read transactor module. Provides an AxiRdMasterXActorIFC interface.

module mkAxiRdMaster (AxiRdMasterXActorIFC#('TLM_XTR))
provisos(Bits#(req_t, s0),
Bits#(resp_t, s1),
TLMRequestTC#(req_t, 'TLM_PRM),
TLMResponseTC#(resp_t, 'TLM_PRM),
DefaultValue#(cstm_type),
AxiConvert#(AxiProt, cstm_type)
AxiConvert#(AxiCache, cstm_type));
```

mkAxiWrMaster Creates an AXI master write transactor module. Provides an AxiWrMasterXActorIFC interface.

```
module mkAxiWrMaster (AxiWrMasterXActorIFC#('TLM_XTR))
   provisos(Bits#(req_t, s0),
        Bits#(resp_t, s1),
        TLMRequestTC#(req_t, 'TLM_PRM),
        TLMResponseTC#(resp_t, 'TLM_PRM),
        DefaultValue#(cstm_type),
        Bits#(cstm_type, s2),
        AxiConvert#(AxiProt, cstm_type)
        AxiConvert#(AxiCache, cstm_type),
        AxiConvert#(AxiLock, cstm_type));
```


The following two module constructors are each used to create an AXI bus fabric. mkAxiRdBus is used to create a read bus while mkAxiWrBus is used to create a write bus.

The following module is used to add probe signals for each of the AXI bus signals. This facilitates debugging and waveform viewing of the created bus fabric.

mkAxiMonitor	Adds a probe module for each of the AXI bus signals. The include_pc value indicates whether or not the monitor module should include an instantiation of an AXI protocol checker module (available from ARM). If the protocol checker is not available, the value of include_pc should be set to False.	
	module mkAxiMonitor#(Bool include_pc,	

Functions

The following functions convert from TLM to \mathbf{AXI}

getAxiAddrCmd	Returns an AxiAddrCmd from a TLM RquestDescriptor		
	<pre>function AxiAddrCmd#('TLM_PRM) getAxiAddrCmd (</pre>		
getFirstAxiWrData	Returns the AxiWrData from the TLM RequestDesriptor		
	function AxiWrData#('TLM_PRM) getFirstAxiWrData (RequestDescriptor#('TLM_PRM) tlm_descriptor);		
getAxiByteEn	Returns the AxiByteEn from the TLM RequestDesriptor		
	<pre>function AxiByteEn#('TLM_PRM) getAxiByteEn (</pre>		
getAxiLen	Returns the AxiLen from the TLM burst_length		

function AxiLen getAxiLen(TLMUInt#('TLM_PRM) burst_length);

getAxiSize	Returns the AxiSize from the TLM incr	
	<pre>function AxiSize getAxiSize(TLMBurstSize#('TLM_PRM) incr);</pre>	
getAxiSize	Returns the AxiSize from the TLM incr	
	<pre>function AxiSize getAxiSize(TLMBurstSize#('TLM_PRM) incr);</pre>	
getAxiBurst	Returns the AxiBurst from the TLM burst_mode	
	<pre>function AxiBurst getAxiBurst(TLMBurstMode burst_mode);</pre>	
getAxiId	Returns the AxiId from the TLM transaction_id	
	function AxiId#('TLM_PRM) getAxiId(TLMId#('TLM_PRM) transaction_id);	

The following functions convert from $\mathbf{A}\mathbf{x}\mathbf{i}$ to $\mathbf{T}\mathbf{L}\mathbf{M}$

fromAxiAddrCmd	Returns the TLM RequestDescriptor from the AXI addr_cmd	
	<pre>function RequestDescriptor#('TLM_PRM) fromAxiAddrCmd (</pre>	

fromAxiLen	Returns the TLM burst_length from the AXI len	
	<pre>function TLMUInt#('TLM_PRM) fromAxiLen(AxiLen len);</pre>	

fromAxiBurst	Returns the TLM burst_mode from the AXI burst	
	function TLMBurstMode fromAxiBurst(AxiBurst burst);	
fromAxiSize	Returns the TLM burst_size from the AXI size	
	<pre>function TLMBurstSize#('TLM_PRM) fromAxiSize(AxiSize size);</pre>	
fromAxiId	Returns a TLM id from the AXI id	
	<pre>function TLMId#('TLM_PRM) fromAxiId(AxiId#('TLM_PRM) id);</pre>	
fromAxiResp	Returns the TLM status from the AXI resp	
	function TLMStatus fromAxiResp(AxiResp resp);	

C.12.2 AHB

Packages

import AHB :: * ;

Description

The AHB library includes interface, transactor, module and function definitions to implement the AHB protocol with Bluespec SystemVerilog. The BSV AHB library groups the AHB data and protocols into reusable, parameterized interfaces, which interact with TLM interfaces. An AHB bus is implemented using AHB transactors - interfaces which connect TLM interfaces on one side with AHB interfaces on the other side.

The AHB library supports the following AHB Bus protocol features:

- Basic and Burst Transfers
- Locked Transfers

The AHB library does not support the following AHB Bus protocol features:

• Early Burst Termination




Figure 37: AHB Bus Example

- Split Transfers
- Retry Transfers

This package is an AzureIP Premium offering and is not provided as part of the Foundation library. If you are interested in obtaining this package, please contact your sales representative or sales@bluespec.com. Customers licensed under release 2009.10.B or earlier still have access to this library as part of the standard offering. Please contact support@bluespec.com if you cannot access the latest library.

Data Structures

Inside the transactor modules, the AHB data is organized into the following data structures: the address and control information is defined by AHBCtrl, the write data is defined by AHBCata. These two structures are bundled into an AHBRequest. Finally, the response data is defined by AHBResponse.

AHBRequest An AHB request is defined by the AHBRequest structure as described below.

	AHBRequest		
Member DataType Valid Values			
cntrl	AHBCtrl#('TLM_PRM)	see above	
data	AHBData#('TLM_PRM)	Bit#(data_size)	

```
typedef struct {
          AHBCtrl#('TLM_PRM) ctrl;
          AHBData#('TLM_PRM) data;
} AHBRequest#('TLM_PRM_DCL) 'dv;
```

AHBCtrl The control fields in an AHBRequest are described by the AHBCtrl structure, the components of which are defined in the following table.

	AHBCtrl		
Member	DataType	Valid Values	
command	AHBWrite	READ, WRITE	
size	AHBSize	BITS8, BITS16, BITS32, BITS64, BITS128,	
		BITS256, BITS512, BITS1024	
burst	AHBBurst	SINGLE, INCR, WRAP4, INCR4, WRAP8, INCR8,	
		WRAP16, INCR16	
transfer	AHBTransfer	IDLE, BUSY, NONSEQ, SEQ	
prot	AHBProt	Bit#(4)	
addr	AHBAddr#('TLM_PRM)	Bit#(addr_size)	

```
typedef struct {
    AHBWrite command;
    AHBSize size;
    AHBBurst burst;
    AHBTransfer transfer;
    AHBProt prot;
    AHBAddr#('TLM_TYPES) addr;
} AHBCtrl#('TLM_PRM_DCL) 'dv;
```

AHBResponse An AHBResponse consists of a status fields and data (when responding to a read request). The components of the structure are described in the following table.

AHBResponse		
Member	DataType	Valid Values
status	AHBResp	OKAY, ERROR, RETRY, SPLIT
data	AHBData	Bit#(data_size)
command	Maybe#(AHBWrite)	READ, WRITE

```
typedef struct {
          AHBResp status;
          AHBData#('TLM_PRM) data;
          Maybe#(AHBWrite) command;
          AHBResponse#('TLM_PRM_DCL) 'dv;
```

Bus Interfaces

The two basic bus interfaces included in the AHB library are the AHBMaster interface and the AHBSlave interface.

AHBMaster The AHBMaster interface issues AHB requests and receives AHB responses.

```
(* always_ready, always_enabled *)
interface AHBMaster#('TLM_PRM_DCL);
   // Outputs
   (* result = "HADDR" *)
   method AHBAddr#('TLM_PRM) hADDR;
   (* result = "HWDATA" *)
   method AHBData#('TLM_PRM) hWDATA;
```




Figure 38: AHB Master Interface

```
(* result = "HWRITE" *)
  method AHBWrite
                                hWRITE;
   (* result = "HTRANS" *)
  method AHBTransfer
                                hTRANS;
   (* result = "HBURST" *)
  method AHBBurst
                                hBURST;
   (* result = "HSIZE" *)
  method AHBSize
                                hSIZE;
   (* result = "HPROT" *)
  method AHBProt
                                hPROT;
  // Inputs
   (* prefix = "", result = "unused0" *)
  method Action
                      hRDATA((* port = "HRDATA" *) AHBData#('TLM_PRM) data);
   (* prefix = "", result = "unused1" *)
  method Action
                     hREADY((* port = "HREADY" *) Bool value);
   (* prefix = "", result = "unused2" *)
  method Action
                     hRESP((* port = "HRESP" *) AHBResp response);
endinterface
```

AHBSlave The AHBSlave interface receives AHB requests and returns AHB responses.




Figure 39: AHB Slave Interface

```
(* always_ready, always_enabled *)
interface AHBSlave#('TLM_PRM_DCL);
   // Inputs
   (* prefix = "", result = "unused0" *)
                     hADDR((* port = "HADDR" *)
  method Action
                                                   AHBAddr#('TLM_PRM) addr);
   (* prefix = "", result = "unused1" *)
                     hWDATA((* port = "HWDATA" *)
  method Action
                                                   AHBData#('TLM_PRM) data);
   (* prefix = "", result = "unused2" *)
                     hWRITE((* port = "HWRITE" *) AHBWrite
  method Action
                                                               value);
   (* prefix = "", result = "unused3" *)
                     hTRANS((* port = "HTRANS" *) AHBTransfer value);
  method Action
```

```
(* prefix = "", result = "unused4" *)
                     hBURST((* port = "HBURST" *) AHBBurst
  method Action
                                                                value);
   (* prefix = "", result = "unused5" *)
                     hSIZE((* port = "HSIZE" *)
  method Action
                                                                value);
                                                    AHBSize
   (* prefix = "", result = "unused6" *)
  method Action
                     hPROT((* port = "HPROT" *)
                                                    AHBProt
                                                                value);
  // Outputs
   (* result = "HRDATA" *)
  method AHBData#('TLM_PRM) hRDATA;
   (* result = "HREADY" *)
  method Bool
                             hREADY;
   (* result = "HRESP" *)
  method AHBResp
                             hRESP;
endinterface
```

The AHBMaster and AHBSlave interfaces are connectable.

```
instance Connectable#(AHBMaster#('TLM_PRM), AHBSlave#('TLM_PRM));
```

Fabric Interfaces

When used in the context of a bus or switch, AHB Master and Slave modules must communicate with the arbiter and with address decoding logic. Two additional interfaces are provided to support this communication.

AHBMasterArbiter The AHBMasterArbiter interface connects the master module with the bus arbiter. Through this interface, the master can request control of the bus and determine when control has been granted.

AHBMasterArbiterDual

AHBSlaveSelector The AHBSlaveSelector interface provides an addrMatch method which given an AHB address returns an Boolean value indicating whether the given address maps to the associated slave. By polling this method for each slave on the bus, the decoding logic can determine the appropriate destination for each bus transaction. The AHBSlaveSelector interface also provides a select method by which the decoding logic can indicate which slave is the selected destination.

```
interface AHBSlaveSelector#('TLM_PRM_DCL);
  method Bool   addrMatch(AHBAddr#('TLM_PRM) value);
  (* prefix = "" *)
  method Action select((* port = "HSEL" *) Bool value);
endinterface
```

AHBFabricMaster The AHBFabricMaster interface bundles two sub-interfaces, an AHBMaster interface and an AHBMasterArbiter interface. It is this interface that is provided as an argument when constructing an AHB bus and as the bus side interface of an AHB master transactor module.

```
interface AHBFabricMaster#('TLM_PRM_DCL);
   (* prefix = "" *)
   interface AHBMaster#('TLM_PRM) bus;
   (* prefix = "" *)
   interface AHBMasterArbiter arbiter;
endinterface
```

AHBFabricSlave The AHBFabricSlave interface bundles two sub-interfaces, an AHBSlave interface and an AHBSlaveSelector interface. It is this interface that is provided as an argument when constructing an AHB bus and as the bus side interface of an AHB slave transactor module

Transactor Interfaces

An AHB transactor module provides AHB and TLM interfaces to implement a translation between a stream of TLM operations and the AHB bus protocol. Each transactor has two subinterfaces: a subinterface for the connection with the AHB bus and a subinterface to send and receive TLM objects.

The AHB library package includes two transactor interfaces; The AHBMasterXActor interface for the master and AHBSlaveXActor interface for the slave. The AHB protocol doesn't separate read and write transactions, so there is a single transactor implementation for masters and a single implementation for slaves.

AHBMasterXActor The AHBMasterXActor has two subinterfaces: an AHBFabricMaster subinterface and a TLMRecvifC subinterface. The TLM interface is described in Section C.11.1. The transactor converts TLM requests into the AHB protocol, and converts the AHB response back into TLM.




Figure 40: AHBMasterXActor Interface




Figure 41: AHBSlaveXActor Interface

AHBSlaveXActor The AHBSlaveXActor has two subinterfaces: AHBFabricSlave subinterface and a TLMSendIFC subinterface. The TLM interface is described in Section C.11.1. The transactor converts an AHB request into TLM and the TLM response back into the AHB protocol.

Modules

The following constructors are used to create AHB transactor modules. Versions with associated synthesis boundaries are also available. These versions are called mkAHBMasterStd, and mkAHBSlaveStd. The specific TLM parameter values for these synthesized versions are as specified by the preprocessor macro TLM_STD_TYPES (see section C.11.1).

mkAHBMaster	Creates an AHB Master transactor module. Provides a AHBMasterXActor interface. This version is polymorphic.	
	<pre>module mkAHBMaster (AHBMasterXActor#('TLM_RR, 'TLM_PRM)) provisos(TLMRequestTC#(req_t, 'TLM_PRM),</pre>	
mkAHBMasterStd	Creates an AHB Master transactor module. Provides a AHBMasterXActor interface.	
	module mkAHBMasterStd (AHBMasterXActor#('TLM_RR_STD, 'TLM_PRM_STD));	
mkAHBSlave	Creates an AHB Slave transactor module. Provides an AHBSlaveXActor interface. This version is polymorphic.	
	<pre>module mkAHBSlave#(function Bool addr_match(AHBAddr#('TLM_PRM) addr))</pre>	
mkAHBSlaveStd	Creates an AHB Slave transactor module. Provides an AHBSlaveXActor interface. This version is not polymorphic.	
	module mkAHBSlaveStd#(function Bool addr_match(AHBAddr#('TLM_PRM_STD) a (AHBSlaveXActor#('TLM_RR_STD, 'TLM_PRM_STD));	addr)
mkAHBSlaveDummy	This is the recipient of everything that doesn't have a slave destination.	
	module mkAHBSlaveDummy (AHBFabricSlave#('TLM_PRM));	

The following module constructor is used to create an AHB bus fabric.

mkAHBBus	Given a vector of AHBFabricMaster interfaces and a vector of AHBFabricSlave interfaces, mkAHBBus creates an AHB bus fabric.
	<pre>module mkAHBBus#(Vector#(master_count, AHBFabricMaster#('TLM_PRM)) masters, Vector#(slv_count, AHBFabricSlave#('TLM_PRM)) slvs) (Empty)</pre>

The following module is used to add probe signals for each of the AHB bus signals. This facilitates debugging and waveform viewing of the created bus fabric.

mkAHBMasterMonitor	Adds a probe module for each of the AHB bus signals. The include_pc value indicates whether or not the monitor module should include an instantiation of an AHB protocol checker module (available from ARM). If the protocol checker is not available, the value of include_pc should be set to False.
	<pre>module mkAHBMasterMonitor#(AHBFabricMaster#('TLM_PRM) master)</pre>

getCurrentSlave	Returns the slave_num of the current slave.	
	<pre>module getCurrentSlave#(AHBFabricMaster#('TLM_PRM) master, Vector#(slave_count,</pre>	
	AHBFabricSlave#('TLM_PRM)) slaves) (ReadOnly#(LBit#(slave_count)));	
	(neadonly#(LDIt#(Slave_Count))),	

Index

(Pitarian alamanathan) 150	Φ-+÷
<< (Bitwise class method), 158	\$stime, 96
>> (Bitwise class method), 158	\$stop, 95
(BitReduction class method), 159	\$swrite, 94
(Bitwise class method), 157	\$swriteAV, 94
π (Real constant), 283	\$swriteb, 94
&& (Bool operator), 166	\$swritebAV, 94
() (exporting member names), 20	\$swriteh, 94
* (Arith class method), 153	\$swritehAV, 94
** (Arith class method), 153	\$swriteo, 94
*/ (close nested comment), 14	\$swriteoAV, 94
+ (String concatenation operator), 168	\$test\$plusargs, 96
+ (Arith class method), 153	\$time, 96
- (Arith class method), 153	\$ungetc, 94
., see structs, member selection	\$write, 90
/ (Arith class div method), 153	\$writeb, 90
/* (open block comment), 14	\$writeh, 90
// (one-line comment), 14	\$writeo, 90
/= (Eq class method), 151	%(Arith class mod method), 153
< (Ord class method), 155	& (BitReduction class method), 159
<= (Reg assignment), 58	& (Bitwise class method), 157
<= (Ord class method), 155	_read (PulseWire interface method), 187
== (Eq class method), 151	_read (Reg interface method), 88, 180
> (Ord class method), 155	_write (Reg interface method), 88, 180
>= (Ord class method), 155	{} (Bit concatenation operator), 164
? (don't-care expression), 17, 66	{} (concatenation of bit arrays), 68
[] (bit/part select from bit array), 68	\$ (character in identifiers), 14
\$bitstoreal (Real system function), 96, 168	_ (character in identifiers), 14
\$display, 90	', see compiler directives
\$displayb, 90	~~ (BitReduction class method), 159
\$displayh, 90	^ (BitReduction class method), 159
\$displayo, 90	^ (Bitwise class method), 157
\$dumpoff, 95	<pre>^& (BitReduction class method), 159</pre>
\$dumpon, 95	^~ (Bitwise class method), 157
\$dumpvars, 95	~~ (BitReduction class method), 159
\$fclose, 92	~ (Bitwise class method), 157
\$fdisplay, 93	" (BitReduction class method), 159
\$fdisplayb, 93	(Bitwise class method), 157
\$fdisplayh, 93	,
\$fdisplayo, 93	abs (function), 192
\$fflush, 95	abs (Arith class method), 153
\$fgetc, 94	acosh (Real function), 284
\$finish, 95	Action (type), 176
\$fopen, 92	actions
\$fwrite, 93	Action (type), 70
\$fwriteb, 93	action (keyword), 70
\$fwriteh, 93	combining, 70
\$fwriteo, 93	ActionValue (type), 71, 176
\$realtobits (Real system function), 96, 168	Add (type provisos), 25, 178
\$sformat, 94	addBIUInt (function), 299
\$sformatAV, 94	addRules (Rules function), 176
	()

addToCollection (ModuleCollect function), 406	atan2 (Real function), 285 atanh (Real function), 284
addUInt (function), 300	attribute
AHB, 445	always_enabled, 99
AHB (package), 445	always_ready, 99
AHBAddr (data type), 446	clock_ancestors=, 111
AHBBurst (data type), 446	clock_family=, 111
AHBData (data type), 446	clock_raimy=, 111 clock_prefix, 109
AHBMasterXActor (interface), 450	clocked_by=, 113
AHBMasterXActor (transactor), 450	conflict_free, 106
AHBProt (data type), 446	default_clock_gate=, 110
AHBResponse (data type), 446	default_clock_osc=, 110
AHBSlaveXActor (interface), 451	default_reset=, 110
AHBSlaveXActor (transactor), 451	defualt_gate_inhigh=, 110
AHBTransfer (data type), 446	defualt_gate_unused=, 110
AHBWrite (data type), 446	descending_urgency, 103
Alias, 51, 163	doc=, 114
AlignedFIFOs (package), 235	enable=, 98
all (List function), 273	execution_order, 105
all (Vector function), 249	fire_when_enabled, 101
always_enabled (attribute), 99	gate=, 112
always_ready (attribute), 99	gate_default_clock, 110
ancestor(BVI import statement), 137	gate_inhigh, 112
and (List function), 274	$gate_input_clocks=, 110$
and (Vector function), 250	gate_prefix, 109
any (List function), 273	gate_unused, 112
any (Vector function), 249	mutually_exclusive, 106
AOF (clock ancestor attribute), 111	no_implicit_conditions, 102
append (List function), 266	noinline, 97
append (Vector function), 242	nosplit, 107
application	osc=, 112
of functions to arguments, 73	parameter=, 114
of methods to arguments, 73	port=, 99, 114
applyToContext (module), 401	preempts, 107
applyToContextM (module), 401	prefix=, 99
Arbiter (package), 329	ready=, 98
Arith (type class), 24, 153	reset=, 112
UInt, Int type instances, 87	$reset_by=, 113$
arrays	reset_prefix, 109
update, 57	result=, 99
arrayToVector (Vector function), 264	split, 107
asIfc (interface pseudo-function), 89	synthesize, 97
asinh (Real function), 284	attributes, 96
asReg (Reg function), 89, 180	await (StmtFSM function), 304
Assert (package), 346	Axi (package), 433
AssertFifoTest_IFC (interface), 358	AxiAddrAxiAddr (data type), 434
AssertQuiescentTest_IFC (interface), 357	AxiAddrCmd (data structure), 434
AssertSampleTest_IFC (interface), 356	AxiBurst (data type), 434
AssertStartStopTest_IFC (interface), 357	AxiByteEn (data type), 435
AssertStartTest_IFC (interface), 356	AxiCache (data type), 434
AssertTest_IFC (interface), 356	AxiData (data type), 435
AssertTransitionTest_IFC (interface), 357	AxiId (data type), 434, 435
assignment statements	AxiLen (data type), 434
pattern matching in, 85	AxiLock (data type), 434

AxiProtAxiProt (data type), 434	bsv_assert_increment (module), 362
AxiRdMaster (interface), 435	bsv_assert_never (module), 362
AxiRdMasterXActorIFC (interface), 439	bsv_assert_never_unknown (module), 363
AxiRdResp (data structure), 435	bsv_assert_never_unknown_async (module),
AxiRdSlave (interface), 437	363
AxiRdSlaveXActorIFC (interface), 440	bsv_assert_next (module), 363
AxiResp (data type), 435	bsv_assert_no_overflow (module), 363
AxiSize (data type), 434	bsv_assert_no_transition (module), 364
AxiWrData (data structure), 435	bsv_assert_no_underflow (module), 364
AxiWrMaster (interface), 435	bsv_assert_odd_parity (module), 364
AxiWrMasterXActorIFC (interface), 439	bsv_assert_one_cold (module), 364
AxiWrResp (data structure), 435	bsv_assert_one_hot (module), 365
AxiWrSlave (interface), 437	bsv_assert_proposition (module), 365
AxiWrSlaveXActorIFC (interface), 440	bsv_assert_quiescent_state (module), 365
(bsv_assert_range (module), 365
begin (keyword), 61, 69	bsv_assert_time (module), 366
begin-end expression blocks, 69	bsv_assert_transition (module), 366
begin-end statement blocks, 61	bsv_assert_unchange (module), 366
Bit (type), 86, 164	bsv_assert_width (module), 366
bit (type), 86, 164	bsv_assert_win_change (module), 367
bitconcat (Bit concatenation operator), 164	bsv_assert_win_unchange (module), 367
BitExtend (type class), 24, 161	bsv_assert_window (module), 367
UInt, Int type instances, 87	bsv_assert_zero_one_hot (module), 367
BitReduction (type class), 24, 159	buildVersion, 196
UInt, Int type instances, 87	BVI import (keyword)
Bits (type class), 24, 122, 150	in interfacing to Verilog, 127
deriving, 123	BypassWire (interface), 185
representation of data types, 123	bypasswire (micriace), 100
UInt, Int type instances, 87	C (scheduling annotations), 49
Bitwise (type class), 24, 157	case (keyword), 61, 82, 83
UInt, Int type instances, 87	case expression, 83
Bool (type), 166	case statements
Bounded (type class), 24, 157	ordinary, 61
deriving, 124	pattern matching, 82
UInt, Int type instances, 87	casting, type, 74
BRAM (interface type), 206	CBus (interface), 409
BRAM (package), 204	CBus (package), 408
	()
BRAM_Configure (type), 204 BRAM_DUAL_PORT (interface type), 211	ceil (Real function), 285 CF (scheduling annotations), 49
	,,
BRAM_PORT (interface type), 211	CGetPut (package), 319
BRAMCore (package, 211	clear (FIFO interface method), 89
BRAMFIFO (package), 231	clear (FIFO interface method), 89
BRAMRequest (type), 206	Client (interface), 317
bsv_assert_always (module), 360	ClientServer (package), 317
bsv_assert_always_on_edge (module), 360	Clock (type), 173, 369
bsv_assert_change (module), 360	clock_ancestors= (attribute), 111
bsv_assert_cycle_sequence (module), 360	clock_family= (attribute), 111
bsv_assert_decrement (module), 361	clock_prefix= (attribute), 109
bsv_assert_delta (module), 361	ClockDividerIfc (interface), 377
bsv_assert_even_parity (module), 361	clocked_by=(attribute), 113
bsv_assert_fifo_index (module), 361	clockOf (function), 370
bsv_assert_frame (module), 361	Clocks (package), 369
bsv_assert_handshake (module), 362	cmplx (complex function), 288
bsv_assert_implication (module), 362	cmplxMap (complex function), 288

cmplxSwap (complex function), 288	DefaultValue (package), 344
cmplxWrite (complex function), 289	'define (compiler directive), 18
collectCBusIFC (module), 409	delay (StmtFSM function), 304
comment	dea (FIFOF interface method), 89
block, 14	deq (FIFO interface method), 89
one-line, 14	- \
	deriving
CommitIfc (package), 320	Bits, 123
compare (Ord class method), 155	Bounded, 124
compiler directives, 17	Eq. 124
compilerVersion, 196	brief description, 26
CompletionBuffer (interface), 333	for isomorphic types, 125
CompletionBuffer (package), 333	descending_urgency (attribute), 103
Complex (package), 287	dbgProbe (module), 342
compose (function), 192	Div (type provisos), 25, 178
composeM (function), 193	div (Integer function), 165
concat (List function), 266	doc= (attribute), 114
concat (Vector function), 242	documentation attributes, 114
conditional expressions, 67	don't-care expression, see?
pattern matching in, 84	DReg (package,interface), 202
conditional statements, 61	drop (List function), 268
ConfigReg (package,interface), 201	drop (Vector function), 245
conflict_free (attribute), 106	dropWhile (List function), 269
Connectable (class), 316	dropWhileRev (List function), 269
Connectable (package), 315	DualPortRamIfc (interface), 391
Cons (List constructor), 265	dumpoff, 95
cons (List function), 265	dumpon, 95
cons (Vector function), 242	dumpvars, 95
constFn (function), 193	DWire (interface), 186
context, see provisos	dynamicAssert, 346
context too weak (overloading resolution), 119	,
continuousAssert, 347	elem (List function), 273
Control (interface), 328	elem (Vector function), 249
cos (Real function), 284	'else (compiler directive), 19
cosh (Real function), 284	else (keyword), 61
countElem (Vector function), 250	'elsif (compiler directive), 19
countIf (Vector function), 250	Empty (interface), 30
countLSBZeros (function), 432	emptyRules (Rules variable), 176
countOnes (function), 194	enable= (attribute), 98
countOnesAlt (bit-vector function), 252	end (keyword), 61, 69
countZerosLSB (function), 194	'endif (compiler directive), 19
countZerosMSB (function), 194	endpackage (keyword), 20
CRC (package), 354	enq (FIF0F interface method), 89
(- v /·	
curry (function), 193	enq (FIFO interface method), 89 enum, 51
J-+- 106	,
date, 196	enumerations, 51
decodeReal (Real function), 286	epochTime, 197
default (keyword), 62, 82	epsilon (FixedPoint function), 291
default_clock(BVI import statement), 132	Eq (type class), 24, 151
default_clock_gate= (attribute), 110	deriving, 124
default_clock_osc= (attribute), 110	UInt, Int type instances, 87
default_gate_inhigh (attribute), 110	error (forced error), 191
default_gate_unused (attribute), 110	errorM (forced error), 191
default_reset(BVI import statement), 135	execution_order (attribute), 105
default_reset= (attribute), 110	exp_e (Arith class method), 153

export (keyword), 20	fromInteger (converting unsized integer lit-
export, identifiers from a package, 20	erals to specific types), 15
exposeCBusIFC (module), 410	fromMaybe (Maybe function), 170
exposeCollection (ModuleCollect function), 406	fromReal (RealLiteral class method), 152 fromSizedInteger (SizedLiteral class method)
exposeCurrentClock (function), 370	153
exposeCurrentReset (function), 370	${\tt fromSizedInteger}({\tt SizedLiteral}\ {\rm class}\ {\rm method}),$
extend (BitExtend class method), 161	15
	fromUInt (FixedPoint function), 292
False (Bool constant), 166	FShow (data type), 340
FIFO (package), 216	FShow (package), 339
FIFO (interface type), 89	fshow (function), 341
FIFOCountIfc (interface), 225	FSMs, 86
FIFOF (package), 216	function calls, 73
FIFOF (interface type), 89	function definitions, 64
fifofToFifo (function), 221	fxptAdd (FixedPoint function), 293
FIFOLevel (package), 223	fxptGetFrac (FixedPoint function), 292
FIFOLevelIfc (interface), 224	<pre>fxptGetInt (FixedPoint function), 292</pre>
fifoToGet (GetPut function), 314	fxptMult (FixedPoint function), 293
fifoToPut (GetPut function), 314	fxptQuot (FixedPoint function), 293
File (type), 92	fxptSignExtend (FixedPoint function), 296
select (filter function), 268	fxptSub (FixedPoint function), 293
find (List function), 269	fxptTruncate (FixedPoint function), 294
find (Vector function), 250	fxptTruncateRoundSat (FixedPoint function),
findElem (Vector function), 250	294
findIndex (Vector function), 251	fxptTruncateSat (FixedPoint function), 294
finite state machines, 86	fxptWrite (FixedPoint function), 296
fire_when_enabled (attribute), 101	fxptZeroExtend (FixedPoint function), 296
first (FIFOF interface method), 89	- , , , , , , , , , , , , , , , , , , ,
first (FIFO interface method), 89	gate= (attribute), 112
FixedPoint (package), 289	gate_default_clock (attribute), 110
flatten (function), 419	gate_inhigh (attribute), 112
flattenO (function), 419	gate_input_clocks= (attribute), 110
flip (function), 193	gate_prefix= (attribute), 109
floor (Real function), 286	gate_unused (attribute), 112
Fmt (type), 169	GatedClockIfc (interface), 372
fold (List function), 278	gcd (function), 195
fold (Vector function), 257	Gearbox (interface), 239
foldl (List function), 278	Gearbox (package), 238
foldl (Vector function), 256	genC, 195
fold11 (List function), 278	generated clock port renaming, 109
foldl1 (Vector function), 256	genVector (Vector function), 241
foldr (List function), 277	genVerilog, 196
foldr (Vector function), 256	genWith (Vector function), 241
foldr1 (List function), 278	genWithM (Vector function), 262
foldr1 (Vector function), 256	Get (interface), 310
fromAxiAddrCmd (function), 444	getAxiAddrCmd (function), 443
fromAxiBurst (function), 444	getAxiBurst (function), 444
fromAxiId (function), 445	getAxiByteEn (function), 443
fromAxiLen (function), 444	getAxiId (function), 444
fromAxiResp (function), 445	getAxiLen (function), 443
fromAxiSize (function), 445	getAxiSize (function), 444
fromInt (FixedPoint function), 292	getCurrentSlave (module), 453
fromInteger (Literal class method), 152, 166	getFirstAxiWrData (function), 443

GetPut (package), 310	associativity, 67
Gettable (typeclass), 417	precedence, 67
getTLMBurstSize (function), 431	predefined, 67
getTLMByteEn (function), 431	init (List function), 268
getTLMCycleCount (function), 431	init (Vector function), 244
getTLMData (function), 432	Inout (type), 174
getTLMIncr (function), 431	inout(BVI import statement), 140
grammar, 13	input_clock(BVI import statement), 131
Gray (package), 331	input_reset(BVI import statement), 134
GrayCounter (package), 330	instance (of overloading group), 118
grayDecode (function), 332	instance (of type class), 118
grayDecr (function), 333	Int (type), 87, 165
grayEncode (function), 332	int (type), 87, 165
grayIncr (function), 333	Integer (type), 87, 165
grayIncrDecr (function), 333	Integer literals, 14
group (List function), 272	interface
groupBy (List function), 272	expression, 77
- · · · · · · · · · · · · · · · · · · ·	instantiation, 33
HAppend (typeclass), 416	interface (BVI import statement), 140
head (List function), 267	interface (keyword)
head (Vector function), 244	in interface declarations, 28
HHead (typeclass), 415	in interface expressions, 77
higher order functions, 125	interfaces, 28
HLength (typeclass), 416	definition of, 27
HList (package), 415	Invalid
HSplit (typeclass), 416	tagged union member of Maybe type, 55
HTail (typeclass), 416	Invalid (type constructor), 170
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	invert (Bitwise class method), 157
id (function), 193	invertCurrentClock (function), 371
Identifier (grammar terminal), 14	invertCurrentReset (function), 371
identifier (grammar terminal), 14	isAncestor (function), 370
identifiers, 14	isInfinite (Real function), 286
case sensitivity, 14	isNegativeZero (Real function), 286
export from a package, 20	isResetAsserted (module), 399
import into a package, 21	isValid (Maybe function), 170
qualified, 21	IWithCBus (interface), 409
static scoping, 21	,,,
with \$ as first letter, 14	joinActions (List function), 278
if (keyword), 61	joinActions (Vector function), 257
in method implicit conditions, 35	joinRules (List function), 279
if statements, 61	joinRules (Vector function), 257
pattern matching in, 84	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
if-else statements, 61	last (List function), 268
'ifdef (compiler directive), 19	last (Vector function), 244
'ifndef (compiler directive), 19	lcm (function), 195
implicit conditions, 35	length (List function), 273
on interface methods, 35	let, 57
import (keyword), 20	LevelFIFO, see FIFOLevel
import "BDPI" (keyword), 141	LFSR (package), 325
import "BVI" (keyword), 127	'line (compiler directive), 18
import, identifiers into a package, 21	List (type), 265
'include (compiler directive), 17	ListN (type), 264
incrTLMAddr (function), 432	Literal (type class), 24, 152
infix operators	UInt, Int type instances, 87

Literals	mkAHBMasterStd (module), 452
Integer, 14	mkAHBSlave (module), 452
real, 15	mkAHBSlaveDummy (module), 452
String, 16	mkAHBSlaveStd (module), 452
Log (type provisos), 25, 178	mkAlignedFIFO (module), 237
log (Arith class method), 153	mkArbiter (module), 330
log10 (Arith class method), 153	mkAsyncReset (module), 395
log2 (Arith class method), 153	mkAsyncResetFromCR (module), 395
logb (Arith class method), 153	mkAutoFSM, 304
lookup (List function), 269	mkAxiRdMaster (module), 441
loop statements	mkAxiRdSlave (module), 441
statically unrolled, 63	mkAxiWrMaster (module), 441
temporal, in FSMs, 302	mkAxiWrSlave (module), 442
1sb (Bitwise class method), 159	mkBRAM1Server (module), 208
,,,	mkBRAM1ServerBE (module), 208
macro invocation (compiler directive), 19	mkBRAM2Server (module), 209
MakeClockIfc (interface), 371	mkBRAMCore1 (module), 213
MakeResetIfc (interface), 394	mkBRAMCore1BE (module), 213
map (List function), 275	mkBRAMCore1BELoad (module), 213
map (Vector function), 254	mkBRAMCore1Load (module), 213
mapAccumL (List function), 281	mkBRAMCore2 (module), 213
mapAccumL (Vector function), 260	mkBRAMCore2BE (module), 213
mapAccumR (List function), 281	mkBRAMCore2BELoad (module), 214
mapAccumR (Vector function), 260	mkBRAMCore2Load (module), 214
mapCollection (ModuleCollect function), 406	mkBRAMStore1W2R (module), 237
mapM (Monad function on List), 282	mkBRAMStore2W1R (module), 237
mapM (Monad function on Vector), 261	mkBypassFIFO (module), 234
mapM_ (List function), 282	mkBypassFIF0F (module), 234
mapM_ (Vector function), 261	mkBypassFIF0Level (module), 234
mapPairs (List function), 279	mkBypassWire (module), 185
mapPairs (Vector function), 257	mkCBRegFile (module), 411
match (keyword), 85	mkCBRegR (module), 410
Max (type provisos), 25, 178	mkCBRegRC (module), 410
max (Ord class method), 155	mkCBRegRW (module), 410
max (function), 191	mkCBRegW (module), 410
maxBound (Bounded class method), 157	mkCClientServer (function), 320
Maybe (type), 55, 170	mkCGetPut (function), 320
message (compilation message), 191	mkClientCServer (function), 320
messageM (compilation message), 191	mkClock (module), 372
meta notation, see grammar	mkClockDivider (module), 377
method(BVI import statement), 130	mkClockDividerOffset (module), 377
method calls, 73	mkClockInverter (module), 377
methods	mkClockMux (module), 376
of an interface, 28	mkClockSelect (module), 376
pattern matching in, 85	mkCompletionBuffer (module), 334
Min (type provisos), 178	mkConfigReg (module), 201
min (Ord class method), 155	mkConfigRegA (module), 201
min (function), 191	mkConfigRegU (module), 201
minBound (Bounded class method), 157	mkConstrainedRandomizer (module), 328
mk1toNGearbox (module), 240	mkCRC(module), 354
mkAbsoluteClock (module), 374	mkCRC16(module), 355
mkAbsoluteClockFull (module), 374	mkCRC32(module), 355
mkAHBMaster (module), 451	mkCRC_CCIT(module), 355
mkAHBMasterMonitor (module), 453	mkDepthParamFIFO (module), 219

${\tt mkDepthParamFIFOF}\ (module),\ {\tt 219}$	mkRegFileFullFile (RegFileLoad function),
mkDFIFOF (module), 234	199
mkDReg (module), 202	mkRegFileLoad (RegFileLoad function), 199
mkDRegA (module), 202	mkRegStore (module), 237
mkDRegU (module), 202	mkRegU (Reg function), 88, 180
mkDualRam (module), 391	mkRegVectorStore (module), 237
mkDWire (module), 186	mkReset (module), 396
mkFeedLFSR(module), 325	mkResetEither (module), 398
mkFIFO (module), 218	mkResetInverter (module), 399
mkFIFO (FIFO function), 89	mkResetMux (module), 397
mkFIF01 (module), 218	mkResetSync (module), 396
mkFIF0Count (module), 227	mkRevertingVirtualReg (module), 203
mkFIFOF (module), 218	mkRWire (RWire module), 183
mkFIFOF (FIFOF function), 89	mkSizedBRAMFIFO (module), 231
mkFIF0F1 (module), 218	mkSizedBRAMFIFOF (module), 231
mkFIFOLevel (module), 227	${\tt mkSizedBypassFIFOF}\ ({\tt module}), {\tt 234}$
mkFSM, 304	mkSizedFIFO (module), 219
mkFSMServer, 308	mkSizedFIFO (FIFO function), 89
mkFSMWithPred, 304	mkSizedFIFOF (module), 219
mkGatedClock (module), 373	mkSizedFIFOF (FIFOF function), 89
mkGatedClockDivider (module), 377	mkStickyArbiter (module), 330
mkGateClockFromCC (module), 373	mkSyncBit (module), 380
mkGatedClockInverter (module), 377	mkSyncBit05 (module), 383
mkGDepthParamFIFOF (module), 220	mkSyncBitO5FromCC (module), 383
mkGenericRandomizer (module), 328	mkSyncBitO5ToCC (module), 383
mkGetCPut (function), 320	mkSyncBit1 (module), 382
mkGFIF0Count (module), 227	mkSyncBit15 (module), 381
mkGFIFOF (module), 219	mkSyncBit15FromCC (module), 381
mkGFIF0F1 (module), 220	mkSyncBit15ToCC (module), 382
mkGFIF0Level (module), 227	mkSyncBit1FromCC (module), 382
mkGLFIFOF (module), 220	mkSyncBit1ToCC (module), 382
mkGPFIFO (GetPut module), 313	mkSyncBitFromCC (module), 381
mkGPFIF0 (GetPut module), 314	mkSyncBitToCC (module), 381
mkGPSizedFIF0 (GetPut module), 314	mkSyncBRAM2Server (module), 209
*	mkSyncBRAM2ServerBE (module), 209
mkGrayCounter (module), 331	mkSyncBRAMCore2 (module), 214
mkGSizedFIF0F (module), 220	mkSyncBRAMCore2BE (module), 214
mkInitialReset (module), 396	mkSyncBRAMCore2BELoad (module), 215
mkLFIFO (module), 220	mkSyncBRAMCore2Load (module), 215
mkLFIF0F (module), 220	mkSyncBRAMFIFO (module), 232
mkNto1Gearbox (module), 239	${\tt mkSyncBRAMFIFOFromCC}\ ({\tt module}), 232$
mkNullCrossingReg (module), 393	mkSyncBRAMFIFOToCC $(module)$, 232
mkNullCrossingRegA (module), 393	mkSyncFIFO (module), 389
mkNullCrossingRegU (module), 393	mkSyncFIF01 (module), 390
mkNullCrossingWire (module), 392	mkSyncFIFOCount (module), 228
mkOnce, 304	mkSyncFIFOFromCC (module), 390
mkPipelineFIFO (module), 233	mkSyncFIFOLevel (module), 228
mkPipelineFIF0F (module), 234	mkSyncFIFOToCC (module), 390
mkPulseWire (module), 187	mkSyncHandshake (module), 386
mkPulseWireOR (module), 187	mkSyncHandshakeFromCC (module), 386
mkReg (Reg function), 88, 180	mkSyncHandshakeToCC (module), 386
mkRegA (Reg function), 180	mkSyncPulse (module), 385
mkRegFile (RegFile module), 198	mkSyncPulseFromCC (module), 385
mkRegFileFull (RegFile module), 198	mkSyncPulseToCC (module), 385

mkSyncReg (module), 387	noAction (empty action), 70, 176
mkSyncRegFromCC (module), 388	noClock (function), 371
mkSyncRegToCC (module), 388	noinline (attribute), 97
mkSyncReset (module), 395	noReset (function), 371
mkSyncResetFromCR (module), 395	nosplit (attribute), 107
mkTLMBRAM (module), 429	not (Bool function), 166
	*
mkTLMBRAMBE (module), 429	NumAlias, 51, 163
mkTLMCBusAdapter (module), 430	NumberTypes (package), 298
mkTLMCBusAdapterToReadWrite (module), 430	OInt (nackage) 207
mkTLMRam (module), 428	OInt (package), 297
mkTLMRandomizer (module), 427	OInt (type), 297
mkTLMReadWriteRam (module), 428	oneHotSelect (List function), 267
mkTLMReducer (module), 427	operators
mkTLMSource (module), 427	infix, 67
mkTriState, 351	prefix, 67
mkUGDepthParamFIF0F (module), 219	or (List function), 273
mkUGFIFOF (module), 219	or (Vector function), 250
mkUGFIF0F1 (module), 219	Ord (type class), 24, 118, 155
mkUGLFIFOF (module), 220	UInt, Int type instances, 87
mkUGSizedFIFOF (module), 219	Ordering $(type)$, 171
mkUngatedClock (module), 373	osc= (attribute), 112
mkUngatedClockMux (module), 376	output_clock(BVI import statement), 134
mkUngatedClockSelect (module), 376	output_reset(BVI import statement), 137
mkUniqueWrappers (UniqueWrappers module),	overloading groups, see type classes
336	overloading, of types, 117
mkUnsafeDWire (module), 186	OVLAssertions (package), 356
mkUnsafePulseWire (module), 187	
inkonsarci discurre (module), 101	
mkUnsafePulseWireOR (module), 187	pack (Bits type class overloaded function),
mkUnsafePulseWireOR (module), 187	pack (Bits type class overloaded function), $122, 150$
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183	122, 150
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184	122, 150 package, 20
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184	122, 150 package, 20 package (keyword), 20
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353	122, 150 package, 20 package (keyword), 20 parameter, 31
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353	122, 150 package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165	122, 150 package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module	122, 150 package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31	122, 150 package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33	122, 150 package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404	122, 150 package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405	122, 150 package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399	122, 150 package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules	122, 150 package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules definition of, 27	122, 150 package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82 in conditional expressions, 84
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules definition of, 27 module (keyword), 31	122, 150 package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82 in conditional expressions, 84 in if statements, 84
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules definition of, 27 module (keyword), 31 msb (Bitwise class method), 159	package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82 in conditional expressions, 84 in if statements, 84 in methods, 85
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules definition of, 27 module (keyword), 31 msb (Bitwise class method), 159 Mul (type provisos), 25, 178	package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82 in conditional expressions, 84 in if statements, 84 in methods, 85 in rules, 85
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules definition of, 27 module (keyword), 31 msb (Bitwise class method), 159 Mul (type provisos), 25, 178 mutually_exclusive (attribute), 106	package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82 in conditional expressions, 84 in if statements, 84 in methods, 85 in rules, 85 patterns, 80
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules definition of, 27 module (keyword), 31 msb (Bitwise class method), 159 Mul (type provisos), 25, 178 mutually_exclusive (attribute), 106 MuxClockIfc (interface), 375	122, 150 package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82 in conditional expressions, 84 in if statements, 84 in methods, 85 in rules, 85 patterns, 80 pi (Real constant), 283
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules definition of, 27 module (keyword), 31 msb (Bitwise class method), 159 Mul (type provisos), 25, 178 mutually_exclusive (attribute), 106	package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82 in conditional expressions, 84 in if statements, 84 in methods, 85 in rules, 85 patterns, 80 pi (Real constant), 283 polymorphism, 24
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules definition of, 27 module (keyword), 31 msb (Bitwise class method), 159 Mul (type provisos), 25, 178 mutually_exclusive (attribute), 106 MuxClockIfc (interface), 375 MuxRstIfc (interface), 394	package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82 in conditional expressions, 84 in if statements, 84 in methods, 85 in rules, 85 patterns, 80 pi (Real constant), 283 polymorphism, 24 port(BVI import statement), 131
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules definition of, 27 module (keyword), 31 msb (Bitwise class method), 159 Mul (type provisos), 25, 178 mutually_exclusive (attribute), 106 MuxClockIfc (interface), 375 MuxRstIfc (interface), 394 negate (Arith class method), 153	package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82 in conditional expressions, 84 in if statements, 84 in methods, 85 in rules, 85 patterns, 80 pi (Real constant), 283 polymorphism, 24 port(BVI import statement), 131 port= (attribute), 99, 114
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules definition of, 27 module (keyword), 31 msb (Bitwise class method), 159 Mul (type provisos), 25, 178 mutually_exclusive (attribute), 106 MuxClockIfc (interface), 375 MuxRstIfc (interface), 394 negate (Arith class method), 153 newVector (Vector function), 241	package, 20 package (keyword), 20 parameter, 31 parameter (BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path (BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82 in conditional expressions, 84 in if statements, 84 in methods, 85 in rules, 85 patterns, 80 pi (Real constant), 283 polymorphism, 24 port (BVI import statement), 131 port= (attribute), 99, 114 pow (Real function), 285
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules definition of, 27 module (keyword), 31 msb (Bitwise class method), 159 Mul (type provisos), 25, 178 mutually_exclusive (attribute), 106 MuxClockIfc (interface), 375 MuxRstIfc (interface), 394 negate (Arith class method), 153 newVector (Vector function), 241 Nil (List constructor), 265	package, 20 package (keyword), 20 parameter, 31 parameter(BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path(BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82 in conditional expressions, 84 in if statements, 84 in methods, 85 in rules, 85 patterns, 80 pi (Real constant), 283 polymorphism, 24 port(BVI import statement), 131 port= (attribute), 99, 114 pow (Real function), 285 preempts (attribute), 107
mkUnsafePulseWireOR (module), 187 mkUnsafeRWire (RWire module), 183 mkUnsafeWire (module), 184 mkWire (module), 184 mkZBus (function), 353 mkZBusBuffer (function), 353 mod (Integer function), 165 module definition of, 31 instantiation, 33 ModuleCollect (package), 404 ModuleCollect (type), 405 ModuleContext (package), 399 modules definition of, 27 module (keyword), 31 msb (Bitwise class method), 159 Mul (type provisos), 25, 178 mutually_exclusive (attribute), 106 MuxClockIfc (interface), 375 MuxRstIfc (interface), 394 negate (Arith class method), 153 newVector (Vector function), 241	package, 20 package (keyword), 20 parameter, 31 parameter (BVI import statement), 129 parameter= (attribute), 114 parity (function), 194 path (BVI import statement), 139 pattern matching, 80 error, 83 in assignment statements, 85 in case expressions, 83 in case statements, 82 in conditional expressions, 84 in if statements, 84 in methods, 85 in rules, 85 patterns, 80 pi (Real constant), 283 polymorphism, 24 port (BVI import statement), 131 port= (attribute), 99, 114 pow (Real function), 285

Probe (package), 347	reset_prefix= (attribute), 109
provisos, 118, 178	'resetall (compiler directive), 19
brief description, 24	resetOf (function), 371
PulseWire (interface), 187	result= (attribute), 99
pulseWireToReadOnly (function), 189	reverse (List function), 271
Put (interface), 310	reverse (Vector function), 248
	reverseBits (function), 194
quot (Integer function), 165	RevertingVirtualReg (package), 203
	rJoin (Rules operator), 176
Randomizable (package), 327	rJoinConflictFree (Rules operator), 176
Randomize (interface), 327	rJoinDescendingUrgency (Rules operator),
ReadOnly (interface), 189	176
readReadOnly (function), 189	rJoinExecutionOrder (Rules operator), 176
readReg (Reg function), 180	rJoinMutuallyExclusive (Rules operator),
readVReg (Vector function), 252	176
ready= (attribute), 98	rJoinPreempts (Rules operator), 176
Real (package), 283	rotate (List function), 271
Real (type), 167	rotate (Vector function), 247
real (type), 167	rotateBitsBy (bit-vector function), 252
Real literals, 15	rotateBy (Vector function), 247
RealLiteral (type class), 152	rotateR (List function), 271
reburyContext (module), 402	rotateR (Vector function), 247
records, see struct	round (Real function), 285
reduceAnd (BitReduction class method), 159	rules, 39
reduceNand (BitReduction class method), 159	expression, 79
reduceNor (BitReduction class method), 159	pattern matching in, 85
reduceOr (BitReduction class method), 159	Rules (type), 79, 176
reduceXnor (BitReduction class method), 159	runWithContext (function), 403
reduceXor (BitReduction class method), 159	runWithContexts (function), 403
reflect(CRC function), 355	RWire, 182
Reg (interface), 387	
Reg (type), 88, 180	SA (scheduling annotations), 49
RegFile (interface type), 198	<pre>same_family(BVI import statement), 137</pre>
RegFileLoad (package), 199	sameFamily (function), 370
register assignment, 58	SAR (scheduling annotations), 49
array element, 59	satMinus (SaturatingArith class method),
partial, 59	162
register writes, 58	satPlus (SaturatingArith class method), 162
regToReadOnly (function), 189	SaturatingArith (type class), 162
rem (Integer function), 165	SB (scheduling annotations), 49
replicate (List function), 266	SBR (scheduling annotations), 49
replicate (Vector function), 241	sbtrctBIUInt (function), 299
replicateM (List function), 283	scanl (List function), 281
replicateM (Vector function), 262	scanl (Vector function), 259
RequestData (data structure), 421	scanr (List function), 280
RequestDescriptor (data structure), 421	scanr (Vector function), 258
Reserved (type), 348	schedule(BVI import statement), 138
Reserved (package), 348	scheduling annotations, 49
ReservedOne (type), 348	select (List function), 267
ReservedZero (type), 348	select (Vector function), 243
Reset (type), 174, 369	SelectClockIfc (interface), 375
clear, 300	send (PulseWire interface method), 187
reset= (attribute), 112	Server (interface), 318
reset_by=(attribute), 113	shiftInAtO (Vector function), 247

shiftInAtN (Vector function), 247	\$test\$plusargs, 96
shiftOutFromO (Vector function), 247	time, 96
shiftOutFromN (Vector function), 248	system tasks, 90
signedMul (function), 192	θ
signedQuot (function), 192	θ
signExtend (BitExtend class method), 161	$sigmath{displayh}$
signum (Arith class method), 153	stimes 0
sin (Real function), 283	\$dumpoff, 95
sinh (Real function), 284	30,95
size types, 23	3dumpvars, 95
type classes for constraints, 25	fclose, 92
SizedLiteral (type class), 153	fdisplay, 93
SizeOf (pseudo-function on types), 123, 179	fdisplayb, 93
sort (List function), 271	fdisplayh, 93
sortBy (List function), 271	fdisplayo, 93
SpecialFIFOs (package), 232	flush, 95
split (Bit function), 86, 164	fgetc, 94
split (attribute), 107	finish, 95
splitReal (Real function), 286	\$fopen , 92
sqrt (Real function), 285	five 100
sscanl (List function), 281	five 100, 93
sscanl (Vector function), 259	five 1, 93
sscanr (List function), 280	five 100, 93
sscanr (Vector function), 259	sformat, 94
Standard Prelude, 22, 70, 86, 87, 119, 150	sformatAV, 94
start, 300	\$stop, 95
$\mathtt{staticAssert},346$	swrite, 94
StmtFSM (package), 300	swriteAV, 94
strConcat (String concatenation operator),	swriteb, 94
168	swritebAV, 94
String (type), 87, 168	swriteh, 94
String literals, 16	swritehAV, 94
struct	swriteo, 94
type definition, 52	swriteoAV, 94
'struct', 52	sungetc, 94
structs	\$write , 90
member selection, 75	\$writeb, 90
update, 57	\$writeh, 90
sub (RegFile interface method), 198	\$writeo, 90
subinterfaces	
declaration of, 30	TAdd (type functions), 179
definition of, 37	'tagged', see union
SyncBitIfc (interface), 380	tagged union
SyncFIFOCountIfc (interface), 226	member selection, see pattern matching
SyncFiFOifc (interface), 388	member selection using dot notation, 76
SyncFIFOLevelIfc (interface), 226	type definition, 52
SyncPulseIfc (interface), 384	update, 57
synthesize	tail (List function), 268
modules, 42	tail (Vector function), 244
synthesize (attribute), 97	take (List function), 268
system functions, 90	take (Vector function), 245
bitstoreal, 96	takeAt (Vector function), 245
realtobits, 96	takeWhile (List function), 269
\$stime, 96	takeWhileRev (List function), 269

tan (Real function), 284	uaMapM (function), 419
tanh (Real function), 284	UInt (type), 87, 165
TDiv (type functions), 179	unburyContext (module), 402
TExp (type functions), 179	unburyContextWithClocks (module), 402
TieOff (package), 346	uncurry (function), 193
TLM.defines, 422	'undef (compiler directive), 19
TLM2 (package), 420	underscore, see _
TLM_PRM_DCL, 422	'union',52
TLM_PRM_STD, 422	union tagged
TLM_TYPE, 422	type definition, 52
TLMReadWriteRecvIFC (interface), 426	UnitAppendList (package), 419
TLMReadWriteSendIFC (interface), 426	unpack (Bits type class overloaded function),
TLMRecvIFC (interface), 425	122, 150
TLMRequest (data structure), 421	unsignedMul (function), 192
TLMResponse (data structure), 422	unsignedQuot (function), 192
TLMSendIFC (interface), 425	unwrap (function), 300
TLMTransformIFC (interface), 427	unwrapBI (function), 299
TLog (type functions), 179	unzip (List function), 275
TMax (type functions), 179	unzip (Vector function), 253
TMin (type functions), 179	upd (RegFile interface method), 198
TMul (type functions), 179	update (List function), 267
toChunks (Vector function), 264	update (Vector function), 244
toGet (function), 310	upto (List function), 265
toList (Vector function), 264	ap 00 (2200 ramotion), 200
toPut (function), 311	Valid
	tagged union member of Maybe type, 55
to Vector (Vector function), 264	Valid (type constructor), 170
Transactors, 439	Value Change Dump, 95
transpose (List function), 271	valueOf (pseudo-function of size types), 26,
transpose (Vector function), 248	179
transposeLN (Vector function), 248	value of (pseudo-function of size types), 179
TriState (interface), 350	variable assignment, 56
TriState (package), 350	variable declaration, 55
True (Bool constant), 166	variable initialization, 55
trunc (Real function), 285	variables, 55
truncate (BitExtend class method), 161	VCD, 94, 95
truncateLSB (function), 194	Vector, 240
TSub (type functions), 179	vectorToArray (Vector function), 264
tuples	Void (type), 169
expressions, 87, 173	void (type, in tagged unions), 53
patterns, 88	(01 / 00 //
selecting components, 88, 173	warning (forced warning), 191
type definition, 87, 171	warningM (forced warning), 191
type assertions	wget (RWire interface method), 182
static, 74	when (function), 195
type casting, 74	while (function), 195
type classes, 118, 150	Wire (interface), 184
type declaration, 22	wrap (function), 300
type variables, 24	Wrapper (interface type), 336
typedef (keyword), 50	WriteOnly (interface), 190
types, 22	writeReg (Reg function), 180
parameterized, 23	writeVReg (Vector function), 252
polymorphic, 24	wset (RWire interface method), 182
uaMap (function), 419	ZBus (package), 351

```
ZBusBusIFC (interface), 352
ZBusClientIFC (interface), 352
ZBusDualIFC (interface), 352
zeroExtend (BitExtend class method), 161
zip (List function), 274
zip (Vector function), 252
zip3 (List function), 274
zip3 (Vector function), 253
zip4 (List function), 275
zip4 (Vector function), 253
zipAny (Vector function), 253
zipWith (List function), 276
zipWith (Vector function), 254
zipWith3 (List function), 276
zipWith3 (Vector function), 255
zipWith3M (List function), 282
zipWith3M (Vector function), 261
zipWith4 (List function), 276
zipWithAny (Vector function), 254
zipWithAny3 (Vector function), 255
zipWithM (List function), 282
zipWithM (Vector function), 261
```

Function and Module by Package

ATID	1.C DDAMOC DE 200
AHB	mkSyncBRAM2ServerBE, 209
getCurrentSlave, 453	mkSyncBRAMCore2, 214
mkAHBBus, 453	mkSyncBRAMCore2BE, 214
mkAHBMaster, 451	mkSyncBRAMCore2BELoad, 215
mkAHBMasterMonitor, 453	mkSyncBRAMCore2Load, 215
mkAHBMasterStd, 452	BRAMFIFO
mkAHBSlave, 452	mkSizedBRAMFIFO, 231
mkAHBSlaveDummy, 452	mkSizedBRAMFIFOF, 231
mkAHBSlaveStd, 452	mkSyncBRAMFIFO, 232
AlignedFIFOs	mkSyncBRAMFIFOFromCC, 232
mkAlignedFIFO, 237	mkSyncBRAMFIFOToCC, 232
mkBRAMStore1W2R, 237	,
mkBRAMStore2W1R, 237	CBus
mkRegStore, 237	collectCBusIFC, 409
mkRegVectorStore, 237	exposeCBusIFC, 410
AXI	mkCBRegFile, 411
fromAxiAddrCmd, 444	mkCBRegR, 410
fromAxiBurst, 444	mkCBRegRC, 410
fromAxiId, 445	mkCBRegRW, 410
· · · · · · · · · · · · · · · · · · ·	mkCBRegW, 410
fromAxiLen, 444	Clocks
fromAxiResp, 445	
fromAxiSize, 445	clockOf, 370
getAxiAddrCmd, 443	exposeCurrentClock, 370
getAxiBurst, 444	exposeCurrentReset, 370
getAxiByteEn, 443	invertCurrentClock, 371
getAxiId, 444	invertCurrentReset, 371
getAxiLen, 443	isAncestor, 370
getAxiSize, 444	isResetAsserted, 399
getFirstAxiWrData, 443	mkAbsoluteClock, 374
mkAxiMonitor, 442	mkAbsoluteClockFull, 374
mkAxiRdBus, 442	mkAsyncReset, 395
mkAxiRdMaster, 441	mkAsyncResetFromCR, 395
mkAxiRdSlave, 441	mkClock, 372
mkAxiWrBus, 442	mkClockDivider, 377
mkAxiWrMaster, 441	mkClockDividerOffset, 377
mkAxiWrSlave, 442	mkClockInverter, 377
	mkClockMux, 376
BRAM	mkClockSelect, 376
mkBRAM1Server, 208	mkDualRam, 391
mkBRAM1ServerBE, 208	mkGatedClock, 373
mkBRAM2Server, 209	mkGatedClockDivider, 377
mkBRAMCore1, 213	mkGatedClockFromCC, 373
mkBRAMCore1BE, 213	mkGatedClockInverter, 377
mkBRAMCore1BELoad, 213	mkInitialReset, 396
mkBRAMCore1Load, 213	mkNullCrossingReg, 393
mkBRAMCore2, 213	mkNullCrossingRegA, 393
mkBRAMCore2BE, 213	mkNullCrossingRegU, 393
mkBRAMCore2BELoad, 214	mkNullCrossingWire, 392
mkBRAMCore2Load, 214	mkReset, 396
mkSyncBRAM2Server, 209	mkResetEither, 398
mksynchrawizserver, 209	HIKITESETTITHEI, 930

mkResetInverter, 399	mkLFIFOF, 220
mkResetMux, 397	mkSizedFIFOF, 219
mkResetSync, 396	mkUGDepthParamFIFOF, 219
mkSyncBit, 380	mkUGFIFO1, 219
mkSyncBit05, 383	mkUGFIFOF, 219
mkSyncBit05FromCC, 383	mkUGLFIFOF, 220
mkSyncBit05ToCC, 383	mkUGSizedFIFOF, 219
mkSyncBit1, 382	FIFOLevel
mkSyncBit15, 381	mkFIFOCount, 227
mkSyncBit15FromCC, 381	mkFIFOLevel, 227
mkSyncBit15ToCC, 382	mkGFIFOCount, 227
mkSyncBit1FromCC, 382	mkGFIFOLevel, 227
mkSyncBit1ToCC, 382	mkSyncFIFOCount, 228
mkSyncBitFromCC, 381	mkSyncFIFOLevel, 228
mkSyncBitToCC, 381	FixedPoint
· · · · · · · · · · · · · · · · · · ·	fxptTruncateSat, 294
mkSyncFIFO, 389	Experiumeates at, 254
mkSyncFIFO1, 390	Gearbox
mkSyncFIFOFromCC, 390	mk1toNGearbox, 240
mkSyncFIFOToCC, 390	mkNto1Gearbox, 239
mkSyncHandshake, 386	GetPut
mkSyncHandshakeFromCC, 386	fifoToGet, 314
mkSyncHandshakeToCC, 386	fifoToPut, 314
mkSyncPulse, 385	mkGPFIFO, 313
mkSyncPulseFromCC, 385	mkGPFIFO1, 314
mkSyncPulseToCC, 385	mkGPSizedFIFO, 314
mkSyncReg, 387	toGet, 310
mkSyncRegFromCC, 388	
mkSyncRegToCC, 388	toPut, 311
mkSyncReset, 395	Gray
mkSyncResetFromCR, 395	grayDecode, 332
mkUngatedClock, 373	grayDecr, 333
mkUngatedClockMux, 376	grayEncode, 332
mkUngatedClockSelect, 376	grayIncr, 333
noClock, 371	grayIncrDecr, 333
noReset, 371	GrayCounter
resetOf, 371	mkGrayCounter, 331
sameFamily, 370	HList
<i>V</i> /	Gettable, 417
FIFO	
fifofToFifo, 221	HAppend, 416
mkDepthParamFIFO, 219	HHead, 415
mkFIFO, 218	HLength, 416
mkFIFO1, 218	hSplit, 416
mkLFIFO, 220	HTail, 416
mkSizedFIFO, 219	List
FIFOF	all, 273
mkDepthParamFIFOF, 219	and, 274
mkFIFOF, 218	and, 274 any, 273
mkFIFOF1, 218	• .
mkGDepthParamFIFOF, 220	append, 266
	concat, 266
mkGFIFOF, 219	cons, 265
mkGFIFOF1, 220	drop, 268
mkGLFIFOF, 220	dropWhile, 269
mkGSizedFIFOF, 220	dropWhileRev, 269

elem, 273	ModuleContext
filter, 268	applyToContext, 401
find, 269	apply To Context M, 401
fold, 278	reburyContext, 402
foldl, 278	runWithContext, 403
foldl1, 278	unburyContext, 402
foldr, 277	unburyContextWithClocks, 402
foldr1, 278	
group, 272	NumberTypes
groupBy, 272	addBIUInt, 299
head, 267	addUInt, 300
init, 268	sbtrctBIUInt, 299
joinActions, 278	unwrap, 300
joinRules, 279	unwrapBI, 299
last, 268	wrap, 300
length, 273	OVLAssertions
lookup, 269	
map, 275	bsv_assert_always, 360 bsv_assert_always_on_edge, 360
mapAccumL, 281	bsv_assert_change, 360
mapAccumR, 281	bsv_assert_cycle_sequence, 360
mapM, 282	bsv_assert_decrement, 361
mapM_, 282	bsv_assert_delta, 361
mapPairs, 279	bsv_assert_even_parity, 361
oneHotSelect, 267	bsv_assert_fifo_index, 361
or, 273	bsv_assert_frame, 361
replicate, 266	bsv_assert_handshake, 362
replicateM, 283	bsv_assert_implication, 362
reverse, 271	bsv_assert_increment, 362
rotate, 271	bsv_assert_never, 362
rotateR, 271	bsv_assert_never_unknown, 363
scanl, 281	bsv_assert_never_unknown_async, 363
scanr, 280	bsv_assert_next, 363
select, 267	bsv_assert_no_overflow, 363
sort, 271	bsv_assert_no_transition, 364
sortBy, 271	bsv_assert_no_underflow, 364
sscanl, 281	bsv_assert_odd_parity, 364
sscanr, 280	bsv_assert_one_cold, 364
tail, 268	bsv_assert_one_hot, 365
take, 268	bsv_assert_proposition, 365
takeWhile, 269	bsv_assert_quiescent_state, 365
takeWhileRev, 269	bsv_assert_range, 365
transpose, 271	bsv_assert_time, 366
unzip, 275	bsv_assert_transition, 366
update, 267	bsv_assert_unchange, 366
upto, 265	bsv_assert_width, 366
zip, 274	bsv_assert_win_change, 367
zip3, 274	bsv_assert_win_unchange, 367
zip4, 275	bsv_assert_window, 367
zipWith, 276	bsv_assert_zero_one_hot, 367
zipWith3, 276	Prelude
zipWith3M, 282	!=, 151
zipWith4, 276	<<, 158
zipWithM, 282	>>, 158
21P 11 1011111, 202	//, 100

, 157, 159	$\log 2, 153$
*, 153	logb, 153
**, 153	lsb, 159
+, 153, 168	$\max, 155, 191$
-, 153	maxBound, 157
/, 153	message, 191
<, 155	messageM, 191
<=, 155	$\min, 155, 191$
==, 151	minBound, 157
>, 155	mkBypassWire, 185
>=, 155	mkDWire, 186
\$bitstoreal, 168	mkPulseWire, 187
\$realtobits, 168	mkPulseWireOR, 187
%, 153	mkReg, 180
&, 157, 159	mkRegA, 180
^, 157, 159	mkRegU, 180
^~, 157, 159	mkRWire, 183
~, 157, 159	mkUnsafeDWire, 186
~[, 159	mkUnsafePulseWire, 187
~^, 157, 159	mkUnsafePulseWireOR, 187
abs, 153, 192	mkUnsafeRWire, 183
addRules, 176	mkUnsafeWire, 184
asReg, 180	mkWire, 184
buildVersion, 196	mod, 165
compare, 155	msb, 159
compiler Version, 196	negate, 153
compose, 192	not, 166
composeM, 193	pack, 150
constFn, 193	parity, 194
countOnes, 194	pulseWireToReadOnly, 189
countZerosLSB, 194	quot, 165
countZerosMSB, 194	readReadOnly, 189
curry, 193	$\frac{180}{\text{readReg}}$
date, 196	reduceAnd, 159
div, 165	reduceNand, 159
epochTime, 197	reduceNor, 159
error, 191	reduceOr, 159
errorM, 191	reduceXNor, 159
\exp , 153	reduceXor, 159
extend, 161	regToReadOnly, 189
flip, 193	rem, 165
fromInteger, 152, 166	reverseBits, 194
fromMaybe, 170	rJoin, 176
fromReal, 152	rJoinConflictFree, 176
fromSizedInteger, 153	rJoinDescendingUrgency, 176
gcd, 195	rJoinExecutionOrder, 176
genC, 195	rJoinMutuallyExclusive, 176
genVerilog, 196	rJoinPreempts, 176
id, 193	satMinus, 162
invert, 157	satPlus, 162
isValid, 170	signedMul, 192
lcm, 195	signedQuot, 192
log, 153	signExtend, 161
$\log 10, 153$	signum, 153
10810, 100	signum, 100

SizeOf, 179	$\operatorname{StmtFSM}$
split, 164	await, 304
strConcat, 168	callServer, 308
TAdd, 179	delay, 304
TDiv, 179	mkAutoFSM, 304
TExp, 179	mkFSM, 304
TLog, 179	mkFSMServer, 308
TMax, 179	mkFSMwithPred, 304
TMin, 179	mkOnce, 304
TMul, 179	
truncate, 161	TLM
truncateLSB, 194	countLSBZeros, 432
TSub, 179	getTLMBurstSize, 431
unpack, 150	getTLMByteEn, 431
unsignedMul, 192	getTLMCycleCount, 431
unsigned Quot, 192	getTLMData, 432
valueOf, 179	getTLMIncr, 431
warning, 191	incrTLMAddr, 432
warningM, 191	mkTLMBRAM, 429
when, 195	mkTLMBRAMBE, 429
while, 195	mkTLMCBusAdapter, 430
writeReg, 180	mkTLMCBusAdapterToReadWrite, 430
zeroExtend, 161	mkTLMRam, 428
,	mkTLMRandomizer, 427
Real	mkTLMReadWriteRam, 428
acosh, 284	mkTLMReducer, 427
asinh, 284	mkTLMSource, 427
atan 2, 285	${\it Unit Append List}$
atanh, 284	flatten, 419
ceil, 285	flatten0, 419
$\cos, 284$	uaMap, 419
$\cosh, 284$	uaMapM, 419
decodeReal, 286	uawapwi, 419
floor, 286	Vector, 264
isInfinite, 286	all, 249
isNegativeZero, 286	and, 250
pow, 285	any, 249
round, 285	append, 242
$\sin, 283$	arrayToVector, 264
\sinh , 284	concat, 242
splitReal, 286	$\cos, 242$
sqrt, 285	countElem, 250
$\tan, 284$	countIf, 250
tanh, 284	countOnesAlt, 252
trunc, 285	drop, 245
	elem, 249
SpecialFIFOs	find, 250
mkBypassFIFO, 234	findElem, 250
mkBypassFIFOF, 234	findIndex, 251
mkBypassFIFOLevel, 234	fold, 257
mkDFIFOF, 234	foldl, 256
mkPipelineFIFO, 233	foldl1, 256
mkPipelineFIFOF, 234	foldr, 256
mkSizedBypassFIFOF, 234	foldr1, 256

```
genVector, 241
                                                    zipWithM, 261
genWith, 241
genWithM, 262
head, 244
init, 244
joinActions, 257
joinRules, 257
last, 244
map, 254
mapAccumL, 260
mapAccumR, 260
mapM, 261
mapM_, 261
mapPairs, 257
newVector, 241
nil, 242
or, 250
readVReg, 252
replicate, 241
replicateM, 262
reverse, 248
rotate, 247
rotateBitsBy, 252
rotateBy, 247
rotateR, 247
scanl, 259
scanr, 258
select, 243
shiftInAt0, 247
shiftInAtN, 247
shiftOutFrom0, 247
shiftOutFromN, 248
sscanl, 259
sscanr, 259
tail, 244
take, 245
takeAt, 245
toChunks, 264
toList, 264
transpose, 248
transposeLN, 248
unzip, 253
update, 244
vectorToArray, 264
writeVReg, 252
zip, 252
zip3, 253
zip4, 253
zipAny, 253
zipWith, 254
zipWith3, 255
zipWith3M, 261
zipWithAny, 254
zipWithAny3, 255
```

Packages provided as BSV source code

```
AHB, 445
AHBBus, 445
AHBDefines, 445
AHBMaster, 445
AHBMonitor, 445
AHBPC, 445
AHBSlave, 445
AlignedFIFOs, 235
Arbiter, 329
Axi, 433
AxiDefines, 433
AxiMaster, 433
AxiMonitor, 433
AxiPC, 433
AxiRdBus, 433
AxiSlave, 433
AxiWrBus, 433
BRAM, 204
BRAMFIFO, 231
CBus, 408
CommitIfc, 320
Complex, 287
DefaultValue, 344
FixedPoint, 289
FShow, 339
Gearbox, 238
Gray, 331
GrayCounter, 330
HList, 415
ModuleContext, 399
NumberTypes, 298
Randomizable, 327
SpecialFIFOs, 232
TieOff, 346
TLM, 420
TLMCBusAdapter, 420
TLMDefines, 420
TLMRam, 420
TLMReadWriteRam, 420
TLMReduce, 420
TLMUtils, 420
UnitAppendList, 419
```

Typeclasses

```
Arith, 153
BitExtend, 161
BitReduction, 159
Bits, 150
Bitwise, 157
Bounded, 157
Connectable, 316
DefaultValue, 344
Eq, 151
FShow, 340
Literal, 152
\mathrm{Ord},\, \underline{155}
Randomizable, 327
RealLiteral, 152
SaturatingArith, 162
SizedLiteral, 153
TieOff, 346
\mathrm{ToGet},\, \textcolor{red}{\mathbf{310}}
\mathrm{ToPut},\, \textcolor{red}{\mathbf{310}}
```