

VX1000 TCP/IP Control Command Summary

■■	■■■
■■ ■■	TCP (■■■)
■■ ■■	5200
IP ■■ ■■	192.168.0.150 (■■ IP ■■)

■■	HEX ■■■	■■	■■■■
Power ON (Normal)	55 aa 00 00 fe 00 00 00 00 00 01 00 04 00 00 13 02 00 03 00 70	5200	TCP
Power OFF (Black Screen)	55 aa 00 00 fe 00 00 00 00 00 01 00 04 00 00 13 02 00 06 00 5b	5200	TCP
Preset 1	55 aa 00 00 fe 00 00 00 00 00 01 00 00 01 51 13 01 00 00 ba 56 5200		TCP
Preset 2	55 aa 00 00 fe 00 00 00 00 00 01 00 00 01 51 13 01 00 01 bb 56 5200		TCP
Preset 3	55 aa 00 00 fe 00 00 00 00 00 01 00 00 01 51 13 01 00 02 bc 56 5200		TCP
Brightness 0%	55 aa 00 00 fe ff 01 ff ff 01 00 01 00 00 02 01 00 55 5a	5200	TCP
Brightness 20%	55 aa 00 00 fe ff 01 ff ff 01 00 01 00 00 02 01 00 33 88 5a	5200	TCP
Brightness 40%	55 aa 00 00 fe ff 01 ff ff 01 00 01 00 00 02 01 00 66 bb 5a	5200	TCP
Brightness 60%	55 aa 00 00 fe ff 01 ff ff 01 00 01 00 00 02 01 00 99 ee 5a	5200	TCP
Brightness 80%	55 aa 00 00 fe ff 01 ff ff 01 00 01 00 00 02 01 00 cc 21 5b	5200	TCP