## KDL库安装

## KDL库安装:

```
#选择一个库保存路径,执行
 1
    git clone https://github.com/orocos/orocos_kinematics_dynamics.git
 2
    进入orocos_kdl目录
 3
    mkdir build
 4
    cd build
 5
    cmake ..
 6
 7
    make
8
    sudo make install
    #完成安装
9
10
11
    #选择一个库保存路径,执行
12
13
    git clone https://github.com/ros/kdl_parser.git
    #进入kdl parser目录:
14
    #20.04 切换分支为noetic
15
    mkdir build
16
    cd build
17
18
    cmake ..
    make
19
    #编译完成后
20
    sudo make install
21
    #完成安装
22
23
24
25
    export LD_LIBRARY_PATH=/usr/local/lib:$LD_LIBRARY_PATH
26
27
28
    echo 'export LD_LIBRARY_PATH=/usr/local/lib:$LD_LIBRARY_PATH' >> ~/.bashrc
    source ~/.bashrc
29
    echo 'export LD_LIBRARY_PATH=/usr/local/lib:$LD_LIBRARY_PATH' >> ~/.zshrc
30
    source ~/.bashrc
31
32
33
    sudo ldconfig
34
```