

```
IDLE Shell 3.10.8
File Edit Shell Debug Options Window Help
Python 3.10.8 (tags/v3.10.8:aaaf517, Oct 11 2022, 16:50:30) [MSC v.1933 64 bit (AMD64)] on win32
Type "help", "copyright", "credits" or "license()" for more information.
>>>
===== RESTART: C:\Users\dell\Documents\squaremission.py =====
Connecting to vehicle on: tcp:127.0.0.1:5760
CRITICAL:autopilot:APM:Copter V3.3 (d6053245)
CRITICAL:autopilot:Frame: QUAD
CRITICAL:autopilot:Calibrating barometer
CRITICAL:autopilot:Initialising APM...
CRITICAL:autopilot:barometer calibration complete
CRITICAL:autopilot:GROUND START
Performing basic pre-arm checks
Waiting for vehicle to initialise (GPS/EKF)...
Waiting for vehicle to initialise (GPS/EKF)...
Waiting for vehicle to initialise (GPS/EKF)...
Waiting for vehicle to initialise (GPS/EKF)...
Waiting for vehicle to initialise (GPS/EKF)...
Waiting for vehicle to initialise (GPS/EKF)...
Arming motors
Waiting for arming...
Waiting for arming...
Waiting for arming...
Waiting for arming...
ERROR:autopilot:ARMING MOTORS
CRITICAL:autopilot:GROUND START
Waiting for arming...
WARNING:dronekit:Link timeout, no heartbeat in last 5 seconds
CRITICAL:autopilot:Initialising APM...
Taking off!
Altitude: 0.0
Altitude: 0.0
Altitude: 0.0
Ln: 16 Col: 47
```

IT IS THE OUTPUT OF SQUARE MISSION PROJECT. IT HELPS TO TAKEOFF,SQUARE PATTERN FLIGHT MOTION AND TO LAND SAFELY. SITL ,PYMAVLINK,DRONEKIT, AND PYTHON IDLE 3.10.8 64BIT IS USED.